

SERVICE MANUAL

MTM690 MTM690-U

(XSR)

B34-F8197-E0

EAS20002

MTM690/MTM690-U SERVICE MANUAL ©2015 by MBK Industrie First edition, November 2015 All rights reserved. Any reproduction or unauthorized use without the written permission of MBK Industrie is expressly prohibited.

EAS20003

This manual was produced by MBK Industrie. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

Yamaha Motor Company, Ltd. and MBK Industrie are continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

TIP _

Designs and specifications are subject to change without notice.

IMPORTANT MANUAL INFORMATION


Particularly important information is distinguished in this manual by the following notations.

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
	A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
NOTICE	A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.
TIP	A TIP provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- The manual is divided into chapters and each chapter is divided into sections. The current section title "1" is shown at the top of each page.
- Sub-section titles "2" appear in smaller print than the section title.
- To help identify parts and clarify procedure steps, there are exploded diagrams "3" at the start of each removal and disassembly section.
- Numbers "4" are given in the order of the jobs in the exploded diagram. A number indicates a disassembly step.
- Symbols "5" indicate parts to be lubricated or replaced. Refer to "SYMBOLS".
- A job instruction chart "6" accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc. This step explains removal and disassembly procedure only. For installation and assembly procedure, reverse the steps.
- Jobs "7" requiring more information (such as special tools and technical data) are described sequentially.



EAS20005

The following symbols are used in this manual for easier understanding.

TIP _

The following symbols are not relevant to every vehicle.

SYMBOL	DEFINITION	SYMBOL	DEFINITION
0	Serviceable with engine mounted	G	Gear oil
	Filling fluid		Molybdenum disulfide oil
	Lubricant	BF	Brake fluid
A REAL PROPERTY OF A REAL PROPER	Special tool	B	Wheel bearing grease
	Tightening torque	LS	Lithium-soap-based grease
K	Wear limit, clearance		Molybdenum disulfide grease
	Engine speed		Silicone grease
0	Electrical data		Apply locking agent (LOCTITE®).
Ē	Engine oil	New	Replace the part with a new one.
6	Silicone fluid		

TABLE OF CONTENTS

EAS10003

Г

GENERAL INFORMATION	1
SPECIFICATIONS	2
PERIODIC CHECKS AND ADJUSTMENTS	3
CHASSIS	4
ENGINE	5
COOLING SYSTEM	6
FUEL SYSTEM	7
ELECTRICAL SYSTEM	8
TROUBLESHOOTING	9


GENERAL INFORMATION

IDENTIFICATION	
VEHICLE IDENTIFICATION NUMBER	1-1
MODEL LABEL	1-1
FEATURES	1-2
MULTI-FUNCTION METER UNIT	
IMPORTANT INFORMATION	1-7
PREPARATION FOR REMOVAL AND DISASSEMBLY	
REPLACEMENT PARTS	1-7
GASKETS, OIL SEALS AND O-RINGS	
LOCK WASHERS/PLATES AND COTTER PINS	
BEARINGS AND OIL SEALS	
CIRCLIPS	
RUBBER PARTS	
BASIC SERVICE INFORMATION	
QUICK FASTENERS	1-9
ELECTRICAL SYSTEM	1-10
SPECIAL TOOLS	1-14

EAS20007 **IDENTIFICATION**


VEHICLE IDENTIFICATION NUMBER

The vehicle identification number "1" is stamped into the right side of the steering head pipe.



EAS30003

The model label "1" is affixed to the frame under the seat. This information will be needed to order spare parts.




FEATURES

EAS30982 MULTI-FUNCTION METER UNIT



- 1. Transmission gear display
- 2. Tachometer
- 3. Eco indicator "ECO"
- 4. Speedometer
- 5. Multi-function display
- 6. Fuel meter



- 1. Top set button
- 2. Bottom set button

EWA17650

Be sure to stop the vehicle before making any setting changes to the multi-function meter unit. Changing settings while riding can distract the operator and increase the risk of an accident.

The multi-function meter unit is equipped with the following:

- a speedometer
- a tachometer
- a fuel meter
- an eco indicator
- a transmission gear display
- a multi-function display


TIP _

- Except when switching to the brightness control mode or to display the clock, turn the key to "ON" before using the bottom and top set buttons.
- For the UK: To switch the speedometer and multi-function display between kilometers and miles, set the multi-function display to the odometer mode or a tripmeter mode, and then press the bottom set button for three seconds.

Speedometer

The speedometer shows the vehicle's traveling speed.

Tachometer



- 1. Tachometer
- 2. Tachometer red zone


The tachometer allows the rider to monitor the engine speed and keep it within the ideal power range.

NOTICE

Do not operate the engine in the tachometer red zone.

Red zone 10000 r/min and above

Fuel meter




- 1. Frame
- 2. Fuel meter

The fuel meter indicates the amount of fuel in the fuel tank. The display segments of the fuel meter disappear from "F" (full tank) towards "E" (empty tank) as the fuel level decreases. When the last segment and frame start flashing, refuel as soon as possible.

TIP_

This fuel meter is equipped with a self-diagnosis system. If a problem is detected in the fuel tank electrical circuit, the fuel level segments, frame, and "∎" flash repeatedly. If this occurs, check the electrical circuit. Refer to "SIGNALING SYS-TEM" on page 8-21.

Eco indicator



1. Eco indicator "ECO"

This indicator comes on when the vehicle is being operated in an environmentally friendly, fuelefficient manner. The indicator goes off when the vehicle is stopped.

TIP.

Consider the following tips to reduce fuel consumption:

- Avoid high engine speeds during acceleration.
- Travel at a constant speed.
- Select the transmission gear that is appropriate for the vehicle speed.


Transmission gear display



- 1. Neutral indicator light "N"
- 2. Transmission gear display

This display shows the selected gear. The neutral position is indicated by "–" and by the neutral indicator light.

Multi-function display



1. Multi-function display

The multi-function display is equipped with the following:

- an odometer
- two tripmeters
- a fuel reserve tripmeter
- an instantaneous fuel consumption display
- an average fuel consumption display
- a coolant temperature display
- an air temperature display
- a clock
- a brightness control mode

The odometer shows the total distance the vehicle has traveled.

The tripmeters show the distance traveled since they were last reset.

TIP _

- The odometer will lock at 999999 and cannot be reset.
- The tripmeter will reset to 0 and continue counting after 9999.9 is reached.

Push the bottom set button to switch the display between odometer "ODO", tripmeters "TRIP 1" and "TRIP 2", instantaneous fuel consumption "km/L" or "L/100 km", average fuel consumption "AVE__._ km/L" or "AVE__._ L/100 km", coolant temperature "__ °C", ambient temperature "Air__ °C", and clock "__:__" in the following order:

 $\begin{array}{l} ODO \rightarrow TRIP \ 1 \rightarrow TRIP \ 2 \rightarrow km/L \ or \ L/100 \ km \\ \rightarrow AVE_ _._ \ km/L \ or \ AVE_ _._ \ L/100 \ km \rightarrow __ \\ ^{\circ}C \rightarrow Air__ ^{\circ}C \rightarrow Clock__:_ \rightarrow ODO \end{array}$

For the UK:

Push the bottom set button to switch the display between odometer "ODO", tripmeters "TRIP 1" and "TRIP 2", instantaneous fuel consumption "km/L", "L/100 km" or "MPG", average fuel consumption "AVE__._ km/L", "AVE__._ L/100 km" or "AVE__._ MPG", coolant temperature "___ °C", and ambient temperature, and "Air__ °C", and clock "__:_ " in the following order:

 $\begin{array}{l} ODO \rightarrow TRIP \ 1 \rightarrow TRIP \ 2 \rightarrow km/L, \ L/100 \ km \ or \\ MPG \rightarrow AVE__._ \ km/L, \ AVE__._ \ L/100 \ km \ or \\ AVE__._ \ MPG \rightarrow __ \ ^{\circ}C \rightarrow Air__ \ ^{\circ}C \rightarrow Clock \\ _ \ \vdots _ \rightarrow ODO \end{array}$

TIP ____

- Push the top set button to switch the display in the reverse order.
- The fuel reserve tripmeter and error code displays come on automatically, while the brightness control mode is accessed separately.


If the lower segment and frame of the fuel meter start flashing, the display automatically changes to fuel reserve tripmeter "TRIP F" and starts counting the distance traveled from that point. In this case, push the bottom set button to switch the display between the various tripmeter, odometer, and fuel consumption modes in the following order:

 $\begin{array}{l} {\sf TRIP}\;{\sf F} \rightarrow {\sf km/L}\; {\sf or}\; {\sf L}/100\; {\sf km} \rightarrow {\sf AVE__._}\; {\sf km/L} \\ {\sf or}\; {\sf AVE__._}\; {\sf L}/100\; {\sf km} \rightarrow __^\circ{\sf C} \rightarrow {\sf Air__}^\circ{\sf C} \rightarrow \\ {\sf Clock__:_} \rightarrow {\sf ODO} \rightarrow {\sf TRIP}\; 1 \rightarrow {\sf TRIP}\; 2 \rightarrow \\ {\sf TRIP}\; {\sf F} \end{array}$

For the UK: TRIP F \rightarrow km/L, L/100 km or MPG \rightarrow AVE__._ km/L, AVE__. L/100 km or AVE_ .._ MPG \rightarrow __ °C \rightarrow Air__ °C \rightarrow Clock __:_ \rightarrow ODO \rightarrow TRIP 1 \rightarrow TRIP 2 \rightarrow TRIP F To reset a tripmeter, select it by pushing the bottom set button, and then push the top set button for one second.

If you do not reset the fuel reserve tripmeter manually, after refueling and traveling 5km (3mi) it resets automatically and disappears from the display.

Instantaneous fuel consumption



1. Instantaneous fuel consumption display

The instantaneous fuel consumption display can be set to either "km/L" or "L/100 km"; or for the UK, "MPG" or "km/L" or "L/100 km".


- "km/L": The distance that can be traveled on 1.0 L of fuel under current riding conditions.
- "L/100 km": The amount of fuel necessary to travel 100 km under current riding.
- "MPG": The distance that can be traveled on 1.0 Imp.gal of fuel under current riding conditions.

To switch the instantaneous fuel consumption display settings, push the bottom set button for two second.

TIP.

If traveling at speeds under 20 km/h (12 mi/h), "_ _._" is displayed.

Average fuel consumption



1. Average fuel consumption display

This display shows the average fuel consumption since it was last reset.

The average fuel consumption display can be set to either "AVE__._ km/L", "AVE__._ L/100 km" or "AVE__._ MPG" (for the UK).

- "AVE__._ km/L": The average distance that can be traveled on 1.0 L of fuel.
- "AVE__._ L/100 km": The average amount of fuel necessary to travel 100 km.
- "AVE__._ MPG": The average distance that can be traveled on 1.0 Imp.gal of fuel.


To switch the average fuel consumption display settings, push the bottom set button for two seconds.

To reset the average fuel consumption, push the top set button for one second.

TIP_

After resetting the average fuel consumption, "_ _._" will be shown until the vehicle has traveled 1 km (0.6 mi).

Coolant temperature




1. Coolant temperature display

This display shows the coolant temperature from 40 °C to 116 °C in 1 °C increments. If the message "HI" flashes, stop the vehicle,

then stop the engine and let the it cool.

- When the coolant temperature is below 40 °C, "Lo" will be displayed.
- The coolant temperature varies with changes in the weather and engine load.

Air temperature




1. Air temperature display

This display shows the air temperature from -9 °C to 99 °C in 1 °C increments. The temperature displayed may vary from the actual ambient temperature.

TIP ___

- When the air temperature is below –9 °C, "Lo" will be displayed.
- The accuracy of the temperature reading may be affected when riding slowly (under 20 km/h [12.5 mi/h]) or when stopped at traffic signals, railroad crossings, etc.

Clock



1. Clock

The clock displays time in 12-hour format. Even when the key is not in the "ON" position, the clock can be viewed for 10 seconds by pushing the bottom set button.


To set the clock

- 1. Turn the main switch to "ON".
- 2. Push the bottom set button and top set button together for two seconds and the hour digits will start flashing.
- 3. Push the top set button to set the hours.
- 4. Push the bottom set button and the minute digits will start flashing.
- 5. Push the top set button to set the minutes.
- 6. Push the bottom set button to confirm settings and start the clock.

TIP.

• When setting the hours and minutes, push the top set button briefly to increase the increment value one by one, or push and hold the button to increase the increment value continuously.

Brightness control



1. Brightness level display

The brightness level of the multi-function meter unit panel can be adjusted to suit the rider's preference.

To adjust the brightness

- 1. Turn the main switch to "OFF".
- 2. Push and hold the bottom set button.
- 3. Turn the main switch to "ON" and continue pushing the bottom set button until the display switches to the brightness control mode.
- 4. Push the top set button to set the brightness level.
- 5. Push the bottom set button to confirm the selected brightness level and exit the brightness control mode.

TIP_

There are 6 brightness level settings.

IMPORTANT INFORMATION

EAS30006

PREPARATION FOR REMOVAL AND DISASSEMBLY

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.



2. Use only the proper tools and cleaning equipment.

Refer to "SPECIAL TOOLS" on page 1-14.

3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.



- 4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
- 5. Keep all parts away from any source of fire.


REPLACEMENT PARTS

Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.



GASKETS, OIL SEALS AND O-RINGS


- 1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
- 2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.



- 1. Oil
- 2. Lip
- 3. Spring
- 4. Grease

LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates "1" and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.




EAS30010 BEARINGS AND OIL SEALS

Install bearings "1" and oil seals "2" so that the manufacturer marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.


NOTICE

Do not spin the bearing with compressed air because this will damage the bearing surfaces.



CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip "1", make sure the sharp-edged corner "2" is positioned opposite the thrust "3" that the circlip receives.



RUBBER PARTS

Check rubber parts for deterioration during inspection. Some of the rubber parts are sensitive to gasoline, flammable oil, grease, etc. Do not allow any items other than the specified one to contact the parts.

BASIC SERVICE INFORMATION

QUICK FASTENERS

Rivet type

- 1. Remove:
- Quick fastener


TIP ____

To remove the quick fastener, push its pin with a screwdriver, then pull the fastener out.










Screw type


- 1. Remove:
- Quick fastener

TIP .

To remove the quick fastener, loosen the screw with a screwdriver, then pull the fastener out.








- 2. Install:
 - Quick fastener
- TIP _

To install the quick fastener, insert the fastener into the part to be secured and tighten the screw.







Quick fastener

TIP ____

To install the quick fastener, push its pin so that it protrudes from the fastener head, then insert the fastener into the part to be secured and push the pin in with a screwdriver. Make sure that the pin is flush with the fastener's head.






ELECTRICAL SYSTEM

Electrical parts handling

ECA16600


Never disconnect a battery lead while the engine is running; otherwise, the electrical components could be damaged.



ECA16751


NOTICE

When disconnecting the battery leads from the battery, be sure to disconnect the negative battery lead first, then the positive battery lead. If the positive battery lead is disconnected first and a tool or similar item contacts the vehicle, a spark could be generated, which is extremely dangerous.



TIP_


If a battery lead is difficult to disconnect due to rust on the battery terminal, remove the rust using hot water.



NOTICE


ECA16760

Be sure to connect the battery leads to the correct battery terminals. Reversing the battery lead connections could damage the electrical components.




NOTICE

When connecting the battery leads to the battery, be sure to connect the positive battery lead first, then the negative battery lead. If the negative battery lead is connected first and a tool or similar item contacts the vehicle while the positive battery lead is being connected, a spark could be generated, which is extremely dangerous.



NOTICE

Turn the main switch to "OFF" before disconnecting or connecting an electrical component.




ECA16620

Handle electrical components with special care, and do not subject them to strong shocks.




ECA16630

Electrical components are very sensitive to and can be damaged by static electricity. Therefore, never touch the terminals and be sure to keep the contacts clean.



TIP __


When resetting the ECU by turning the main switch to "OFF", be sure to wait approximately 5 seconds before turning the main switch back to "ON".



Checking the electrical system

TIP_


Before checking the electrical system, make sure that the battery voltage is at least 12 V.



NOTICE


ECA14371

Never insert the tester probes into the coupler terminal slots. Always insert the probes from the opposite end "a" of the coupler, taking care not to loosen or damage the leads.



ECA16640

For waterproof couplers, never insert the tester probes directly into the coupler. When performing any checks using a waterproof coupler, use the specified test harness or a suitable commercially available test harness.




Checking the connections

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

- 1. Disconnect:
- Lead
- Coupler
- Connector ECA16780


NOTICE

- When disconnecting a coupler, release the coupler lock, hold both sections of the coupler securely, and then disconnect the coupler.
- There are many types of coupler locks; therefore, be sure to check the type of coupler lock before disconnecting the coupler.




ECA16790

When disconnecting a connector, do not pull the leads. Hold both sections of the connector securely, and then disconnect the connector.





- 2. Check:
 - Lead
 - Coupler
 - Connector

Moisture \rightarrow Dry with an air blower. Rust/stains \rightarrow Connect and disconnect several times.





- 3. Check:
 - All connections Loose connection \rightarrow Connect properly.
- TIP ___
- If the pin "1" on the terminal is flattened, bend it up.
- After disassembling and assembling a coupler, pull on the leads to make sure that they are installed securely.





- 4. Connect:
- Lead
- Coupler
- Connector
- TIP _____
- When connecting a coupler or connector, push both sections of the coupler or connector together until they are connected securely.
- Make sure all connections are tight.






- 5. Check:
 - Continuity


(with the pocket tester)

Pocket tester 90890-03132

TIP _

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (4).
- As a quick remedy, use a contact revitalizer available at most part stores.







- 6. Check:
- Resistance



TIP __

The resistance values shown were obtained at the standard measuring temperature of 20 °C (68 °F). If the measuring temperature is not 20 °C (68 °F), the specified measuring conditions will be shown.





The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country. When placing an order, refer to the list provided below to avoid any mistakes.

- TIP_
- For U.S.A. and Canada, use part number starting with "YM-", "YU-", or "ACC-".
- For others, use part number starting with "90890-".

Tool name/Tool No.	Illustration	Reference pages
Pocket tester 90890-03132	State Contraction	1-13
Pocket tester 90890-03112 Analog pocket tester YU-03112-C		1-13, 8-155, 8-156, 8-157, 8-157, 8-161, 8-162, 8-163, 8-163, 8-164, 8-164, 8-165, 8-165, 8-167, 8-167, 8-168, 8-169, 8-170, 8-170, 8-171
Thickness gauge 90890-03180 Feeler gauge set YU-26900-9		3-6, 4-19, 4-28, 5-51
Valve lapper 90890-04101 Valve lapping tool YM-A8998	90890-04101 ø14	3-7
	OTIO	
Yamaha diagnostic tool 90890-03250	VIANARA VIANARA States States	3-8, 4-61, 4-62, 5-2, 8-36, 8-124, 8-147

Tool name/Tool No.	Illustration	Reference pages
Vacuum gauge 90890-03094 Vacuummate YU-44456	90890-03094	3-9
	YU-44456	
Carburetor angle driver 2 90890-03173		3-9
Steering nut wrench 90890-01403 Exhaust flange nut wrench YU-A9472	R20 R20	3-19, 4-82
Oil filter wrench 90890-01426 Oil filter wrench YU-38411	64.2	3-22
Pressure gauge 90890-03153 Pressure gauge YU-03153	Contraction of the second seco	3-23, 7-14, 7-15
Oil pressure adapter H 90890-03139	M16×P1.5	3-23
Damper rod holder 90890-01460	021.2	4-74, 4-76
T-handle 90890-01326 T-handle 3/8" drive 60 cm long YM-01326	a	4-74, 4-76

Tool name/Tool No.	Illustration	Reference pages
Fork seal driver weight 90890-01367 Replacement hammer YM-A9409-7	90890-01367	4-77, 4-77, 4-77
	YM-A9409-7/YM-A5142-4	
Fork seal driver attachment (ø41) 90890-01381 Replacement 41 mm YM-A5142-2	041	4-77, 4-77
Extension 90890-04136		5-1
Compression gauge 90890-03081 Engine compression tester YU-33223	90890-03081	5-1
	YU-33223	
Rotor holding tool 90890-01235 Universal magneto and rotor holder YU-01235		5-15, 5-19
Yamaha bond No. 1215 90890-85505 (Three bond No.1215®)	Contraction of the second seco	5-22, 5-41, 5-66, 5-68
Valve spring compressor 90890-04019 Valve spring compressor YM-04019	0000 0001 000 M6×P1.0	5-29, 5-34

Tool name/Tool No.	Illustration	Reference pages
Valve spring compressor attachment 90890-01243 Valve spring compressor adapter (26 mm) YM-01253-1	ø26	5-29, 5-34
Valve guide remover (ø4.5) 90890-04116 Valve guide remover (4.5 mm) YM-04116		5-31
Valve guide installer (ø4.5) 90890-04117 Valve guide installer (4.5 mm) YM-04117	04.5 08.3 010	5-31
Valve guide reamer (ø4.5) 90890-04118 Valve guide reamer (4.5 mm) YM-04118		5-31
Rotor holding tool 90890-04166 YM-04166		5-39, 5-39, 5-40, 5-40
Flywheel puller 90890-01362 Heavy duty puller YU-33270-B		5-39
Digital circuit tester 90890-03174 Model 88 Multimeter with tachometer YU-A1927		5-44, 8-166, 8-169
Universal clutch holder 90890-04086 Universal clutch holder YM-91042	90890-04086 <u>M8×P1.25</u> 30 ¹¹⁹ 156	5-50, 5-53
	YM-91042	

Tool name/Tool No.	Illustration	Reference pages
Piston pin puller set 90890-01304 Piston pin puller YU-01304	90890-01304	5-72
	YU-01304	
Piston ring compressor 90890-05158 Piston ring compressor YM-08037		5-79
		0.0
Radiator cap tester 90890-01325 Mityvac cooling system tester kit YU-24460-A	90890-01325 90890-01325	6-3
	YU-24460-A	
Radiator cap tester adapter 90890-01352 Pressure tester adapter YU-33984	90890-01352 041 028	6-3
	YU-33984	

Tool name/Tool No.	Illustration	Reference pages
Mechanical seal installer 90890-04132 Water pump seal installer YM-33221-A	ø33 ø27.5	6-12
Middle driven shaft bearing driver 90890-04058 Middle drive bearing installer 40 & 50 mm YM-04058	ø40	6-12
Fuel injector pressure adapter 90890-03210 Fuel injector pressure adapter YU-03210		7-14
Fuel pressure adapter 90890-03176 Fuel pressure adapter YM-03176		7-15
OBD/ GST Leadwire kit 90890-03249		8-36
Ignition checker 90890-06754 Oppama pet–4000 spark checker YM-34487	a contraction of the second seco	8-164
Test harness– lean angle sensor (6P) 90890-03209 Test harness– lean angle sensor (6P) YU-03209		8-165
Test harness S– pressure sensor (3P) 90890-03207 Test harness S– pressure sensor (3P) YU-03207		8-169

SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
ENGINE SPECIFICATIONS	2-2
CHASSIS SPECIFICATIONS	2-8
ELECTRICAL SPECIFICATIONS	2-11
TIGHTENING TORQUES GENERAL TIGHTENING TORQUE SPECIFICATIONS ENGINE TIGHTENING TORQUES CHASSIS TIGHTENING TORQUES	2-14 2-15
LUBRICATION POINTS AND LUBRICANT TYPES ENGINE CHASSIS	2-24
LUBRICATION SYSTEM CHART AND DIAGRAMS ENGINE OIL LUBRICATION CHART LUBRICATION DIAGRAMS	2-27
COOLING SYSTEM DIAGRAMS	2-41
CABLE ROUTING	2-43

GENERAL SPECIFICATIONS

Model

Dimensions Overall length Overall width Overall height Seat height Wheelbase B341 (MTM690) B342 (MTM690-U)

2075 mm (81.7 in)
820 mm (32.3 in)
1130 mm (44.5 in)
815 mm (32.1 in)
1405 mm (55.3 in)
140 mm (5.51 in)
2700 mm (106.3 in)

Weight

Curb weight

Ground clearance Minimum turning radius

186 kg (410 lb)

Loading

Maximum load

172 kg (379 lb)

ENGINE SPECIFICATIONS

Engine	
Engine type	Liquid cooled 4-stroke, DOHC
Displacement	Equid cooled 4-stroke, DONC 689 cm^3 Inline 2-cylinder $80.0 \times 68.6 \text{ mm} (3.15 \times 2.70 \text{ in})$ 11.5 : 1 $770-990 \text{ kPa/355 r/min} (7.7-9.9 \text{ kgf/cm}^2/355 \text{ r/min}, 109.5-140.8 \text{ psi}/355 r/min})$ $690-880 \text{ kPa}/355 \text{ r/min} (6.9-8.8 \text{ kgf/cm}^2/355 \text{ r/min}, 98.1-125.2 \text{ psi}/355 r/min})$
Cylinder arrangement	
Bore × stroke	
Compression ratio	
Compression pressure (#1 cylinder)	
Compression pressure (#2 cylinder) Starting system	
	Electric starter
Fuel	
Recommended fuel	Premium unleaded gasoline (Gasohol (E10) acceptable)
Minimum research octane	95
Fuel tank capacity	14.0 L (3.70 US gal, 3.08 Imp.gal)
Fuel reserve amount	2.7 L (0.71 US gal, 0.59 Imp.gal)
Engine oil	
Lubrication system	Wet sump
Recommended brand	YAMALUBE
SAE viscosity grades	10W-40
Recommended engine oil grade	API service SG type or higher, JASO standard MA
Engine oil quantity	
Quantity (disassembled)	3.00 L (3.17 US qt, 2.64 Imp.qt)
Without oil filter cartridge replacement	2.30 L (2.43 US qt, 2.02 Imp.qt)
With oil filter cartridge replacement	2.60 L (2.75 US qt, 2.29 Imp.qt)
Oil pressure	280.0 kPa/5000 r/min at 100 °C (40.6 psi/5000 r/min at 212 °F)
Oil filter	
Oil filter type	Cartridge
Oil pump	
Oil pump type	Trochoid
Inner-rotor-to-outer-rotor-tip clearance	Less than 0.120 mm (0.0047 in)
Limit	0.20 mm (0.0079 in)
Outer-rotor-to-oil-pump-housing clearance Limit	0.09–0.15 mm (0.0035–0.0059 in) 0.22 mm (0.0087 in)
Oil-pump-housing-to-inner-and-outer-rotor	
clearance	0.03–0.08 mm (0.0012–0.0032 in)
Bypass valve opening pressure	80.0–120.0 kPa (0.80–1.20 kgf/cm², 11.6–17.4 psi)
Relief valve operating pressure	630.0–810.0 kPa (6.30–8.10 kgf/cm², 91.4– 117.5 psi)

Cooling system		
Coolant quantity Radiator (including all routes)	1.60 L (1.69 US qt, 1.41 Imp.qt) 0.25 L (0.26 US qt, 0.22 Imp.qt) 108.0–137.4 kPa (1.08–1.37 kgf/cm², 15.7–19.9 psi) 80.0–84.0 °C (176.00–183.20 °F) 95.0 °C (203.00 °F)	
		Coolant reservoir (up to the maximum level
mark) Radiator cap valve opening pressure Thermostat		
		Valve opening temperature
		Valve full open temperature
Valve lift (full open)		8.0 mm (0.31 in)
Radiator core		
Width		322.6 mm (12.70 in) 180.0 mm (7.09 in)
Height		
Depth	24.0 mm (0.94 in)	
Water pump		
Water pump type	Single suction centrifugal pump	
Reduction ratio	77/40 × 17/25 (1.309)	
Spark plug(s)		
Manufacturer/model	NGK/LMAR8A-9	
Spark plug gap	0.8–0.9 mm (0.031–0.035 in)	
Cylinder head		
Combustion chamber volume	18.48–20.08 cm³ (1.13–1.23 cu.in)	
Warpage limit	0.05 mm (0.0020 in)	
Camshaft		
Drive system	Chain drive (right)	
Camshaft cap inside diameter	22.000–22.021 mm (0.8661–0.8670 in)	
Camshaft journal diameter	21.959–21.972 mm (0.8645–0.8650 in)	
Camshaft-journal-to-camshaft-cap clearance	0.028–0.062 mm (0.0011–0.0024 in)	
Camshaft lobe dimensions		
Lobe height (Intake)	35.610–35.710 mm (1.4020–1.4059 in)	
Limit	35.510 mm (1.3980 in)	
Base circle diameter (Intake)	27.950–28.050 mm (1.1004–1.1043 in)	
Limit	27.850 mm (1.0965 in)	
Lobe height (Exhaust)	35.710–35.810 mm (1.4059–1.4098 in)	
Limit	35.610 mm (1.4020 in)	
Base circle diameter (Exhaust)	27.950–28.050 mm (1.1004–1.1043 in)	
Limit	27.850 mm (1.0965 in)	
Camshaft runout limit	0.030 mm (0.0012 in)	
Timing chain		

Tensioning system

Valve, valve seat, valve guide

Valve clearance (cold) Intake Exhaust Valve dimensions Valve head diameter (intake)

0.11–0.20 mm (0.0043–0.0079 in) 0.24–0.30 mm (0.0094–0.0118 in)

31.40–31.60 mm (1.2362–1.2441 in)

Automatic

Valve head diameter (exhaust) Valve seat contact width (intake) Valve seat contact width (exhaust) Valve stem diameter (intake) Limit Valve stem diameter (exhaust) Limit Valve guide inside diameter (intake) Valve guide inside diameter (exhaust) Valve-stem-to-valve-guide clearance (intake) Limit Valve-stem-to-valve-guide clearance (exhaust) Limit Valve stem runout

Valve spring

Free length (intake) Limit Free length (exhaust) Limit Installed length (intake) Installed length (exhaust) Spring rate K1 (intake) Spring rate K2 (intake) Spring rate K2 (exhaust) Spring rate K2 (exhaust) Installed compression spring force (intake)

Installed compression spring force (exhaust)

Spring tilt (intake) Spring tilt (exhaust) Winding direction (intake) Winding direction (exhaust)

Cylinder

Bore Taper limit Out of round limit

Piston

Piston-to-cylinder clearance Diameter Measuring point (from piston skirt bottom) Offset Piston pin bore inside diameter Limit Piston pin outside diameter Limit Piston-pin-to-piston-pin-bore clearance Limit 26.40–26.60 mm (1.0394–1.0472 in) 0.90–1.10 mm (0.0354–0.0433 in) 0.90–1.10 mm (0.0354–0.0433 in) 4.475–4.490 mm (0.1762–0.1768 in) 4.445 mm (0.1750 in) 4.460–4.475 mm (0.1756–0.1762 in) 4.430 mm (0.1744 in) 4.500–4.512 mm (0.1772–0.1776 in) 4.500–4.512 mm (0.1772–0.1776 in) 0.010–0.037 mm (0.0004–0.0015 in) 0.080 mm (0.0032 in) 0.025–0.052 mm (0.0010–0.0020 in) 0.100 mm (0.0039 in) 0.010 mm (0.0004 in)

40.30 mm (1.59 in)
38.29 mm (1.51 in)
41.39 mm (1.63 in)
39.32 mm (1.55 in)
34.34 mm (1.35 in)
35.84 mm (1.41 in)
26.03 N/mm (2.65 kgf/mm, 148.63 lbf/in)
42.21 N/mm (4.30 kgf/mm, 241.02 lbf/in)
28.90 N/mm (2.95 kgf/mm, 165.02 lbf/in)
44.19 N/mm (4.51 kgf/mm, 252.32 lbf/in)
144.00–166.00 N (14.68–16.93 kgf, 32.37–
37.32 lbf)
149.00–171.00 N (15.19–17.44 kgf, 33.50–
38.44 lbf)
1.8 mm (0.07 in)
1.8 mm (0.07 in)
Clockwise
Clockwise

80.000–80.010 mm (3.1496–3.1500 in) 0.050 mm (0.0020 in) 0.050 mm (0.0020 in)

0.015–0.040 mm (0.0006–0.0016 in) 79.970–79.985 mm (3.1484–3.1490 in) 8.0 mm (0.31 in) 0.00 mm (0.0000 in) 18.004–18.015 mm (0.7088–0.7093 in) 18.045 mm (0.7104 in) 17.990–17.995 mm (0.7083–0.7085 in) 17.970 mm (0.7075 in) 0.009–0.025 mm (0.0004–0.0010 in) 0.075 mm (0.0030 in)

Piston ring			
Top ring			
Ring type	Barrel		
End gap (installed)	0.15–0.25 mm (0.0059–0.0098 in)		
Limit	0.50 mm (0.0197 in) 0.030–0.065 mm (0.0012–0.0026 in) 0.115 mm (0.0045 in)		
Ring side clearance			
Limit			
2nd ring			
Ring type End gap (installed) Limit	Taper 0.30–0.45 mm (0.0118–0.0177 in) 0.80 mm (0.0315 in)		
		Ring side clearance	0.020–0.055 mm (0.0008–0.0022 in)
		Limit	0.115 mm (0.0045 in)
Oil ring			
End gap (installed)	0.10–0.35 mm (0.0039–0.0138 in)		
Connecting rod			
Oil clearance	0.027–0.051 mm (0.0011–0.0020 in)		
Bearing color code	1. Blue 2. Black 3. Brown 4. Green		
Crankshaft			
Runout limit	0.030 mm (0.0012 in)		
Big end side clearance	0.160–0.262 mm (0.0063–0.0103 in)		
Journal oil clearance	0.018–0.042 mm (0.0007–0.0017 in)		
Bearing color code	-1. Violet-Pink 0. White-Pink 1. Blue-Pink 2.		
	Black-Pink 3. Brown-Pink		
Balancer			
Balancer drive method	Gear		
Balancer shaft runout limit	0.030 mm (0.0012 in)		
Balancer shaft journal to balancer shaft bearing			
clearance	0.020–0.054 mm (0.0008–0.0021 in)		
Clutch Clutch type	Wet, multiple-disc		
	•		
Clutch release method	Outer pull, rack and pinion pull $5.0, 10.0$ mm (0.20, 0.20 in)		
Clutch lever free play	5.0–10.0 mm (0.20–0.39 in)		
Friction plate 2 thickness	2.92–3.08 mm (0.115–0.121 in)		
Wear limit	2.82 mm (0.111 in)		
Plate quantity	5 pcs		
Friction plate 1 thickness	2.90–3.10 mm (0.114–0.122 in)		
Wear limit	2.80 mm (0.110 in)		
Plate quantity	2 pcs		
Clutch plate thickness	1.90–2.10 mm (0.075–0.083 in)		
Plate quantity	6 pcs		
Warpage limit	0.10 mm (0.004 in)		
Clutch spring free length	50.00 mm (1.97 in)		
Limit	47.50 mm (1.87 in)		
Spring quantity	6 pcs		
Transmission			

Transmission

Transmission type

Constant mesh 6-speed

Primary reduction ratio	1.925 (77/40)
Final drive	Chain
Secondary reduction ratio	2.688 (43/16)
Operation	Left foot operation
Gear ratio	
1st	2.846 (37/13)
2nd 3rd	2.125 (34/16) 1.632 (31/19)
5th	1.091 (24/22)
6th	0.964 (27/28)
Main axle runout limit	0.08 mm (0.0032 in)
Drive axle runout limit	0.08 mm (0.0032 in)
Shifting mechanism	
Shift mechanism type	Shift drum and guide bar
Shift fork guide bar bending limit	0.050 mm (0.0020 in)
Shift fork thickness	5.76–5.89 mm (0.2268–0.2319 in)
Air filter	
Air filter element	Oil-coated paper element
Fuel pump	
Pump type	Electrical
Maximum consumption amperage	3.3 A
Fuel injector	
Model/quantity	297500–2310/2
Throttle body	
Type/quantity	EHDW38–1
ID mark	1WS1 10
Throttle position sensor	
Resistance	2.64–6.16 kΩ
Output voltage (at idle)	0.63–0.73 V
Fuel injection sensor	
Crankshaft position sensor resistance	228–342 Ω
Intake air pressure sensor output voltage	3.57–3.71 V at 101.3 kPa (3.57–3.71 V at 1.01 kgf/cm², 3.57–3.71 V at 14.7 psi)
Intake air temperature sensor resistance	$290-390 \Omega$ at 80 °C (290-390 Ω at 176 °F)
Coolant temperature sensor resistance	2510–2780 Ω at 20 °C (2510–2780 Ω at 68 °F)
Idling condition	
Fuel line pressure at idling	300–390 kPa (3.0–3.9 kgf/cm², 43.5–56.6 psi) /
	Regulated pressure 324 kPa (3.2 kgf/cm ² , 47.0
Engine idling speed	psi) 1250–1450 r/min
CO%	0.0–2.0 %
Intake vacuum	40.6 kPa (305 mmHg, 12.0 inHg)
Water temperature	85.0–105.0 °C (185.00–221.00 °F)
Oil temperature	60.0–80.0 °C (140.00–176.00 °F)
· · · ·	,

ENGINE SPECIFICATIONS

Throttle grip free play

3.0-5.0 mm (0.12-0.20 in)

CHASSIS SPECIFICATIONS

Chassis	
Frame type	Diamond
Caster angle	25.0°
Trail	90 mm (3.5 in)
Front wheel	
Wheel type	Cast wheel
Rim size	$17M/C \times MT3.50$
Rim material	Aluminum
Wheel travel	130 mm (5.1 in)
Radial wheel runout limit	1.0 mm (0.04 in)
Lateral wheel runout limit	0.5 mm (0.02 in)
Rear wheel	
Wheel type	Cast wheel
Rim size	$17M/C \times MT5.50$
Rim material	Aluminum
Wheel travel	130 mm (5.1 in)
Radial wheel runout limit	1.0 mm (0.04 in)
Lateral wheel runout limit	0.5 mm (0.02 in)
Front tire	
Туре	Tubeless
Size	120/70 R17M/C (58V)
Manufacturer/model	PIRELLI/PHANTOM SPORTSCOMP
Wear limit (front)	1.6 mm (0.06 in)
Rear tire	
Туре	Tubeless
Size	180/55 R17M/C (73V)
Manufacturer/model	PIRELLI/PHANTOM SPORTSCOMP
Wear limit (rear)	1.6 mm (0.06 in)
Tire air pressure (measured on cold tires)	
Loading condition	0–173 kg (0–381 lb)
Front	225 kPa (2.25 kgf/cm², 33 psi)
Rear	250 kPa (2.50 kgf/cm², 36 psi)
High-speed riding	
Front	225 kPa (2.25 kgf/cm², 33 psi)
Rear	250 kPa (2.50 kgf/cm², 36 psi)
Front brake	
Туре	Dual disc brake
Operation	Right hand operation
Front disc brake	
Disc outside diameter \times thickness	282.0 $ imes$ 4.5 mm (11.10 $ imes$ 0.18 in)
Brake disc thickness limit	4.0 mm (0.16 in)
Brake disc runout limit (as measured on wheel)	0.10 mm (0.0039 in)
Brake pad lining thickness (inner)	4.5 mm (0.18 in)
Limit	0.5 mm (0.02 in)

Brake pad lining thickness (outer)	4.5 mm (0.18 in)
Limit	0.5 mm (0.02 in)
Master cylinder inside diameter	15.00 mm (0.59 in)
Caliper cylinder inside diameter	30.23 mm (1.19 in)
Caliper cylinder inside diameter	27.00 mm (1.06 in)
Specified brake fluid	DOT 4
Rear brake	
Туре	Single disc brake
Operation	Right foot operation
Rear disc brake	5
Disc outside diameter × thickness	245.0 $ imes$ 5.0 mm (9.65 $ imes$ 0.20 in)
Brake disc thickness limit	4.5 mm (0.18 in)
Brake disc runout limit (as measured on wheel)	0.15 mm (0.0059 in)
Brake pad lining thickness (inner)	6.0 mm (0.24 in)
Limit	1.0 mm (0.04 in)
Brake pad lining thickness (outer)	6.0 mm (0.24 in)
Limit	1.0 mm (0.04 in)
Master cylinder inside diameter	12.7 mm (0.50 in)
Caliper cylinder inside diameter	38.18 mm (1.50 in)
Specified brake fluid	DOT 4
	B01 4
Steering	
Steering bearing type	Angular bearing
Center to lock angle (left)	35.0°
Center to lock angle (right)	35.0°
Front suspension	
Туре	Telescopic fork
Spring/shock absorber type	Coil spring/oil damper
Front fork travel	130.0 mm (5.12 in)
Fork spring free length	345.4 mm (13.60 in)
Limit	331.6 mm (13.06 in)
Fork spring installed length	338.4 mm (13.32 in)
Collar length	150.0 mm (5.91 in)
Spring rate K1	8.50 N/mm (0.87 kgf/mm, 48.54 lbf/in)
Spring stroke K1	0.0–130.0 mm (0.00–5.12 in)
Inner tube outer diameter	41.0 mm (1.61 in)
Inner tube bending limit	0.2 mm (0.01 in)
Recommended oil	Fork oil 10W or equivalent
Quantity	403.0 cm³ (13.63 US oz, 14.21 Imp.oz)
Level	162.0 mm (6.38 in)
Rear suspension	
Type	Swingarm (link suspension)
Spring/shock absorber type	Coil spring/gas-oil damper
Rear shock absorber assembly travel	55.0 mm (2.17 in)
Spring free length	171.5 mm (6.75 in)
Spring installed length	158.5 mm (6.24 in)
Spring rate K1	107.80 N/mm (10.99 kgf/mm, 615.54 lbf/in)
Spring stroke K1	0.0-55.0 mm (0.00-2.17 in)
Enclosed gas/air pressure (STD)	980 kPa (9.8 kgf/cm², 139.4 psi)

Spring preload	
Minimum	1
Standard	3
Maximum	9
Drive chain	
Size/manufacturer	525VAZ/DAIDO

Chain type Number of links 15-link length limit Drive chain slack Limit 525VAZ/DAIDO Sealed type 108 239.3 mm (9.42 in) 51.0–56.0 mm (2.01–2.20 in) 58.0 mm (2.28 in)

ELECTRICAL SPECIFICATIONS

Voltage	
System voltage	12 V
Ignition system	
Ignition system	TCI
Ignition timing (B.T.D.C.)	10.0°/1200 r/min
Engine control unit	
Model/manufacturer	TBDFS2/DENSO (MTM690)
	TBDFU1/DENSO (MTM690-U)
Ignition coil	
Minimum ignition spark gap	6.0 mm (0.24 in)
Primary coil resistance	1.19–1.61 Ω
Secondary coil resistance	8.50–11.50 kΩ
Lean angle sensor output voltage	
Less than 65°	0.4–1.4 V
More than 65°	3.7–4.4 V
AC magneto	
Charging system	AC magneto
Standard output	14.0 V, 29.3 A at 5000 r/min
Stator coil resistance	0.128–0.192 Ω (W-W)
Rectifier/regulator	
Regulator type	Semi conductor-short circuit
Regulated voltage (DC)	14.1–14.9 V
Rectifier capacity	50.0 A
Battery	
Model	YTZ10S
Voltage, capacity	12 V, 8.6 Ah
Specific gravity	1.310
Manufacturer	GS YUASA
Ten hour rate charging current	0.86 A
Headlight	
Bulb type	Halogen bulb
Bulb voltage, wattage $ imes$ quantity	
Headlight	12 V, 60.0 W/55.0 W × 1
Auxiliary light	12 V, 5.0 W $ imes$ 1
Tail/brake light	LED
Front turn signal light	12 V, 10.0 W × 2
Rear turn signal light	12 V, 10.0 W × 2
License plate light	12 V, 5.0 W × 1
Meter lighting	LED

Indicator light	
Neutral indicator light	LED
Turn signal indicator light	LED
Oil pressure warning light	LED
High beam indicator light	LED
Coolant temperature warning light	LED
Engine trouble warning light	LED
ABS warning light	LED
Immobilizer system indicator light	LED
Electric starting system	
System type	Constant mesh
Starter motor	
Power output	0.50 kW
Armature coil resistance	0.0150–0.0250 Ω
Brush overall length	12.0 mm (0.47 in)
Limit	6.50 mm (0.26 in)
Brush spring force	6.03–6.52 N (615–665 gf, 21.71–23.47 oz)
Mica undercut (depth)	0.70 mm (0.03 in)
Starter relay	
Amperage	180.0 A
Coil resistance	4.18–4.62 Ω
Horn	
Horn type	Plane
Quantity	1
Maximum amperage	3.0 A
Turn signal/hazard relay	
Relay type	Full transistor
Built-in, self-canceling device	No
Fuel sender unit	
Sender unit resistance (full)	9.0–11.0 Ω
Sender unit resistance (empty)	213.0–219.0 Ω
Fuse	
Main fuse	30.0 A
Headlight fuse	15.0 A
Signaling system fuse	10.0 A
Ignition fuse	10.0 A
Radiator fan motor fuse	10.0 A
Parking lighting fuse	7.5 A
Fuel injection system fuse	10.0 A
ABS motor fuse	30.0 A
ABS control unit fuse	7.5 A
ABS solenoid fuse	20.0 A
Auxiliary fuse	2.0 A
Backup fuse	7.5 A
Spare fuse	30.0 A


ELECTRICAL SPECIFICATIONS

Spare fuse	20.0 A	
Spare fuse	15.0 A	
Spare fuse	10.0 A	
Spare fuse	7.5 A	
Spare fuse	2.0 A	
	-	

EAS30015

GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



- A. Distance between flats
- B. Outside thread diameter

A (nut) B (bolt)		General tightening torques					
	B (BOIL)	Nm	m∙kgf	ft∙lbf			
10 mm	6 mm	6	0.6	4.3			
12 mm	8 mm	15	1.5	11			
14 mm	10 mm	30	3.0	22			
17 mm	12 mm	55	5.5	40			
19 mm	14 mm	85	8.5	61			
22 mm	16 mm	130	13.0	94			

EAS30016 ENGINE TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Exhaust pipe nut	M8	4	20 Nm (2.0 m·kgf, 14 ft·lbf)	
Cylinder head stud bolt (exhaust pipe)	M8	4	15 Nm (1.5 m·kgf, 11 ft·lbf)	
Muffler bracket bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Muffler bracket bolt	M8	2	20 Nm (2.0 m·kgf, 14 ft·lbf)	
Muffler cover bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
O ₂ sensor	M12	1	25 Nm (2.5 m·kgf, 18 ft·lbf)	
Starter motor terminal nut	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Engine ground lead bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
O ₂ sensor coupler bracket bolt	M6	1	7 Nm (0.7 m⋅kgf, 5.1 ft⋅lbf)	
Spark plug	M10	2	13 Nm (1.3 m·kgf, 9.4 ft·lbf)	
Exhaust camshaft sprocket bolt	M7	2	24 Nm (2.4 m·kgf, 17 ft·lbf)	
Intake camshaft sprocket bolt	M7	2	24 Nm (2.4 m·kgf, 17 ft·lbf)	
Exhaust camshaft cap bolt	M6	6	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-C
Intake camshaft cap bolt	M6	6	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Timing chain tensioner bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Timing chain tensioner cap bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Timing mark accessing bolt	M8	1	15 Nm (1.5 m·kgf, 11 ft·lbf)	
Crankshaft end cover	M36	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Cylinder head cover bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Breather plate bolt	M5	6	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	-6
Cylinder head bolt	M10	6	See TIP.	-C
Cylinder head bolt	M6	2	See TIP.	
Timing chain guide bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-0
Timing chain bolt (right side of cylin- der head)	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Starter clutch bolt	M8	3	32 Nm (3.2 m·kgf, 23 ft·lbf)	-6
Generator rotor bolt	M12	1	70 Nm (7.0 m·kgf, 51 ft·lbf)	
Generator cover bolt	M6	2	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	-0
Generator cover bolt	M6	8	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	
Stator coil bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-@
Crankshaft position sensor bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-6
Coupler and hose bracket bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Starter motor bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Starter motor front cover bolt	M5	2	5 Nm (0.5 m·kgf, 3.6 ft·lbf)	
Starter motor terminal and rear cov- er nut	M6	1	11 Nm (1.1 m·kgf, 8.0 ft·lbf)	
Clutch boss nut	M20	1	95 Nm (9.5 m⋅kgf, 69 ft⋅lbf)	Stake.

Item	Thread size	Q'ty	Tightening torque	Remarks
Clutch spring bolt	M6	6	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	
Clutch cover bolt	M6	10	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	
Clutch cable holder bolt	M6	2	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	-6
Oil pump drive chain guide bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-0
Shift shaft spring stopper	M8	1	22 Nm (2.2 m·kgf, 16 ft·lbf)	-0
Oil pump cover screw	M5	1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Oil pump bolt	M6	4	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	
Holder bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-0
Oil pan bolt	M6	11	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Oil strainer bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-0
Crankcase bolt	М9	6	See TIP.	l=80 mm (3.15 in) →■€
Crankcase bolt	M8	6	See TIP.	I=70 mm (2.76 in) →∎€
Crankcase bolt	M8	2	See TIP.	l=65 mm (2.56 in) →€
Crankcase bolt	M6	2	See TIP.	l=65 mm (2.56 in) →€
Crankcase bolt	M6	3	See TIP.	l=60 mm (2.36 in) →€
Crankcase bolt	M6	8	See TIP.	l=40 mm (1.57 in) →∎€
Oil pressure switch	PT1/8	1	15 Nm (1.5 m·kgf, 11 ft·lbf)	Three bond No.1215®
Oil pressure switch lead bolt	M4	1	1.8 Nm (0.18 m·kgf, 1.3 ft·lbf)	
Oil pressure switch lead holder bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Blind plate bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-0
Gear position switch bolt	M5	2	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	-6
Cylinder plug bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Main gallery bolt	M16	1	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	
Connecting rod bolt	M8	4	See TIP.	-®
Balancer driven gear bolt	M10	1	40 Nm (4.0 m·kgf, 29 ft·lbf)	
Balancer shaft cover bolt	M6	2	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	-0
Bearing retainer bolt	M6	3	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	-6
Shift drum retainer bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-0
Radiator cap bolt	M3	1	1.0 Nm (0.10 m·kgf, 0.72 ft·lbf)	
Coolant reservoir bolt	M6	1	5 Nm (0.5 m·kgf, 3.6 ft·lbf)	


ltem	Thread size	Q'ty	Tightening torque	Remarks
Radiator side cover bolt	M6	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Radiator side cover bracket bolt	M6	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Radiator fan motor bolt	M6	3	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	
Radiator bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Horn nut	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Radiator inlet hose clamp screw	M5	1	2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)	
Water jacket joint inlet hose clamp screw	M5	1	2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)	
Water jacket joint bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Oil filter cartridge	M20	1	17 Nm (1.7 m·kgf, 12 ft·lbf)	
Oil filter cartridge union bolt	M20	1	40 Nm (4.0 m·kgf, 29 ft·lbf)	-E
Coolant temperature sensor	M10	1	16 Nm (1.6 m·kgf, 12 ft·lbf)	
Thermostat cover bolt	M6	2	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	
Water pump housing bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-6
Water pump inlet/outlet pipe bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Coolant drain bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Intake air pressure sensor bolt	M5	1	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Intake air temperature sensor bolt	M5	1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Air duct bracket screw	M5	4	1.6 Nm (0.16 m·kgf, 1.2 ft·lbf)	
Air filter element screw	M5	1	1.6 Nm (0.16 m·kgf, 1.2 ft·lbf)	
Throttle cable locknut (throttle body side)	M6	2	4.5 Nm (0.45 m·kgf, 3.3 ft·lbf)	
Throttle cable locknut (handlebar side)	M6	1	4.3 Nm (0.43 m·kgf, 3.1 ft·lbf)	
Throttle body joint clamp screw	M5	4	3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)	
Air filter case joint clamp screw	M5	2	3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)	
Air filter case bolt	M6	2	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	
Fuel rail bolt	M5	2	3.5 Nm (0.35 m·kgf, 2.5 ft·lbf)	
Throttle position sensor screw	M5	2	3.5 Nm (0.35 m·kgf, 2.5 ft·lbf)	
ISC (Idle Speed Control) valve plate screw	M6	1	5 Nm (0.5 m·kgf, 3.6 ft·lbf)	
Engine oil drain bolt	M14	1	43 Nm (4.3 m·kgf, 31 ft·lbf)	

TIP_

Cylinder head bolt

Tighten the cylinder head bolts "1"-"8" in the proper tightening sequence as follows:

- Lubricate the cylinder head bolts "1"-"6" threads and mating surface with engine oil.
 Tighten the cylinder head bolts "1"-"6" to 10 Nm (1.0 m·kgf, 7.2 ft·lbf).
- 3. Tighten the cylinder head bolts "1"-"6" to 40 Nm (4.0 m·kgf, 29 ft·lbf).
- 4. Loosen and retighten the cylinder head bolts "1"-"6" to 20 Nm (2.0 m·kgf, 14 ft·lbf) in the proper tightening sequence, and then tighten them further to reach the specified angle 90° in the proper tightening sequence.
- 5. Tighten the cylinder head bolts "7" and "8" to 10 Nm (1.0 m·kgf, 7.2 ft·lbf).




TIP ____

Crankcase bolt

Tighten the crankcase bolts "1"–"27" in the proper tightening sequence as follows: Tighten the bolts "1"– "16" in the order of the embossed numbers on the crankcase.

- 1. Lubricate the crankcase bolts "1"-"27" threads, mating surfaces, washers, and O-rings with the engine oil.
- 2. Tighten the crankcase bolts "1"-"6" to 24 Nm (2.4 m·kgf, 17 ft·lbf).
- 3. Loosen and retighten the crankcase bolts "1"–"6" to 17 Nm (1.7 m·kgf, 12 ft·lbf) in the proper tightening sequence, and then tighten them further to reach the specified angle 60° in the proper tightening sequence.
- Tighten the crankcase bolts "7"–"27".
 "7"–"14": 24 Nm (2.4 m·kgf, 17 ft·lbf)
 "15"–"16": 10 Nm (1.0 m·kgf, 7.2 ft·lbf)
 "17"–"27": 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

Tighten the bolts "17"-"27" in any tightening sequence using a crisscross pattern.



TIP ____

Connecting rod bolt

Tighten the connecting rod bolts to 20 Nm (2.0 m·kgf, 14 ft·lbf), and then tighten them further to reach the specified angle 175–185°.

CHASSIS TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Engine mounting nut (rear upper side)	M10	1	55 Nm (5.5 m⋅kgf, 40 ft⋅lbf)	
Engine mounting nut (rear lower side)	M10	1	55 Nm (5.5 m⋅kgf, 40 ft⋅lbf)	
Engine mounting bolt (left front side)	M12	1	75 Nm (7.5 m·kgf, 54 ft·lbf)	
Engine mounting bolt (left upper side)	M10	1	55 Nm (5.5 m·kgf, 40 ft·lbf)	
Engine mounting bolt (right front side)	M12	1	75 Nm (7.5 m⋅kgf, 54 ft⋅lbf)	
Engine mounting bolt (right upper side)	M10	1	55 Nm (5.5 m·kgf, 40 ft·lbf)	
Engine bracket bolt (right)	M8	2	25 Nm (2.5 m·kgf, 18 ft·lbf)	
Engine bracket bolt (left)	M8	2	25 Nm (2.5 m·kgf, 18 ft·lbf)	
Clutch cable guide bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear frame bolt	M8	4	25 Nm (2.5 m·kgf, 18 ft·lbf)	
Seat bracket bolt	M6	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Seat lock bracket bolt	M6	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Seat lock nut	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Seat lock key cylinder bolt	M6	2	2.5 Nm (0.25 m·kgf, 1.8 ft·lbf)	
Battery cover bolt	M5	2	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Battery terminal bolt	M6	2	2.3 Nm (0.23 m·kgf, 1.7 ft·lbf)	
Lean angle sensor bolt	M4	2	2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)	
Starter relay bolt	M6	2	3.6 Nm (0.36 m·kgf, 2.6 ft·lbf)	
Battery box bolt	M6	4	9 Nm (0.9 m·kgf, 6.5 ft·lbf)	-0
Battery box nut	M6	2	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Tail/brake light nut	M6	2	3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)	
Rear fender cover bolt	M5	5	6 Nm (0.6 m·kgf, 4.3 ft·lbf)	
Clamp screw	M4	2	1.5 Nm (0.15 m·kgf, 1.1 ft·lbf)	
Mudguard assembly bolt	M6	4	11 Nm (1.1 m·kgf, 8.0 ft·lbf)	
Lower fender cover screw	M5	3	2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)	
License plate nut	M5	2	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
License plate bracket bolt	M5	3	6 Nm (0.6 m·kgf, 4.3 ft·lbf)	
Rear reflector nut	M5	1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Headlight assembly bolt (M6 \times 16 mm)	M6	2	7 Nm (0.7 m⋅kgf, 5.1 ft⋅lbf)	
Headlight assembly bolt (M5 \times 12 mm)	M5	1	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Headlight lens unit bolt	M5	2	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Front turn signal light bolt	M6	6	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Meter assembly cover bolt	M5	2	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Fuel tank top cover bolt	M5	8	1.5 Nm (0.15 m·kgf, 1.1 ft·lbf)	
Fuel tank top cover bolt	M5	6	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	

Item	Thread size	Q'ty	Tightening torque	Remarks
Fuel tank cover bolt	M5	6	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Fuel tank center cover bolt	M5	4	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Outer side cover bolt	M5	8	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Inner side cover bolt	M5	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Air scoop bolt	M6	6	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Electrical components tray 1 bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rectifier/regulator bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Electrical components tray 2 nut	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Electrical components tray 2 bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Hydraulic unit assembly bolt	M6	3	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front brake hose guide bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front reflector nut	M6	2	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Front brake disc bolt	M6	10	18 Nm (1.8 m·kgf, 13 ft·lbf)	-6
Front wheel sensor rotor bolt	M5	3	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	-6
Front wheel sensor bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front wheel axle	M16	1	65 Nm (6.5 m·kgf, 47 ft·lbf)	
Front wheel axle pinch bolt	M8	1	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Drive chain puller locknut	M8	2	16 Nm (1.6 m·kgf, 12 ft·lbf)	
Rear wheel sprocket nut	M10	6	80 Nm (8.0 m·kgf, 58 ft·lbf)	
Rear brake disc bolt	M8	5	30 Nm (3.0 m·kgf, 22 ft·lbf)	-6
Rear wheel sensor rotor bolt	M5	3	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	-6
Rear wheel sensor bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Wheel axle nut	M18	1	105 Nm (10.5 m·kgf, 76 ft·lbf)	
Rear brake caliper retaining bolt	M12	1	27 Nm (2.7 m·kgf, 20 ft·lbf)	
Rear brake caliper bolt	M8	1	22 Nm (2.2 m·kgf, 16 ft·lbf)	-6
Brake master cylinder reservoir cap bolt	M4	2	1.5 Nm (0.15 m·kgf, 1.1 ft·lbf)	
Brake lever pivot bolt	M6	1	1.0 Nm (0.10 m·kgf, 0.72 ft·lbf)	
Brake lever pivot nut	M6	1	6 Nm (0.6 m·kgf, 4.3 ft·lbf)	
Front brake light switch screw	M4	1	1.2 Nm (0.12 m·kgf, 0.87 ft·lbf)	
Brake caliper bleed screw	M8	3	5 Nm (0.5 m·kgf, 3.6 ft·lbf)	
Front brake caliper bolt	M10	2	40 Nm (4.0 m·kgf, 29 ft·lbf)	
Front brake hose union bolt	M10	5	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Front brake master cylinder holder bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Brake pad retaining bolt	M10	1	17 Nm (1.7 m·kgf, 12 ft·lbf)	
Screw plug	M10	1	2.5 Nm (0.25 m·kgf, 1.8 ft·lbf)	
Rear brake hose joint bracket bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear brake hose joint bolt	M6	3	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear brake hose union bolt	M10	4	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Rear brake pipe holder bracket bolt	M5	1	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	

ltem	Thread size	Q'ty	Tightening torque	Remarks
Brake fluid reservoir holder bolt	M5	1	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Footrest assembly bolt (right foot- rest)	M8	2	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Rear brake master cylinder bolt	M8	2	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Brake pedal bolt	M8	1	22 Nm (2.2 m·kgf, 16 ft·lbf)	-6
Rear brake hose/lead guide bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear brake hose/lead holder bolt	M6	1	5 Nm (0.5 m·kgf, 3.6 ft·lbf)	
Rear brake pedal adjusting locknut	M8	1	18 Nm (1.8 m·kgf, 13 ft·lbf)	
Rearview mirror	M10	2	17 Nm (1.7 m·kgf, 12 ft·lbf)	
Handlebar switch screw (right)	M4	2	2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)	
Throttle cable housing bolt	M5	2	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Handlebar switch screw (left)	M4	2	2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)	
Grip end	M16	2	26 Nm (2.6 m·kgf, 19 ft·lbf)	
Upper handlebar holder bolt	M8	4	28 Nm (2.8 m·kgf, 20 ft·lbf)	
Lower handlebar holder nut	M10	2	32 Nm (3.2 m·kgf, 23 ft·lbf)	
Clutch lever pivot nut	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Clutch lever holder pinch bolt	M6	1	11 Nm (1.1 m·kgf, 8.0 ft·lbf)	
Clutch cable locknut	M8	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Meter assembly screw	M4	3	1.8 Nm (0.18 m·kgf, 1.3 ft·lbf)	
Meter assembly bracket bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front fork damper rod bolt	M10	2	30 Nm (3.0 m·kgf, 22 ft·lbf)	-15
Lower bracket pinch bolt	M8	4	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Upper bracket pinch bolt (left and right)	M8	2	26 Nm (2.6 m·kgf, 19 ft·lbf)	
Upper bracket pinch bolt (center)	M10	1	21 Nm (2.1 m·kgf, 15 ft·lbf)	
Front fork cap bolt	M38	2	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Front fender bracket bolt	M6	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front fender bolt	M6	4	9 Nm (0.9 m·kgf, 6.5 ft·lbf)	
Front brake hose/lead holder bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front brake hose holder bracket bolt	M5	1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Front brake hose lower holder bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Cap nut	M25	1	See TIP.	
Drive chain guard bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Relay arm nut	M10	1	40 Nm (4.0 m·kgf, 29 ft·lbf)	
Connecting arm nut (relay arm side)	M10	1	40 Nm (4.0 m·kgf, 29 ft·lbf)	
Rear shock absorber assembly bolt (front side)	M10	1	44 Nm (4.4 m·kgf, 32 ft·lbf)	
Rear shock absorber assembly nut (rear side)	M10	1	40 Nm (4.0 m·kgf, 29 ft·lbf)	
Pivot shaft protector bolt	M6	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Pivot shaft protector bracket bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Sidestand bolt	M10	2	63 Nm (6.3 m·kgf, 46 ft·lbf)	-6

ltem	Thread size	Q'ty	Tightening torque	Remarks
Footrest assembly bolt (left footrest)	M8	2	30 Nm (3.0 m⋅kgf, 22 ft⋅lbf)	
Footrest plate bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Passenger footrest bolt	M8	4	28 Nm (2.8 m·kgf, 20 ft·lbf)	
Pivot shaft nut	M16	1	110 Nm (11 m·kgf, 80 ft·lbf)	
Footrest bracket bolt	M10	4	45 Nm (4.5 m·kgf, 33 ft·lbf)	-
Sidestand pivot nut	M10	1	46 Nm (4.6 m·kgf, 33 ft·lbf)	
Sidestand switch nut	M5	2	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Connecting arm nut (frame side)	M12	1	52 Nm (5.2 m·kgf, 38 ft·lbf)	
Drive sprocket cover bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-6
Drive sprocket nut	M22	1	95 Nm (9.5 m·kgf, 69 ft·lbf)	Stake
Shift rod locknut (shift arm side)	M6	1	9 Nm (0.9 m·kgf, 6.5 ft·lbf)	
Shift rod locknut (shift pedal side)	M6	1	9 Nm (0.9 m·kgf, 6.5 ft·lbf)	Left-hand threads
Shift arm pinch bolt	M6	1	14 Nm (1.4 m·kgf, 10 ft·lbf)	
Shift rod upper joint bolt	M6	1	9 Nm (0.9 m·kgf, 6.5 ft·lbf)	- D
Fuel pump bolt	M5	4	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Fuel tank cap bolt	M5	5	6 Nm (0.6 m·kgf, 4.3 ft·lbf)	
Fuel tank bolt (front side)	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Fuel tank bolt (rear side)	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear fuel tank bracket bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Front fuel tank bracket bolt	M8	1	30 Nm (3.0 m⋅kgf, 22 ft⋅lbf)	
Fuel tank overflow/breather hose clamp screw	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	

TIP _____

Cap nut

1. First, tighten the cap nut to approximately 52 Nm (5.2 m·kgf, 38 ft·lbf) with a torque wrench, then loosen the cap nut completely.

2. Retighten the cap nut to 18 Nm (1.8 m kgf, 13 ft lbf) with a torque wrench.

LUBRICATION POINTS AND LUBRICANT TYPES

EAS30018 ENGINE

Lubrication point	Lubricant	
Oil seal lips		
O-rings		
Coolant hose insertion part	Water or –	
Bearings		
Camshaft lobes and journals (intake and exhaust)		
Valve stem seal (installed on valve guide)	-6	
Valve lifter outer surface (intake and exhaust)	- E	
Valve stems and stem ends (intake and exhaust)		
Decompression camshaft moving point	- E	
Crankshaft big ends	- E	
Piston surfaces	- E	
Piston pins	- E	
Connecting rod bolts		
Crankshaft journals	- E	
Balancer shaft journals	- E	
Generator rotor bolt thread and washer	- E	
Balancer shaft buffer plate bolt	- E	
Oil pump rotors (inner and outer)	- E	
Oil pump shaft	- E	
Oil cooler union bolt	- E	
Starter clutch idle gear inner surface and end	- E	
Starter clutch outer assembly	-E	
Starter clutch gear	- E	
Primary driven gear end	- E	
Crankcase cover and clutch pull rod		
Clutch housing thrust washer		
Clutch boss nut and conical washer	C	
Transmission gears (wheel and pinion) and collar		
Transmission gears inner surface (shift fork contact parts)		
Drive sprocket nut	- E	
Shift drum assembly	- E	
Shift forks and shift fork guide bars	- E	
Shift shaft washer	(E)	
Shift shaft moving surface		


LUBRICATION POINTS AND LUBRICANT TYPES

EAS30019 CHASSIS

Lubrication point	Lubricant
Front wheel oil seal lips	-LS-
Rear wheel oil seal lip	
Rear wheel drive hub mating surface	
Pivot shaft bearing and pivot shaft spacer	
Pivot shaft	
Connecting arm inside surface	
Connecting arm bearing and connecting arm spacer	
Relay arm bearing and relay arm spacer	
Shift pedal pivoting point and metal-to-metal moving parts	
Shift rod joint (engine side)	
Rear brake pedal pivoting point and metal-to-metal moving parts	
Upper bearing and lower bearing	
Upper bearing cover seal lip and lower bearing dust seal lip	
Throttle cable housing inner surface and throttle cable	
Clutch lever pivoting point and clutch cable	
Sidestand pivoting point and metal-to-metal moving parts	
Sidestand and sidestand switch	
Passenger footrest pivoting point	

LUBRICATION SYSTEM CHART AND DIAGRAMS


ENGINE OIL LUBRICATION CHART



- 1. Oil strainer
- 2. Oil pump
- 3. Relief valve
- 4. Oil cooler
- 5. Oil filter cartridge
- 6. Main gallery
- 7. Oil pressure switch
- 8. Crankshaft
- 9. Oil nozzle
- 10. Balancer shaft assembly
- 11. Timing chain tensioner
- 12. Intake camshaft
- 13. Exhaust camshaft
- 14. Main axle
- 15. Drive axle

LUBRICATION DIAGRAMS


Crankcase, cylinder, and cylinder head (right side view)



- 1. Timing chain tensioner
- 2. Intake camshaft
- 3. Exhaust camshaft
- 4. Crankshaft
- 5. Oil filter cartridge
- 6. Oil cooler
- 7. Oil drain bolt
- 8. Oil strainer
- 9. Oil pump


LUBRICATION SYSTEM CHART AND DIAGRAMS

Crankcase and cylinder (left side view)



- 1. Crankshaft
- 2. Balancer shaft assembly
- 3. Connecting rod
- 4. Oil cooler
- 5. Oil filter cartridge


Oil pump (bottom view)



- 1. Oil pump
- 2. Oil pressure switch
- 3. Oil filter cartridge
- 4. Oil cooler
- 5. Oil strainer


LUBRICATION SYSTEM CHART AND DIAGRAMS

Camshaft (top view)



- 1. Intake camshaft
- 2. Cylinder head
- 3. Exhaust camshaft


Crankshaft (front view)



- 1. Oil nozzle
- 2. Piston
- 3. Crankshaft
- 4. Main gallery


LUBRICATION SYSTEM CHART AND DIAGRAMS

Crankshaft and transmission (top view)



- 1. Balancer shaft assembly
- 2. Crankshaft
- 3. Main axle
- 4. Drive axle


COOLING SYSTEM DIAGRAMS



- 1. Thermostat
- 2. Oil cooler inlet hose
- 3. Oil cooler
- 4. Oil cooler outlet hose
- 5. Water jacket joint inlet hose
- 6. Water pump outlet pipe
- 7. Water pump inlet pipe
- 8. Radiator outlet hose
- 9. Water jacket joint
- 10. Water pump


CABLE ROUTING

Handlebar (front view)




- 1. Throttle cable (decelerator cable)
- 2. Throttle cable (accelerator cable)
- 3. Clutch cable
- 4. Clutch switch lead
- 5. Handlebar switch lead (left handlebar switch)
- 6. Handlebar switch coupler (left handlebar switch)
- 7. Wire harness
- 8. Cable guide
- 9. Brake hose (hydraulic unit to left front brake caliper)
- 10. Front wheel sensor lead
- 11. Sub-wire harness coupler (headlight, turn signal light, and auxiliary light)
- 12. Handlebar switch coupler (right handlebar switch)
- 13. Brake hose (front brake master cylinder to hydraulic unit)
- 14. Handlebar switch lead (right handlebar switch)
- 15. Front brake light switch lead
- 16. Front turn signal light lead (right turn signal light)
- 17. Front turn signal light lead (left turn signal light)
- 18. Handlebar
- 19. Front brake master cylinder assembly
- 20. Clutch lever holder
- 21. Front fork
- 22. Coupler cover
- A. Insert the projection on the holder into the hole in the cable guide.
- B. Fasten the left handlebar switch coupler to the wire harness with tape, and then place the coupler in the coupler cover. Make sure that the wire harness is positioned to the rear of the coupler.
- C. Route the throttle cables through the guide. Be sure to route the throttle cable (decelerator cable) over the throttle cable (accelerator cable).
- D. Connect the sub-wire harness coupler (headlight, turn signal light, and auxiliary light), and then insert the projection on the coupler into the hole in the cable guide.
- E. Position the right handlebar switch coupler to the rear of the left handlebar switch coupler.
- F. Route the throttle cables to the rear of the main switch.
- G. Connect the auxiliary light coupler, and then place the coupler in the headlight body.
- H. To meter assembly
- I. Upward
- J. Downward
- K. Forward
- L. Rearward
- M. Route the brake hose (front brake master cylinder to hydraulic unit) through the guide as shown in the illustration.
- N. Outward
- O. Inward
- P. Bend the wire harness 180° and secure it with tape.
- Q. Connect the right handlebar switch coupler, and then place the coupler in the coupler cover.

ECU and clutch cable (right side view)




- 1. Throttle cable (accelerator cable)
- 2. Throttle cable (decelerator cable)
- 3. Brake hose (front brake master cylinder to hydraulic unit)
- 4. Front wheel sensor lead
- 5. Handlebar switch coupler (left handlebar switch)
- 6. Handlebar switch coupler (right handlebar switch)
- 7. Sub-wire harness coupler (headlight, turn signal light, and auxiliary light)
- 8. Clutch cable
- 9. Fuel pump coupler
- 10. Sub-wire harness coupler
- 11. Fuel tank breather hose
- 12. Fuel tank overflow hose
- 13. Wire harness
- 14. Intake air temperature sensor coupler
- 15. Brake hose (hydraulic unit to left front brake caliper)
- 16. Meter assembly cover
- 17. Damper
- 18. Frame
- 19. Cylinder head breather hose
- 20. Sub-wire harness
- A. Route the clutch cable through the guide as shown in the illustration.
- B. Fasten the brake hose (hydraulic unit to left front brake caliper) and front wheel sensor lead with the holders. Refer to "CABLE ROUTING (Hydraulic unit assembly (top and right side view))".
- C. Blue paint mark
- D. After connecting the meter assembly coupler, install the coupler cover completely until it contacts the meter assembly.
- E. Inward
- F. Outward
- G. Forward
- H. Rearward
- I. Insert the projection on the wire harness holder into the hole in the frame.



- 1. Wire harness
- 2. Clutch cable
- 3. Oil pressure switch lead
- 4. Oil pressure switch
- 5. O₂ sensor
- 6. O₂ sensor lead
- 7. Rear brake light switch lead
- 8. Rear brake light switch
- 9. O₂ sensor coupler
- 10. Rear brake light switch coupler
- 11. Rear wheel sensor coupler
- 12. Oil pressure switch connector
- 13. Fuel tank overflow hose
- 14. Canister purge hose (hose joint to canister)
- 15. Fuel tank breather hose
- 16. Canister
- 17. Rear wheel sensor lead
- A. Route the oil pressure switch lead through the guide, and then secure the lead by bending the guide around the lead.
- B. Route the oil pressure switch lead to the inside of the O₂ sensor lead, and then secure the leads by bending the guides around the leads.
- C. Do not pinch the O₂ sensor lead between the pivot shaft protector and the engine.
- D. Fasten the rear brake light switch lead and O_2 sensor lead with the holder.
- E. To rear brake caliper bracket
- F. Connect the O₂ sensor coupler, and then insert the projection on the coupler into the hole in the bracket.
- G. Make sure that the wire harness is not pinched between the pivot shaft protector (right) and the frame.
- H. Route the wire harness to the inside of the bracket as shown in the illustration so that the harness does not contact the air filter case bolt flange.
- I. Less than 10 mm (0.39 in)
- J. Point the ends of the hose clamp upward.
- K. Point the ends of the hose clamp downward.
- L. Forward
- M. Rearward
- N. Inward
- O. Outward


Rectifier/regulator (left side view)




- 1. Wire harness
- 2. Main switch lead
- 3. Intake air temperature sensor coupler
- 4. Throttle cable (decelerator cable)
- 5. Throttle cable (accelerator cable)
- 6. Fuel pump coupler
- 7. Throttle body assembly
- 8. Oil cooler inlet hose
- 9. Coolant reservoir hose
- 10. Horn lead
- 11. AC magneto lead
- 12. Radiator inlet hose
- 13. Clutch cable
- 14. Handlebar switch lead (left handlebar switch)
- 15. Ignition coil #2 coupler
- 16. Ignition coil #1 coupler
- 17. Injector #1 coupler
- 18. ISC (Idle Speed Control) unit coupler
- 19. Injector #2 coupler
- 20. Throttle position sensor coupler
- 21. Throttle position sensor
- 22. Coolant temperature sensor lead
- 23. Crankshaft position sensor coupler
- 24. Radiator fan motor coupler
- 25. AC magneto lead coupler
- 26. Rectifier/regulator coupler
- 27. Joint coupler
- 28. Auxiliary DC outlet coupler
- A. Fasten the main switch lead and wire harness with the plastic band at the location shown in the illustration.
- B. Make sure that the throttle cables do not cross between the guide on the frame and the throttle body.
- C. 5-10 mm (0.20-0.39 in)
- D. Fasten the AC magneto lead to the oil cooler inlet hose with a plastic locking tie. Make sure to route the AC magneto lead to the outside of the oil cooler inlet hose. Align the plastic locking tie with the blue tape on the AC magneto lead. Face the buckle of the plastic locking tie rearward, and then cut off the excess end of the tie to 2 mm (0.08 in) or less.
- E. Fasten the AC magneto lead and coolant reservoir hose with the holder at the location shown in the illustration. Make sure that there is no slack in the AC magneto lead.
- F. Secure the holder by inserting the projection on the holder into the hole in the radiator fan motor bracket, and then fasten the AC magneto lead, horn lead, and coolant reservoir hose with the holder. Make sure that the coolant reservoir hose and leads do not cross between the oil cooler inlet hose and this holder.
- G. Fasten the AC magneto lead, horn lead, and coolant reservoir hose with the holder.
- H. Fasten the AC magneto lead, horn lead, and coolant reservoir hose with the holder at the location shown in the illustration. Make sure that there is no slack in the AC magneto lead, horn lead, and coolant reservoir hose.

- I. Route the AC magneto lead to the inside of the radiator inlet hose, and then connect the AC magneto coupler to the rectifier/regulator.
- J. Route the clutch cable through the hole in the cover.
- K. Fasten the left handlebar switch lead and wire harness with the plastic band at the location shown in the illustration.
- L. Inward
- M. Outward
- N. Route the coolant temperature sensor lead and gear position switch lead between the throttle position sensor and the cylinder head.
- O. The gear position switch lead and coolant temperature sensor lead may be positioned and routed in any order. Make sure that there is no slack in the gear position switch lead.
- P. Route the coolant temperature sensor lead to the front of the gear position switch lead.
- Q. Face the catch of the holder inward.
- R. Upward
- S. Downward
- T. Install the joint coupler completely onto the tab on the electrical components tray 1.
- U. Connect the coupler, and then insert the projection on the coupler into the hole in the electrical components tray 1.
- V. Connect the coupler, and then insert the projection on the coupler into the hole in the electrical components tray 1.

Canister (left side view)




- 1. Starter motor lead
- 2. Positive battery sub-wire harness
- 3. Tail/brake light coupler
- 4. License plate light coupler
- 5. Rear turn signal light coupler
- 6. Engine ground lead
- 7. Sidestand switch lead
- 8. Sidestand switch coupler
- 9. Terminal cover
- 10. Canister breather hose
- 11. Canister
- 12. Fuel tank overflow hose
- 13. Fuel tank breather hose
- 14. Coolant temperature sensor coupler
- 15. Gear position switch coupler
- 16. Battery
- 17. Battery box
- 18. Frame
- 19. Drive sprocket cover
- 20. Gear position switch lead
- A. Fasten the engine ground lead and starter motor lead to the frame with plastic locking ties. Point the end of each plastic locking tie rearward, and then cut off the excess end of the tie to 2 mm (0.08 in) or less.
- B. Make sure that the starter motor lead is not twisted.
- C. Fasten the starter motor lead and engine ground lead with the holder. Align the white tape on the starter motor lead with the holder.
- D. Make sure that there is no twist in the starter motor lead and sidestand switch lead.
- E. Fit the starter motor lead between the bottom of the battery box and the rib on the battery box.
- F. Inward
- G. Outward
- H. Do not pinch the sidestand switch lead between the engine ground lead and the frame.
- I. Forward
- J. Rearward
- K. Blue paint mark
- L. White paint mark
- M. 2-3 mm (0.08-0.12 in)
- N. Upward
- O. Downward



- 1. Rectifier/regulator
- 2. Headlight relay
- 3. Turn signal/hazard relay
- 4. Throttle cable
- 5. Radiator fan motor relay
- 6. Relay unit
- Brake hose (front brake master cylinder to hydraulic unit)
- 8. Front wheel sensor lead
- 9. Brake hose (hydraulic unit to left front brake caliper)
- 10. Intake air temperature sensor coupler
- 11. ABS ECU coupler
- 12. Hydraulic unit assembly
- 13. ECU (Engine Control Unit)
- 14. Immobilizer unit coupler
- 15. Immobilizer unit lead
- 16. ECU lead
- 17. Sub-wire harness coupler
- 18. Brake hose (hydraulic unit to rear brake caliper)
- 19. Brake hose (rear brake master cylinder to hydraulic unit)
- 20. Wire harness
- 21. Fuel pump coupler
- 22. Intake air pressure sensor
- 23. Intake air pressure sensor coupler
- 24. Main switch coupler
- 25. Frame
- 26. Main switch lead
- 27. Electrical components tray 1
- A. Insert the projection on the bracket into the hole in the sub-wire harness coupler.
- B. White paint mark
- C. Insert the projection on the wire harness holder into the hole in the frame.
- D. Forward
- E. Rearward
- F. Inward
- G. Outward
- H. Insert the projection on the wire harness holder into the hole in the frame from the bottom of the frame.
- I. Route the immobilizer unit lead and main switch lead to the outside of the wire harness.
- J. Face the buckle of the plastic band downward with the end pointing inward.
- K. Position the immobilizer unit coupler and main switch couplers under the frame.
- L. Route the headlight relay lead and turn signal/hazard relay lead through the rear hole in the electrical component tray 1.
- M. Insert the projection on the main switch lead holder into the upper hole in the frame.
- N. Insert the projection on the wire harness holder into the lower hole in the frame.


Battery and rear fender (top view)




- 1. Battery band
- 2. Positive battery lead
- 3. Negative battery lead
- 4. Fuse box 1
- 5. Yamaha diagnostic tool coupler
- 6. Fuse box 2
- 7. Lean angle sensor
- 8. Rear turn signal light lead (right turn signal light)
- 9. License plate light lead
- 10. Rear turn signal light lead (left turn signal light)
- 11. Seat lock cable
- 12. Starter motor lead
- 13. Positive battery sub-wire harness coupler
- 14. Wire harness
- 15. Tail/brake light lead
- 16. Rear fender
- 17. Lower fender cover
- 18. Frame
- 19. Rear turn signal light coupler
- 20. License plate light coupler
- 21. Battery
- 22. Battery box
- A. Route the positive battery lead through the hole in the battery band.
- B. Position the Yamaha diagnostic tool lead and coupler above fuse boxes 1 and 2 as shown in the illustration.
- C. Connect all of the couplers near fuse box 2, and then install fuse box 2 to the battery box.
- D. Route the seat lock cable over the each lead.
- E. Insert the projection on the wire harness holder into the hole in the battery box.
- F. Inward
- G. Outward
- H. Right
- I. Left

CABLE ROUTING

Rear brake hose (right side view)




- 1. Rear wheel sensor lead
- 2. Brake hose (hydraulic unit to rear brake caliper)
- 3. Rear brake fluid reservoir hose
- 4. Seal
- 5. Brake hose (rear brake master cylinder to hydraulic unit)
- 6. O₂ sensor lead
- 7. Rear brake light switch lead
- 8. Frame
- A. Route the rear wheel sensor lead to the outside of the brake hose (hydraulic unit to rear brake caliper). Make sure that the rear wheel sensor lead is not twisted.
- B. Align the holder with the pipe section of the brake hose (hydraulic unit to rear brake caliper).
- C. Position the holder halfway between the guide and the end of the protective sleeve on the rear wheel sensor lead as shown in the illustration.
- D. Route the brake hoses to the inside of the frame.
- E. To O₂ sensor
- F. Fasten the seal to the frame with a plastic locking tie. Face the buckle of the plastic locking tie inward with the end pointing downward.
- G. Route the brake hoses on top of the frame.
- H. Point the end of the plastic locking tie rearward, and then cut off the excess end of the tie to 5 mm (0.20 in) or less.
- I. Fasten the grommets on the rear wheel sensor lead and the brake hose (hydraulic unit to rear brake caliper) with the holder.
- J. Fasten the rear wheel sensor lead and brake hose (hydraulic unit to rear brake caliper) with the holder. Route the rear wheel sensor lead over the brake hose (hydraulic unit to rear brake caliper). Align the holder with the pipe section of the brake hose (hydraulic unit to rear brake caliper), making sure that the white tape on the rear wheel sensor lead is positioned to the front of the holder.
- K. White tape
- L. Route the rear brake light switch lead and O_2 sensor lead to the inside of the rear wheel sensor lead.
- M. Route the rear wheel sensor lead and brake hose (hydraulic unit to rear brake caliper) through the guide.



Front brake hose (left and right side view)


- 1. Brake hose (hydraulic unit to left front brake caliper)
- 2. Front wheel sensor lead
- 3. Brake hose (left front brake caliper to right front brake caliper)
- 4. Brake hose (front brake master cylinder to hydraulic unit)
- A. Make sure that there is no slack in the front wheel sensor lead and that the lead is not pinched between the headlight bracket and the brake hose (hydraulic unit to left front brake caliper) in the area shown in the illustration.
- B. Fasten the front wheel sensor lead and brake hose (hydraulic unit to left front brake caliper) with the holder as shown in the illustration. Position the holder 80–100 mm (3.15–3.94 in) from the grommet on the hose and route the lead over the hose.
- C. Face the catch of the holder forward, and then close the holder until three clicks or more are heard.
- D. Make sure that the holder contacts the end of the hose protector on the brake hose.
- E. Fasten the front wheel sensor lead and brake hose (hydraulic unit to left front brake caliper) with the holder as shown in the illustration. Position the holder 30–50 mm (1.18–1.97 in) from the grommet on the hose and route the lead to the rear of the hose.
- F. To front brake master cylinder
- G. To hydraulic unit
- H. 15-25 mm (0.59-0.98 in)
- I. Fasten the front wheel sensor lead and brake hose (hydraulic unit to left front brake caliper) with the holder as shown in the illustration. Position the holder 15 mm (0.59 in) or less from the grommet on the hose and route the lead to the outside of the hose. Face the catch of the holder inward, and then close the holder until three clicks or more are heard.

Hydraulic unit assembly (top and right side view)



- 1. Brake hose (rear brake master cylinder to hydraulic unit)
- 2. Brake hose (front brake master cylinder to hydraulic unit)
- 3. Front wheel sensor lead
- 4. Brake hose (hydraulic unit to left front brake caliper)
- 5. Brake hose (hydraulic unit to rear brake caliper)
- A. Make sure that the pipe section of the brake hose (rear brake master cylinder to hydraulic unit) does not contact the hydraulic unit.
- B. Protective sleeve and tape
- C. Tape
- D. Fasten the front wheel sensor lead to the brake hose (hydraulic unit to left front brake caliper) with the holder. Align the edge of the holder with the edge of the tape on the front wheel sensor lead as shown in the illustration.
- E. Upward
- F. Downward
- G. Inward
- H. Outward


Fuel tank (left side view)



- 1. Fuel tank
- 2. Fuel hose
- 3. Fuel tank breather hose
- 4. Fuel tank overflow hose
- A. Face the blue paint mark on the fuel tank breather hose to the right. Install the hose up to the wide portion of the pipe.
- B. Align the ends of the hose clamp with the paint mark on the hose. Make sure not to install the hose clamp on the raised portion of the hose fitting. Make sure that the hose clamp does not contact the bottom of the fuel tank.
- C. Face the white paint mark on the fuel tank overflow hose to the right. Install the hose up to the wide portion of the pipe.


Throttle body (top, right, and left side view)

1




- 1. Throttle cable (accelerator cable)
- 2. Throttle cable (decelerator cable)
- 3. Intake air pressure sensor
- 4. Intake air pressure sensor hose
- 5. Fuel hose
- 6. Air filter case
- 7. Throttle body assembly
- 8. Cylinder head breather hose
- A. Install the intake air pressure sensor hose up to the bend in the hose fitting of the intake air pressure sensor.
- B. Make sure that the hose is not twisted.
- C. Install the intake air pressure sensor hose onto the throttle body assembly, making sure that the hose contacts the throttle body assembly.
- D. Forward
- E. Face the yellow paint mark on the cylinder head breather hose to the left. Install the cylinder head breather hose completely onto the hose fitting.
- F. Position the hose clamp 1–4 mm (0.04–0.16 in) from the end of the hose. Point the ends of the hose clamp to the left.
- G. Position the hose clamp 1–4 mm (0.04–0.16 in) from the end of the hose.
- H. 90°
- I. Position the ends of the hose clamp within the range shown in the illustration.
- J. Face the blue paint mark on the cylinder head breather hose upward. Install the cylinder head breather hose onto the air filter case, making sure that the hose contacts the case.

Radiator (front view)




- 1. Radiator
- 2. Radiator cap
- 3. Coolant reservoir hose
- 4. Radiator inlet hose
- 5. Coolant reservoir
- 6. Radiator outlet hose
- A. Connect the end of the coolant reservoir hose that is identified by the white paint mark to the radiator.
- B. Point the ends of the hose clamp toward the frame.

Radiator (left side view)



- 1. Coolant reservoir hose
- 2. Radiator inlet hose
- 3. Thermostat housing
- 4. Oil cooler inlet hose
- 5. Coolant reservoir breather hose
- 6. Coolant reservoir
- 7. Coolant reservoir cap
- 8. Radiator
- 9. Radiator cap
- 10. AC magneto lead
- 11. Horn lead
- 12. Frame
- A. Fasten the coolant reservoir hose to the radiator inlet hose with the plastic locking tie. Position the coolant reservoir hose directly under the radiator inlet hose. Face the buckle of the plastic locking tie inward with the end pointing downward.
- B. Align the white paint mark on the radiator inlet hose with the projection on the thermostat housing. Install the radiator inlet hose onto the thermostat housing, making sure that the hose contacts the projection on the housing.
- C. Point the ends of the hose clamp outward.
- D. Install the coolant reservoir hose onto the coolant reservoir cap, making sure that the hose contacts the cap.
- E. Face the catch of the holder forward.
- F. Position the clamp screw within the range shown in the illustration.
- G. 90°
- H. Outward
- I. Route the coolant reservoir breather hose to the outside of the oil cooler inlet hose.

Radiator (right side view)



- 1. Radiator inlet hose
- 2. Coolant reservoir hose
- 3. Radiator cap
- 4. Radiator
- 5. Coolant reservoir
- 6. Coolant reservoir breather hose
- 7. Radiator outlet hose
- 8. Oil cooler inlet hose
- A. Align the plastic locking tie with the white paint marks on the radiator inlet hose and coolant reservoir hose.
- B. Point the ends of the hose clamp in the direction shown in the illustration. Make sure that the ends of the hose clamp do not contact the coolant reservoir hose.
- C. Align the yellow paint mark on the radiator inlet hose with the projection on the radiator pipe. Install the radiator inlet hose onto the radiator pipe, making sure that the hose contacts the projection on the pipe.

PERIODIC CHECKS AND ADJUSTMENTS

PERIODIC MAINTENANCE	
PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM	
GENERAL MAINTENANCE AND LUBRICATION CHART	
CHECKING THE FUEL LINE	
CHECKING THE SPARK PLUGS	
ADJUSTING THE VALVE CLEARANCE	
CHECKING THE ENGINE IDLING SPEED	
SYNCHRONIZING THE THROTTLE BODIES	
CHECKING THE THROTTLE BODY JOINTS	
CHECKING THE CANISTER	
REPLACING THE AIR FILTER ELEMENT AND CLEANING THE	
CHECK HOSE	3-11
ADJUSTING THE CLUTCH LEVER FREE PLAY	
CHECKING THE BRAKE OPERATION	
ADJUSTING THE FRONT DISC BRAKE	
CHECKING THE FRONT BRAKE PADS	
ADJUSTING THE REAR DISC BRAKE	3-13
CHECKING THE REAR BRAKE PADS	3-14
CHECKING THE BRAKE HOSES	3-14
BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)	3-14
CHECKING THE BRAKE FLUID LEVEL	
CHECKING THE WHEELS	3-16
CHECKING THE TIRES	3-16
CHECKING THE WHEEL BEARINGS	3-17
CHECKING THE SWINGARM OPERATION	
LUBRICATING THE SWINGARM PIVOT	3-17
ADJUSTING THE DRIVE CHAIN SLACK	3-17
LUBRICATING THE DRIVE CHAIN	
CHECKING AND ADJUSTING THE STEERING HEAD	3-19
LUBRICATING THE STEERING HEAD	3-19
CHECKING THE CHASSIS FASTENERS	3-19
LUBRICATING THE BRAKE LEVER	
LUBRICATING THE PEDAL	
LUBRICATING THE CLUTCH LEVER	3-20
CHECKING THE SIDESTAND	
LUBRICATING THE SIDESTAND	
CHECKING THE SIDESTAND SWITCH	
CHECKING THE FRONT FORK	
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY	
ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY	
CHECKING THE CONNECTING ARM AND RELAY ARM	
CHECKING THE ENGINE OIL LEVEL	
CHANGING THE ENGINE OIL	3-21
MEASURING THE ENGINE OIL PRESSURE	
CHECKING THE COOLANT LEVEL	
CHECKING THE COOLING SYSTEM	
CHANGING THE COOLANT	
CHECKING THE FRONT BRAKE LIGHT SWITCH	3-26

ADJUSTING THE REAR BRAKE LIGHT SWITCH	3-26
CHECKING AND LUBRICATING THE CABLES	3-26
CHECKING THE THROTTLE GRIP OPERATION	3-27
CHECKING AND CHARGING THE BATTERY	3-28
CHECKING THE FUSES	3-28
REPLACING THE HEADLIGHT BULB	3-28
ADJUSTING THE HEADLIGHT BEAM	3-29
REPLACING THE LICENSE PLATE LIGHT BULB	3-29

PERIODIC MAINTENANCE

EAS30022

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM

- The annual checks must be performed every year, except if a kilometer-based maintenance, or for the UK, a mileage-based maintenance, is performed instead.
- From 50000 km (30000 mi), repeat the maintenance intervals starting from 10000 km (6000 mi).
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

				ODOMETER READING					ANNUAL
NO.		ITEM	JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
1	*	Fuel line	 Check fuel hoses for cracks or damage. 		\checkmark	\checkmark			
2	*	Spark plugs	Check condition.Clean and regap.		\checkmark		\checkmark		
			Replace.			\checkmark			
3	*	Valves	Check valve clearance.Adjust.	Every 40000 km (24000 mi)					
4	*	Fuel injection sys- tem	Adjust synchronization.	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark

EAS30615

GENERAL MAINTENANCE AND LUBRICATION CHART

- The annual checks must be performed every year, except if a kilometer-based maintenance, or for the UK, a mileage-based maintenance, is performed instead.
- From 50000 km (30000 mi), repeat the maintenance intervals starting from 10000 km (6000 mi).
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

		CHE	CHECK OR MAINTENANCE	ODOMETER READING					ANNUAL
NO.		O. ITEM	JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
1	*	Air filter element	Replace.						
2		Air filter check hose	Clean.	\checkmark	\checkmark	\checkmark	\checkmark		
3		Clutch	Check operation.Adjust.	\checkmark	\checkmark	\checkmark	\checkmark		
4	*	Front brake	Check operation, fluid level and vehicle for fluid leakage.	\checkmark	\checkmark	\checkmark	\checkmark		
			Replace brake pads.		١	Whenever wo	orn to the lim	it	
5	*	Rear brake	Check operation, fluid level and vehicle for fluid leakage.	\checkmark	\checkmark	\checkmark	\checkmark		
			Replace brake pads.		١	Whenever wo	orn to the lim	it	

PERIODIC MAINTENANCE

NC) .	ITEM	CHECK OR MAINTENANCE JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	ANNUAL CHECK
6	*	Brake hoses	 Check for cracks or damage. Check for correct routing and clamping. 		\checkmark		\checkmark	\checkmark	\checkmark
			Replace.			Every 4	4 years		
7	*	Brake fluid	Change.			Every	2 years		
8	*	Wheels	 Check runout and for dam- age. 		\checkmark	\checkmark	\checkmark	\checkmark	
9	*	Tires	 Check tread depth and for damage. Replace if necessary. Check air pressure. Correct if necessary. 		\checkmark	V	V	V	V
10	*	Wheel bearings	 Check bearings for loose- ness or damage. 		\checkmark	\checkmark	\checkmark		
11	*	Swingarm	Check operation and for ex- cessive play.		\checkmark	\checkmark	\checkmark	\checkmark	
		• · · · · gu · · ·	 Lubricate with lithium-soap- based grease. 		E	very 50000 l	km (30000 m	ii)	
12		Drive chain	 Check chain slack, alignment and condition. Adjust and lubricate chain with a special O-ring chain lu- bricant thoroughly. 	Every 800 km (500 mi) and after washing the vehicle, riding in the rain or					
13	*	Steering bearings	Check bearing play and steer- ing for roughness.	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	
13		Steering bearings	 Lubricate with lithium-soap- based grease. 		E	very 20000 l	km (12000 m	ii)	
14	*	Chassis fasteners	• Make sure that all nuts, bolts and screws are properly tight- ened.		\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
15		Brake lever pivot shaft	 Lubricate with silicone grease. 		\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
16		Brake pedal pivot shaft	 Lubricate with lithium-soap- based grease. 		\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
17		Clutch lever pivot shaft	 Lubricate with lithium-soap- based grease. 		\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
18		Shift pedal pivot shaft	 Lubricate with lithium-soap- based grease. 		\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
19		Sidestand	 Check operation. Lubricate with lithium-soap- based grease. 		\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
20	*	Sidestand switch	Check operation.	\checkmark	\checkmark	\checkmark			
21	*	Front fork	 Check operation and for oil leakage. 		\checkmark	\checkmark	\checkmark	\checkmark	
22	*	Shock absorber assembly	Check operation and shock absorber for oil leakage.		\checkmark	\checkmark			
		Rear suspension relay arm and	Check operation.		\checkmark	\checkmark	\checkmark	\checkmark	
23	*	connecting arm pivoting points	 Lubricate with lithium-soap- based grease. 			\checkmark		\checkmark	
24		Engine oil	 Change. Check oil level and vehicle for oil leakage. 	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
25		Engine oil filter cartridge	Replace.	\checkmark		\checkmark		\checkmark	
26	*	Cooling system	Check coolant level and vehi- cle for coolant leakage.		\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
			Change coolant.			Every	3 years		
27	*	Front and rear brake switches	Check operation.	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	

PERIODIC MAINTENANCE

NO.			CHECK OR MAINTENANCE		ANNUAL				
	0.	ITEM	JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
28	8	Moving parts and cables	Lubricate.		\checkmark	\checkmark	\checkmark		\checkmark
29	*	Throttle grip	 Check operation. Check throttle grip free play, and adjust if necessary. Lubricate cable and grip housing. 		V	V	V	V	\checkmark
30	*	Lights, signals and switches	Check operation.Adjust headlight beam.	\checkmark	\checkmark	\checkmark	\checkmark		\checkmark

TIP _____

• Air filter

- This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
- The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.

CHECKING THE FUEL LINE

The following procedure applies to all of the fuel overflow, and breather hoses.

- 1. Remove:
 - Seat

Refer to "GENERAL CHASSIS (1)" on page 4-1.


- Fuel tank top cover
- Fuel tank covers
- Fuel tank center cover Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Rear fuel tank bracket bolts "1"

TIP.

After removing the rear fuel tank bracket bolts, lift up the rear of the fuel tank.

ECA20070

When lifting up the fuel tank, be careful not to pull the fuel tank overflow hose and fuel tank breather hose.




- 2. Check:
 - Fuel hose "1"
 - Fuel tank overflow hose "2"
 - Fuel tank breather hose "3" Cracks/damage → Replace.

Loose connection \rightarrow Connect properly.

NOTICE

Make sure the fuel tank breather/overflow hose is routed correctly.



- 3. Install:
- Rear fuel tank bracket bolt



Rear fuel tank bracket bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

- 4. Install:
 - Fuel tank center cover
 - Fuel tank covers
 - Fuel tank top cover

Refer to "GENERAL CHASSIS (3)" on page 4-5.

• Seat Refer to "GENERAL CHASSIS (1)" on page 4-1.

EAS30620 CHECKING THE SPARK PLUGS

The following procedure applies to all of the spark plugs.

- 1. Remove:
- Seat


Refer to "GENERAL CHASSIS (1)" on page 4-1.

- Fuel tank top cover
- Fuel tank covers
- Fuel tank center cover
- Air scoops Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
- 2. Remove:
- Ignition coils
- Spark plugs
 ECA13320

NOTICE

Before removing the spark plugs, blow away any dirt accumulated in the spark plug wells with compressed air to prevent it from falling into the cylinders.

- 3. Check:
 - Spark plug type Incorrect → Change.



- 4. Check:
 - Electrode "1"
 - Damage/wear \rightarrow Replace the spark plug. • Insulator "2"

Abnormal color \rightarrow Replace the spark plug. Normal color is medium-to-light tan.

5. Clean:


Spark plug

(with a spark plug cleaner or wire brush) 6. Measure:

 Spark plug gap "a" (with a wire thickness gauge) Out of specification → Regap.



Spark plug gap 0.8–0.9 mm (0.031–0.035 in)



- 7. Install:
- Spark plugs
- Ignition coils

Spark plug 13 Nm (1.3 m⋅kgf, 9.4 ft⋅lbf)

TIP

Before installing the spark plug, clean the spark plug and gasket surface.

- 8. Install:
 - Fuel tank Refer to "FUEL TANK" on page 7-1.
 - Air scoops
 - Fuel tank center cover
 - Fuel tank covers
 - Fuel tank top cover

Refer to "GENERAL CHASSIS (3)" on page 4-5.

Seat

Refer to "GENERAL CHASSIS (1)" on page 4-1.

EAS30622


ADJUSTING THE VALVE CLEARANCE

The following procedure applies to all of the valves.

TIP .

• Valve clearance adjustment should be made on a cold engine, at room temperature.


- When the valve clearance is to be measured or adjusted, the piston must be at top dead center (TDC) on the compression stroke.
- 1. Drain:
 - Coolant Refer to "CHANGING THE COOLANT" on page 3-24.
- 2. Remove:
 - Seat Befer to "GE
 - Refer to "GENERAL CHASSIS (1)" on page 4-1.
 - Fuel tank top cover
 - Fuel tank covers
 - Fuel tank center cover
 - Air scoop
 - Refer to "GENERAL CHASSIS (3)" on page 4-5.
 - Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
 - Radiator
 - Radiator inlet hose Refer to "RADIATOR" on page 6-1.
 - Clutch cable guide
 - Refer to "ENGINE REMOVAL" on page 5-3.
- 3. Remove:
 - Ignition coils
 - Spark plugs
 - Cylinder head cover
 - Cylinder head cover gasket Refer to "CAMSHAFTS" on page 5-11.
- 4. Remove:
 - Timing mark accessing bolt "1"
 - Crankshaft end cover "2"



- 5. Measure:
 - Valve clearance Out of specification → Adjust.




- a. Turn the crankshaft counterclockwise.
- b. When piston #1 is at TDC on the compression stroke, align the TDC mark "a" on the generator rotor with the slot "b" in the generator rotor cover.



c. Measure the valve clearance with a thickness gauge "1".






TIP


- If the valve clearance is incorrect, record the measured reading.
- Measure the valve clearance in the following sequence.

Valve clearance measuring sequence Cylinder #1 \rightarrow #2



A. Front

 d. To measure the valve clearances of cylinder #2 turn the crankshaft 270° counterclockwise.




- B. Degrees that the crankshaft is turned counterclockwise
- C. Cylinder
- D. Combustion cycle

- 6. Remove:
- Camshaft

TIP ___

- Refer to "CHANGING THE COOLANT" on page 3-24.
- When removing the timing chain and camshafts, fasten the timing chain with a wire to retrieve it if it falls into the crankcase.
- 7. Adjust:
 - Valve clearance
- *****
- a. Remove the valve lifter "1" and the valve pad "2" with a valve lapper "3".






Valve lapper 90890-04101 Valve lapping tool YM-A8998

TIP_

- Cover the timing chain opening with a rag to prevent the valve pad from falling into the crankcase.
- Make a note of the position of each valve lifter "1" and valve pad "2" so that they can be installed in the correct place.



b. Calculate the difference between the specified valve clearance and the measured valve clearance.

Example:

Specified valve clearance = 0.11-0.20 mm (0.0043-0.0079 in)

Measured valve clearance = 0.25 mm(0.0098 in)


0.25 mm (0.0098 in)–0.20 mm (0.0079 in) = 0.05 mm (0.0020 in)

c. Check the thickness of the current valve pad.

The thickness "a" of each valve pad is marked in hundredths of millimeters on the side that touches the valve lifter.

Example:

If the valve pad is marked "158", the pad thickness is 1.58 mm (0.0622 in).



d. Calculate the sum of the values obtained in steps (b) and (c) to determine the required valve pad thickness and the valve pad number.

Example:

1.58 mm (0.0622 in) + 0.05 mm (0.0020 in) = 1.63 mm (0.0641 in)

The valve pad number is 163.

e. Round off the valve pad number according to the following table, and then select the suitable valve pad.

Last digit	Rounded value
0, 1, 2	0
3, 4, 5, 6	5
7, 8, 9	10

TIP ____

Refer to the following table for the available valve pads.


Valve pad range	No. 150–240
Valve pad thickness	1.50–2.40 mm (0.0590–0.0944 in)
Available valve pads	25 thicknesses in 0.05 mm (0.0020 in) incre- ments

Example: Valve pad number = 163 Rounded value = 165

- New valve pad number = 165
- f. Install the new valve pad "1" and the valve lifter "2".

TIP ____

- Lubricate the valve pad with molybdenum disulfide oil.
- Lubricate the valve lifter with engine oil.
- Install the valve lifter and the valve pad in the correct place.
- The valve lifter must turn smoothly when rotated by hand.



g. Install the exhaust and intake camshafts, timing chain and camshaft caps.



Exhaust camshaft cap bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf) Intake camshaft cap bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

TIP .

- Refer to "CAMSHAFTS" on page 5-11.
- Lubricate the camshaft lobes and camshaft journals with molybdenum disulfide oil.
- First, install the exhaust camshaft.
- Align the camshafts sprocket marks with the cylinder head edge.
- Turn the crankshaft counterclockwise several full turns to seat the parts.

h. Measure the valve clearance again.

i. If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.

8. Install:

All removed parts

TIP_

For installation, reverse the removal procedure.

CHECKING THE ENGINE IDLING SPEED

Prior to checking the engine idling speed, the throttle body synchronization should be adjusted properly, the air filter element should be clean, and the engine should have adequate compression.

- 1. Start the engine and let it warm up for several minutes.
- 2. Check:
 - Engine idling speed

Out of specification \rightarrow Go to next step.

Engine idling speed 1250–1450 r/min

- 3. Check:
 - ISC (idle speed control) learning value "00" or "01" → Check the intake system.
 "02" → Clean the ISC (idle speed control) valve.

Refer to "CLEANING THE ISC (IDLE SPEED CONTROL) VALVE" on page 7-10.

 a. Connect the Yamaha diagnostic tool.
 Use the diagnostic code number "67".
 Refer to "SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE" on page 9-5.



Yamaha diagnostic tool 90890-03250

b. Check the ISC (idle speed control) leaning value.

EAS30797 SYNCHRONIZING THE THROTTLE BODIES TIP

Before synchronizing the throttle bodies, check the following items:

- Valve clearance
- Spark plugs
- Air filter element
- Throttle body joints
- Fuel hose
- Exhaust system
- · Cylinder head breather hose
- Vacuum hoses

Checking the throttle body synchronization

1. Stand the vehicle on a level surface.

TIP

Place the vehicle on a suitable stand.

- 2. Remove:
- Seat

Refer to "GENERAL CHASSIS (1)" on page 4-1.

- Fuel tank top cover
- Fuel tank covers
- Fuel tank center cover
- Air scoops
- Outer side covers
- Inner side covers Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Fuel tank

Refer to "FUEL TANK" on page 7-1.


- 3. Disconnect:
 - Intake air pressure sensor hose
 - Cap

Refer to "THROTTLE BODIES" on page 7-7. 4. Install:

- Hose "1" (Parts No.: 5JW-24311-00)
- 3-way joint "2" (Parts No.: 90413-05014)

- Vacuum gauge hose #1 "3"
- Vacuum gauge hose #2 "4"
- Intake air pressure sensor hose "5"
- Vacuum gauge "6"

Vacuum gauge 90890-03094 Vacuummate YU-44456



- A. Throttle body #1
- B. Throttle body #2
- 5. Install:
- Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
- 6. Check:
 - Throttle body synchronization
- a. Start the engine, warm it up for several minutes, and then let it run at the specified engine idling speed.

Engine idling speed 1250–1450 r/min

b. Check the vacuum pressure.



The difference in vacuum pressure between the throttle bodies should not exceed 1.33 kPa (10 mmHg). If out of specification \rightarrow Adjust the throttle body synchronization.

Adjusting the throttle body synchronization

- 1. Adjust:
 - Throttle body synchronization
- *****
- a. Start the engine, warm it up for several minutes, and then let it run at the specified engine idling speed.




b. With throttle body #1 as standard, adjust throttle body #2 using the air screw "1".

TIP _

- Turn the bypass air screw using the carburetor angle driver.
- After each step, rev the engine two or three times, each time for less than a second, and check the synchronization again.
- If a bypass air screw was removed, turn the screw in fully and be sure to synchronize the throttle bodies.
- If the throttle body synchronization can not be adjusted using the bypass air screw, clean or replace the throttle bodies.
- The difference in vacuum pressure between the throttle bodies should not exceed 1.33 kPa (10 mmHg).



Carburetor angle driver 2 90890-03173



- A. Throttle body #1
- B. Throttle body #2

- 2. Stop the engine and remove the measuring equipment.
- 3. Connect:
 - Intake air pressure sensor hose
 - Cap
- Refer to "THROTTLE BODIES" on page 7-7. 4. Install:
- Fuel tank
 Befor to "EUEL
- Refer to "FUEL TANK" on page 7-1.
- Inner side covers
- Outer side covers
- Air scoops
- Fuel tank center cover
- Fuel tank covers
- Fuel tank top cover
- Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Seat

Refer to "GENERAL CHASSIS (1)" on page 4-1.

- 5. Adjust:
 - Throttle grip free play Refer to "CHECKING THE THROTTLE GRIP OPERATION" on page 3-27.

Throttle grip free play 3.0–5.0 mm (0.12–0.20 in)

CHECKING THE THROTTLE BODY JOINTS

- 1. Remove:
 - Seat Refer to "GENERAL CHASSIS (1)" on page 4-1.
 - Fuel tank top cover
 - Fuel tank covers
 - Fuel tank center cover
 - Outer side covers
 - Inner side covers Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
- 2. Disconnect:
- Intake air pressure sensor hose Refer to "THROTTLE BODIES" on page 7-7.
- 3. Remove:
 - Throttle bodies Refer to "THROTTLE BODIES" on page 7-7.
- 4. Check:
- Throttle body joints Cracks/damage → Replace.
- 5. Install:
 - Throttle bodies Refer to "THROTTLE BODIES" on page 7-7.
- 6. Connect:
 - Intake air pressure sensor hose Refer to "THROTTLE BODIES" on page 7-7.
- 7. Install:
 - Fuel tank Refer to "FUEL TANK" on page 7-1.
 - Inner side covers
 - Outer side covers
 - Fuel tank center cover
 - Fuel tank center cove
 Fuel tank covers
 - Fuel tank top cover Refer to "GENERAL CHASSIS (3)" on page 4-5.
 - Seat Refer to "GENERAL CHASSIS (1)" on page 4-1.

EAS30626 CHECKING THE CANISTER


- 1. Remove:
 - Fuel tank Refer to "FUEL TANK" on page 7-1.
- 2. Check:
- Canister
- Canister purge hoses
- Fuel tank breather hoses

- Canister breather hose Cracks/damage→ Replace.
- 3. Install:
 - Fuel tank Refer to "FUEL TANK" on page 7-1.

REPLACING THE AIR FILTER ELEMENT AND CLEANING THE CHECK HOSE

TIP_


There is an air filter check hose "1" at the bottom of the air filter case. If dust and/or water collects in this hose, clean the air filter check hose and replace the air filter element.




- 1. Remove:
 - Seat

Refer to "GENERAL CHASSIS (1)" on page 4-1.

- Fuel tank top cover
- Fuel tank covers
- Fuel tank center cover
- Outer side cover (left)
- Inner side cover (left)
- Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Fuel tank Refer to "FUEL TANK" on page 7-1.
- 2. Remove:
 - Air duct bracket "1" Refer to "GENERAL CHASSIS (4)" on page 4-7.



- 3. Remove:
- Air filter element "1"



- 4. Check:
 - Air filter element
 Damage → Replace.

TIP

- Replace the air filter element every 40000 km (24000 mi) of operation.
- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.

5. Install:

- Air filter element
- Air duct bracket



Air filter element screw 1.6 Nm (0.16 m·kgf, 1.2 ft·lbf) Air duct bracket screw 1.6 Nm (0.16 m·kgf, 1.2 ft·lbf)

ECA14401


Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect carburetor synchronization, leading to poor engine performance and possible overheating.

- 6. Install:
 - Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
 - Inner side cover (left)
 - Outer side cover (left)
 - Fuel tank center cover
 - Fuel tank covers
 - Fuel tank top cover Refer to "GENERAL CHASSIS (3)" on page 4-5.
 - Seat Refer to "GENERAL CHASSIS (1)" on page 4-1.

ADJUSTING THE CLUTCH LEVER FREE PLAY

- 1. Check:
 - Clutch lever free play "a" Out of specification → Adjust.
 - Clutch lever free play






- 2. Adjust:
 - Clutch lever free play

Handlebar side

a. Turn the adjusting bolt "1" in direction "a" or "b" until the specified clutch lever free play is obtained.

Direction "a" Clutch lever free play is increased. Direction "b" Clutch lever free play is decreased.



TIP

If the specified clutch lever free play cannot be obtained on the handlebar side of the cable, use the adjusting nut on the engine side.


Engine side


a. Loosen the locknut "1".

b. Turn the adjusting nut "2" in direction "a" or "b" until the specified clutch lever free play is obtained.

Direction "a" Clutch lever free play is increased. Direction "b" Clutch lever free play is decreased.

c. Tighten the locknut "1".





EAS30801

CHECKING THE BRAKE OPERATION

- 1. Check:
 - Brake operation Brake not working properly → Check the brake system.
 Refer to "FRONT BRAKE" on page 4-29 and "REAR BRAKE" on page 4-43.

REAR E

TIP _

Drive on the dry road, operate the front and rear brakes separately and check to see if the brakes are operating properly.


ADJUSTING THE FRONT DISC BRAKE

- 1. Adjust:
- Brake lever position (distance "a" from the throttle grip to the brake lever)

TIP _

- While pushing the brake lever forward, turn the adjusting dial "1" until the brake lever is in the desired position.
- Be sure to align the setting on the adjusting dial with the arrow mark "2" on the brake lever holder.

Position #1 Distance "a" is the largest. Position #5 Distance "a" is the smallest.



WARNING

- After adjusting the brake lever position, make sure the pin on the brake lever holder is firmly inserted in the hole in the adjusting dial.
- A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce brake performance resulting in loss of control and possibly cause an accident. Therefore, check and if necessary, bleed the brake system.

ECA13490

NOTICE After adjusting the brake lever position,

make sure there is no brake drag.


EAS30633

CHECKING THE FRONT BRAKE PADS

The following procedure applies to all of the brake pads.

- 1. Operate the brake.
- 2. Check:
- Front brake pad

Wear indicators "a" almost touch the brake disc \rightarrow Replace the brake pads as a set. Refer to "FRONT BRAKE" on page 4-29.



ADJUSTING THE REAR DISC BRAKE

- 1. Adjust:
- Brake pedal position

- a. Loosen the locknut "1".
- b. Turn the adjusting nut "2" in direction "a" or "b" until the specified brake pedal position is obtained.

Direction "a" Brake pedal is raised. Direction "b" Brake pedal is lowered.

EWA13070

A WARNING

After adjusting the brake pedal position, check that the end of the adjusting bolt "c" is visible through the hole "d".

c. Tighten the locknut "1" to specification.



Rear brake pedal adjusting lock-


nut 18 Nm (1.8 m·kgf, 13 ft·lbf)

WARNING

A soft or spongy feeling in the brake pedal can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce braking performance.

ECA13510

After adjusting the brake pedal position, make sure there is no brake drag.



2. Adjust:

• Rear brake light switch Refer to "ADJUSTING THE REAR BRAKE LIGHT SWITCH" on page 3-26.


EAS30634

CHECKING THE REAR BRAKE PADS

The following procedure applies to all of the brake pads.

- 1. Operate the brake.
- 2. Check:
- Rear brake pad

Wear indicators "a" almost touch the brake disc \rightarrow Replace the brake pads as a set. Refer to "REAR BRAKE" on page 4-43.



CHECKING THE BRAKE HOSES

The following procedure applies to all of the brake hoses and brake hose holders.

- 1. Check:
- Brake hoses Cracks/damage/wear \rightarrow Replace.
- 2. Check:
- Brake hose holders
 - Loose \rightarrow Tighten the holder bolts.
- 3. Hold the vehicle upright and apply the brake several times.
- 4. Check:
 - Brake hose

Brake fluid leakage \rightarrow Replace the damaged hose.

Refer to "FRONT BRAKE" on page 4-29, "REAR BRAKE" on page 4-43 and "ABS (AN-TI-LOCK BRAKE SYSTEM)" on page 4-56.

BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)

Always bleed the brake system when the brake related parts are removed.

ECA18050

- Bleed the brake system in the following order.
- 1st step: Front brake calipers
- 2nd step: Rear brake caliper

- Bleed the ABS whenever:
- the system is disassembled.
- a brake hose is loosened, disconnected or replaced.
- the brake fluid level is very low.
- brake operation is faulty.


TIP

- Be careful not to spill any brake fluid or allow the brake master cylinder reservoir or brake fluid reservoir to overflow.
- When bleeding the ABS, make sure that there is always enough brake fluid before applying the brake. Ignoring this precaution could allow air to enter the ABS, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the brake fluid settle for a few hours.
- Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.

1. Bleed:

• ABS

- a. Fill the brake master cylinder reservoir or brake fluid reservoir to the proper level with the specified brake fluid.
- b. Install the diaphragm (brake master cylinder reservoir or brake fluid reservoir).
- c. Connect a clear plastic hose "1" tightly to the bleed screw "2".



- A. Front brake caliper
- B. Rear brake caliper
- d. Place the other end of the hose into a container.
- e. Slowly apply the brake several times.
- f. Fully squeeze the brake lever or fully depress the brake pedal and hold it in position.
- a. Loosen the bleed screw.

TIP_

Loosening the bleed screw will release the pressure and cause the brake lever to contact the throttle grip or the brake pedal to fully extend.

- h. Tighten the bleed screw and then release the brake lever or brake pedal.
- i. Repeat steps (e) to (h) until all of the air bubbles have disappeared from the brake fluid in the plastic hose.
- j. Check the operation of the hydraulic unit. **Refer to "HYDRAULIC UNIT OPERATION** TESTS" on page 4-60.

ECA18060 NOTICE

Make sure that the main switch is turned to "OFF" before checking the operation of the hydraulic unit.

- k. After operating the ABS, repeat steps (e) to (i), and then fill the brake master cylinder reservoir or brake fluid reservoir to the proper level with the specified brake fluid.
- I. Tighten the bleed screw to specification.



Brake caliper bleed screw 5 Nm (0.5 m·kgf, 3.6 ft·lbf)

m. Fill the brake master cylinder reservoir or brake fluid reservoir to the proper level with the specified brake fluid. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.

After bleeding the hydraulic brake system, check the brake operation.

......


EAS3063

- CHECKING THE BRAKE FLUID LEVEL
- 1. Stand the vehicle on a level surface.

TIP

- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.
- 2. Check:
 - Brake fluid level Below the minimum level mark "a" \rightarrow Add the specified brake fluid to the proper level.

Specified brake fluid DOT 4



- A. Front brake
- B. Rear brake

EWA13090 WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

TIP.

In order to ensure a correct reading of the brake fluid level, make sure the top of the brake fluid reservoir is horizontal.

EAS30638

CHECKING THE WHEELS

The following procedure applies to both of the wheels.

- 1. Check:
- Wheel
 - Damage/out-of-round \rightarrow Replace.

EWA13260

Never attempt to make any repairs to the wheel.


TIP.

After a tire or wheel has been changed or replaced, always balance the wheel.


CHECKING THE TIRES

The following procedure applies to both of the tires.

- 1. Check:
- Tire pressure Out of specification → Regulate.




- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding speed.
- Operation of an overloaded vehicle could cause tire damage, an accident or an injury. NEVER OVERLOAD THE VEHICLE.



- 2. Check:
- Tire surfaces Damage/wear → Replace the tire.

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.



- 3
- 1. Tire tread depth
- 2. Side wall
- 3. Wear indicator

Wear limit (front) 1.6 mm (0.06 in) Wear limit (rear) 1.6 mm (0.06 in)

WARNING

After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this vehicle.

Front tire Size

Rear tire

120/70 R17M/C (58V) Manufacturer/model PIRELLI/PHANTOM SPORTS-COMP

Size 180/55 R17M/C (73V) Manufacturer/model PIRELLI/PHANTOM SPORTS-COMP


WARNING

New tires have a relatively low grip on the road surface until they have been slightly worn. Therefore, approximately 100 km should be traveled at normal speed before any high-speed riding is done.

TIP .

For tires with a direction of rotation mark "1":

Install the tire with the mark pointing in the direction of wheel rotation.



CHECKING THE WHEEL BEARINGS

The following procedure applies to all of the wheel bearings.

- 1. Check:
 - Wheel bearings Refer to "CHECKING THE FRONT WHEEL" on page 4-14 and "CHECKING THE REAR WHEEL" on page 4-24.

CHECKING THE SWINGARM OPERATION

- 1. Check:
 - Swingarm operation Swingarm not working properly → Check the swingarm.
 - Refer to "SWINGARM" on page 4-88.
- 2. Check:
- Swingarm excessive play Refer to "SWINGARM" on page 4-88.

LUBRICATING THE SWINGARM PIVOT

- 1. Lubricate:
- Bearing
- Spacer



Recommended lubricant Lithium-soap-based grease

Refer to "INSTALLING THE SWINGARM" on page 4-91.

ADJUSTING THE DRIVE CHAIN SLACK

NOTICE

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.

1. Stand the vehicle on a level surface.

WARNING

Securely support the vehicle so that there is no danger of it falling over.


TIP _

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- 2. Shift the transmission into the neutral position.
- 3. Check:
- Drive chain slack
 Out of specification → Adjust.

TIP ___

Measure the distance "a" between the rib end "b" on the drive chain guide "1" and the center of the drive chain "2".






Drive chain slack 51.0–56.0 mm (2.01–2.20 in) Limit 58.0 mm (2.28 in)

ECA20870

Improper drive chain slack will overload the engine as well as other vital parts of the motorcycle and can lead to chain slippage or breakage. If the drive chain slack is more than the specified limit, the chain can damage the frame, swingarm, and other parts. To prevent this from occurring, keep the drive chain slack within the specified limits.

4. Loosen:

Wheel axle nut "1"




- 5. Adjust:
- Drive chain slack
- *****
- a. Loosen both of the drive chain puller locknuts "1".
- b. Turn both of the drive chain puller adjusting nuts "2" in direction "a" or "b" until the specified drive chain slack is obtained.

Direction "a" Drive chain is tightened. Direction "b" Drive chain is loosened.

TIP _

- To maintain the proper wheel alignment, adjust both sides evenly.
- There should be no clearance between the swingarm end plate and the adjusting nuts.



c. Tighten the wheel axle nut to specification.

Wheel axle nut 105 Nm (10.5 m·kgf, 76 ft·lbf)

d. Tighten the drive chain puller locknuts to specification.

Drive chain puller locknut 16 Nm (1.6 m·kgf, 12 ft·lbf)

......

LUBRICATING THE DRIVE CHAIN

The drive chain consists of many interacting parts. If the drive chain is not maintained properly, it will wear out quickly. Therefore, the drive chain should be serviced, especially when the vehicle is used in dusty areas.

This vehicle has a drive chain with small rubber O-rings between each side plate. Steam cleaning, high-pressure washing, certain solvents, and the use of a coarse brush can damage these O-rings. Therefore, use only kerosene to clean the drive chain. Wipe the drive chain dry and thoroughly lubricate it with engine oil or chain lubricant that is suitable for O-ring chains. Do not use any other lubricants on the drive chain since they may contain solvents that could damage the O-rings.

Recommended lubricant Chain lubricant suitable for Oring chains

EAS30645

CHECKING AND ADJUSTING THE STEERING HEAD

1. Stand the vehicle on a level surface.

WARNING

Securely support the vehicle so that there is no danger of it falling over.


TIP _

Place the vehicle on a suitable stand so that the front wheel is elevated.

- 2. Check:
 - Steering head Grasp the bottom of the front fork legs and gently rock the front fork.
 Blinding/looseness → Adjust the steering head.
- 3. Remove:
- Upper bracket
- Refer to "FRONT FORK" on page 4-70. 4. Adjust:
 - Steering head
- *****
- a. Loosen the cap nut "1", and then tighten it to specification with a steering nut wrench "2".

TIP _

- Set the torque wrench at a right angle to the steering nut wrench.
- Move the steering to the left and right a couple of times to check that it moves smoothly.



b. Loosen the cap nut completely, then tighten it to specification.

Do not overtighten the cap nut.



Cap nut (final tightening torque) 18 Nm (1.8 m·kgf, 13 ft·lbf)

c. Check the steering head for looseness or binding by turning the front fork all the way in both directions. If any binding is felt, remove the lower bracket and check the upper and lower bearings.

Refer to "STEERING HEAD" on page 4-80.

- 5. Install:
- Upper bracket
 - Refer to "FRONT FORK" on page 4-70.

LUBRICATING THE STEERING HEAD

- 1. Lubricate:
 - Upper bearing
 - Lower bearing
- Bearing cover

properly tightened.

Lower bearing dust seal



EAS31802

CHECKING THE CHASSIS FASTENERS Make sure that all nuts, bolts, and screws are Refer to "CHASSIS TIGHTENING TORQUES" on page 2-20.

LUBRICATING THE BRAKE LEVER

Lubricate the pivoting point and metal-to-metal moving parts of the lever.



Recommended lubricant Silicone grease

LUBRICATING THE PEDAL

Lubricate the pivoting point and metal-to-metal moving parts of the pedal.



Recommended lubricant Lithium-soap-based grease

LUBRICATING THE CLUTCH LEVER

Lubricate the pivoting point and metal-to-metal moving parts of the lever.



Recommended lubricant Lithium-soap-based grease

EAS30650

CHECKING THE SIDESTAND

- 1. Check:
 - Sidestand operation

Check that the sidestand moves smoothly. Rough movement \rightarrow Repair or replace.

LUBRICATING THE SIDESTAND

Lubricate the pivoting point, metal-to-metal moving parts and spring contact point of the sidestand.



Recommended lubricant Lithium-soap-based grease

CHECKING THE SIDESTAND SWITCH

Refer to "CHECKING THE SWITCHES" on page 8-153.

CHECKING THE FRONT FORK


1. Stand the vehicle on a level surface.

WARNING

Securely support the vehicle so that there is no danger of it falling over.

- 2. Check:
 - Inner tube Damage/scratches \rightarrow Replace.
 - Front fork leg
 Oil leaks between inner tube and outer tube
 → Replace the oil seal.
- 3. Hold the vehicle upright and apply the front brake.
- 4. Check:
 - Front fork operation Push down hard on the handlebar several times and check if the front fork rebounds smoothly.

Rough movement \rightarrow Repair. Refer to "FRONT FORK" on page 4-70.



CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

Refer to "CHECKING THE REAR SHOCK AB-SORBER ASSEMBLY" on page 4-86.

ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY

Securely support the vehicle so that there is no danger of it falling over.


Spring preload


NOTICE

Never go beyond the maximum or minimum adjustment positions.

- 1. Adjust:
- Spring preload
- a. Adjust the spring preload with the special wrench "1" and extension bar "2" included in the owner's tool kit.
- b. Turn the adjusting ring "3" in direction "a" or "b".
- c. Align the desired position on the adjusting ring with the stopper "4".

Direction "a" Spring preload is increased (suspension is harder). **Direction "b"** Spring preload is decreased (suspension is softer).





CHECKING THE CONNECTING ARM AND **RELAY ARM**

Refer to "CHECKING THE RELAY ARM" on page 4-86 and "CHECKING THE CONNECT-ING ARM" on page 4-90.

EAS30656

CHECKING THE ENGINE OIL LEVEL

1. Stand the vehicle on a level surface. TIP


- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Check:
- Engine oil level

The engine oil level should be between the minimum level mark "a" and maximum level mark "b".

Below the minimum level mark \rightarrow Add the recommended engine oil to the proper level.

TIP_

Before checking the engine oil level, wait a few minutes until the oil has settled.



ECA13361 NOTICE

- Engine oil also lubricates the clutch and the wrong oil types or additives could cause clutch slippage. Therefore, do not add any chemical additives or use engine oils with a grade of "CD" or higher and do not use oils labeled "ENERGY CONSERVING II".
- Do not allow foreign materials to enter the crankcase.
- 4. Start the engine, warm it up for several minutes, and then turn it off.
- 5. Check the engine oil level again.


TIP


Before checking the engine oil level, wait a few minutes until the oil has settled.

EAS30657

CHANGING THE ENGINE OIL

- 1. Start the engine, warm it up for several minutes, and then turn it off.
- 2. Place a container under the engine oil drain bolt.
- 3. Remove:
 - Engine oil filler cap "1"
 - Engine oil drain bolt "2" (along with the gasket "3")






- 4. Drain:
- Engine oil (completely from the oil pan)
- 5. If the oil filter cartridge is also to be replaced, perform the following procedure.
- ******
- a. Remove the oil filter cartridge "1" with an oil filter wrench "2".




Oil filter wrench 90890-01426 Oil filter wrench YU-38411



b. Lubricate the O-ring "3" of the new oil filter cartridge with a thin coat of engine oil.

ECA13390

Make sure the O-ring "3" is positioned correctly in the groove of the oil filter cartridge.




c. Tighten the new oil filter cartridge to specification with an oil filter wrench.


Oil filter cartridge 17 Nm (1.7 m·kgf, 12 ft·lbf)

- 6. Install:
 - Engine oil drain bolt

(along with the gasket New)



- 7. Fill:
 - Oil pan (with the specified amount of the recommended engine oil)



- 8. Install:
 - Engine oil filler cap (along with the O-ring New)
- 9. Start the engine, warm it up for several minutes, and then turn it off.
- 10.Check:
 - Engine

(for engine oil leaks)


- 11.Check:
 - Engine oil level
 - Refer to "CHECKING THE ENGINE OIL LEVEL" on page 3-21.

EAS30810 MEASURING THE ENGINE OIL PRESSURE

1. Stand the vehicle on a level surface.

- Place the vehicle on the suitable stand.
- Make sure that the vehicle is upright.
- 2. Check:
- Engine oil level

Below the minimum level mark "a" \rightarrow Add the recommended engine oil to the proper level.



3. Start the engine, warm it up for several minutes, and then turn it off.


NOTICE

When the engine is cold, the engine oil will have a higher viscosity, causing the engine oil pressure to increase. Therefore, be sure to measure the engine oil pressure after warming up the engine.

- 4. Remove:
- Main gallery bolt "1"

WARNING

The engine, muffler and engine oil are extremely hot.




- 5. Install:
- Oil pressure gauge "1"
- Adapter "2"



Pressure gauge 90890-03153

Pressure gauge YU-03153 Oil pressure adapter H 90890-03139



- 6. Measure:
 - Engine oil pressure (at the following conditions)



Oil pressure 280.0 kPa/5000 r/min at 100 °C (40.6 psi/5000 r/min at 212 °F)

Out of specification \rightarrow Check.

Engine oil pressure	Possible causes
Below specification	 Faulty oil pump Clogged oil filter Leaking oil passage Broken or damaged oil seal
Above specification	 Leaking oil passage Faulty oil filter Oil viscosity too high

- 7. Install:
 - Main gallery bolt
 - O-ring New



Main gallery bolt 8 Nm (0.8 m·kgf, 5.8 ft·lbf)

TIP .

Lubricate the O-ring with a thin coat of lithiumsoap-based grease.

EAS30811

CHECKING THE COOLANT LEVEL

1. Stand the vehicle on a level surface.

TIP


- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.

2. Check:

Coolant level

The coolant level should be between the minimum level mark "a" and maximum level mark "b".

Below the minimum level mark \rightarrow Add the recommended coolant to the proper level.



ECA13470 **NOTICE**

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.
- 3. Start the engine, warm it up for several minutes, and then turn it off.
- 4. Check:
 - Coolant level


TIP _

Before checking the coolant level, wait a few minutes until it settles.

CHECKING THE COOLING SYSTEM

- 1. Check:
- Radiator "1"
- Radiator inlet hose "2"
- Radiator outlet hose "3"
- Oil cooler "4"
- Oil cooler inlet hose "5"
- Oil cooler outlet hose "6"
- Water jacket joint "7"
- Water jacket joint inlet hose "8"
- Thermostat cover "9"
- Thermostat "10"
- Water pump inlet pipe "11"
- Water pump outlet pipe "12" Cracks/damage → Replace.

Refer to "RADIATOR" on page 6-1, "OIL COOLER" on page 6-5, "THERMOSTAT" on page 6-7 and "WATER PUMP" on page 6-9.




CHANGING THE COOLANT

- 1. Remove:
- Radiator cap bolt "1"
- Radiator cap "2"


WARNING

A hot radiator is under pressure. Therefore, do not remove the radiator cap when the engine is hot. Scalding hot fluid and steam may be blown out, which could cause serious injury. When the engine has cooled, open the radiator cap as follows:


Place a thick rag or a towel over the radiator cap and slowly turn the radiator cap counterclockwise toward the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the radiator cap and turn it counterclockwise to remove.




- 2. Remove:
- Coolant reservoir cap "1"




- 3. Remove:
 - Coolant reservoir bolt "1"
 - Coolant reservoir quick fastener "2"
 - Coolant reservoir cover "3"
 - Coolant reservoir "4"
 - Collar "5"



- 4. Drain:
 - Coolant (from the coolant reservoir)
- 5. Remove:
 - Coolant drain bolt "1"
 - Copper washer "2"



- 6. Drain:
 - Coolant (from the engine and radiator)
 - (from the engine and
- 7. Install:Coolant drain bolt
 - Copper washer New



- 8. Install:
- Collar
- Coolant reservoir
- Coolant reservoir cover
- Coolant reservoir quick fastener
- Coolant reservoir bolt

Coolant reservoir bolt 5 Nm (0.5 m·kgf, 3.6 ft·lbf)

9. Fill:

Cooling system

(with the specified amount of the recommended coolant)

Handling notes for coolant Coolant is potentially harmful and should be handled with special care.

WARNING

- If coolant splashes in your eyes, thoroughly wash them with water and consult a doctor.
- If coolant splashes on your clothes, quickly wash it away with water and then with soap and water.
- If coolant is swallowed, induce vomiting and get immediate medical attention.

ECA13481 **NOTICE**

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant, check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.
- If coolant comes into contact with painted surfaces, immediately wash them with water.

• Do not mix different types of antifreeze.

10.Install:

- Radiator cap
- Radiator cap bolt




Radiator cap bolt

1.0 Nm (0.10 m·kgf, 0.72 ft·lbf)

- 11.Fill:
 - Coolant reservoir

(with the recommended coolant to the maximum level mark "a")



12.Install:

- Coolant reservoir cap
- 13.Start the engine, warm it up for several minutes, and then turn it off.
- 14.Check:
- Coolant level
 Refer to "CHECKING THE COOLANT LEV-
 - EL" on page 3-23.

TIP _

Before checking the coolant level, wait a few minutes until the coolant has settled.

CHECKING THE FRONT BRAKE LIGHT SWITCH

Refer to "CHECKING THE SWITCHES" on page 8-153.


ADJUSTING THE REAR BRAKE LIGHT SWITCH

TIP ___

The rear brake light switch is operated by movement of the brake pedal. The rear brake light switch is properly adjusted when the brake light comes on just before the braking effect starts.

- 1. Check:
- Rear brake light operation timing Incorrect → Adjust.
- 2. Adjust:
- Rear brake light operation timing
- ****
- a. Hold the main body "1" of the rear brake light switch so that it does not rotate and turn the adjusting nut "2" in direction "a" or "b" until the rear brake light comes on at the proper time.

Direction "a" Brake light comes on sooner. Direction "b" Brake light comes on later.



CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the inner and outer cables.

EWA13270

Damaged outer cable may cause the cable to corrode and interfere with its movement. Replace damaged outer cable and inner cables as soon as possible.

- 1. Check:
- Outer cable Damage \rightarrow Replace.
- 2. Check:
- Cable operation Rough movement → Lubricate.

Recommended lubricant Engine oil or a suitable cable lubricant

TIP_

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubricating device.

CHECKING THE THROTTLE GRIP OPERATION

- 1. Check:
- Throttle cables Damage/deterioration \rightarrow Replace.
- Throttle cable installation Incorrect \rightarrow Reinstall the throttle cables. Refer to "HANDLEBAR" on page 4-65.
- 2. Check:
 - Throttle grip movement Rough movement → Lubricate or replace the defective part(s).

Recommended lubricant Suitable cable lubricant


TIP_

With the engine stopped, turn the throttle grip slowly and release it. Make sure that the throttle grip turns smoothly and returns properly when released.

Repeat this check with the handlebar turned all the way to the left and right.

3. Check:
Throttle grip free play "a" Out of specification → Adjust.

> Throttle grip free play 3.0–5.0 mm (0.12–0.20 in)



4. Adjust:

• Throttle grip free play

TIP

Prior to adjusting the throttle grip free play, throttle body synchronization should be adjusted properly.

Throttle body side


- a. Loosen the locknut "1" on the accelerator cable.
- b. Turn the adjusting nut "2" in direction "a" or "b" until the specified throttle grip free play is obtained.


Direction "a"

Throttle grip free play is increased. Direction "b"

Throttle grip free play is decreased.

c. Tighten the locknut.






TIP

If the specified throttle grip free play cannot be obtained on the throttle body side of the cable, use the adjusting nut on the handlebar side.


Handlebar side

- a. Slide back the rubber cover "1".
- b. Loosen the locknut "2".
- c. Turn the adjusting nut "3" in direction "a" or "b" until the specified throttle grip free play is obtained.

Direction "a" Throttle grip free play is increased. Direction "b" Throttle grip free play is decreased.



d. Tighten the locknut.



e. Slide the rubber cover to its original position.

Make sure that the adjusting nut is covered completely by the rubber cover.

EAS30816

CHECKING AND CHARGING THE BATTERY Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158.


CHECKING THE FUSES

Refer to "CHECKING THE FUSES" on page 8-157.


EAS30665

REPLACING THE HEADLIGHT BULB


- 1. Remove:
 - Headlight lens unit bolt "1"
- Headlight lens unit "2"



- 2. Disconnect:
- Headlight coupler "3"
- 3. Remove:
- Headlight bulb cover "4"



- 4. Detach:
- Headlight bulb holder "5"
- 5. Remove:
- Headlight bulb "6"



WARNING

Since the headlight bulb gets extremely hot, keep flammable products and your hands away from the bulb until it has cooled down.

6. Install:

• Headlight bulb New Secure the new headlight bulb with the headlight bulb holder.

ECA13690

Avoid touching the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the life of the bulb and the luminous flux will be adversely

affected. If the headlight bulb gets soiled, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.

- 7. Attach:
- Headlight bulb holder
- 8. Install:
 - Headlight bulb cover
- 9. Connect:
- Headlight coupler
- 10.Install:
- Headlight lens unit




Headlight lens unit bolt 4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)

ADJUSTING THE HEADLIGHT BEAM


- 1. Adjust:
- Headlight beam (vertically)
- ******
- a. Turn the adjusting screw "1" in direction "a" or "b".

Direction "a" Headlight beam is raised. Direction "b" Headlight beam is lowered.




- 2. Adjust:
 - Headlight beam (horizontally)
- ***
- a. Turn the adjusting screw "1" in direction "a" or "b".

Direction "a" Headlight beam moves to the left. Direction "b" Headlight beam moves to the right.




EAS31831


- REPLACING THE LICENSE PLATE LIGHT BULB
- 1. Remove:
- Lower fender cover screws "1"
- Lower fender cover "2"




- 2. Remove:
- License plate bracket bolts "1"
- License plate bracket "2"



- 3. Remove:
- License plate nuts "1"
- License plate light



- 4. Remove:
 - License plate light bulb "1"



- 5. Install:
 - License plate light bulb New
- 6. Install:
 - License plate light
 - License plate nuts
 - License plate bracket
 - License plate bracket bolts
 - Lower fender cover
 - Lower fender cover screws

License plate nut 3.8 Nm (0.38 m·kgf, 2.8 ft·lbf) License plate bracket bolt 6 Nm (0.6 m·kgf, 4.3 ft·lbf) Lower fender cover screw 2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)


CHASSIS

GENERAL CHASSIS (1)	4-1
INSTALLING THE YAMAHA DIAGNOSTIC TOOL COUPLER	4-2
INSTALLING THE SEAT	
	4.0
GENERAL CHASSIS (2)	4-3
INSTALLING THE HEADLIGHT ASSEMBLY	4-4
GENERAL CHASSIS (3)	4-5
INSTALLING THE FUEL TANK COVERS	4-6
GENERAL CHASSIS (4)	4-7
INSTALLING THE AIR DUCT	4-8
GENERAL CHASSIS (5)	4-9
REMOVING THE ECU (engine control unit)	4-11
INSTALLING THE ECU (engine control unit)	4-11
INSTALLING THE ELECTRICAL COMPONENTS TRAYS	4-11
FRONT WHEEL	
REMOVING THE FRONT WHEEL	4-14
DISASSEMBLING THE FRONT WHEEL	
CHECKING THE FRONT WHEEL	4-14
MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR	
ROTOR	
ASSEMBLING THE FRONT WHEEL	
ADJUSTING THE FRONT WHEEL STATIC BALANCE	4-16
INSTALLING THE FRONT WHEEL (DISC BRAKE)	4-17
REAR WHEEL	4-20
REMOVING THE REAR WHEEL (DISC BRAKE)	4-24
DISASSEMBLING THE REAR WHEEL	4-24
CHECKING THE REAR WHEEL	4-24
CHECKING THE REAR WHEEL DRIVE HUB	
CHECKING AND REPLACING THE REAR WHEEL SPROCKET	4-25
MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR	
ROTOR	
ASSEMBLING THE REAR WHEEL	
ADJUSTING THE REAR WHEEL STATIC BALANCE	-
INSTALLING THE REAR WHEEL (REAR BRAKE DISC)	4-26

FRONT BRAKE	
INTRODUCTION	
CHECKING THE FRONT BRAKE DISCS	
REPLACING THE FRONT BRAKE PADS	
REMOVING THE FRONT BRAKE CALIPERS	
DISASSEMBLING THE FRONT BRAKE CALIPERS	
CHECKING THE FRONT BRAKE CALIPERS	
ASSEMBLING THE FRONT BRAKE CALIPERS	
INSTALLING THE FRONT BRAKE CALIPERS	
REMOVING THE FRONT BRAKE MASTER CYLINDER	
CHECKING THE FRONT BRAKE MASTER CYLINDER	
ASSEMBLING THE FRONT BRAKE MASTER CYLINDER	
INSTALLING THE FRONT BRAKE MASTER CYLINDER	
CHECKING THE REAR BRAKE DISC	
REPLACING THE REAR BRAKE PADS	
REMOVING THE REAR BRAKE CALIPER	
DISASSEMBLING THE REAR BRAKE CALIPER	
CHECKING THE REAR BRAKE CALIPER	
ASSEMBLING THE REAR BRAKE CALIPER	
INSTALLING THE REAR BRAKE CALIPER	
REMOVING THE REAR BRAKE MASTER CYLINDER	
CHECKING THE REAR BRAKE MASTER CYLINDER	
	4 - 4
ASSEMBLING THE REAR BRAKE MASTER CYLINDER	
INSTALLING THE REAR BRAKE MASTER CYLINDER	
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM) REMOVING THE HYDRAULIC UNIT ASSEMBLY	4-54 4-56 4-58
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM) REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY	4-54 4-56 4-58 4-58
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM) REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY INSTALLING THE HYDRAULIC UNIT ASSEMBLY	
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM) REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY INSTALLING THE HYDRAULIC UNIT ASSEMBLY HYDRAULIC UNIT OPERATION TESTS	
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM) REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY INSTALLING THE HYDRAULIC UNIT ASSEMBLY	
INSTALLING THE REAR BRAKE MASTER CYLINDER	
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM) REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY INSTALLING THE HYDRAULIC UNIT ASSEMBLY HYDRAULIC UNIT OPERATION TESTS CHECKING THE ABS WARNING LIGHT HANDLEBAR	4-54 4-56 4-58 4-58 4-58 4-58 4-60 4-64 4-64
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54 4-58 4-58 4-58 4-58 4-60 4-64 4-64
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM). REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY INSTALLING THE HYDRAULIC UNIT ASSEMBLY HYDRAULIC UNIT OPERATION TESTS. CHECKING THE ABS WARNING LIGHT HANDLEBAR REMOVING THE HANDLEBAR. CHECKING THE HANDLEBAR	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM). REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY INSTALLING THE HYDRAULIC UNIT ASSEMBLY HYDRAULIC UNIT OPERATION TESTS. CHECKING THE ABS WARNING LIGHT HANDLEBAR REMOVING THE HANDLEBAR. CHECKING THE HANDLEBAR	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67 4-67
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM). REMOVING THE HYDRAULIC UNIT ASSEMBLY CHECKING THE HYDRAULIC UNIT ASSEMBLY INSTALLING THE HYDRAULIC UNIT ASSEMBLY HYDRAULIC UNIT OPERATION TESTS. CHECKING THE ABS WARNING LIGHT HANDLEBAR REMOVING THE HANDLEBAR. CHECKING THE HANDLEBAR	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67 4-67 4-67
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67 4-67 4-67 4-70 4-74
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67 4-67 4-67 4-70 4-74
INSTALLING THE REAR BRAKE MASTER CYLINDER ABS (ANTI-LOCK BRAKE SYSTEM). REMOVING THE HYDRAULIC UNIT ASSEMBLY	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67 4-67 4-67 4-74 4-74 4-74
INSTALLING THE REAR BRAKE MASTER CYLINDER	4-54 4-58 4-58 4-58 4-58 4-58 4-60 4-64 4-64 4-65 4-67 4-67 4-67 4-67 4-70 4-74 4-74 4-74 4-75 4-75

STEERING HEAD REMOVING THE LOWER BRACKET CHECKING THE STEERING HEAD INSTALLING THE STEERING HEAD	4-82 4-82
REAR SHOCK ABSORBER ASSEMBLY HANDLING THE REAR SHOCK ABSORBER DISPOSING OF A REAR SHOCK ABSORBER REMOVING THE REAR SHOCK ABSORBER ASSEMBLY CHECKING THE REAR SHOCK ABSORBER ASSEMBLY CHECKING THE RELAY ARM INSTALLING THE RELAY ARM INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY	4-86 4-86 4-86 4-86 4-86 4-86
SWINGARM REMOVING THE SWINGARM CHECKING THE SWINGARM CHECKING THE CONNECTING ARM INSTALLING THE CONNECTING ARM INSTALLING THE SWINGARM	4-90 4-90 4-90 4-91
CHAIN DRIVE REMOVING THE DRIVE CHAIN REMOVING THE DRIVE SPROCKET CHECKING THE DRIVE CHAIN CHECKING THE DRIVE SPROCKET CHECKING THE REAR WHEEL SPROCKET CHECKING THE REAR WHEEL DRIVE HUB INSTALLING THE DRIVE SPROCKET INSTALLING THE DRIVE CHAIN	

EAS20026 **GENERAL CHASSIS (1)**




Positive battery lead

Battery band

Battery

6

7 8



1

1

1

Disconnect.


EAS31798 **INSTALLING THE YAMAHA DIAGNOSTIC TOOL COUPLER**

1. Install:

• Yamaha diagnostic tool coupler "1"

TIP_

Install the Yamaha diagnostic tool coupler onto the tab "a" on the battery cover.




EAS30125


- 1. Install:
- Seat "1"

TIP

Fit the slot "a" in the seat onto the projection "b" on the rider seat bracket as shown, push the rear of the seat down to lock it in place, and then remove the key.



GENERAL CHASSIS (2)



EAS31128 INSTALLING THE HEADLIGHT ASSEMBLY


- 1. Install:
 - Headlight assembly "1"




Headlight assembly bolt (M6 \times 16 mm) 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Headlight assembly bolt (M5 \times 12 mm) 4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)

TIP_

Fit the projections "a" on the headlight bracket into the grooves "b" in the headlight assembly.





EAS20156

EAS31105 INSTALLING THE FUEL TANK COVERS

The following procedure applies to both of the fuel tank covers.


- 1. Install:
- Fuel tank cover "1"




Fuel tank cover bolt 4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)


TIP_

Align the holes "a" in the fuel tank cover with the projections "b" on the fuel tank center cover, and fit the fuel tank cover into the slots "c" in the fuel tank center cover.



GENERAL CHASSIS (4)






Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Fuel tank center cover/Outer side cover (left)/In- ner side cover (left)		Refer to "GENERAL CHASSIS (3)" on page 4-5.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
1	Air duct bracket	1	
2	Air duct	1	
3	Air filter element	1	


EAS31797

- 1. Install:
- Air duct "1"


TIP_

- Align the tab "a" on the air duct between the projections "b" on the air duct bracket.
- Align the projection "c" on the air duct with the slot "d" in the seal "2".






GENERAL CHASSIS (5)



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Fuel tank center cover/Air scoops/Outer side covers/Inner side covers		Refer to "GENERAL CHASSIS (3)" on page 4-5.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Hydraulic unit assembly		Refer to "ABS (ANTI-LOCK BRAKE SYS- TEM)" on page 4-56.
1	Stator coil coupler	1	Disconnect.
2	Rectifier/regulator coupler	1	Disconnect.
3	Rectifier/regulator	1	
4	Turn signal/hazard relay	1	
5	Headlight relay	1	
6	Relay unit	1	
7	Fan motor relay	1	




REMOVING THE ECU (engine control unit)

- 1. Disconnect:
- ECU coupler "1"

TIP.

While pushing the portion "a" of the ECU coupler, move the lock lever "b" in the direction of the arrow shown to disconnect the coupler.




EAS31109

INSTALLING THE ECU (engine control unit) 1. Connect:

• ECU coupler "1"

TIP_

Connect the ECU coupler, and then push the lock lever "a" of the coupler in the direction of the arrow shown.



EAS31129

INSTALLING THE ELECTRICAL COMPONENTS TRAYS


- 1. Install:
 - Electrical components tray 2 "1"



Electrical components tray 2 nut 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Electrical components tray 2 bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

TIP.

Tighten the electrical components tray 2 nuts and bolt in the proper tightening sequence as shown.




- 2. Install:
 - Intake air pressure sensor "1"



Intake air pressure sensor bolt 4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)

TIP _


Make sure that the intake air pressure sensor contacts the frame.



FRONT WHEEL Removing the front wheel and brake discs 1 🔌 40 Nm (4.0 m·kgf, 29 ft·lbf) 🔌 7 Nm (0.7 m·kgf, 5.1 ft·lbf) 🔌 40 Nm (4.0 m·kgf, 29 ft·lbf) 🔀 7 Nm (0.7 m·kgf, 5.1 ft·lbf) ଶ 🔌 23 Nm (2.3 m·kgf, 17 ft·lbf) 🔀 18 Nm (1.8 m·kgf, 13 ft·lbf) 2 New 2 5 ത G ²⁰(5) 3 Ŕ \bigcirc -4 🔌 18 Nm (1.8 m·kgf, 13 ft·lbf) ľ T. 6 New 9 (5) 7 🔌 65 Nm (6.5 m·kgf, 47 ft·lbf) 6PA New (3) 9 Ū 8 🔌 8 Nm (0.8 m·kgf, 5.8 ft·lbf)

EAS20028

Order	Job/Parts to remove	Q'ty	Remarks
1	Front brake hose/lead holder	2	
2	Front reflector	2	
3	Front brake caliper	2	
4	Front wheel sensor	1	
5	Wheel axle pinch bolt	1	Loosen.
6	Front wheel axle	1	
7	Collar	2	
8	Front wheel	1	
9	Front brake disc	2	
10	Front wheel sensor rotor	1	



REMOVING THE FRONT WHEEL

NOTICE

- Keep any type of magnets (including magnetic pick-up tools, magnetic screwdrivers, etc.) away from the front wheel sensor or front wheel sensor rotor; otherwise, the sensor or rotor may be damaged, resulting in improper performance of the ABS system.
- Do not drop the front wheel sensor rotor or subject it to shocks.
- If any solvent gets on the front wheel sensor rotor, wipe it off immediately.
- 1. Stand the vehicle on a level surface.

WARNING

Securely support the vehicle so that there is no danger of it falling over.

- 2. Remove:
 - Front brake hose/lead holders
 - Front reflectors
 - Front brake calipers
 - Front wheel sensor

ECA20990

NOTICE

- Do not apply the brake lever when removing the brake calipers.
- Be sure not to contact the sensor electrode to any metal part when removing the front wheel sensor from the outer tube.
- 3. Elevate:
- Front wheel

TIP_

Place the vehicle on a suitable stand so that the front wheel is elevated.

EAS30146


DISASSEMBLING THE FRONT WHEEL

- 1. Remove:
- Oil seal
- Wheel bearings


- a. Clean the surface of the front wheel hub.b. Remove the oil seals "1" with a flat-head
- screwdriver.

TIP _

To prevent damaging the wheel, place a rag "2" between the screwdriver and the wheel surface.



c. Remove the wheel bearings "3" with a general bearing puller.



CHECKING THE FRONT WHEEL

- 1. Check:
 - Wheel axle Roll the wheel axle on a flat surface.
- Bends \rightarrow Replace.

Do not attempt to straighten a bent wheel axle.




- 2. Check:
- Tire
- Front wheel Damage/wear → Replace. Refer to "CHECKING THE TIRES" on page 3-16 and "CHECKING THE WHEELS" on page 3-16.
- 3. Measure:
- Radial wheel runout "1"

• Lateral wheel runout "2" Over the specified limits \rightarrow Replace.



Radial wheel runout limit 1.0 mm (0.04 in) Lateral wheel runout limit 0.5 mm (0.02 in)



- 4. Check:
- Wheel bearings
 - Front wheel turns roughly or is loose \rightarrow Replace the wheel bearings.
- Oil seal Damage/wear → Replace.




EAS30155

MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR ECA21070

NOTICE

- Handle the ABS components with care since they have been accurately adjusted. Keep them away from dirt and do not subject them to shocks.
- The front wheel sensor cannot be disassembled. Do not attempt to disassemble it. If faulty, replace with a new one.
- Keep any type of magnets (including magnetic pick-up tools, magnetic screwdrivers, etc.) away from the front wheel sensor or front wheel sensor rotor.
- Do not drop or shock the wheel sensor or the wheel sensor rotor.


- 1. Check:
- Front wheel sensor "1" Cracks/bends/distortion → Replace. Iron powder/dust → Clean.



- 2. Check:
 - Front wheel sensor rotor "1" Cracks/damage/scratches → Replace the front wheel sensor rotor.
 Iron powder/dust/solvent → Clean.

TIP

- The wheel sensor rotor is installed on the inner side of the wheel hub.
- When cleaning the wheel sensor rotor, be careful not to damage the surface of the sensor rotor.



- 3. Measure:
 - Wheel sensor rotor deflection Out of specification → Clean the installation surface of the wheel sensor rotor and correct the wheel sensor rotor deflection, or replace the wheel sensor rotor.




Wheel sensor rotor deflection limit 0.25 mm (0.0098 in)

- ****
- a. Hold the dial gauge at a right angle against the wheel sensor rotor surface.
- b. Measure the wheel sensor rotor deflection.

TIP __

Do not touch the surface of the wheel sensor rotor with a sharp object.



c. If the deflection is above specification, remove the sensor rotor from the wheel, rotate it by one or two bolt holes, and then install it.



Front wheel sensor rotor bolt 8 Nm (0.8 m·kgf, 5.8 ft·lbf) LOCTITE®


ECA18100

Replace the wheel sensor rotor bolts with new ones.

d. If the deflection is still above specification, replace the wheel sensor rotor.

TIP _

Install the wheel sensor rotor with the stamped mark "a" facing outward.



ASSEMBLING THE FRONT WHEEL

1. Install:

EAS30151

- Wheel bearings New
- Oil seals New
- ****


a. Install the new wheel bearing (right side).

NOTICE

Do not contact the wheel bearing inner race "1" or balls "2". Contact should be made only with the outer race "3".

TIP_


Use a socket "4" that matches the diameter of the wheel bearing outer race.



- b. Install the spacer.
- c. Install the new wheel bearing (left side).

TIP _

Place a suitable washer "1" between the socket "2" and the bearing so that both the inner race "3" and outer race "4" are pressed at the same time, and then press the bearing until the inner race makes contact with the spacer "5".



ADJUSTING THE FRONT WHEEL STATIC

BALANCE


• After replacing the tire, wheel or both, the front wheel static balance should be adjusted.

- Adjust the front wheel static balance with the brake disc installed.
- 1. Remove:
- Balancing weight(s)
- 2. Find:
 - Front wheel's heavy spot


TIP_

Place the front wheel on a suitable balancing stand.

- a. Spin the front wheel.
- b. When the front wheel stops, put an "X₁" mark at the bottom of the wheel.



- c. Turn the front wheel 90° so that the "X₁" mark is positioned as shown.
- d. Release the front wheel.
- e. When the wheel stops, put an " X_2 " mark at the bottom of the wheel.




- f. Repeat steps (c) through (e) several times until all the marks come to rest at the same spot.
- g. The spot where all the marks come to rest is the front wheel's heavy spot "X".


- 3. Adjust:
- Front wheel static balance
- *****
- a. Install a balancing weight "1" onto the rim exactly opposite the heavy spot "X".

TIP _

Start with the lightest weight.




b. Turn the front wheel 90° so that the heavy spot is positioned as shown.



- c. If the heavy spot does not stay in that position, install a heavier weight.
- d. Repeat steps (b) and (c) until the front wheel is balanced.

- 4. Check:
- Front wheel static balance
- *****
- a. Turn the front wheel and make sure it stays at each position shown.



b. If the front wheel does not remain stationary at all of the positions, rebalance it.

EAS30154 INSTALLING THE FRONT WHEEL (DISC BRAKE)

- 1. Install:
 - Front wheel sensor rotor
 - Front brake discs




Front wheel sensor rotor bolt 8 Nm (0.8 m·kgf, 5.8 ft·lbf) LOCTITE® Front brake disc bolt 18 Nm (1.8 m·kgf, 13 ft·lbf) LOCTITE®


ECA21011

- Do not drop the wheel sensor rotor or subject it to shocks.
- If any solvent gets on the wheel sensor rotor, wipe it off immediately.
- Replace the brake disc bolts and wheel sensor rotor bolts with new ones.

TIP_

- Install the wheel sensor rotor with the stamped mark "a" facing outward.
- Install each front brake disc so that the chamfered portions of the rivets "b" face outward.
- Tighten the brake disc bolts in stages and in a crisscross pattern.





2. Check:


- Front brake discs Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-35.
- 3. Lubricate:
- Oil seal lips

Recommended lubricant Lithium-soap-based grease

- 4. Install:
- Collars
- Front wheel
- Front wheel axle

TIP _

Install the front wheel with the mark "a" on the front tire pointing in the direction of wheel rotation.



- 5. Tighten:
- Front wheel axle
- Front wheel axle pinch bolt

Front wheel axle 65 Nm (6.5 m·kgf, 47 ft·lbf) Front wheel axle pinch bolt 23 Nm (2.3 m·kgf, 17 ft·lbf)

ECA14140

Before tightening the wheel axle nut, push down hard on the handlebar(s) several times and check if the front fork rebounds smoothly.

TIP _

First, tighten the wheel axle, then the wheel axle pinch bolt.

6. Install:

Front wheel sensor

Front wheel sensor bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

NOTICE

Make sure there are no foreign materials in the front wheel sensor rotor and front wheel sensor. Foreign materials cause damage to the front wheel sensor rotor and front wheel sensor.

TIP.

• When installing the front wheel sensor, check the wheel sensor lead for twists.

- To route the front wheel sensor lead, refer to "CABLE ROUTING" on page 2-43.
- 7. Measure:
- Distance "a"

(between the front wheel sensor rotor "1" and front wheel sensor "2") Out of specification \rightarrow Check the wheel bear-


Out of specification \rightarrow Check the wheel bearing for looseness, and the front wheel sensor and sensor rotor installation conditions (warpage caused by overtorque, wrong installation direction, rotor decentering, LOC-TITE® on the mounting surface of the rotor, deformation caused by an impact during service and caught foreign materials). If there is any defective part, repair or replace the defective part.



Distance "a" (between the front wheel sensor rotor and front wheel sensor) 0.5–1.3 mm (0.02–0.05 in)

TIP_

Measure the distance between the front wheel sensor rotor and front wheel sensor in several places in one rotation of the front wheel. Do not turn the front wheel while the thickness gauge is installed. This may damage the front wheel sensor rotor and the front wheel sensor.



- 8. Install:
 - Front brake calipers
 - Front reflectors
 - Front brake hose/lead holders "1"




Front brake caliper bolt 40 Nm (4.0 m·kgf, 29 ft·lbf) Front brake hose/lead holder bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

WARNING

Make sure the brake hose is routed properly.

TIP .

Install the front brake hose/lead holder so that the projection "a" on the holder contacts the stopper "b" on the front fork.





EAS20029 **REAR WHEEL** Removing the rear wheel 🔌 105 Nm (10.5 m·kgf, 76 ft·lbf) 🔌 16 Nm (1.6 m·kgf, 12 ft·lbf) 8 ĵ 3 (Ø 3 Ô **(**S) 2 🔌 16 Nm (1.6 m•kgf, 12 ft•lbf) 🔀 7 Nm (0.7 m·kgf, 5.1 ft·lbf) 22 Nm (2.2 m·kgf, 16 ft·lbf) 🔀 27 Nm (2.7 m·kgf, 20 ft·lbf) Remarks Order Job/Parts to remove Q'ty Rear wheel sensor 1 1 2 Rear brake caliper 1 Drive chain puller locknut 2 3 Loosen. 4 Drive chain adjusting nut 2 Loosen. 5 Swingarm end plate (left) 1 Swingarm end plate (right) 6 1 7 Wheel axle nut 1 8 Washer 1

1

Rear wheel axle

9





Disassemb	<image/>		
Order	Job/Parts to remove	Q'ty	Remarks
1	Oil seal	1	
2	Wheel bearing	2	
3	Spacer	1	
			1

EAS30156 REMOVING THE REAR WHEEL (DISC BRAKE) ECA21030

NOTICE

- Keep any type of magnets (including magnetic pick-up tools, magnetic screwdrivers, etc.) away from the rear wheel sensor or rear wheel sensor rotor; otherwise, the sensor or rotor may be damaged, resulting in improper performance of the ABS system.
- Do not drop the rear wheel sensor rotor or subject it to shocks.
- If any solvent gets on the rear wheel sensor rotor, wipe it off immediately.

1. Stand the vehicle on a level surface.

WARNING

Securely support the vehicle so that there is no danger of it falling over.


TIP.

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- 2. Remove:
 - Rear wheel sensor
 - Rear brake caliper

ECA21040

- Do not depress the brake pedal when removing the brake caliper.
- Be sure not to contact the sensor electrode to any metal part when removing the rear wheel sensor from the rear brake caliper bracket.
- 3. Loosen:
- Drive chain puller locknuts "1"
- Drive chain adjusting nuts "2"




- 4. Remove:
- Wheel axle nut "1"
- Washer
- Rear wheel axle "2"
- Drive chain slack adjusting plates

Rear wheel

TIP .

Push the rear wheel forward and remove the drive chain from the rear wheel sprocket.



DISASSEMBLING THE REAR WHEEL

- 1. Remove:
- Oil seal
- Wheel bearings Refer to "DISASSEMBLING THE FRONT WHEEL" on page 4-14.


EAS30159

CHECKING THE REAR WHEEL

- 1. Check:
- Rear wheel axle
- Wheel bearings
- Oil seal Refer to "CHECKING THE FRONT WHEEL" on page 4-14.
- 2. Check:
- Tire
- Rear wheel Damage/wear → Replace. Refer to "CHECKING THE TIRES" on page 3-16 and "CHECKING THE WHEELS" on page 3-16.
- 3. Measure:
 - Radial wheel runout
 - Lateral wheel runout Refer to "CHECKING THE FRONT WHEEL" on page 4-14.

CHECKING THE REAR WHEEL DRIVE HUB

- 1. Check:
 - Rear wheel drive hub "1" Cracks/damage → Replace.
 - Rear wheel drive hub dampers "2" Damage/wear → Replace.




EAS30161

CHECKING AND REPLACING THE REAR WHEEL SPROCKET

- 1. Check:
 - Rear wheel sprocket More than 1/4 tooth "a" wear → Replace the drive sprockets as a set.

Bent teeth \rightarrow Replace the drive sprockets as a set.




- b. Correct
- 1. Drive chain roller
- 2. Rear wheel sprocket
- 2. Replace:
 - Rear wheel sprocket

- a. Remove the rear wheel sprocket nuts, bracket, and the rear wheel sprocket.
- b. Clean the rear wheel drive hub with a clean cloth, especially the surfaces that contact the sprocket.
- c. Install a new rear wheel sprocket.

Rear wheel sprocket nut 80 Nm (8.0 m·kgf, 58 ft·lbf)

- TIP_
- Install the rear wheel sprocket so that the stepped side "a" of the sprocket faces away from the hub.
- Tighten the rear wheel sprocket nuts in stages and in a crisscross pattern.



EAS30167 MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR ECA21060

NOTICE

- Handle the ABS components with care since they have been accurately adjusted. Keep them away from dirt and do not subject them to shocks.
- The rear wheel sensor cannot be disassembled. Do not attempt to disassemble it. If faulty, replace with a new one.
- Keep any type of magnets (including magnetic pick-up tools, magnetic screwdrivers, etc.) away from the rear wheel sensor or rear wheel sensor rotor.
- Do not drop or shock the wheel sensor or the wheel sensor rotor.
- 1. Check:
 - Rear wheel sensor Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.
- 2. Check:
- Rear wheel sensor rotor Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.
- 3. Measure:
 - Wheel sensor rotor deflection Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.

Wheel sensor rotor deflection limit 0.25 mm (0.0098 in)

ASSEMBLING THE REAR WHEEL

NOTICE

- Do not drop the wheel sensor rotor or subject it to shocks.
- If any solvent gets on the wheel sensor rotor, wipe it off immediately.
- 1. Install:
- Wheel bearings New
- Oil seal <u>New</u> Refer to "ASSEMBLING THE FRONT WHEEL" on page 4-16.

ADJUSTING THE REAR WHEEL STATIC BALANCE

TIP_

- After replacing the tire, wheel or both, the rear wheel static balance should be adjusted.
- Adjust the rear wheel static balance with the brake disc and rear wheel drive hub installed.

1. Adjust:

• Rear wheel static balance Refer to "ADJUSTING THE FRONT WHEEL STATIC BALANCE" on page 4-16.

INSTALLING THE REAR WHEEL (REAR BRAKE DISC)

- 1. Install:
- Rear brake disc
- Rear wheel sensor rotor



Rear wheel sensor rotor bolt 8 Nm (0.8 m·kgf, 5.8 ft·lbf) LOCTITE® Rear brake disc bolt 30 Nm (3.0 m·kgf, 22 ft·lbf) LOCTITE®


ECA21011 NOTICE


- Do not drop the wheel sensor rotor or subject it to shocks.
- If any solvent gets on the wheel sensor rotor, wipe it off immediately.
- Replace the brake disc bolts and wheel sensor rotor bolts with new ones.

TIP _

• Install the wheel sensor rotor with the stamped mark "a" facing outward.

- Install the brake disc so that the recessed portions of the bolt holes "b" face away from the hub.
- Tighten the brake disc bolts in stages and in a crisscross pattern.





- 2. Install:
 - Rear wheel sprocket Refer to "CHECKING AND REPLACING THE REAR WHEEL SPROCKET" on page 4-25.
- 3. Check:
 - Rear brake disc Refer to "CHECKING THE REAR BRAKE DISC" on page 4-49.
- 4. Lubricate:
 - Oil seal lips




Recommended lubricant Lithium-soap-based grease

- 5. Install:
 - Collar (right)
 - Collar (left)
 - Brake caliper bracket "1"
 - Rear wheel
 - Chain pullers "2"
 - Drive chain slack adjusting plates
 - Rear wheel axle
 - Washer
 - Wheel axle nut
 - Swingarm end plates "3"


TIP _

- Install the rear wheel with the mark "a" on the rear tire pointing in the direction of wheel rotation.
- Align the projection "b" in the swingarm with the slot "c" of the brake caliper bracket.
- Make sure that the arrow mark "d" on each chain puller points upward.
- Make sure that the arrow mark "e" on each swingarm end plate points upward.




- 6. Install:
 - Rear brake caliper

- Rear brake caliper retaining bolt
- Rear brake caliper bolt
- 7. Fit the space "a" between the side plates of the drive chain "1" onto the rib "b" on the drive chain guide "2".



8. Adjust:
Drive chain slack Refer to "ADJUSTING THE DRIVE CHAIN SLACK" on page 3-17.



- 9. Tighten:
 - Wheel axle nut
 - Rear brake caliper retaining bolt
 - Rear brake caliper bolt



WARNING

Make sure the brake hose is routed properly.

10.Install:

Rear wheel sensor



ECA21080

Rear wheel sensor bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

NOTICE

Make sure there are no foreign materials in the rear wheel sensor rotor and rear wheel sensor. Foreign materials cause damage to the rear wheel sensor rotor and rear wheel sensor.

TIP ___

To route the rear wheel sensor lead, refer to "CABLE ROUTING" on page 2-43.

11.Measure:

• Distance "a"

(between the rear wheel sensor rotor "1" and rear wheel sensor "2")


Out of specification \rightarrow Check the wheel bearing for looseness, and the rear wheel sensor and sensor rotor installation conditions (warpage caused by overtorque, wrong installation direction, rotor decentering, LOC-TITE® on the mounting surface of the rotor, deformation caused by an impact during service and caught foreign materials). If there is any defective part, repair or replace the defective part.



Distance "a" (between the rear wheel sensor rotor and rear wheel sensor) 0.7–1.5 mm (0.03–0.06 in)

TIP _

Measure the distance between the rear wheel sensor rotor and rear wheel sensor in several places in one rotation of the rear wheel. Do not turn the rear wheel while the thickness gauge is installed. This may damage the rear wheel sensor rotor and the rear wheel sensor.



3

4

5

6

7

8


Brake pad spring

Front brake caliper

Brake caliper bleed screw

Brake caliper bleed screw

Brake pad Front reflector



1 2

1


1


1


1


Left side only.


Right side only.











EAS30168 INTRODUCTION EWA14101

Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury. FIRST AID FOR BRAKE FLUID ENTERING

THE EYES:

• Flush with water for 15 minutes and get immediate medical attention.

EAS30169

CHECKING THE FRONT BRAKE DISCS

The following procedure applies to both brake discs.


- 1. Remove:
- Front wheel
- Refer to "FRONT WHEEL" on page 4-12. 2. Check:
- Front brake disc Damage/galling → Replace.
- 3. Measure:
 - Brake disc deflection
 Out of specification → Correct the brake disc deflection or replace the brake disc.



Brake disc runout limit (as measured on wheel) 0.10 mm (0.0039 in)


- a. Place the vehicle on a suitable stand so that the front wheel is elevated.
- b. Before measuring the brake disc deflection, turn the handlebar to the left or right to ensure that the front wheel is stationary.
- c. Remove the brake caliper.


- d. Hold the dial gauge at a right angle against the brake disc surface.
- e. Measure the deflection 1.5 mm (0.06 in) below the edge of the brake disc.



- 4. Measure:
 - Brake disc thickness Measure the brake disc thickness at a few different locations.

Out of specification \rightarrow Replace.





- 5. Adjust:
 - Brake disc deflection
- *****
- a. Remove the brake disc.
- b. Rotate the brake disc by one bolt hole.
- c. Install the brake disc.




Front brake disc bolt 18 Nm (1.8 m·kgf, 13 ft·lbf) LOCTITE®

ECA19150

Replace the brake disc bolts with new ones.

TIP .

- Install each front brake disc so that the chamfered portions of the rivets "a" face outward.
- Tighten the brake disc bolts in stages and in a crisscross pattern.



- d. Measure the brake disc deflection.
- e. If out of specification, repeat the adjustment steps until the brake disc deflection is within specification.
- f. If the brake disc deflection cannot be brought within specification, replace the brake disc.

- 6. Install:
- Front wheel

Refer to "FRONT WHEEL" on page 4-12.


REPLACING THE FRONT BRAKE PADS

The following procedure applies to both brake calipers.


TIP _

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.


- 1. Remove:
 - Brake pad clips "1"
 - Brake pad pin "2"
 - Brake pad spring "3"




- 2. Remove:
 - Brake pads "1"
 - Front reflector "2"
 - Front brake caliper "3"



- 3. Measure:
 - Brake pad wear limit "a" Out of specification → Replace the brake pads as a set.






- 4. Install:
 - Brake pads
- Brake pad spring

TIP

Always install new brake pads and new brake pad spring as a set.

- a. Connect a clear plastic hose "1" tightly to the bleed screw "2". Put the other end of the hose into an open container.
- b. Loosen the bleed screw and push the brake caliper pistons into the brake caliper with your finger.



c. Tighten the bleed screw.




Brake caliper bleed screw 5 Nm (0.5 m·kgf, 3.6 ft·lbf)

d. Install the new brake pads and a new brake pad spring.

TIP.


The arrow mark "a" on the brake pad spring must point in the direction of disc rotation.



- 5. Install:
 - Brake pad pin
 - Brake pad clips
 - Front reflector
 - Front brake caliper

Front brake caliper bolt 40 Nm (4.0 m·kgf, 29 ft·lbf)

- 6. Check:
 - Brake fluid level Below the minimum level mark "a" → Add the specified brake fluid to the proper level. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.



- 7. Check:
 - Brake lever operation Soft or spongy feeling → Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.

EAS30724

REMOVING THE FRONT BRAKE CALIPERS The following procedure applies to both of the brake calipers.


TIP _


Before removing the brake caliper, drain the brake fluid from the entire brake system.

- 1. Remove:
 - Brake hose union bolt "1"
 - Brake hose gaskets "2"
 - Brake hose (hydraulic unit to left front brake caliper) "3"
 - Brake hose (left front brake caliper to right front brake caliper) "4"

TIP _

Put the end of the brake hose into a container and pump out the brake fluid carefully.






- A. Left side
- B. Right side

DISASSEMBLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.


- 1. Remove:
 - Brake caliper pistons "1"
 - Brake caliper piston dust seals "2"
 - Brake caliper piston seals "3"



- a. Secure the right side brake caliper pistons with a piece of wood "a".
- b. Blow compressed air into the brake hose joint opening "b" to force out the left side pistons from the brake caliper.

WARNING

- Never try to pry out the brake caliper pistons.
- Do not loosen the bolts "4".



- c. Remove the brake caliper piston dust seals and brake caliper piston seals.
- d. Repeat the previous steps to force out the right side pistons from the brake caliper.

CHECKING THE FRONT BRAKE CALIPERS


The following procedure applies to both of the brake calipers.

Recommended brake component replacement schedule		
Brake pads	If necessary	
Piston seals	Every two years	
Piston dust seals	Every two years	
Brake hoses	Every four years	
Brake fluid	Every two years and whenever the brake is disassembled	

- 1. Check:
 - Brake caliper pistons "1" Rust/scratches/wear → Replace the brake caliper pistons.
 - Brake caliper cylinders "2" Scratches/wear → Replace the brake caliper assembly.
 - Brake caliper body "3" Cracks/damage → Replace the brake caliper assembly.
 - Brake fluid delivery passages (brake caliper body)
 Obstruction → Blow out with compressed air.

WARNING

Whenever a brake caliper is disassembled, replace the brake caliper piston dust seals and brake caliper piston seals.



ASSEMBLING THE FRONT BRAKE CALIPERS

WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the brake caliper piston dust seals and brake caliper piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston dust seals and brake caliper piston seals.

· M

Specified brake fluid DOT 4

INSTALLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.

- 1. Install:
- Front brake caliper "1"
- Front reflector "2"
- Brake hose gaskets "3" New
- Brake hose (left front brake caliper to right front brake caliper) "4"
- Brake hose (hydraulic unit to left front brake caliper) "5"
- Brake hose union bolt "6"




Front brake caliper bolt 40 Nm (4.0 m·kgf, 29 ft·lbf) Front brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)


WARNING

Proper brake hose routing is essential to insure safe vehicle operation.


ECA20851 NOTICE

- When installing the brake hose onto the brake caliper "1", make sure the brake pipe "a" touches the projection "b" on the brake caliper.
- There should be 0.5–1.5 mm (0.020–0.059 in) of clearance between the brake pipes. (Left side only)





- A. Left side
- B. Right side
- 2. Install:
- Brake pads
- Brake pad spring
- Brake pad pin
- Brake pad clips Refer to "REPLACING THE FRONT BRAKE PADS" on page 4-36.
- 3. Fill:
- Brake master cylinder reservoir (with the specified amount of the specified brake fluid)




- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540 NOTICE

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 4. Bleed:
 - Brake system **Refer to "BLEEDING THE HYDRAULIC** BRAKE SYSTEM (ABS)" on page 3-14.
- 5. Check:
- Brake fluid level

Below the minimum level mark "a" \rightarrow Add the specified brake fluid to the proper level. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.



- 6. Check:
 - Brake lever operation Soft or spongy feeling \rightarrow Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.

EAS30179

REMOVING THE FRONT BRAKE MASTER CYLINDER


TIP_

Before removing the front brake master cylinder, drain the brake fluid from the entire brake system.

- 1. Disconnect:
 - Brake light switch connectors (from the front brake light switch)
- 2. Remove:
 - Brake hose union bolt "1"
 - Brake hose gaskets "2"
 - Brake hose (front brake master cylinder to hydraulic unit) "3"

TIP.


To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.



EAS30725 **CHECKING THE FRONT BRAKE MASTER** CYLINDER

- 1. Check:
 - Brake master cylinder Damage/scratches/wear \rightarrow Replace.
- Brake fluid delivery passages (brake master cylinder body) Obstruction \rightarrow Blow out with compressed air.
- 2. Check:
 - Brake master cylinder kit Damage/scratches/wear \rightarrow Replace.
- 3. Check:
 - Brake master cylinder reservoir "1"
- Brake master cylinder reservoir diaphragm holder "2"
- Cracks/damage \rightarrow Replace.
- Brake master cylinder reservoir diaphragm "3"

Damage/wear \rightarrow Replace.



- 4. Check:
 - Brake hoses

Cracks/damage/wear \rightarrow Replace.

EAS3018

ASSEMBLING THE FRONT BRAKE MASTER **CYLINDER** EWA13520

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.

Specified brake fluid DOT 4

INSTALLING THE FRONT BRAKE MASTER CYLINDER


- 1. Install:
- Front brake master cylinder assembly
- Front brake master cylinder holder



Front brake master cylinder holder bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

TIP_

- Install the front brake master cylinder holder with the "UP" mark "a" facing up.
- Align the end of the front brake master cylinder holder with the punch mark "b" on the handle-bar.
- First, tighten the upper bolt, then the lower bolt.
- There should be more than 11 mm (0.43 in) for clearance between the right handlebar switch and the front brake master cylinder holder. Also, the punch mark should be seen.



- 2. Install:
 - Brake hose (front brake master cylinder to hydraulic unit)
 - Brake hose gaskets New
 - Brake hose union bolt

Front brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)


WARNING

Proper brake hose routing is essential to insure safe vehicle operation.

TIP _

• Install the brake pipe so that paint mark "a" on the pipe faces to the rear of the vehicle.

- Attach the brake hose so that its angle is 15° to 25° against the straight line in parallel with the ceiling plane of the master cylinder.
- While holding the brake hose, tighten the union bolt as shown.
- Turn the handlebar to the left and right to make sure the brake hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.



- 3. Fill:
- Brake master cylinder reservoir (with the specified amount of the specified brake fluid)



Specified brake fluid DOT 4

WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.


ECA13540 NOTICE

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 4. Bleed:
 - Brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.

- 5. Check:
 - Brake fluid level

Below the minimum level mark "a" \rightarrow Add the specified brake fluid to the proper level. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.





6. Check:


• Brake lever operation Soft or spongy feeling \rightarrow Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.


Removing the rear brake pads 0 <					
7		0	n (2.2 m·kgf, 16 ft·lbf)		
7 Order	6	0	n (2.2 m·kgf, 16 ft·lbf)		
	6	7	n (2.2 m·kgf, 16 ft·lbf)		
Order	6 Job/Parts to remove	7 Q'ty	n (2.2 m·kgf, 16 ft·lbf)		
Order 1	Job/Parts to remove Screw plug Brake pad retaining bolt Rear brake caliper retaining bolt	7 Q'ty 1	n (2.2 m·kgf, 16 ft·lbf)		
Order 1 2	Job/Parts to remove Screw plug Brake pad retaining bolt	Q'ty 1 1	n (2.2 m·kgf, 16 ft·lbf)		
Order 1 2 3	Job/Parts to remove Screw plug Brake pad retaining bolt Rear brake caliper retaining bolt	7 7 2'ty 1 1 1	n (2.2 m·kgf, 16 ft·lbf)		
Order 1 2 3 4	Job/Parts to remove Screw plug Brake pad retaining bolt Rear brake caliper retaining bolt Rear brake caliper bolt	Q'ty 1 1 1 1 1	n (2.2 m·kgf, 16 ft·lbf)		
Order 1 2 3 4 5	Job/Parts to remove Screw plug Brake pad retaining bolt Rear brake caliper retaining bolt Rear brake caliper bolt Rear brake caliper	7 7 0'ty 1 1 1 1 1	n (2.2 m·kgf, 16 ft·lbf)		
Order 1 2 3 4 5 6	Job/Parts to remove Screw plug Brake pad retaining bolt Rear brake caliper retaining bolt Rear brake caliper bolt Rear brake caliper Brake pad	Q'ty 1 1 1 1 1 2	n (2.2 m·kgf, 16 ft·lbf)		
Order 1 2 3 4 5 6 7	Job/Parts to remove Screw plug Brake pad retaining bolt Rear brake caliper retaining bolt Rear brake caliper bolt Rear brake caliper Brake pad Brake pad	Q'ty 1 1 1 1 1 2 2	n (2.2 m·kgf, 16 ft·lbf)		







Removing the rear brake caliper					
0 0					
Order	Job/Parts to remove	Q'ty	Remarks		
	Brake fluid		Drain. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.		
1	Rear brake hose union bolt	1			
2	Brake hose gasket	2			
3	Brake hose (hydraulic unit to rear brake caliper)	1			
4	Rear brake caliper retaining bolt	1			
5	Rear brake caliper bolt	1			
6	Rear brake caliper	1			



EAS30183 INTRODUCTION EWA14101

Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.
 FIRST AID FOR BRAKE FLUID ENTERING

THE EYES:

• Flush with water for 15 minutes and get immediate medical attention.

EAS30184

CHECKING THE REAR BRAKE DISC

- 1. Remove:
 - Rear wheel
- Refer to "REAR WHEEL" on page 4-20. 2. Check:
- Rear brake disc Damage/galling \rightarrow Replace.
- 3. Measure:
- Brake disc deflection

Out of specification \rightarrow Correct the brake disc deflection or replace the brake disc. Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-35.

K

Brake disc runout limit (as measured on wheel) 0.15 mm (0.0059 in)

4. Measure:

- Brake disc thickness Measure the brake disc thickness at a few different locations.
- Out of specification \rightarrow Replace.

Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-35.



Brake disc thickness limit 4.5 mm (0.18 in)

- 5. Adjust:
 - Brake disc deflection Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-35.

30 Nm (3.0 m·kgf, 22 ft·lbf)

Rear brake disc bolt

LOCTITE®



. . .

6. Install:• Rear wheel


Refer to "REAR WHEEL" on page 4-20.

REPLACING THE REAR BRAKE PADS

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

- 1. Measure:
 - Brake pad wear limit "a" Out of specification → Replace the brake pads as a set.

X	Brake pad lining thickness (in- ner) 6.0 mm (0.24 in) Limit 1.0 mm (0.04 in) Brake pad lining thickness (out- er) 6.0 mm (0.24 in) Limit
	Limit 1.0 mm (0.04 in)




- 2. Install:
 - Brake pad insulators (onto the brake pads)
 - Brake pad shims (onto the brake pads)

- Brake pad spring (into the rear brake caliper)
- Brake pads

TIP_

Always install new brake pads, brake pad insulators, brake pad shims, and brake pad spring as a set.

- a. Connect a clear plastic hose "1" tightly to the bleed screw "2". Put the other end of the hose into an open container.
- b. Loosen the bleed screw and push the brake caliper piston into the brake caliper with your finger.



c. Tighten the bleed screw.



Brake caliper bleed screw 5 Nm (0.5 m·kgf, 3.6 ft·lbf)

d. Install the brake pad insulators and brake pad shims onto each brake pads.

TIP


Apply silicone grease between the brake pad insulator and the brake pad shim.

ECA18210

- Do not allow grease to contact the brake pads.
- Remove any excess grease.

e. Install the brake pads and brake pad spring.

The longer tangs "a" of the brake pad spring must point in the direction of the brake caliper piston.



- 3. Lubricate:
- Rear brake caliper bolt
- Rear brake caliper retaining bolt



Recommended lubricant Silicone grease

NOTICE


FCA18210

- Do not allow grease to contact the brake pads.
- Remove any excess grease.
- 4. Install:
- Rear brake caliper
- Rear brake caliper bolt
- Rear brake caliper retaining bolt
- Brake pad retaining bolt
- Screw plug



5. Check:

 Brake fluid level Below the minimum level mark "a" → Add the specified brake fluid to the proper level. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.



- 6. Check:
 - Brake pedal operation

Soft or spongy feeling \rightarrow Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.


EAS30186 **REMOVING THE REAR BRAKE CALIPER** TIP_

Before disassembling the brake caliper, drain the brake fluid from the entire brake system.

- 1. Remove:
 - Rear brake hose union bolt "1"
 - Brake hose gaskets "2"
 - · Brake hose (hydraulic unit to rear brake caliper) "3"

TIP.


Put the end of the brake hose into a container and pump out the brake fluid carefully.



EAS30187


DISASSEMBLING THE REAR BRAKE CALIPER

- 1. Remove:
- Brake caliper piston "1"
- Brake caliper piston dust seal "2"
- Brake caliper piston seal "3"



a. Blow compressed air into the brake hose joint opening "a" to force out the piston from the brake caliper.

- Cover the brake caliper piston with a rag. Be careful not to get injured when the piston is expelled from the brake caliper.
- Never try to pry out the brake caliper piston.



b. Remove the brake caliper piston dust seal and brake caliper piston seal.

____ EAS30188

CHECKING THE REAR BRAKE CALIPER

Recommended brake component replacement schedule			
Brake pads	If necessary		
Piston seal	Every two years		
Piston dust seal	Every two years		
Brake hoses	Every four years		
Brake fluid	Every two years and whenever the brake is disassembled		


1. Check:

• Brake caliper piston "1" Rust/scratches/wear \rightarrow Replace the brake caliper piston.

- Brake caliper cylinder "2" Scratches/wear \rightarrow Replace the brake caliper assembly.
- Brake caliper body "3" Cracks/damage → Replace the brake caliper assembly.
- Brake fluid delivery passages (brake caliper body)
 Obstruction → Blow out with compressed air.


WARNING

Whenever a brake caliper is disassembled, replace the brake caliper piston dust seal and brake caliper piston seal.



2. Check:

 Rear brake caliper bracket "1" Cracks/damage → Replace.
 Refer to "REAR WHEEL" on page 4-20.



EAS30189

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the brake caliper piston dust seal and brake caliper piston seal to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston dust seal and brake caliper piston seal.





Specified brake fluid DOT 4

EAS30190

INSTALLING THE REAR BRAKE CALIPER

- 1. Install:
 - Rear brake caliper "1"
 (temporarily)
 - Brake hose gaskets "2" New
- Brake hose (hydraulic unit to rear brake caliper) "3"
- Rear brake hose union bolt "4"






WARNING

Proper brake hose routing is essential to insure safe vehicle operation.

ECA19080

When installing the brake hose onto the brake caliper "1", make sure the brake pipe "a" passes between the projections "b" on the brake caliper.



- 2. Remove:
- Rear brake caliper
- 3. Install:
 - Brake pad insulators (onto the brake pads)

- Brake pad shims (onto the brake pads)
- Brake pad spring (into the rear brake caliper)
- Brake pads
- Rear brake caliper Refer to "REPLACING THE REAR BRAKE PADS" on page 4-49.



- 4. Fill:
 - Brake fluid reservoir (with the specified amount of the specified brake fluid)

Specified brake fluid DOT 4


- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540 NOTICE

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 5. Bleed:
 - Brake system **Refer to "BLEEDING THE HYDRAULIC** BRAKE SYSTEM (ABS)" on page 3-14.
- 6. Check:
 - Brake fluid level Below the minimum level mark "a" \rightarrow Add the specified brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.



7. Check:

 Brake pedal operation Soft or spongy feeling \rightarrow Bleed the brake system.


Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.

REMOVING THE REAR BRAKE MASTER CYLINDER

- 1. Remove:
 - Brake hose union bolt "1"
 - Brake hose gaskets "2"
 - Brake hose (rear brake master cylinder to hydraulic unit) "3"

TIP.

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.




EAS3019 **CHECKING THE REAR BRAKE MASTER CYLINDER**

- 1. Check:
- Brake master cylinder Damage/scratches/wear \rightarrow Replace.
- Brake fluid delivery passages (brake master cylinder body) Obstruction \rightarrow Blow out with compressed air.
- 2. Check:
- Brake master cylinder kit Damage/scratches/wear \rightarrow Replace.

3. Check:

- Brake fluid reservoir "1"
- Brake fluid reservoir diaphragm holder "2" Cracks/damage \rightarrow Replace.
- Brake fluid reservoir diaphragm "3" Damage/wear → Replace.



- 4. Check:
- Brake hose
- Brake fluid reservoir hose Cracks/damage → Replace.

ASSEMBLING THE REAR BRAKE MASTER CYLINDER

WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.



Specified brake fluid DOT 4

- 1. Install:
- Brake master cylinder kit New

EAS30196

INSTALLING THE REAR BRAKE MASTER CYLINDER


- 1. Install:
 - Rear brake hose/lead guide "1"
 - Rear brake hose/lead holder "2"

TIP _

- Fit the projection "a" on the rear brake hose/lead guide into the hole "b" in the swing-arm.
- Make sure that the projection "c" on the rear brake hose/lead holder contacts the swingarm.



Rear brake hose/lead guide bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Rear brake hose/lead holder bolt 5 Nm (0.5 m·kgf, 3.6 ft·lbf)



- 2. Install:
 - Brake hose gaskets New
 - Brake hose (rear brake master cylinder to hydraulic unit)
 - Brake hose union bolt
 - Brake fluid reservoir hose




Rear brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

Proper brake hose routing is essential to insure safe vehicle operation.

ECA14160 NOTICE

When installing the brake hose onto the brake master cylinder, make sure the brake pipe touches the projection "a" as shown.



- 3. Fill:
- Brake fluid reservoir (with the specified amount of the specified brake fluid)

•

Specified brake fluid DOT 4

WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.


ECA13540 NOTICE

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 4. Bleed:
 - Brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14.
- 5. Check:

• Brake fluid level

Below the minimum level mark "a" \rightarrow Add the specified brake fluid to the proper level. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.



- 6. Adjust:
 - Brake pedal position Refer to "ADJUSTING THE REAR DISC BRAKE" on page 3-13.
- 7. Adjust:
 - Rear brake light operation timing Refer to "ADJUSTING THE REAR BRAKE LIGHT SWITCH" on page 3-26.


ABS (ANTI-LOCK BRAKE SYSTEM)

2

3


Brake hose union bolt

Brake hose gasket



4

8



EAS31036 **REMOVING THE HYDRAULIC UNIT** ASSEMBLY ECA21091

NOTICE

Unless necessary, avoid removing and installing the brake hoses of the hydraulic unit assembly.

EWA13930


Refill with the same type of brake fluid that is already in the system. Mixing fluids may result in a harmful chemical reaction, leading to poor braking performance.

ECA18241

- NOTICE
- Handle the ABS components with care since they have been accurately adjusted. Keep them away from dirt and do not subject them to shocks.
- Do not turn the main switch to "ON" when removing the hydraulic unit assembly.
- Do not clean with compressed air.
- Do not reuse the brake fluid.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Do not allow any brake fluid to contact the couplers. Brake fluid may damage the couplers and cause bad contacts.
- If the union bolts for the hydraulic unit assembly have been removed, be sure to tighten them to the specified torque and bleed the brake system.
- 1. Disconnect:
- ABS ECU coupler "1"

TIP.

While pushing the portion "a" of the ABS ECU coupler, move the lock lever "b" in the direction of the arrow shown to disconnect the coupler.



- 2. Remove:
- Brake hoses

TIP_

Do not operate the brake lever and brake pedal while removing the brake hoses.


ECA14530 NOTICE

When removing the brake hoses, cover the area around the hydraulic unit to catch any spilt brake fluid. Do not allow the brake fluid to contact other parts.

- 3. Remove:
- Hydraulic unit assembly "1"

TIP.

- To avoid brake fluid leakage and to prevent foreign materials from entering the hydraulic unit assembly, insert a rubber plug "a" or a bolt $(M10 \times 1.25)$ into each brake hose union bolt hole.
- When using a bolt, do not tighten the bolt until the bolt head touches the hydraulic unit. Otherwise, the brake hose union bolt seating surface could be deformed.




EAS31037 CHECKING THE HYDRAULIC UNIT ASSEMBLY

- 1. Check:
 - Hydraulic unit assembly Cracks/damage \rightarrow Replace the hydraulic unit assembly and the brake hoses that are connected to the assembly as a set.

EAS31039 INSTALLING THE HYDRAULIC UNIT ASSEMBLY

1. Install:

Hydraulic unit assembly



Hydraulic unit assembly bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

TIP_

Do not allow any foreign materials to enter the hydraulic unit assembly or the brake hoses when installing the hydraulic unit assembly.

ECA21110 NOTICE

Do not remove the rubber plugs or bolts $(M10 \times 1.25)$ installed in the brake hose union bolt holes before installing the hydraulic unit assembly.

- 2. Remove:
- Rubber plugs or bolts (M10 \times 1.25)
- 3. Install:
 - Brake hose (rear brake master cylinder to hydraulic unit) "1"
 - Brake hose (front brake master cylinder to hydraulic unit) "2"
 - Brake hose (hydraulic unit to left front brake caliper) "3"
 - Brake hose (hydraulic unit to rear brake caliper) "4"

Front brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf) Rear brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

ECA21121 **NOTICE**

If the brake hose union bolt does not turn easily, replace the hydraulic unit assembly, brake hoses, and related parts as a set.


- a. Temporarily install the brake hoses as shown in the illustration.
- b. Position the brake hose (front brake master cylinder to hydraulic unit) "2" so that its projection "a" contacts the brake hose (rear brake master cylinder to hydraulic unit) "1", and then temporarily tighten the union bolt for the brake hose (front brake master cylinder to hydraulic unit).
- c. Temporarily tighten the union bolt for the brake hose (rear brake master cylinder to hydraulic unit) "1".

TIP _

Make sure that the pipe section "b" of the brake hose (rear brake master cylinder to hydraulic unit) does not contact the hydraulic unit.

 d. Position the brake hose (hydraulic unit to left front brake caliper) "3" so that its projection "c" contacts the brake hose (front brake master cylinder to hydraulic unit) "2", and then temporarily tighten the union bolt for the brake hose (hydraulic unit to left front brake caliper).


- e. Position the brake hose (hydraulic unit to rear brake caliper) "4" so that its projection "d" contacts the brake hose (rear brake master cylinder to hydraulic unit) "1", and then temporarily tighten the union bolt for the brake hose (hydraulic unit to rear brake caliper).
- f. Tighten the brake hose union bolts to specification.




- *****
- 4. Connect:
- ABS ECU coupler "1"

TIP _

- Connect the ABS ECU coupler, and then push the lock lever "a" of the coupler in the direction of the arrow shown.
- Make sure that the ABS ECU coupler is connected in the correct position as shown in illustration "A".





- A. The ABS ECU coupler is connected correctly.
- B. The ABS ECU coupler is not connected.
- 5. Fill:
 - Brake master cylinder reservoir
 - Brake fluid reservoir (with the specified amount of the specified brake fluid)



Specified brake fluid DOT 4

WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

ECA13540 NOTICE

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

6. Bleed:

• Brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-14. Check the operation of the hydraulic unit according to the brake lever and the brake pedal response. (Refer to "HYDRAULIC UNIT OPERATION TESTS" on page 4-60.)

NOTICE

Always check the operation of the hydraulic unit according to the brake lever and the brake pedal response.

- Delete the fault codes. (Refer to "[B-3] DE-LETING THE FAULT CODES" on page 8-147.)
- 9. Perform a trial run. (Refer to "CHECKING THE ABS WARNING LIGHT" on page 4-64.)

EAS31040 HYDRAULIC UNIT OPERATION TESTS

The reaction-force pulsating action generated in the brake lever and brake pedal when the ABS is activated can be tested when the vehicle is stopped.

The hydraulic unit operation can be tested using the following two methods.

- Brake line routing confirmation: this test checks the function of the ABS after the system was disassembled, adjusted, or serviced.
- ABS reaction-force confirmation: this test generates the same reaction-force pulsating action that is generated in the brake lever and brake pedal when the ABS is activated.

Brake line routing confirmation

WARNING

Securely support the vehicle so that there is no danger of it falling over.

TIP _

- For the brake line routing confirmation, use the diagnosis of function of the Yamaha diagnostic tool.
- Before performing the brake line routing confirmation, make sure that no malfunctions have been detected in the ABS ECU and that the wheels are not rotating.
- 1. Place the vehicle on a suitable stand.
- 2. Turn the main switch to "OFF".
- 3. Remove:
 - Seat
 - Seat bracket
 - Battery cover
 - Refer to "GENERAL CHASSIS (1)" on page 4-1.

- 4. Check:
 - Battery voltage


Lower than 12.8 V \rightarrow Charge or replace the battery.

0

Battery voltage Higher than 12.8 V


TIP

If the battery voltage is lower than 12.8 V, charge the battery, and then perform brake line routing confirmation.



5. Removing the protective cap "1", and then connect the Yamaha diagnostic tool to the Yamaha diagnostic tool coupler (4P).


Yamaha diagnostic tool 90890-03250



- 6. Start the Yamaha diagnostic tool and display the diagnosis of function screen.
- 7. Select code No. 2, "Brake line routing confirmation".
- 8. Click "Actuator Check" "1", and then operate the brake lever "2" and brake pedal "3" simultaneously.


TIP

• The hydraulic unit operates 1 second after the brake lever and brake pedal are operated simultaneously and continues for approximately 5 seconds. The operation of the hydraulic unit can be confirmed using the indicator.
 On: The hydraulic unit is operating.
 Flashing: The conditions for operating the hydraulic unit have not been met.
 Off: The brake lever and brake pedal are not being operated.



- 9. Check:
 - Hydraulic unit operation

Click "Actuator Check", a single pulse will be generated in the brake lever "1", brake pedal "2", and again in the brake lever "1", in this order.



TIP _

"ON" and "OFF" on the tool screen indicate when the brakes are being applied and released respectively.

ECA18280

• Check that the pulse is felt in the brake lever, brake pedal, and again in the brake lever, in this order.

- If the pulse is felt in the brake pedal before it is felt in the brake lever, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
- If the pulse is hardly felt in either the brake lever or brake pedal, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
- 10.If the operation of the hydraulic unit is normal, delete all of the fault codes.

ABS reaction-force confirmation

Securely support the vehicle so that there is no danger of it falling over.

TIP _


- For the ABS reaction-force confirmation, use the diagnosis of function of the Yamaha diagnostic tool. For more information, refer to the operation manual of the Yamaha diagnostic tool.
- Before performing the ABS reaction-force confirmation, make sure that no malfunctions have been detected in the ABS ECU and that the wheels are not rotating.
- 1. Place the vehicle on a suitable stand.
- 2. Turn the main switch to "OFF".
- 3. Remove:
- Seat
- Seat bracket
- Battery cover
- Refer to "GENERAL CHASSIS (1)" on page 4-1.
- 4. Check:
 - Battery voltage Lower than 12.8 V → Charge or replace the battery.



Battery voltage Higher than 12.8 V


TIP

If the battery voltage is lower than 12.8 V, charge the battery, and then perform ABS reactionforce confirmation.



5. Removing the protective cap "1", and then connect the Yamaha diagnostic tool to the Yamaha diagnostic tool coupler (4P).

Yamaha diagnostic tool 90890-03250



- 6. Start the Yamaha diagnostic tool and display the diagnosis of function screen.
- 7. Select code No. 1, "ABS reaction-force confirmation".
- 8. Click "Actuator Check" "1", and then operate the brake lever "2" and brake pedal "3" simultaneously.

TIP _

• The hydraulic unit operates 1 second after the brake lever and brake pedal are operated simultaneously and continues for approximately 5 seconds.


• The operation of the hydraulic unit can be confirmed using the indicator.

On: The hydraulic unit is operating.

Flashing: The conditions for operating the hydraulic unit have not been met.

Off: The brake lever and brake pedal are not being operated.


ABS (ANTI-LOCK BRAKE SYSTEM)



9. A reaction-force pulsating action is generated in the brake lever "1" and continues for a few seconds.


TIP

- The reaction-force pulsating action consists of quick pulses.
- Be sure to continue operating the brake lever and brake pedal even after the pulsating action has stopped.
- "ON" and "OFF" on the tool screen indicate when the brakes are being applied and released respectively.



- 10.After the pulsating action has stopped in the brake lever, it is generated in the brake pedal "1" and continues for a few seconds.
- TIP_
- The reaction-force pulsating action consists of quick pulses.
- Be sure to continue operating the brake lever and brake pedal even after the pulsating action has stopped.

 "ON" and "OFF" on the tool screen indicate when the brakes are being applied and released respectively.



11.After the pulsating action has stopped in the brake pedal, it is generated in the brake lever and continues for a few seconds.

TIP

- The reaction-force pulsating action consists of quick pulses.
- "ON" and "OFF" on the tool screen indicate when the brakes are being applied and released respectively.

ECA18280

- Check that the pulse is felt in the brake lever, brake pedal, and again in the brake lever, in this order.
- If the pulse is felt in the brake pedal before it is felt in the brake lever, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
- If the pulse is hardly felt in either the brake lever or brake pedal, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
- 12.Turn the main switch to "OFF".
- 13.Remove the Yamaha diagnostic tool from the Yamaha diagnostic tool coupler, and then install the protective cap.
- 14.Turn the main switch to "ON".
- 15.Set the start/engine stop switch to " \bigcirc ".
- 16.Check for brake fluid leakage around the hydraulic unit.
 - Brake fluid leakage \rightarrow Replace the hydraulic unit, brake hoses, and related parts as a set.

17.If the operation of the hydraulic unit is normal, delete all of the fault codes.


CHECKING THE ABS WARNING LIGHT

After all checks and servicing are completed, ensure that the ABS warning light goes off by walking the vehicle at a speed of faster than 10 km/h (6 mph) or performing a trial run.

HANDLEBAR

Removing	Removing the handlebar and meter assembly					
	X 7 Nm (0.7 m·kgf, 5.1 ft·lbf)		🔌 1.8 Nm (0.18 m·kgf, 1.3 ft·lbf)			
		-4				
₹ 17 Nr	n (1.7 m·kgf, 12 ft·lbf)	3/7	🔌 17 Nm (1.7 m·kgf, 12 ft·lbf)			
			🔌 28 Nm (2.8 m·kgf, 20 ft·lbf)			
		-				
_						
' I			10			
	5 5	_	8 4 9			
		P				
Ċ		S P				
0	AL	UG /				
/						
		Image: Second state 2.0 Nm (0.20 m·kgf, 1.4 ft·lbf) Image: Second state 10 Nm (1.0 m·kgf, 7.2 ft·lbf)				
/ 📉 26 Nn	n (2.6 m·kgf, 19 ft·lbf)					
💐 2.0 Nm ((0.20 m·kgf, 1.4 ft·lbf)	🔌 3.8 Nm (0.38 m•kgf, 2.8 ft•lbf)				
Image: Non-Kgf, 5.1 ft·lbf) Image: Non-Kgf, 5.1 ft·lbf)						
Solution New York Strength (1.1 m-kgf, 8.0 ft-lbf) Solution New York Strength (1.1 m-kgf, 8.0 ft-lbf)						
Order	Job/Parts to remove	Q'ty	Remarks			
1	Rearview mirror	2				
2	Meter assembly bracket	1				
3	Meter assembly coupler	1	Disconnect.			
4	Meter assembly	1				
5	Front brake light switch connector	2	Disconnect.			
6	Front brake master cylinder holder	1				
7	Front brake master cylinder assembly	1				
8	Handlebar switch (right)	1				
9	Throttle cable housing	1				
10	Throttle cable	2	Disconnect.			

HANDLEBAR



REMOVING THE HANDLEBAR

1. Stand the vehicle on a level surface.

WARNING


Securely support the vehicle so that there is no danger of it falling over.

2. Remove:

- Throttle cable housings "1"
- Grip end (right) "2"
- Throttle grip "3"

TIP _


While removing the throttle cable housing, pull back the rubber cover "4".



- 3. Remove:
- Handlebar grip "1"

TIP .

Blow compressed air between the left handlebar and the handlebar grip, and gradually push the grip off the handlebar.



EAS30204 CHECKING THE HANDLEBAR

- 1. Check:
- Handlebar Bends/cracks/damage \rightarrow Replace.

WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken it.

EAS30205 INSTALLING THE HANDLEBAR

1. Stand the vehicle on a level surface.

Securely support the vehicle so that there is no danger of it falling over.

- 2. Install:
 - Lower handlebar holder
 - Handlebar "1"
 - Upper handlebar holders "2"




Lower handlebar holder nut 32 Nm (3.2 m·kgf, 23 ft·lbf) Upper handlebar holder bolt 28 Nm (2.8 m·kgf, 20 ft·lbf)

NOTICE


First, tighten the bolts on the front side of the handlebar holder, and then on the rear side.

TIP

- The upper handlebar holders should be installed with the punch marks "a" facing forward.
- Align the punch mark "b" on the handlebar with the left side upper surface of the lower handlebar holder "3".




- 3. Install:
 - Clutch lever holder "1"
 - Clutch lever "2"
 - Clutch lever pivot bolt "3"
 - Clutch cable
 - Clutch switch "4"




TIP _

• Lubricate the clutch lever pivot bolt with the lithium-soap-based grease.

- Align the center of slit on the clutch lever holder with the punch mark "a" on the handlebar.
- Fit the projection "b" on the bottom of the bolt head into the slot "c" in the bolt hole in the clutch lever holder.
- While squeezing the clutch lever, fit the projection "d" on the clutch switch into the slot "e" in the clutch lever holder.





- 4. Install:
- Handlebar grip "1"
- Grip end (left) "2"

Grip end 26 Nm (2.6 m·kgf, 19 ft·lbf)


- *****
- a. Apply a thin coat of rubber adhesive onto the end of the left handlebar.
- b. Side the handlebar grip over the end of the left handlebar.
- c. Wipe off any excess rubber adhesive with a clean rag.

WARNING

Do not touch the handlebar grip until the rubber adhesive has fully dried.

TIP .

There should be 1–3 mm (0.04–0.12 in) of clearance "a" between the handlebar grip and the grip end.




- 5. Install:
- Handlebar switch (left) "1"


Handlebar switch screw (left) 2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)

TIP .

Align the projection "a" on the left handlebar switch with the hole "b" in the handlebar.




- 6. Install:
 - Throttle grip "1"
 - Throttle cables
 - Grip end (right)
 - Throttle cable housings "2"



HANDLEBAR

TIP __

- Lubricate the end of the throttle cables and the inside of the throttle grip with a thin coat of lith-ium-soap-based grease.
- Align the projection "a" on the throttle cable housing with the hole "b" in the handlebar.
- There should be 1–3 mm (0.04–0.12 in) of clearance "c" between the throttle grip and the grip end.




- 7. Install:
- Handlebar switch (right) "1"


Handlebar switch screw (right) 2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)


TIP

Align the projection "a" on the right handlebar switch with the hole "b" in the handlebar.



- 8. Install:
 - Throttle cable holder 1 "1"
 - Throttle cable holder 2 "2"
- TIP_
- Make sure that the throttle cable holder 1 "1" contacts the throttle cable adjusting nut and that the open ends of the holder are pointing rearward.
- Align the throttle cable holder 2 "2" with the edge "a" of the front brake master cylinder.





- 9. Install:
- Front brake master cylinder assembly Refer to "INSTALLING THE FRONT BRAKE MASTER CYLINDER" on page 4-41.
- 10.Adjust:
 - Throttle grip free play Refer to "CHECKING THE THROTTLE GRIP OPERATION" on page 3-27.




Throttle grip free play 3.0–5.0 mm (0.12–0.20 in)


11.Adjust:


• Clutch lever free play Refer to "ADJUSTING THE CLUTCH LEVER FREE PLAY" on page 3-12.




Clutch lever free play 5.0–10.0 mm (0.20–0.39 in)









REMOVING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Stand the vehicle on a level surface.

EWA13120


Securely support the vehicle so that there is no danger of it falling over.

TIP_

Place the vehicle on a suitable stand so that the front wheel is elevated.

2. Loosen:

- Front fork cap bolt "1"
- Upper bracket pinch bolts (left and right) "2"
- Upper bracket pinch bolt (center) "3"
- Lower bracket pinch bolts "4"



EWA13640

Before loosening the upper and lower bracket pinch bolts, support the front fork leg.


DISASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- 1. Drain:
- Fork oil

TIP .


Stroke the outer tube several times while draining the fork oil.



- 2. Remove:
 - Dust seal "1"
 - Oil seal clip "2"
- (with a flathead screwdriver)

NOTICE

Do not scratch the inner tube.




- 3. Remove:
 - Front fork damper rod bolt "1"
 - Copper washer

TIP _

While holding the damper rod with the damper rod holder "2" and T-handle "3", loosen the front fork damper rod bolt.






4. Remove:

Inner tube

- a. Hold the front fork leg horizontally.
- b. Securely clamp the brake caliper bracket in a vise with soft jaws.
- c. Separate the inner tube from the outer tube by pulling the inner tube forcefully but carefully.

ECA14190

- Excessive force will damage the oil seal and bushing. A damaged oil seal or bushing must be replaced.
- Avoid bottoming the inner tube into the outer tube during the above procedure, as the oil flow stopper will be damaged.



EAS30208 CHECKING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- 1. Check:
- Inner tube
- Outer tube Bends/damage/scratches → Replace.

EWA13650


Do not attempt to straighten a bent inner tube as this may dangerously weaken it.

2. Measure:

1

Fork spring free length "a"
 Out of specification → Replace.

Fork spring free length 345.4 mm (13.60 in) Limit 331.6 mm (13.06 in)



- 3. Check:
 - Damper rod Damage/wear → Replace.
 Obstruction → Blow out all of the oil passages with compressed air.
- Oil flow stopper
 Damage → Replace.

NOTICE

- The front fork leg has a built-in damper adjusting rod and a very sophisticated internal construction, which are particularly sensitive to foreign material.
- When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.

EAS30209

ASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- Make sure the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.


TIP

- When assembling the front fork leg, be sure to replace the following parts:
 - -Inner tube bushing
 - -Outer tube bushing
 - –Oil seal
 - -Oil seal clip
 - -Dust seal
 - –O-ring
- Before assembling the front fork leg, make sure all of the components are clean.
- 1. Install:
 - Oil flow stopper spring "1"
 - Oil flow stopper "2"
 - Damper rod ring "3"

- Damper rod "4"
- Rebound spring
- Inner tube bushing "5" New
- a. Install the oil flow stopper spring into the oil flow stopper.

TIP_


Make sure that the oil flow stopper spring is installed securely into the grooves "a" in the oil flow stopper.



b. Install the damper rod ring onto the damper rod.

TIP ____

Fit the damper rod ring into the damper rod groove so that the side of the ring with the projections is facing in the direction shown in the illustration.




c. Install the damper rod and rebound spring to the inner tube.

TIP.

Allow the damper rod to slide slowly down the inner tube until it protrudes from the bottom of the inner tube. Be careful not to damage the inner tube.



d. Install the oil flow stopper and inner tube bushing onto the inner tube "6".



- _____
- 2. Lubricate:
 - Inner tube's outer surface


- commended oil amaha fork oil 10WT
- 3. Install:
- Inner tube (in the outer tube)
- 4. Install:
- Copper washer New
- Front fork damper rod bolt
- 5. Tighten:
 - Front fork damper rod bolt "1"

Front fork damper rod bolt 30 Nm (3.0 m·kgf, 22 ft·lbf) LOCTITE®

TIP


While holding the damper rod assembly with the damper rod holder "2" and T-handle "3", tighten the front fork damper rod bolt.





- 6. Install:
- Outer tube bushing "1" New
- Washer "2" (with the fork seal driver attachment "3" and fork seal driver weight "4")





- 7. Install:
 - Oil seal "1" New (with the fork seal driver attachment "2" and fork seal driver weight "3")

ECA14220

Make sure the numbered side of the oil seal faces up.


TIP_

- Before installing the oil seal, lubricate its lips with lithium-soap-based grease.
- Lubricate the outer surface of the inner tube with fork oil.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag to protect the oil seal during installation.



Fork seal driver weight 90890-01367 Replacement hammer YM-A9409-7 Fork seal driver attachment (ø41) 90890-01381 Replacement 41 mm YM-A5142-2






8. Install:

Oil seal clip "1" New

TIP _


Adjust the oil seal clip so that it fits into the outer tube's groove.



- 9. Install:
 - Dust seal "1" New (with the fork seal driver weight "2")



Fork seal driver weight 90890-01367 Replacement hammer YM-A9409-7



10.Fill:

• Front fork leg

(with the specified amount of the recommended fork oil)



Quantity 403.0 cm³ (13.63 US oz, 14.21 Imp.oz) Recommended oil Fork oil 10W or equivalent

11.Measure:

• Front fork leg oil level "a"


(from the top of the inner tube, with the outer tube fully compressed and without the fork spring)

Out of specification \rightarrow Correct.

Level 162.0 mm (6.4 in)

TIP.

- While filling the front fork leg, keep it upright.
- After filling, slowly pump the front fork leg up and down to distribute the fork oil.



12.Install:

- Fork spring
- Spring seat
- Spacer
- Front fork cap bolt

(along with the O-ring New)

TIP _


- Before installing the front fork cap bolt, lubricate its O-ring with grease.
- Temporarily tighten the front fork cap bolt.
- Tighten the front fork cap bolt specified torque, when installing the front fork with upper bracket.

13.Install:

• Protector "1"

TIP __

Align the projection "a" on the protector with the slot "b" in the outer tube.



EAS30210 INSTALLING THE FRONT FORK LEGS


The following procedure applies to both of the front fork legs.


- 1. Install:
 - Front fork leg Temporarily tighten the lower bracket pinch bolts.
- 2. Install:
- Upper bracket "1"

TIP _

Before installing the upper bracket, remove any grease from the outer surface "a" of the cap nut.

• Make sure the inner tube end is flush with the top of the upper bracket.





3. Tighten:

- Lower bracket pinch bolts
- Upper bracket pinch bolt (center)
- Upper bracket pinch bolts (left and right)
- Front fork cap bolt



4. Install:


- Front fender brackets "1"
- Front fender



Front fender bracket bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Front fender bolt 9 Nm (0.9 m·kgf, 6.5 ft·lbf)

TIP _

Install the front fender bracket to the front fork with the arrow mark "a" on the bracket pointing forward.



STEERING HEAD


4

Front brake hose holder bracket

Removing	the lower bracket			
* Loosen the cap nut completely, and then tighten it to specification.				
Order	Job/Parts to remove	Q'ty	Remarks	
	Headlight assembly		Refer to "GENERAL CHASSIS (2)" on page 4-3.	
	Handlebar	+	Refer to "HANDLEBAR" on page 4-65.	
	Front fork legs	+	Refer to "FRONT FORK" on page 4-70.	
1	Front brake hose lower holder	1	1	
2	Front brake hose upper holder	1		
3	Headlight bracket	1	1	

1

STEERING HEAD



REMOVING THE LOWER BRACKET

1. Stand the vehicle on a level surface.

Securely support the vehicle so that there is no danger of it falling over.

- 2. Remove:
- Cap nut "1"
- Lower bracket

WARNING


Securely support the lower bracket so that there is no danger of it falling.

TIP_

Remove the cap nut with the steering nut wrench "2".



Steering nut wrench 90890-01403 Exhaust flange nut wrench YU-A9472



EAS30214

CHECKING THE STEERING HEAD

- 1. Wash:
- Bearing
- Bearing races



- Recommended cleaning solvent Kerosene
- 2. Check:
- Bearing
- Bearing races

Damage/pitting \rightarrow Replace the bearings and bearing races as a set.

- 3. Replace:
 - Bearing
 - Bearing races

a. Remove the bearing races from the steering head pipe "1" with a long rod "2" and hammer.


- b. Remove the bearing race "3" from the lower bracket with a floor chisel "4" and hammer.
- c. Install a new dust seal and new bearing races.

ECA14270

If the bearing race is not installed properly, the steering head pipe could be damaged.

TIP

- Always replace the bearings and bearing races as a set.
- Whenever the steering head is disassembled, replace the dust seal.



- 4. Check:
 - Lower bracket (along with the steering stem) Bends/cracks/damage \rightarrow Replace.

EAS30216 INSTALLING THE STEERING HEAD


- 1. Lubricate:
 - Upper bearing
 - Lower bearing



- 2. Install:
 - Lower bracket cap "1" (onto the lower bracket "2")

TIP_


Face the holes "a" in the lower bracket cap rearward.



- 3. Install:
 - Lower bracket
 - Cap nut "1" Refer to "CHECKING AND ADJUSTING THE STEERING HEAD" on page 3-19.

TIP.

Before installing the cap nut, remove any grease from the contact surfaces "a" between the cap nut and the bearing cover and from the threads "b" of the lower bracket and cap nut.




- 4. Install:
 - Front brake hose holder bracket "1"
 - Headlight bracket
 - Front brake hose upper holder "2"
 - Front brake hose lower holder "3"

Front brake hose holder bracket bolt 3.8 Nm (0.38 m·kgf, 2.8 ft·lbf) Front brake hose lower holder bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

TIP __

• Make sure that the front brake hose holder bracket contacts the projection "a" on the lower bracket.

• Make sure that the projection "b" on the front brake hose lower holder fits into the hole in the front brake hose upper holder.




REAR SHOCK ABSORBER ASSEMBLY Removing the rear shock absorber assembly 🔌 7 Nm (0.7 m·kgf, 5.1 ft·lbf) 1 @ ₀ Ø G 0 🔌 44 Nm (4.4 m•kgf, 32 ft•lbf) 3 5 🔌 40 Nm (4.0 m·kgf, 29 ft·lbf) il Ø0 Ø 4 2 New New R Ø 9 New 8 Ø 0 New 8 New C New Ro_O 🔌 40 Nm (4.0 m·kgf, 29 ft·lbf) 1.5

EAS20036

Order	Job/Parts to remove	Q'ty	Remarks
1	Drive chain guard	1	
2	Rear shock absorber assembly nut/bolt (front side)	1/1	
3	Spacer	1	
4	Rear shock absorber assembly nut/bolt (rear side)	1/1	
5	Rear shock absorber assembly	1	
6	Relay arm rubber cover	1	
7	Spacer	1	
8	Oil seal	2	
9	Bearing	1	

REAR SHOCK ABSORBER ASSEMBLY



EAS30826 HANDLING THE REAR SHOCK ABSORBER EWA13740

This rear shock absorber contains highly compressed nitrogen gas. Before handling the rear shock absorber, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber.


- Do not tamper or attempt to open the rear shock absorber.
- Do not subject the rear shock absorber to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber in any way. Rear shock absorber damage will result in poor damping performance.

EAS30729

DISPOSING OF A REAR SHOCK ABSORBER

Gas pressure must be released before disposing of a rear shock absorber. To release the gas pressure, drill a 2–3 mm (0.08– 0.12 in) hole through the rear shock absorber at a point 20–25 mm (0.79–0.98 in) from its end as shown.

Wear eye protection to prevent eye damage from released gas or metal chips.



REMOVING THE REAR SHOCK ABSORBER ASSEMBLY

1. Stand the vehicle on a level surface.

Securely support the vehicle so that there is no danger of it falling over.

TIP _

Place the vehicle on a suitable stand so that the rear wheel is elevated.

CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

- 1. Check:
- Rear shock absorber rod Bends/damage \rightarrow Replace the rear shock absorber assembly.
- Rear shock absorber assembly Gas leaks → Replace the rear shock absorber assembly.
- Spring Damage/wear → Replace the rear shock absorber assembly.
- Bolts Bends/damage/wear \rightarrow Replace.

CHECKING THE RELAY ARM

- 1. Check:
- Relay arm
- Damage/wear \rightarrow Replace.
- 2. Check:
 - Bearings
 - Oil seals
 Damage/pitting → Replace.
- 3. Check:
- Collars

 $\mathsf{Damage/scratches} \to \mathsf{Replace}.$

EAS30222

INSTALLING THE RELAY ARM

- 1. Lubricate:
- Spacers
- Bearings



Recommended lubricant Lithium-soap-based grease

- 2. Install:
- Bearings "1"
- Oil seals "2" New
- Spacers "3"
 - (to the relay arm "4")




Installed depth "a" 4.0 mm (0.16 in) Installed depth "b" More than 0.3 mm (0.01 in)

REAR SHOCK ABSORBER ASSEMBLY

TIP __

When installing the oil seals to the relay arm, face the character stamps of the oil seals outside.




- A. Left side
- B. Right side

3. Install:


- Relay arm "1"
- Relay arm rubber cover "2" (to the relay arm)

TIP .

Make sure that the portion "a" of the relay arm rubber cover is positioned on top of the swing-arm.



- 4. Tighten:
- Connecting arm nut
- Relay arm nut




INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY

- 1. Install:
- Rear shock absorber assembly "1"

TIP _

Make sure that the label "a" on the rear shock absorber assembly faces down.



- 2. Tighten:
 - Rear shock absorber assembly nut (front side)
 - Rear shock absorber bolt (rear side)

Rear shock absorber assembly bolt (front side) 44 Nm (4.4 m·kgf, 32 ft·lbf) Rear shock absorber assembly nut (rear side) 40 Nm (4.0 m·kgf, 29 ft·lbf)

SWINGARM

3

4

5

6

7

8

Sidestand switch coupler


Footrest assembly (left)

Sidestand

Washer

Pivot shaft

Pivot shaft nut



1

1

1


1

1

1

Disconnect.

SWINGARM



REMOVING THE SWINGARM

1. Stand the vehicle on a level surface.

Securely support the vehicle so that there is no danger of it falling over.

TIP.

Place the vehicle on a suitable stand so that the rear wheel is elevated.


- 2. Measure:
 - Swingarm side play
 - Swingarm vertical movement

a. Measure the tightening torque of the pivot shaft nut.



Pivot shaft nut 110 Nm (11 m·kgf, 80 ft·lbf)

- b. Check the swingarm side play "A" by moving the swingarm from side to side.
 If the swingarm has side-to-side play, check the collars, bearings, and dust covers.
- c. Check the swingarm vertical movement "B" by moving the swingarm up and down. If the swingarm vertical movement is not smooth or if there is binding, check the pivot shaft, collars, bearings, and dust covers.



- 3. Remove:
- Swingarm


EAS30227

CHECKING THE SWINGARM

- 1. Check:
 - Swingarm
 Bondo/arooko/domogo
- Bends/cracks/damage \rightarrow Replace. 2. Check:
- Pivot shaft Roll the pivot shaft on a flat surface. Bends \rightarrow Replace.

EWA13770 WARNING


Do not attempt to straighten a bent pivot shaft.



- 3. Wash:
 - Pivot shaft
 - Dust covers
 - Collars
 - Bearings
 - Washer

Recommended cleaning solvent Kerosene

- 4. Check:
 - Dust covers "1"
 - Oil seals "2"
 - Damage /wear \rightarrow Replace.
 - Bearings "3" Damage/pitting → Replace.
 - Collars "4" Damage/scratches \rightarrow Replace.



CHECKING THE CONNECTING ARM

- 1. Check:
- Connecting arm
- Damage/wear \rightarrow Replace.
- 2. Check:
 - Bearings
 - Oil seals
 - $\mathsf{Damage/pitting} \to \mathsf{Replace}.$


SWINGARM

- 3. Check:
 - Collar

Damage/scratches \rightarrow Replace.

EAS31114 INSTALLING THE CONNECTING ARM


- 1. Lubricate:
- Spacers
- Bearings



- 2. Install:
- Bearings "1"
- Oil seals "2" New (to the connecting arm "3")

TIP.

When installing the oil seals to the connecting arm, face the character stamp of the oil seals outside.



- A. Left side
- B. Right side




Installed depth "a" 3.5–4.5 mm (0.14–0.18 in) Installed depth "b" 8.0–9.0 mm (0.31–0.35 in)

- 3. Install:
 - Spacer
 - Connecting arm
 - Connecting arm bolt "1"
 - Connecting arm nut

Connecting arm nut (frame side) 52 Nm (5.2 m·kgf, 38 ft·lbf)


TIP.

Align two flat sides "a" of the connecting arm bolt with the projections "b" on the frame.




EAS30228 INSTALLING THE SWINGARM

- 1. Lubricate:
 - Collar
 - Pivot shaft
 - Bearings




- 2. Install:
- Bearings "1"
- Oil seals "2" New (to the swingarm)




TIP -

Install the oil seals to the swingarm so that they are facing in the directions shown in the illustration.




- A. Left side
- B. Right side
- 3. Adjust:
 - Drive chain slack Refer to "ADJUSTING THE DRIVE CHAIN SLACK" on page 3-17.

Drive chain slack 51.0–56.0 mm (2.01–2.20 in)



CHAIN DRIVE



REMOVING THE DRIVE CHAIN

1. Stand the vehicle on a level surface.

WARNING

Securely support the vehicle so that there is no danger of it falling over.

TIP

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- 2. Remove:
- Drive chain "1"

TIP_


Push the rear wheel forward and remove the drive chain from the rear wheel sprocket. Refer to "ADJUSTING THE DRIVE CHAIN SLACK" on page 3-17.

a. Loosen the pivot shaft nut "2" so that the engaged thread length on the pivot shaft "3" is 3–4 ridges.


ECA21200

Make sure that the pivot shaft nut does not come off the pivot shaft.


b. Tap the pivot shaft nut to push the pivot shaft to the left.



c. Remove the footrest bracket bolts "4".




d. Move the footrest bracket "5" rearward, and then remove the drive chain.



EAS31115

REMOVING THE DRIVE SPROCKET

1. Straighten the drive sprocket nut ribs "a".



- 2. Loosen:
- Drive sprocket nut

TIP ___

Loosen the drive sprocket nut while pressing the brake pedal.

CHECKING THE DRIVE CHAIN

- 1. Measure:
- 15-link section "a" of the drive chain Out of specification → Replace the drive chain.




15-link length limit 239.3 mm (9.42 in)


- a. Measure the length "b" between the inner sides of the pins and the length "c" between the outer sides of the pins on a 15-link section of the drive chain as shown in the illustration.
- b. Calculate the length "a" of the 15-link section of the drive chain using the following formula. Drive chain 15-link section length "a" = (length "b" between pin inner sides + length "c" between pin outer sides)/2

TIP _


• When measuring a 15-link section of the drive chain, make sure that the drive chain is taut.

• Perform this procedure 2–3 times, at a different location each time.





- 2. Check:
 - Drive chain







- 3. Clean:
- Drive chain
- a. Wipe the drive chain with a clean cloth.
- b. Put the drive chain in kerosene and remove
- b. Put the drive chain in kerosene and remove any remaining dirt.
- c. Remove the drive chain from the kerosene and completely dry it.

NOTICE


• This motorcycle has a drive chain with small rubber O-rings "1" between the drive chain side plates. Never use high-pressure water or air, steam, gasoline, certain solvents (e.g., benzine), or a coarse brush to clean the drive chain. High-pressure methods could force dirt or water into the drive chain's internals, and solvents will deteriorate the O-rings. A coarse brush can also damage the O-rings. Therefore, use only kerosene to clean the drive chain.

• Do not soak the drive chain in kerosene for more than ten minutes, otherwise the O-rings can be damaged.





- 4. Check:
- O-rings "1"
 - Damage \rightarrow Replace the drive chain.
- Drive chain rollers "2"
- Damage/wear → Replace the drive chain. • Drive chain side plates "3"
- Damage/wear/cracks \rightarrow Replace the drive chain.



- 5. Lubricate:
 - Drive chain

CHAIN DRIVE




Recommended lubricant Chain lubricant suitable for Oring chains

CHECKING THE DRIVE SPROCKET

- 1. Check:
- Drive sprocket

More than 1/4 tooth "a" wear \rightarrow Replace the drive sprocket, drive chain, and rear wheel sprocket as a set.

Bent teeth \rightarrow Replace the drive sprocket, drive chain, and rear wheel sprocket as a set.



- b. Correct
- 1. Drive chain roller
- 2. Drive sprocket

EAS30232

CHECKING THE REAR WHEEL SPROCKET

Refer to "CHECKING AND REPLACING THE REAR WHEEL SPROCKET" on page 4-25.

EAS30233

CHECKING THE REAR WHEEL DRIVE HUB Refer to "CHECKING THE REAR WHEEL

DRIVE HUB" on page 4-24.

EAS31116

INSTALLING THE DRIVE SPROCKET


- 1. Install:
 - Drive sprocket "1"
 - Washer "2"
 - Drive sprocket nut "3" New



Drive sprocket nut 95 Nm (9.5 m·kgf, 69 ft·lbf)

TIP_

- While applying the rear brake, tighten the drive sprocket nut.
- Install washer with the "OUT" mark "a" facing out.
- Stake the drive sprocket nut at cutouts "b" in the drive axle.




INSTALLING THE DRIVE CHAIN


- 1. Install:
 - Drive chain "1"


TIP _

Make sure that the drive chain is positioned above the portion "a" of the footrest bracket "2".





- 2. Tighten:
- Footrest bracket bolts "1"






Drive chain





CHAIN DRIVE


4. Fit the space "a" between the side plates of the drive chain "1" onto the rib "b" on the drive chain guide "2".



- 5. Install:
 - Shift arm "1"
 - Shift rod joint
 - Shift rod
 - Shift rod locknuts

TIP_


Before installing, make sure to align the mark "a" of the shift shaft with the punch mark "b" of the shift arm.



- 6. Measure:
 - Installed shift rod length "a" and "b" Incorrect → Adjust.



Installed length "a" 217.5–219.5 mm (8.56–8.64 in) Installed length "b" 35.0–36.0 mm (1.38–1.42 in)



- 7. Adjust:
- Installed shift rod length


a. Loosen both locknuts "1".

TIP

The shift rod locknut (shift pedal side) has lefthand threads.

b. Turn the shift rod "2" in direction "a" or "b" to obtain the correct shift pedal position.


Direction "a" Installed shift rod length increases. Direction "b" Installed shift rod length decreases.




c. Tighten both locknuts.

TIP .

The shift rod locknut (shift pedal side) has lefthand threads.



d. Make sure the installed shift rod length is within specification. Make sure that the installed shift rod length is within specification and that the angle between the shift arm and the shift rod is 90°.



- 8. Adjust:
- Drive chain slack Refer to "ADJUSTING THE DRIVE CHAIN SLACK" on page 3-17.



Drive chain slack 51.0–56.0 mm (2.01–2.20 in)

ECA13550

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.

ENGINE

ENGINE INSPECTION	5-1
MEASURE THE COMPRESSION PRESSURE	5-1
ADJUSTING THE EXHAUST GAS VOLUME	5-2
CHECKING THE CYLINDER HEAD BREATHER HOSE	5-2
ENGINE REMOVAL	
REMOVING THE ENGINE	5-8
INSTALLING THE ENGINE	5-8
CAMSHAFTS	F 44
REMOVING THE CAMSHAFTS	
CHECKING THE CAMSHAFTS	
CHECKING THE CAMSHAFT SPROCKETS	
CHECKING THE TIMING CHAIN TENSIONER	
CHECKING THE DECOMPRESSION SYSTEM	
INSTALLING THE CAMSHAFTS	
INSTALLING THE CYLINDER HEAD COVER	5-22
CYLINDER HEAD	E 00
REMOVING THE CYLINDER HEAD	
CHECKING THE TIMING CHAIN GUIDES	
CHECKING THE CYLINDER HEAD	
INSTALLING THE CYLINDER HEAD	5-27
VALVES AND VALVE SPRINGS	
REMOVING THE VALVES	
CHECKING THE VALVES AND VALVE GUIDES	
CHECKING THE VALVE SEATS	
CHECKING THE VALVE SPRINGS	
CHECKING THE VALVE LIFTERS	
INSTALLING THE VALVES	
GENERATOR AND STARTER CLUTCH	5-36
REMOVING THE GENERATOR	5-39
REMOVING THE STARTER CLUTCH	
CHECKING THE STARTER CLUTCH	
CHECKING THE TORQUE LIMITER	
INSTALLING THE STARTER CLUTCH	
INSTALLING THE GENERATOR	
ELECTRIC STARTER	
CHECKING THE STARTER MOTOR	5-44
ASSEMBLING THE STARTER MOTOR	5-45
INSTALLING THE STARTER MOTOR	5-45

CLUTCH	5-46
REMOVING THE CLUTCH	5-50
CHECKING THE FRICTION PLATES	5-51
CHECKING THE CLUTCH PLATES	5-51
CHECKING THE CLUTCH SPRINGS	5-51
CHECKING THE CLUTCH HOUSING	5-52
CHECKING THE CLUTCH BOSS	5-52
CHECKING THE PRESSURE PLATE	5-52
CHECKING THE PRIMARY DRIVE GEAR	5-52
CHECKING THE PRIMARY DRIVEN GEAR	5-52
CHECKING THE PULL LEVER SHAFT AND PULL ROD	5-52
INSTALLING THE CLUTCH	5-53
	F F O
CHECKING THE STOPPER LEVER	
INSTALLING THE SHIFT SHAFT	5-57
OIL PUMP	5-58
CHECKING THE SPROCKET AND CHAIN	
CHECKING THE OIL PUMP	
CHECKING THE RELIEF VALVE	
ASSEMBLING THE OIL PUMP	
INSTALLING THE OIL PUMP	
CHECKING THE OIL STRAINER	
INSTALLING THE OIL PAN	5-63
CRANKCASE	5-64
DISASSEMBLING THE CRANKCASE	
CHECKING THE CRANKCASE	
ASSEMBLING THE CRANKCASE	
INSTALLING THE OIL PRESSURE SWITCH	
CONNECTING RODS AND PISTONS	
REMOVING THE CONNECTING RODS AND PISTONS	
CHECKING THE CYLINDER AND PISTON	
CHECKING THE PISTON RINGS	
CHECKING THE PISTON PIN	
CHECKING THE CONNECTING RODS	
INSTALLING THE CONNECTING ROD AND PISTON	5-77

CRANKSHAFT AND BALANCER SHAFT	5-83 5-83 5-83 5-85 5-87
TRANSMISSION REMOVING THE TRANSMISSION CHECKING THE SHIFT FORKS CHECKING THE SHIFT DRUM ASSEMBLY CHECKING THE TRANSMISSION ASSEMBLING THE MAIN AXLE AND DRIVE AXLE INSTALLING THE TRANSMISSION	5-93 5-93 5-93 5-94 5-94

ENGINE INSPECTION

EAS30249


MEASURE THE COMPRESSION PRESSURE

The following procedure applies to all of the cylinders.

TIP _

Insufficient compression pressure will result in a loss of performance.

- 1. Measure:
 - Valve clearance Out of specification → Adjust. Refer to "ADJUSTING THE VALVE CLEAR-ANCE" on page 3-5.
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Remove:
- Seat Refer to "GENERAL CHASSIS (1)" on page 4-1.
- Fuel tank center cover
- Air scoops Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Fuel tank Refer to "FUEL TANK" on page 7-1.
- 4. Disconnect:
- Ignition coil couplers "1"
- 5. Remove:
 - Ignition coils "2"



- 6. Remove:
- Spark plugs
- ECA13340


Before removing the spark plugs, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinders.

- 7. Install:
 - Extension "1"
 - Compression gauge "2"



Extension 90890-04136 Compression gauge 90890-03081 Engine compression tester

YU-33223



- 8. Measure:
 - Compression pressure Out of specification → Refer to steps (c) and (d).

TIP _

Due to the engine characteristics, the compression pressure is different for cylinder #1 and cylinder #2.

Compression pressure (#1 cylinder) 770–990 kPa/355 r/min (7.7–9.9 kgf/cm²/355 r/min, 109.5–140.8 psi/355 r/min) Compression pressure (#2 cylinder) 690–880 kPa/355 r/min (6.9–8.8 kgf/cm²/355 r/min, 98.1–125.2 psi/355 r/min)

- a. Turn the main switch to "ON".
- b. With the throttle wide open, crank the engine until the reading on the compression gauge stabilizes.

To prevent sparking, ground all spark plug leads before cranking the engine.

TIP _

The difference in compression pressure between cylinders should not exceed 100 kPa (1 kg/cm², 14 psi). c. If the compression pressure is above the maximum specification, check the cylinder head, valve surfaces and piston crown for carbon deposits.

Carbon deposits \rightarrow Eliminate.

d. If the compression pressure is below the minimum specification, pour a teaspoonful of engine oil into the spark plug bore and measure again.

Refer to the following table.

Compression pressure (with oil applied into the cylinder)			
Reading	Diagnosis		
Higher than without oil	Piston ring(s) wear or damage \rightarrow Repair.		
Same as without oil	Pistons, valves, cylinder head gasket or piston ring(s) possibly defec- tive \rightarrow Repair.		

- 9. Install:
- Spark plugs
- Ignition coils

Spark plug 13 Nm (1.3 m·kgf, 9.4 ft·lbf)

10.Connect:

- Ignition coil couplers
- 11.Install:
- Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
- Air scoops
- Fuel tank center cover
- Fuel tank cover (left)
- Fuel tank cover (right)
- Fuel tank top cover Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Seat
 Befer t

Refer to "GENERAL CHASSIS (1)" on page 4-1.

ADJUSTING THE EXHAUST GAS VOLUME

- Be sure to set the CO density level to standard, and then adjust the exhaust gas volume.
- To adjust the exhaust gas volume, use the CO adjustment mode of the Yamaha diagnostic tool. For more information, refer to the operation manual of the Yamaha diagnostic tool.

1. Connect the Yamaha diagnostic tool to the coupler. For information about connecting the Yamaha diagnostic tool, refer to "YAMAHA DIAGNOSTIC TOOL" on page 8-36.


CHECKING THE CYLINDER HEAD BREATHER HOSE

1. Remove:

- Seat Refer to "GENERAL CHASSIS (1)" on page 4-1.
- Fuel tank top cover
- Fuel tank cover (left)
- Fuel tank cover (right)
- Fuel tank center cover Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
- 2. Check:
- Cylinder head breather hose "1" Cracks/damage \rightarrow Replace. Loose connection \rightarrow Connect properly.

NOTICE


Make sure the cylinder head breather hose is routed correctly.





- 3. Install:
- Fuel tank
 - Refer to "FUEL TANK" on page 7-1.
- Fuel tank center cover
- Fuel tank cover (left)
- Fuel tank cover (right)
- Fuel tank top cover Refer to "GENERAL CHASSIS (3)" on page 4-5.
- Seat


Refer to "GENERAL CHASSIS (1)" on page 4-1.


ENGINE REMOVAL













REMOVING THE ENGINE

TIP_


Pass a suitable rod "1" through the holes in the brackets of the passenger footrests "2" and secure the rod to support the vehicle.



- 1. Remove:
- Engine mounting bolt (rear lower side) "1"
- a. Loosen the pivot shaft nut "2", and then remove the footrest bracket bolts "3".



- A. Left side
- B. Right side
- b. Move the footrest bracket "4" rearward, and then loosen the engine mounting bolt (rear lower side).



2. Remove:


"2".

- Engine mounting bolt (rear upper side) "1"
- a. Remove the rear brake hose joint bracket bolt

b. Move the rear brake hose joint bracket "3" slightly rearward, and then remove the engine mounting bolt (rear upper side).

NOTICE

Do not move the rear brake hose joint bracket more than necessary. Otherwise, the brake hoses could bend and break.




INSTALLING THE ENGINE

- 1. Install: (for models with a stamped "1" mark on the frame)
- Plate "1"

TIP _

- Install the plate only for frames that have a stamped "1" mark at the location "a".
- Fit the projections "b" on the plate into the slots "c" in the frame.



- 2. Install:
- Engine "2"
- 3. Install:
 - Engine mounting bolt (rear upper side) "3"
 - Engine mounting nut (rear upper side) "4"
 - Engine mounting bolt (rear lower side) "5"
 - Engine mounting nut (rear lower side) "6"
 - Engine mounting bolt (left front side) "7"
 - Engine mounting bolt (right front side) "8"
 - Engine mounting bolt (right upper side) "9"
 - Engine bracket bolts (right) "10"
 - Engine bracket (right) "11"

TIP_

Temporarily tighten the bolts and nuts.

- 4. Tighten:
 - Engine mounting nut (rear upper side) "4"
 - Engine mounting nut (rear lower side) "6"
 - Engine mounting bolt (left front side) "7"

Engine mounting nut (rear upper side) 55 Nm (5.5 m·kgf, 40 ft·lbf) Engine mounting nut (rear lower side) 55 Nm (5.5 m·kgf, 40 ft·lbf) Engine mounting bolt (left front side) 75 Nm (7.5 m·kgf, 54 ft·lbf)


- 5. Install:
 - Engine mounting bolt (left upper side) "12"
 - Engine bracket bolts (left) "13"
 - Engine bracket (left) "14"

TIP


Temporarily tighten the bolts.

- 6. Tighten:
 - Engine mounting bolt (left upper side) "12"
 - Engine mounting bolt (right front side) "8"
 - Engine mounting bolt (right upper side) "9"
 - Engine bracket bolts (right) "10"
 - Engine bracket bolts (left) "13"

Engine mounting bolt (left upper side) 55 Nm (5.5 m·kgf, 40 ft·lbf) Engine mounting bolt (right front side) 75 Nm (7.5 m·kgf, 54 ft·lbf) Engine mounting bolt (right upper side) 55 Nm (5.5 m·kqf, 40 ft·lbf) Engine bracket bolt (right) 25 Nm (2.5 m·kgf, 18 ft·lbf) Engine bracket bolt (left) 25 Nm (2.5 m·kgf, 18 ft·lbf)




- 7. Install:
- Rear brake hose joint bracket "1"
- Rear brake hose joint bracket bolt "2"



7 Nm (0.7 m·kgf, 5.1 ft·lbf)

TIP.

Make sure that the rear brake hose joint bracket contacts the projection "a" on the frame.




- 8. Install:
- Clutch cable guide "1"




Clutch cable guide bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)


TIP.

Make sure that the projection "a" on the clutch cable guide contacts the frame.




CAMSHAFTS






CAMSHAFTS




CAMSHAFTS




REMOVING THE CAMSHAFTS

- 1. Remove:
- Crankshaft end cover "1"
- Timing mark accessing bolt "2"




- 2. Align:
- Mark "a" on the generator rotor (with the slot "b" in the generator rotor cover)
- ******
- a. Turn the crankshaft counterclockwise.
- b. When piston #1 is at TDC on the exhaust stroke, align the TDC mark "a" on the generator rotor with the slot "b" in the generator rotor cover.



- 3. Remove:
- Timing chain tensioner "1"

- Timing chain tensioner gasket
- *****
- a. Insert the hexagon wrench "2" (part No.: 1WS-12228-00) into the timing chain tensioner.
- b. Remove the timing chain tensioner.




......

- 4. Remove:
- Intake camshaft cap "1"
- Exhaust camshaft cap "2"

ECA13720


To prevent damage to the cylinder head, camshafts or camshaft caps, loosen the camshaft cap bolts in stages and in a crisscross pattern, working from the outside in.



- 5. Remove:
 - Intake camshaft "1"
 - Exhaust camshaft "2"

TIP.

To prevent the timing chain from falling into the crankcase, fasten it with a wire "3".




- 6. Remove:
- Intake camshaft sprocket "1"

TIP

While holding the intake camshaft sprocket with the rotor holding tool "2", loosen the intake camshaft sprocket bolts.




CAMSHAFTS



- 7. Remove:
- Exhaust camshaft sprocket "1"

TIP .

While holding the exhaust camshaft with a suitable tool, loosen the exhaust camshaft sprocket bolts.





EAS30257

CHECKING THE CAMSHAFTS

- 1. Check:
- Camshaft lobes Blue discoloration/pitting/scratches \rightarrow Replace the camshaft.
- 2. Measure:
- Camshaft lobe dimensions "a" and "b"
 Out of specification → Replace the camshaft.

Camshaft lobe dimensions Lobe height (Intake) 35.610-35.710 mm (1.4020-1.4059 in) Limit 35.510 mm (1.3980 in) Base circle diameter (Intake) 27.950-28.050 mm (1.1004-1.1043 in) Limit 27.850 mm (1.0965 in) Lobe height (Exhaust) 35.710-35.810 mm (1.4059-1.4098 in) Limit 35.610 mm (1.4020 in) Base circle diameter (Exhaust) 27.950-28.050 mm (1.1004-1.1043 in) Limit 27.850 mm (1.0965 in)






- 3. Measure:
 - Camshaft runout

Out of specification \rightarrow Replace.



Camshaft runout limit 0.030 mm (0.0012 in)




- 4. Measure:
 - Camshaft-journal-to-camshaft-cap clearance Out of specification → Measure the camshaft journal diameter.



Camshaft-journal-to-camshaftcap clearance 0.028–0.062 mm (0.0011–0.0024 in)

- a. Install the camshafts into the cylinder head (without the camshaft caps).
- b. Position a strip of Plastigauge® "1" onto the camshaft journal as shown.




c. Install the dowel pins and camshaft caps.

- Tighten the camshaft cap bolts in stages and in a crisscross pattern, working from the inner caps out.
- Do not turn the camshaft when measuring the camshaft journal-to-camshaft cap clearance with the Plastigauge®.





Exhaust camshaft cap bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf) Intake camshaft cap bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

d. Remove the camshaft caps, and then measure the width of the Plastigauge® "1".




- 5. Measure:
 - Camshaft journal diameter "a" Out of specification → Replace the camshaft. Within specification → Replace the cylinder head and camshaft caps as a set.





CHECKING THE CAMSHAFT SPROCKETS

- 1. Check:
 - Camshaft sprocket More than 1/4 tooth wear "a" → Replace the camshaft sprockets and timing chain as a set.




- a. 1/4 tooth
- b. Correct
- 1. Timing chain
- 2. Camshaft sprocket

CHECKING THE TIMING CHAIN TENSIONER 1. Check:


- Timing chain tensioner Cracks/damage/rough movement \rightarrow Replace.
- *****
- a. Lightly press the timing chain tensioner rod into the timing chain tensioner housing by hand.

TIP.

While pressing the timing chain tensioner rod, wind it counterclockwise with a hexagon wrench "1" (Parts No.: 1WS-12228-00) until it stops.



b. Make sure that the timing chain tensioner rod moves in and out of the timing chain tensioner housing smoothly. If there is rough movement, replace the timing chain tensioner.




EAS30267

CHECKING THE DECOMPRESSION SYSTEM 1. Check:

- Decompression system

TIP .

- Check that the decompressor lever pins "1" projects from the camshaft.
- Check that the decompressor cams "2" and decompressor lever pins "1" moves smoothly.




INSTALLING THE CAMSHAFTS

1. Align:

EAS30269

- Mark "a" on the generator rotor (with the slot "b" in the generator rotor cover)
- *****
- a. Turn the crankshaft counterclockwise.
- b. When piston #1 is at TDC, align the TDC mark "a" on the generator rotor with the slot "b" in the generator rotor cover.



- 2. Install:
- Intake camshaft sprocket "1"



Intake camshaft sprocket bolt 24 Nm (2.4 m·kgf, 17 ft·lbf)

ECA19980


Be sure to tighten the camshaft sprocket bolts to the specified torque to avoid the possibility of the bolts coming loose and damaging the engine.


TIP

- Make sure that the marks "a" on the intake camshaft sprocket are aligned with cam lobe #1 "b" as shown in the illustration.
- While holding the intake camshaft sprocket with the rotor holding tool "2", tighten the intake camshaft sprocket bolts in the proper tightening sequence as shown.



Rotor holding tool 90890-01235 Universal magneto and rotor holder YU-01235






- 3. Install:
 - Decompressor lever pins "1"
 - Decompressor lever #1 "2"
 - Decompressor lever #2 "3"

TIP_

- Face the cutout "a" in each decompressor lever pin toward the exhaust camshaft sprocket.
- Install the decompressor lever pins, decompressor lever #1, and decompressor lever #2 into the exhaust camshaft as shown in the illustration.



- 4. Install:
 - Exhaust camshaft sprocket "1"


Exhaust camshaft sprocket bolt 24 Nm (2.4 m·kgf, 17 ft·lbf)


NOTICE

Be sure to tighten the camshaft sprocket bolts to the specified torque to avoid the possibility of the bolts coming loose and damaging the engine.

TIP .

- Make sure that the mark "a" on the exhaust camshaft sprocket is aligned with cam lobe #1 "b" as shown in the illustration.
- While holding the exhaust camshaft with a suitable tool, tighten the exhaust camshaft sprocket bolts.
- Tighten the camshaft sprocket bolts in the tightening sequence as shown.





- 5. Install:
 - Timing chain "1" (onto the exhaust camshaft sprocket "2")
 - Exhaust camshaft
- Exhaust camshaft cap


NOTICE

- Lubricate the camshaft cap bolts with the engine oil.
- The camshaft cap bolts must be tightened evenly or damage to the cylinder head, camshaft caps, and camshafts will result.
- Do not turn the crankshaft when installing the camshaft to avoid damage or improper valve timing.

TIP_

- When installing the timing chain, start with the exhaust camshaft and be sure to keep the timing chain as tight as possible on the exhaust side.
- Make sure that the match marks "a" on the exhaust camshaft sprocket and cam lobe #1 "b" are aligned with the cylinder head edge "c" as shown in the illustration.
- Temporarily tighten the exhaust camshaft cap bolts, and then tighten the bolts to specification in a crisscross pattern.





- 6. Install:
 - Timing chain "1"
 - (onto the intake camshaft sprocket "2")
 - Intake camshaft
- Intake camshaft cap


NOTICE

- Lubricate the camshaft cap bolts with the engine oil.
- The camshaft cap bolts must be tightened evenly or damage to the cylinder head, camshaft caps, and camshafts will result.
- Do not turn the crankshaft when installing the camshaft to avoid damage or improper valve timing.

a. Install the timing chain onto intake camshaft sprocket, and then install the intake camshaft onto the cylinder head.

TIP_

Make sure the match mark "a" on the intake camshaft sprocket is aligned with the cylinder head edge "b".




b. Tighten the intake camshaft cap bolts. **TIP**


Temporarily tighten the intake camshaft cap bolts, and then tighten the bolts to specification in a crisscross pattern.

Intake camshaft cap bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

- 7. Install:
 - Timing chain tensioner
- Timing chain tensioner gasket New
- ****
- a. While lightly pressing the timing chain tensioner rod by hand, turn the timing chain tensioner rod fully counterclockwise with a hexagon wrench "1".




 Keep pressing the timing chain tensioner rod by hand, remove the hexagon wrench, and then insert the hexagon wrench "2" (Parts No.: 1WS-12228-00) into the timing chain tensioner rod.



c. Install a new timing chain tensioner gasket "3", the timing chain tensioner "4", and the timing chain tensioner bolts "5" on the cylinder block.

TIP_

Be sure to install the timing chain tensioner gasket so that the portion "a" of the gasket is protruding from the upper inner side of the timing chain tensioner.




d. Tighten the timing chain tensioner bolts to specification.



Timing chain tensioner bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

- e. Screw the hexagon wrench by hand until the timing chain tensioner rod touches the timing chain guide, and then tighten 1/4 turn by tool.
- TIP.

The timing chain tensioner rod is extended by turning the hexagon wrench clockwise.




- f. Remove the hexagon wrench.
- g. Install the timing chain tensioner cap bolt and gasket, and then tighten the timing chain tensioner cap bolt to specification.



- 8. Turn:
- Crankshaft (several turns counterclockwise)
- 9. Check:
 - Mark "a" Make sure the mark "a" on the generator rotor is aligned with the slot "b" in the generator rotor cover.
- Camshaft sprocket match mark Make sure the match marks "c" on the camshaft sprockets are aligned with the cylinder head mating surface "d".
 Out of alignment → Adjust.

Refer to the installation steps above.



10.Measure:

Valve clearance

Out of specification \rightarrow Adjust.

Refer to "ADJUSTING THE VALVE CLEAR-ANCE" on page 3-5.

- 11.Install:
- Timing mark accessing bolt "1"




Timing mark accessing bolt 15 Nm (1.5 m·kgf, 11 ft·lbf)

• Crankshaft end cover "2"



CAMSHAFTS



INSTALLING THE CYLINDER HEAD COVER 1. Install:


- Timing chain guide (top side)
- Cylinder head cover gasket "1" New (to the cylinder head cover)
- Cylinder head cover "2"





Cylinder head cover bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

TIP

- Apply Yamaha bond No.1215 "3" onto the mating surfaces of the cylinder head cover gasket and cylinder head.
- After installing the cylinder head cover gasket "1" to the cylinder head cover, cut off the "a" section.
- Make sure that the projection "b" on the cylinder head cover gasket is positioned on the exhaust side of the rib "c" on the cylinder head cover.








- A. Exhaust side
- 2. Install:
- Spark plugs
- Ignition coils "1"




park plug 13 Nm (1.3 m⋅kgf, 9.4 ft⋅lbf)

TIP_

Install the ignition coils "1" in the direction shown in the illustration.




CYLINDER HEAD




* Following the tightening order, loosen the bolt one by one, and then retighten it to the specific torque.

Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Fuel tank center cover/Air scoops		Refer to "GENERAL CHASSIS (3)" on page 4-5.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Air duct bracket		Refer to "GENERAL CHASSIS (4)" on page 4-7.
	Throttle bodies		Refer to "THROTTLE BODIES" on page 7-7.
	Footrest assembly (right)		Refer to "REAR BRAKE" on page 4-43.
	Muffler assembly		Refer to "ENGINE REMOVAL" on page 5-3.
	Oil cooler inlet hose		Disconnect. Refer to "OIL COOLER" on page 6-5.
	Radiator		Refer to "RADIATOR" on page 6-1.
	Cylinder head cover/Intake camshaft/Exhaust camshaft		Refer to "CAMSHAFTS" on page 5-11.
	Clutch cover		Refer to "CLUTCH" on page 5-46.
	Thermostat		Refer to "THERMOSTAT" on page 6-7.



Order	Job/Parts to remove	Q'ty	Remarks
1	Coolant temperature sensor coupler	1	Disconnect.
2	Coolant temperature sensor	1	
3	Engine bracket bolt (left)	2	
4	Engine mounting bolt (left upper side)	1	
5	Engine bracket (left)	1	
6	Engine bracket bolt (right)	2	
7	Engine mounting bolt (right upper side)	1	
8	Engine bracket (right)	1	




Order	Job/Parts to remove	Q'ty	Remarks
9	Engine mounting bolt (right front side)	1	
10	Engine mounting bolt (left front side)	1	
11	Timing chain bolt (right side of cylinder head)	1	
12	Timing chain guide (exhaust side)	1	
13	Cylinder head	1	
14	Cylinder head gasket	1	
15	Dowel pin	2	
16	Timing chain	1	
17	Timing chain guide (intake side)	1	

REMOVING THE CYLINDER HEAD

- 1. Remove:
 - The following procedure applies to both of the engine bracket.
 - Engine bracket bolts "1"
 - Engine mounting bolt "2"
 - Engine bracket "3"

TIP_

- Place a suitable stand under the engine.
- Loosen the bolts in the proper sequence as shown.



- 2. Remove:
 - Cylinder head bolt (M6) (×2)
 - Cylinder head bolt (M10) (×6)

TIP ____

- Loosen the bolts in the proper sequence as shown.
- Loosen each bolt 1/2 of a turn at a time. After all of the bolts are fully loosened, remove them.
 - M6 × 45 mm: "1", "2"
 - M10 × 100 mm: "3"—"8"

CHECKING THE TIMING CHAIN GUIDES

- 1. Check:
 - Timing chain guide (exhaust side)
 - Timing chain guide (intake side) Damage/wear → Replace.

EAS30277 CHECKING THE CYLINDER HEAD


- 1. Eliminate:
- Combustion chamber carbon deposits (with a rounded scraper)

TIP _


Do not use a sharp instrument to avoid damaging or scratching:

- Spark plug bore threads
- Valve seats
- 2. Check:
 - Cylinder head
 - Damage/scratches \rightarrow Replace.
 - Cylinder head water jacket Mineral deposits/rust → Eliminate.
- 3. Measure:
 - Cylinder head warpage
 - Out of specification \rightarrow Resurface the cylinder head.

Warpage limit 0.05 mm (0.0020 in)



a. Place a straightedge "1" and a thickness gauge "2" across the cylinder head.



- b. Measure the warpage.
- c. If the limit is exceeded, resurface the cylinder head as follows.
- d. Place a 400–600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.

TIP_

To ensure an even surface, rotate the cylinder head several times.

EAS30282 INSTALLING THE CYLINDER HEAD

- 1. Install:
 - Cylinder head
 - Cylinder head bolt (M10) (×6) New
 - Cylinder head bolt (M6) (×2)

TIP.

- Pass the timing chain through the timing chain cavity.
- Lubricate the cylinder head bolt (M10) threads and mating surface with engine oil.

2. Tighten:

- Cylinder head bolts "1"-"6"
- Cylinder head bolts "7", "8"




Cylinder head bolt ("1"-"6") 1st: 10 Nm (1.0 m·kgf, 7.2 ft·lbf) 2nd: 40 Nm (4.0 m·kgf, 29 ft·lbf) *3rd: 20 Nm (2.0 m·kgf, 14 ft·lbf) Specified angle 90° Cylinder head bolt ("7", "8") 10 Nm (1.0 m·kgf, 7.2 ft·lbf)


* Following the tightening order, loosen the bolt one by one, and then retighten it to the specific torque.

TIP _

Tighten the cylinder head bolts in the tightening sequence as shown and torque them in 4 stages.



VALVES AND VALVE SPRINGS



Order	Job/Parts to remove	Q'ty	Remarks
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-23.
1	Valve lifter	8	
2	Valve pad	8	
3	Valve cotter	16	
4	Valve spring retainer	8	
5	Valve spring	8	
6	Exhaust valve	4	
7	Intake valve	4	
8	Valve stem seal	8	
9	Valve spring seat	8	
10	Valve guide	8	

REMOVING THE VALVES

The following procedure applies to all of the valves and related components.

TIP.


Before removing the internal parts of the cylinder head (e.g., valves, valve springs, valve seats), make sure the valves properly seal.

1. Remove:

- Valve lifter "1"
- Valve pad "2"

TIP .

Make a note of the position of each valve lifter and valve pad so that they can be reinstalled in their original place.




- 2. Check:
 - Valve sealing

Leakage at the valve seat \rightarrow Check the valve face, valve seat, and valve seat width. Refer to "CHECKING THE VALVE SEATS" on page 5-31.

- a. Pour a clean solvent "a" into the intake and exhaust ports.
- b. Check that the valves properly seal.

TIP_

There should be no leakage at the valve seat "1".




3. Remove:

Valve cotters

TIP _

Remove the valve cotters by compressing the valve spring with the valve spring compressor "1" and the valve spring compressor attachment "2".


Valve spring compressor 90890-04019 Valve spring compressor YM-04019 Valve spring compressor attach- ment 90890-01243 Valve spring compressor adapt- er (26 mm)
er (26 mm) YM-01253-1



- 4. Remove:
 - Valve spring retainer "1"
 - Valve spring "2"
 - Valve "3"
 - Valve stem seal "4"
 - Valve spring seat "5"

TIP

Identify the position of each part very carefully so that it can be reinstalled in its original place.




EAS30284


CHECKING THE VALVES AND VALVE GUIDES

The following procedure applies to all of the valves and valve guides.

VALVES AND VALVE SPRINGS

- 1. Measure:
- Valve-stem-to-valve-guide clearance Out of specification → Replace the valve guide.
- Valve-stem-to-valve-guide clearance = Valve guide inside diameter "a" -Valve stem diameter "b"







- 2. Replace:
- Valve guide
- TIP_

To ease valve guide removal and installation, and to maintain the correct fit, heat the cylinder head to 100 $^{\circ}$ C (212 $^{\circ}$ F) in an oven.


a. Remove the valve guide with the valve guide remover "1".



b. Install the new valve guide with the valve guide installer "2" and valve guide remover "1".



- a. Valve guide position
- c. After installing the valve guide, bore the valve guide with the valve guide reamer "3" to obtain the proper valve-stem-to-valve-guide clearance.



TIP.

After replacing the valve guide, reface the valve seat.



Valve guide remover (ø4.5) 90890-04116 Valve guide remover (4.5 mm) YM-04116 Valve guide installer (ø4.5) 90890-04117 Valve guide installer (4.5 mm) YM-04117 Valve guide reamer (ø4.5) 90890-04118 Valve guide reamer (4.5 mm) YM-04118


.....


- 3. Eliminate:
 - Carbon deposits (from the valve face and valve seat)
- 4. Check:
 - Valve face

Pitting/wear → Grind the valve face. • Valve stem end

Mushroom shape or diameter larger than the body of the valve stem \rightarrow Replace the valve.

- 5. Measure:
 - Valve stem runout Out of specification → Replace the valve.
- TIP.
- When installing a new valve, always replace the valve guide.
- If the valve is removed or replaced, always replace the valve stem seal.





EAS30285

CHECKING THE VALVE SEATS

The following procedure applies to all of the valves and valve seats.


- 1. Eliminate:
- Carbon deposits (from the valve face and valve seat)

- 2. Check:
 - Valve seat Pitting/wear \rightarrow Replace the cylinder head.
- 3. Measure:
- Valve seat width "a" Out of specification → Replace the cylinder head.




Valve seat contact width (intake) 0.90–1.10 mm (0.0354–0.0433 in) Valve seat contact width (exhaust)

0.90-1.10 mm (0.0354-0.0433 in)



- a. Apply blue layout fluid "b" onto the valve face.



- b. Install the valve into the cylinder head.
- c. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- d. Measure the valve seat width.

TIP _

Where the valve seat and valve face contacted one another, the blueing will have been removed.

- 4. Lap:
 - Valve face
 - Valve seat


TIP _

After replacing the cylinder head or replacing the valve and valve guide, the valve seat and valve face should be lapped.

a. Apply a coarse lapping compound "a" to the valve face.

ECA13790


Do not let the lapping compound enter the gap between the valve stem and the valve guide.




- b. Apply molybdenum disulfide oil onto the valve stem.
- c. Install the valve into the cylinder head.
- d. Turn the valve until the valve face and valve seat are evenly polished, then clean off all of the lapping compound.

TIP _


For the best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.



- e. Apply a fine lapping compound to the valve face and repeat the above steps.
- f. After every lapping procedure, be sure to clean off all of the lapping compound from the valve face and valve seat.
- g. Apply blue layout fluid "b" onto the valve face.



- h. Install the valve into the cylinder head.
- i. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- j. Measure the valve seat width "c" again. If the valve seat width is out of specification, reface and lap the valve seat.




CHECKING THE VALVE SPRINGS

The following procedure applies to all of the valve springs.

- 1. Measure:
 - Valve spring free length "a" Out of specification → Replace the valve spring.






- 2. Measure:
- Compressed valve spring force "a" Out of specification → Replace the valve spring.




Installed compression spring force (intake) 144.00–166.00 N (14.68–16.93 kgf, 32.37–37.32 lbf) Installed compression spring force (exhaust) 149.00–171.00 N (15.19–17.44 kgf, 33.50–38.44 lbf) Installed length (intake) 34.34 mm (1.35 in) Installed length (exhaust) 35.84 mm (1.41 in)



- b. Installed length
- 3. Measure:
 - Valve spring tilt "a" Out of specification → Replace the valve spring.



Spring tilt (intake) 1.8 mm (0.07 in) Spring tilt (exhaust) 1.8 mm (0.07 in)



EAS30287 CHECKING THE VALVE LIFTERS

The following procedure applies to all of the valve lifters.

- 1. Check:
 - Valve lifter Damage/scratches → Replace the valve lifters and cylinder head.

EAS3028


INSTALLING THE VALVES

The following procedure applies to all of the valves and related components.

- 1. Deburr:
- Valve stem end (with an oil stone)




- 2. Lubricate:
- Valve stem "1"
- Valve stem end
 - (with the recommended lubricant)



- 3. Lubricate:
- Valve stem seal "2" (with the recommended lubricant)

Recommended lubricant Silicone fluid


VALVES AND VALVE SPRINGS



- 4. Install:
- Valve spring seat "1" (into the cylinder head)
- Valve stem seal "2" New
- Valve "3"
- Valve spring "4"
- Valve spring retainer "5"

TIP .

- Make sure each valve is installed in its original place.
- Install the valve springs with the larger pitch "a" facing up.




b. Smaller pitch

5. Install:


Valve cotters

TIP ___

Install the valve cotters by compressing the valve spring with the valve spring compressor "1" and the valve spring compressor attachment "2".




Valve spring compressor 90890-04019 Valve spring compressor YM-04019 Valve spring compressor attachment 90890-01243 Valve spring compressor adapter (26 mm) YM-01253-1




 To secure the valve cotters onto the valve stem, lightly tap the valve tip with a soft-face hammer.

NOTICE

Hitting the valve tip with excessive force could damage the valve.




- 7. Lubricate:
- Valve lifter
 - (with the recommended lubricant)





- 8. Install:
 - Valve pad
 - Valve lifter

TIP _

• The valve lifter must move smoothly when rotated with a finger. • Each valve lifter and valve pad must be reinstalled in their original position.








REMOVING THE GENERATOR

- 1. Remove:
 - Generator rotor bolt "1"
 - Washer

TIP _

While holding the generator rotor "2" with the rotor holding tool "3", loosen the generator rotor bolt.



- 2. Remove:
 - Generator rotor "1"
 - (with the flywheel puller "2")
- Woodruff key ECA13880

NOTICE


To protect the end of the crankshaft, place an appropriate sized socket between the flywheel puller set center bolt and the crankshaft.

TIP

- Install the flywheel puller bolts to the threaded holes of the starter clutch.
- Make sure the flywheel puller is centered over the generator rotor.



Flywheel puller 90890-01362 Heavy duty puller YU-33270-B




REMOVING THE STARTER CLUTCH

- 1. Remove:
- Starter clutch bolts "1"
- Starter clutch

TIP _

While holding the generator rotor "2" with the rotor holding tool "3", loosen the starter clutch bolts.






CHECKING THE STARTER CLUTCH

- 1. Check:
- Starter clutch rollers
 Damage/wear → Replace.
- 2. Check:
- Starter clutch idle gear
- Starter clutch gear Burrs/chips/roughness/wear → Replace the defective part(s).
- 3. Check:
- Starter clutch gear contact surfaces Damage/pitting/wear \rightarrow Replace the starter clutch gear.
- 4. Check:
 - Starter clutch operation
- ****
- a. Install the starter clutch gear "1" onto the generator rotor "2" and hold the generator rotor.

- b. When turning the starter clutch gear clockwise "A", the starter clutch and the starter clutch gear should engage, otherwise the starter clutch is faulty and must be replaced.
- c. When turning the starter clutch gear counterclockwise "B", it should turn freely, otherwise the starter clutch is faulty and must be replaced.



CHECKING THE TORQUE LIMITER


- 1. Check:
- Torque limiter
 - Damage/wear \rightarrow Replace.

TIP.

Do not disassemble the torque limiter.

EAS30871

INSTALLING THE STARTER CLUTCH 1. Install:






Starter clutch bolt 32 Nm (3.2 m·kgf, 23 ft·lbf) LOCTITE®

TIP

- Install the starter clutch so that the side of the starter clutch roller assembly with the arrow mark "a" is toward the generator rotor "2".
- While holding the generator rotor with the rotor holding tool "3", tighten the starter clutch bolts "4".



Rotor holding tool 90890-04166 YM-04166 

INSTALLING THE GENERATOR

1. Install:

EAS30872

- Woodruff key
- Generator rotor
- Washer New
- Generator rotor bolt

TIP

- Clean the tapered portion of the crankshaft and the generator rotor hub.
- When installing the generator rotor, make sure the woodruff key is properly seated in the keyway of the crankshaft.
- Lubricate the generator rotor bolt threads and washer mating surfaces with engine oil.

2. Tighten:

• Generator rotor bolt "1"




Generator rotor bolt 70 Nm (7.0 m·kgf, 51 ft·lbf)

TIP

While holding the generator rotor "2" with the rotor holding tool "3", tighten the generator rotor bolt.


Rotor holding tool 90890-04166 YM-04166



- 3. Install:
- Bearing "1"


TIP_


Make sure that the bearing does not protrude past the surface "a" of the cylinder.



- 4. Apply:
 - Sealant
 (anto the states exil lead area

(onto the stator coil lead grommet)







- 5. Install:
- Bearing "1"

TIP_

Make sure that the bearing contacts the surface "a" of the generator cover "2".




- 6. Install:
 - Generator cover gasket New
 - Generator cover



TIP _

- Tighten the generator cover bolts in stages and in a crisscross pattern.
- Apply LOCTITE® to the threads of only the generator cover bolts "1" shown in the illustration.




- 7. Connect:
- Stator coil coupler
- Crankshaft position sensor coupler

TIP ___

To route the stator coil lead, refer to "CABLE ROUTING" on page 2-43.

ELECTRIC STARTER



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Fuel tank center cover/Outer side covers/Inner side covers		Refer to "GENERAL CHASSIS (3)" on page 4-5.
	Fuel tank/Canister		Refer to "FUEL TANK" on page 7-1.
	Pivot shaft protectors		Refer to "SWINGARM" on page 4-88.
	Air duct bracket		Refer to "GENERAL CHASSIS (4)" on page 4-7.
	Throttle bodies/Air filter case		Refer to "THROTTLE BODIES" on page 7-7.
1	Gear position switch coupler	1	
2	Coupler and hose bracket	1	
3	Starter motor lead	1	Disconnect.
4	Starter motor	1	
5	Canister holder	1	

ELECTRIC STARTER

Disassembling the starter motor			
Disassembling the starter motor			
Order	Job/Parts to remove	Q'ty	Remarks
1	O-ring	1	
2	Starter motor front cover	1	
3	Starter motor yoke	1	
4	Armature assembly	1	
5	Gasket	2	
6	Brush holder set	1	
7	Starter motor rear cover	1	
8	Lead guide	1	

ELECTRIC STARTER

EAS30325 CHECKING THE STARTER MOTOR


- 1. Check:
- Commutator Dirt \rightarrow Clean with 600 grit sandpaper.
- 2. Measure:
 - Mica undercut "a" Out of specification → Cut the mica to the proper measurement with a hacksaw blade that has been grounded to fit the commutator.



Mica undercut (depth) 0.70 mm (0.03 in)

TIP.

The mica of the commutator must be undercut to ensure proper operation of the commutator.



- 3. Measure:
 - Armature assembly resistances (commutator and insulation)

Out of specification \rightarrow Replace the starter motor.

a. Measure the armature assembly resistances with the digital circuit tester.




Digital circuit tester 90890-03174 Model 88 Multimeter with tachometer YU-A1927



Armature coil Commutator resistance "1" $0.015-0.025 \Omega$ Insulation resistance "2" Above 1 M Ω at 20 °C (68 °F)


b. If any resistance is out of specification, replace the starter motor.




- 4. Measure:
- Brush length "a"
 Out of specification → Replace the brush holder set.



Brush overall length 12.0 mm (0.47 in) Limit 6.50 mm (0.26 in)



- 5. Measure:
 - Brush spring force Out of specification → Replace the brush holder set.





- 6. Check:
 - Gear teeth Damage/wear → Replace the starter motor.


- 7. Check:
- Bearing
- Oil seal Damage/wear → Replace the starter motor front cover.

ASSEMBLING THE STARTER MOTOR

- 1. Install:
- Lead guide "1"

TIP_

Make sure that the slot "a" in the lead guide is facing in the direction shown in the illustration.




2. Install:

- Starter motor yoke "1"
- Starter motor front cover "2"
- Starter motor rear cover "3"

TIP_

Align the match marks "a" on the starter motor yoke with the match marks "b" on the front cover and rear covers.




EAS30327 INSTALLING THE STARTER MOTOR

- 1. Install:
- Canister holder "1"
- Starter motor "2"
- Canister "3"

TIP ___

• Pass the starter motor front cover bolts through the slots "a" in the canister holder to secure it.

• Install the canister holder with the stamped mark "2RC" "b" facing forward.




2. Install:


• Coupler and hose holder bracket "1"

TIP ___


Make sure that the tab "a" on the coupler and hose holder bracket contacts the projection "b" on the cylinder block.




CLUTCH




CLUTCH



CLUTCH



CLUTCH




REMOVING THE CLUTCH

- 1. Remove:
 - Clutch cover "1"
- Gasket

TIP_


Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.




- 2. Remove:
 - Compression spring bolts "1"
 - Compression springs
 - Pressure plate "2"
 - Pull rod "3"

TIP __

Loosen the compression spring bolts in stages and in a crisscross pattern.



- 3. Remove:
 - Friction plates 1
 - Clutch plates
- Friction plates 2
- 4. Straighten the clutch boss nut rib "a".




- 5. Loosen:
- Clutch boss nut "1"


TIP _

While holding the clutch boss "2" with the universal clutch holder "3", loosen the clutch boss nut.






- 6. Remove:
 - Spacer "1"
 - Bearing "2"
 - Clutch housing "3"
- *****
- a. Remove the spacer and bearing.



b. Remove the oil pump drive chain "4" from the oil pump driven sprocket "a", and then remove the clutch housing.



EAS30348 **CHECKING THE FRICTION PLATES**


The following procedure applies to all of the friction plates.


- 1. Check:
 - Friction plate Damage/wear \rightarrow Replace the friction plates as a set.
- 2. Measure:
 - Friction plate thickness Out of specification \rightarrow Replace the friction plates as a set.
- TIP_

Measure the friction plate at four places.



Friction plate 1 thickness 2.90-3.10 mm (0.114-0.122 in) Wear limit 2.80 mm (0.110 in) Friction plate 2 thickness 2.92-3.08 mm (0.115-0.121 in) Wear limit 2.82 mm (0.111 in)





A. Friction plate 1

B. Friction plate 2


E4530349 CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

- 1. Check:
- Clutch plate Damage \rightarrow Replace the clutch plates as a set.
- 2. Measure:
 - Clutch plate warpage (with a surface plate and thickness gauge "1") Out of specification \rightarrow Replace the clutch plates as a set.



Warpage limit 0.10 mm (0.004 in)



EAS3035


CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

- 1. Check:
 - Clutch spring Damage \rightarrow Replace the clutch springs as a set.
- 2. Measure:
 - Clutch spring free length "a" Out of specification \rightarrow Replace the clutch springs as a set.



Clutch spring free length 50.00 mm (1.97 in) Limit 47.50 mm (1.87 in)



EAS30352


CHECKING THE CLUTCH HOUSING

- 1. Check:
- Clutch housing dogs Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

TIP

Pitting on the clutch housing dogs will cause erratic clutch operation.

- 2. Check:
 - Oil pump drive sprocket "1" Cracks/damage/wear → Replace.



3. Check:

Bearing

Damage/wear \rightarrow Replace the bearing and clutch housing.

EAS30353 CHECKING THE CLUTCH BOSS

- 1. Check:
- Clutch boss splines Damage/pitting/wear → Replace the clutch boss.


TIP _

Pitting on the clutch boss splines will cause erratic clutch operation.

CHECKING THE PRESSURE PLATE

- 1. Check:
 - Pressure plate "1" Cracks/damage \rightarrow Replace.

• Bearing "2" Damage/wear \rightarrow Replace.



CHECKING THE PRIMARY DRIVE GEAR

- 1. Check:
 - Primary drive gear Damage/wear → Replace the crankshaft and clutch housing as a set.


Excessive noise during operation \rightarrow Replace the crankshaft and clutch housing as a set.

CHECKING THE PRIMARY DRIVEN GEAR

1. Check:


 Primary driven gear "1"
 Damage/wear → Replace the clutch housing and crankshaft as a set.

Excessive noise during operation \rightarrow Replace the clutch housing and crankshaft as a set.



CHECKING THE PULL LEVER SHAFT AND PULL ROD

- 1. Check:
- Pull lever shaft pinion gear teeth "1"
- Pull rod teeth "2" Damage/wear → Replace the pull rod and pull lever shaft as a set.




- 2. Check:
 - Pull rod bearing Damage/wear \rightarrow Replace.

EAS30363 INSTALLING THE CLUTCH

- 1. Install:
 - Oil pump drive chain "1"
 - Thrust plate
 - Clutch housing "2"
 - Bearing
- Spacer

TIP.

Install the oil pump drive chain onto the oil pump drive sprocket "a".



- 2. Install:
 - Thrust plate
 - Clutch boss "1"
 - Washer
 - Conical spring washer
 - Clutch boss nut "2" New


Clutch boss nut 95 Nm (9.5 m·kgf, 69 ft·lbf)


TIP .

- Lubricate the conical spring washer and clutch boss nut threads with engine oil.
- Install the washer on the main axle with the "OUT" mark facing away from the vehicle.
- While holding the clutch boss "1" with the universal clutch holder "3", tighten the clutch boss nut.

• Stake the clutch boss nut at a cutout "a" in the main axle.








- 3. Install:
 - Friction plates 1 "1"
 - Friction plates 2 "2"

TIP __

- First, install a friction plate, and then alternate between a clutch plate and a friction plate.
- Align a projection on friction plate 1 with the punch mark "a" on the clutch housing and align a projection on friction plate 2 with the "[^] " mark "b" on the housing.



- 4. Install:
 - Bearing
 - Pull rod "1"
 - Pressure plate "2"

CLUTCH


- Clutch springs
- Clutch spring bolts "3"




Clutch spring bolt 8 Nm (0.8 m·kgf, 5.8 ft·lbf)

TIP _

- Apply lithium-soap-based grease onto the pull rod.
- Tighten the clutch spring bolts in stages and in a crisscross pattern.




- 5. Install:
- Bearings "1"
- Oil seal "2" New (to the clutch cover)
- TIP
- Lubricate the bearings with engine oil and lubricate the oil seal with lithium-soap-based grease.
- Install the bearings until they contact the surfaces "a" and install the oil seal until it contacts the surface "b" as shown in the illustration.



- 6. Install:
- Pull lever

TIP _

- Install the pull lever with the "UP" mark "a" facing toward upper side.
- When installing the pull lever, push the pull lever and check that the punch mark "b" on the pull lever aligns with the mark "c" on the clutch cover.



7. Install:Dowel pins "1"


- Clutch cover gasket "2" New
- Clutch cover "3"
- Clutch cable holder "4"


J. A.

Clutch cover bolt 12 Nm (1.2 m·kgf, 8.7 ft·lbf) Clutch cable holder bolt 12 Nm (1.2 m·kgf, 8.7 ft·lbf) LOCTITE®

TIP.

- Align the slit "a" in the impeller shaft with the projection "b" on the oil pump driven sprocket.
- Face the serrations on the clutch pull rod "5" rearward and align the rod with the hole "c" in the clutch cover.
- Make sure that the pull rod teeth and pull lever shaft pinion gear are engaged.
- Apply locking agent (LOCTITE®) to the threads of only the clutch cable holder bolts "6" shown in the illustration.
- Tighten the bolts in stages and in a crisscross pattern.






8. Connect:


• Clutch cable "1"

TIP_


• Install the clutch cable so that the clutch cable length "a" is 51.6–62.2mm (2.03–2.45 in) as shown in the illustration. In addition, make sure that the vehicle is positioned upright when measuring the clutch cable length. • After installing the clutch cable, bend the projection "b" on the pull lever.



- 9. Adjust:
 - Clutch lever free play Refer to "ADJUSTING THE CLUTCH LEVER FREE PLAY" on page 3-12.




EAS20057 SHIFT SHAFT



Order	Job/Parts to remove	Q'ty	Remarks
	Clutch housing		Refer to "CLUTCH" on page 5-46.
1	Circlip	1	
2	Washer	1	
3	Shift shaft	1	
4	Washer	1	
5	Circlip	1	
6	Washer	1	
7	Stopper lever	1	
8	Stopper lever spring	1	
9	Collar	1	
10	Shift shaft spring	1	
11	Shift shaft spring stopper	1	
12	Oil seal	1	
13	Bearing	1	

CHECKING THE SHIFT SHAFT

- 1. Check:
 - Shift shaft "1" Bends/damage/wear \rightarrow Replace.
 - Shift shaft spring "2"
 - Collar Damage/wear \rightarrow Replace.



EAS30378 CHECKING THE STOPPER LEVER

- 1. Check:
 - Stopper lever "1" Bends/damage → Replace. Roller turns roughly → Replace the stopper lever.



EAS30381

INSTALLING THE SHIFT SHAFT


- 1. Install:
 - Bearing "1"
 - Oil seal "2" New



Install depth "a" 0.6–1.1 mm (0.02–0.04 in)

TIP.

- Apply engine oil onto the bearing.
- Make sure that the bearing does not protrude past the line "b" shown in the illustration.
- Lubricate the oil seal lips with lithium-soapbased grease.




- 2. Install:
 - Shift shaft spring stopper
 - Washer
 - Shift shaft assembly
 - Stopper lever spring




Shift shaft spring stopper 22 Nm (2.2 m·kgf, 16 ft·lbf) LOCTITE®

TIP _

- Hook the end of the shift shaft spring "2" onto the shift shaft spring stopper "1".
- Hook the ends of the stopper lever spring "3" onto the stopper lever "4" and the stopper lever spring hook "5".
- Mesh the stopper lever with the shift drum segment assembly.



OIL PUMP



OIL PUMP


Disassemb	oling the oil pump		
Image: state in the state			
			3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order	Job/Parts to remove	Q'ty	
			3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order 1 2	Job/Parts to remove Oil pump cover Oil pump rotor assembly	Q'ty 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order 1	Job/Parts to remove Oil pump cover Oil pump rotor assembly Oil pump inner rotor	Q'ty 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order 1 2	Job/Parts to remove Oil pump cover Oil pump rotor assembly	Q'ty 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order 1 2 3	Job/Parts to remove Oil pump cover Oil pump rotor assembly Oil pump inner rotor	Q'ty 1 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order 1 2 3 4	Job/Parts to removeOil pump coverOil pump rotor assemblyOil pump inner rotorOil pump outer rotorOil pump outer rotor	Q'ty 1 1 1 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order 1 2 3 4 5	Job/Parts to remove Oil pump cover Oil pump rotor assembly Oil pump inner rotor Oil pump inner rotor Oil pump outer rotor Pin	Q'ty 1 1 1 1 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)
Order 1 2 3 4 5 6	Job/Parts to remove Oil pump cover Oil pump rotor assembly Oil pump inner rotor Oil pump outer rotor Oil pump driven sprocket	Q'ty 1 1 1 1 1 1 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf) Remarks Hold down the washer when removing the
Order 1 2 3 4 5 6 7	Job/Parts to removeOil pump coverOil pump rotor assemblyOil pump inner rotorOil pump outer rotorOil pump outer rotorPinOil pump driven sprocketCirclip	Q'ty 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf) Remarks Hold down the washer when removing the
Order 1 2 3 4 5 6 7 8	Job/Parts to removeOil pump coverOil pump rotor assemblyOil pump inner rotorOil pump outer rotorOil pump outer rotorPinOil pump driven sprocketCirclipWasher	Q'ty 1 1 1 1 1 1 1 1 1 1 1 1 1 1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf) Remarks Hold down the washer when removing the

CHECKING THE SPROCKET AND CHAIN


- 1. Check:
 - Oil pump drive sprocket Refer to "CHECKING THE CLUTCH HOUS-ING" on page 5-52.
 - Oil pump driven sprocket Refer to "CHECKING THE OIL PUMP" on page 5-60.
- 2. Check:
- Oil pump drive chain Damage/stiffness → Replace the oil pump drive chain, oil pump drive sprocket (clutch housing), and oil pump driven sprocket as a set.


CHECKING THE OIL PUMP

- 1. Check:
 - Oil pump driven sprocket "1"
- Oil pump housing "2" Cracks/damage/wear \rightarrow Replace the defective part(s).



- 2. Measure:
 - Inner-rotor-to-outer-rotor-tip clearance "a"
 - Outer-rotor-to-oil-pump-housing clearance "b"






- 1. Inner rotor
- 2. Outer rotor
- 3. Check:
 - Oil pump operation Rough movement → Repeat steps (1) and (2) or replace the defective part(s).



EAS30338 CHECKING THE RELIEF VALVE

- 1. Check:
 - Relief valve "1"
- Spring "2"

Damage/wear \rightarrow Replace the oil pump assembly.



ASSEMBLING THE OIL PUMP

- 1. Lubricate:
 - Inner rotor
 - Outer rotor
 - (with the recommended lubricant)

Recommended lubricant Engine oil

- 2. Lubricate:
 - Oil pump driven sprocket (with the recommended lubricant)

Engine oil

Recommended lubricant



3. Install:


- Oil pump driven sprocket "1"
- Pin "2"
- Outer rotor "3"
- Inner rotor "4"
- Oil pump cover "5"
- Oil pump cover screw "6"


TIP_

Align the pin in the oil pump shaft with the grooves "a" in the inner rotor.

Oil pump cover screw

3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)





- 4. Check:
 - Oil pump operation Refer to "CHECKING THE OIL PUMP" on page 5-60.


EAS30343 INSTALLING THE OIL PUMP

- 1. Install:
 - Oil pump "1"
 - Oil pump bolts "2"


Oil pump bolt 12 Nm (1.2 m·kgf, 8.7 ft·lbf)

ECA20940 NOTICE

After installing the oil pump drive chain and driven sprocket, make sure the oil pump turns smoothly.



OIL PAN




REMOVING THE OIL PAN

- 1. Remove:
 - Oil pan "1"
 - Oil pan gasket

TIP_

- Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.
- Insert a flat-head screwdriver into the slots "a" in the oil pan to remove the oil pan.



EAS31069

CHECKING THE OIL STRAINER

 Check:
 Oil strainer Damage → Replace.

Contaminants \rightarrow Clean with solvent.

EAS31070

INSTALLING THE OIL PAN

- 1. Install:
 - Oil pan gasket New
- Oil pan

Oil pan bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)


TIP.

Tighten the oil pan bolts in stages and in a crisscross pattern.

- 2. Install:
 - Gasket New
 - Engine oil drain bolt


Engine oil drain bolt 43 Nm (4.3 m·kgf, 31 ft·lbf)

CRANKCASE



* Following the tightening order, loosen the bolt one by one, and then retighten it to the specific torque.

Order	Job/Parts to remove	Q'ty	Remarks
	Engine		Refer to "ENGINE REMOVAL" on page 5-3.
	Cylinder head cover		Refer to "CAMSHAFTS" on page 5-11.
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-23.
	Starter clutch		Refer to "GENERATOR AND STARTER CLUTCH" on page 5-36.
	Starter motor		Refer to "ELECTRIC STARTER" on page 5-42.
	Clutch housing		Refer to "CLUTCH" on page 5-46.
	Oil strainer		Refer to "OIL PAN" on page 5-62.



3

1

7

8

Dowel pin


Blind plate

EAS30389 DISASSEMBLING THE CRANKCASE

- 1. Place the engine upside down.
- 2. Remove:
- Crankcase bolt (×27)

TIP _

- Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.
- Loosen the bolts "1"-"11" in any loosening sequence.
- Loosen the bolts "12"-"27" in the proper sequence as shown.
- The numbers embossed "1"--"16" on the crankcase indicate the crankcase tightening sequence.
- M6 × 40 mm bolt (×8): "1", "2", "4"–"7", "10", "11"
- M6 × 60 mm bolt (×3): "3", "8", "9"
- M6 × 65 mm bolt (×2): "12", "13"
- M8 × 65 mm bolt (×2): "14", "15"
- M8 × 70 mm bolt (×6) (bolts with O-rings): "16"– "21"
- M9 \times 80 mm bolt (×6) (bolts with washers): "22"–"27"



- 3. Remove:
 - Crankcase
 - Dowel pins

ECA13900

Tap on one side of the crankcase with a softface hammer. Tap only on reinforced portions of the crankcase, not on the crankcase mating surfaces. Work slowly and carefully and make sure the crankcase halves separate evenly.

- **CHECKING THE CRANKCASE** 1. Thoroughly wash the crankcase halves in a
- mild solvent.2. Thoroughly clean all the gasket surfaces and crankcase mating surfaces.
- 3. Check:
- Crankcase
- Cracks/damage \rightarrow Replace.
- Oil delivery passages
 Obstruction → Blow out with compressed air.

EAS30397 ASSEMBLING THE CRANKCASE


- 1. Lubricate:
- Crankshaft journal bearing inner surface (with the recommended lubricant)



Recommended lubricant Engine oil


- 2. Apply:
 - Sealant

(onto the crankcase mating surfaces)



ECA20880


Do not allow any sealant to come into contact with the oil gallery, crankshaft journal bearings, or balancer shaft journal bearings.



- 3. Install:
- Dowel pins
- 4. Set the shift drum assembly and transmission gears in the neutral position.
- 5. Install:
 - Crankcase "1" (onto the cylinder "2")
- ECA13980

NOTICE

Before tightening the crankcase bolts, make sure the transmission gears shift correctly when the shift drum assembly is turned by hand.




6. Install:

Crankcase bolt (×27)

TIP _

- Tighten the bolts "1"-"16" in the order of the embossed numbers on the crankcase.
- Lubricate the bolts "1"-"6" threads, mating surfaces and washers with engine oil.
- Lubricate the bolts "7"-"12" threads, mating surfaces and O-rings with engine oil.

- Lubricate the bolts "13"–"27" threads and mating surfaces with engine oil.
 - M9 × 80 mm bolt (×6) (bolts with washers): "1"–"6" New
 - M8 × 70 mm bolt (×6) (bolts with new Orings): "7"–"12"
 - M8 × 65 mm bolt (×2): "13", "14"
 - M6 \times 65 mm bolt (×2): "15", "16"
 - M6 × 40 mm bolt (×8): "17", "18", "21"–"24", "26", "27"
 - M6 × 60 mm bolt (×3): "19", "20", "25"



- 7. Tighten:
- Crankcase bolts "1"-"6"



Crankcase bolts (bolts with washers) "1"–"6" 1st: 24 Nm (2.4 m·kgf, 17 ft·lbf) *2nd: 17 Nm (1.7 m·kgf, 12 ft·lbf) Final: specified angle 60°

* Following the tightening order, loosen the bolt one by one, and then retighten it to the specific torque.

WARNING


If the bolt is tightened more than the specified angle, do not loosen the bolt and then retighten it. Instead, replace the bolt with a new one and perform the procedure again.

ECA20890 NOTICE

Do not use a torgue wrench to tighten the bolt to the specified angle.

TIP.

Tighten the bolts in the tightening sequence cast on the crankcase.




- 8. Tighten:
- Crankcase bolts "7"-"27"

Crankcase bolts "7"-"14" 24 Nm (2.4 m·kgf, 17 ft·lbf) Crankcase bolts "15"-"27" 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

TIP_

- Tighten the bolts "7"-"16" in the tightening sequence cast on the crankcase.
- Tighten the bolts "17"-"27" in any tightening sequence using a crisscross pattern.



EAS3107

INSTALLING THE OIL PRESSURE SWITCH 1. Install:

- Oil pressure switch "1"
- Oil pressure switch lead "2"



Oil pressure switch 15 Nm (1.5 m·kgf, 11 ft·lbf) Oil pressure switch lead bolt 1.8 Nm (0.18 m·kgf, 1.3 ft·lbf)

- 2. Apply:
- Sealant


(onto the oil pressure switch threads)




Yamaha bond No. 1215 90890-85505 (Three bond No.1215®)


TIP

- Apply Three bond No.1215® to the threads "a" of the oil pressure switch. However, do not apply Three bond No.1215® to the portion "b" of the oil pressure switch.
- Install the oil pressure switch lead so that it is routed within the range shown in the illustration.





Order	Job/Parts to remove	Q'ty	Remarks
			The following procedure applies to all of the connecting rods and pistons.
			Refer to "CRANKCASE" on page 5-64.
1	Connecting rod cap	1	
2	Big end lower bearing	1	
3	Big end upper bearing	1	
4	Piston pin clip	2	
5	Piston pin	1	
6	Piston	1	
7	Connecting rod	1	




REMOVING THE CONNECTING RODS AND PISTONS

The following procedure applies to all of the connecting rods and pistons.

- 1. Remove:
 - Connecting rod cap "1"
 - Connecting rod
 - Big end bearings

TIP.

- Identify the position of each connecting rod cap so that it can be reinstalled in its original place.
- After removing the connecting rods and connecting rod caps, care should be taken not to damage the mating surfaces of the connecting rods and connecting rod caps.



- 2. Remove:
 - Piston pin clips "1"
 - Piston pin "2"
 - Piston "3"
 - Connecting rod "4"


ECA13810 **NOTICE**


Do not use a hammer to drive the piston pin out.

TIP

- For reference during installation, put identification marks on the piston crown.
- Before removing the piston pin, deburr the piston pin clip groove and the piston pin bore area. If both areas are debarred and the piston pin is still difficult to remove, remove it with the piston pin puller set "5".

Piston pin puller set 90890-01304 Piston pin puller YU-01304






- 3. Remove:
 - Top ring
 - 2nd ring
 - Oil ring

TIP .

When removing a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.



CHECKING THE CYLINDER AND PISTON

The following procedure applies to all of the cylinders and pistons.

- 1. Check:
 - Piston wall
 - Cylinder wall

Vertical scratches \rightarrow Replace the cylinder, and replace the piston and piston rings as a set.

- 2. Measure:
 - Piston-to-cylinder clearance

a. Measure cylinder bore with the cylinder bore gauge.

TIP_

Measure cylinder bore by taking side-to-side and front-to-back measurements of the cylinder.

Bore

80.000–80.010 mm (3.1496– 3.1500 in) Taper limit 0.050 mm (0.0020 in) Out of round limit 0.050 mm (0.0020 in)


"C" = maximum of D_1 , D_2 , D_3 , D_4 , D_5 , D_6

Taper (front-to-back) = maximum difference between D_1 , D_3 , D_5 Taper (side-to-side) = maximum difference be-

tween D_2 , D_4 , D_6

Out of round (top) = difference between D_1 , D_2 Out of round (middle) = difference between D_3 , D_4


Out of round (bottom) = difference between D_5 , D_6



- b. If out of specification, replace the cylinder, and replace the piston and piston rings as a set.
- c. Measure piston skirt diameter "P" with the micrometer.



Diameter 79.970–79.985 mm (3.1484– 3.1490 in)



- a. 8.0 mm (0.31 in) from the bottom edge of the piston
- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

Piston-to-cylinder clearance = Cylinder bore "C" – Piston skirt diameter "P"


f. If out of specification, replace the cylinder, and replace the piston and piston rings as a set.


CHECKING THE PISTON RINGS

- 1. Measure:
 - Piston ring side clearance Out of specification → Replace the piston and piston rings as a set.

TIP

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.





- 2. Install:
 - Piston ring
 - (into the cylinder)

TIP _

Use the piston crown to level the piston ring near the bottom of the cylinder where the cylinder wear is lowest.


3. Measure:

 Piston ring end gap Out of specification → Replace the piston ring.

TIP_

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.

V	Piston ring Top ring End gap (installed) 0.15–0.25 mm (0.0059–0.0098 in) Limit 0.50 mm (0.0197 in) 2nd ring End gap (installed) 0.30–0.45 mm (0.0118–0.0177 in) Limit
	ι.
	Limit 0.80 mm (0.0315 in)
	Oil ring
	End gap (installed) 0.10–0.35 mm (0.0039–0.0138 in)





- a. Bottom of cylinder
- b. Top of cylinder

EAS30749 CHECKING THE PISTON PIN


The following procedure applies to all of the piston pins.


- 1. Check:
- Piston pin Blue discoloration/grooves → Replace the piston pin, and then check the lubrication system.
- 2. Measure:
 - Piston pin outside diameter "a" Out of specification → Replace the piston pin.





- 3. Measure:
 - Piston pin bore inside diameter "b"
 Out of specification → Replace the piston.





- 4. Calculate:
 - Piston-pin-to-piston-pin-bore clearance Out of specification → Replace the piston pin and piston as a set.

Piston-pin-to-piston-pin-bore clearance = Piston pin bore inside diameter "b" – Piston pin outside diameter "a"



Piston-pin-to-piston-pin-bore clearance 0.009–0.025 mm (0.0004–0.0010 in) Limit 0.075 mm (0.0030 in)

CHECKING THE CONNECTING RODS

- 1. Measure:
- Crankshaft-pin-to-big-end-bearing clearance Out of specification → Replace the big end bearings.



Oil clearance 0.027–0.051 mm (0.0011–0.0020 in)

The following procedure applies to all of the connecting rods.


NOTICE

Do not interchange the big end bearings and connecting rods. To obtain the correct crankshaft-pin-to-big-end-bearing clearance and prevent engine damage, the big end bearings must be installed in their original positions.


- a. Clean the big end bearings, crankshaft pins, and the inside of the connecting rods halves.
- b. Install the big end upper bearing into the connecting rod and the big end lower bearing into the connecting rod cap.

TIP _

Align the projections "a" on the big end bearings with the notches "b" in the connecting rod and connecting rod cap.



c. Put a piece of Plastigauge® "1" on the crankshaft pin.




d. Assemble the connecting rod halves.

NOTICE

Tighten the connecting rod bolts using the plastic-region tightening angle method. Always install new bolts.

TIP.

- Clean the connecting rod bolts and lubricate the bolt threads and seats with molybdenum disulfide oil.
- Make sure that the projection "a" on the connecting rod cap faces the same direction as the "Y" mark "b" on the connecting rod.
- After installing the big end bearing, assemble the connecting rod and connecting rod cap without installing them onto the crankshaft.



TIP.

Install by carrying out the following procedures in order to assemble in the most suitable condition.


e. Tighten the connecting rod bolt while checking that the sections shown "a" and "b" are flush with each other by touching the surface.



Connecting rod bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

TIP


To install the big end bearing, care should be taken not to install it at an angle and the position should not be out of alignment.




- a. Side machined face
- b. Thrusting faces
- f. Loosen the connecting rod bolts, remove the connecting rod and connecting rod cap and install these parts to the crankshaft with the big end bearing kept in the current condition.

TIP _


- Do not move the connecting rod or crankshaft until the clearance measurement has been completed.
- Make sure that the projection "a" on the connecting rod cap faces the same direction as the "Y" mark "b" on the connecting rod.
- Make sure the "Y" marks "b" on the connecting rods face towards the left side of the crank-shaft.




g. Tighten the connecting rod bolts with a torque wrench.




h. Put a mark "1" on the corner of the connecting rod bolt "2" and the connecting rod cap "3".



i. Tighten the connecting rod bolts further to reach the specified angle 175–185°.






EWA16610

If the bolt is tightened more than the specified angle, do not loosen the bolt and then retighten it. Instead, replace the bolt with a new one and perform the procedure again.


ECA20890

Do not use a torque wrench to tighten the bolt to the specified angle.

j. After the installation, check that the section shown "a" is flush with each other by touching the surface.



- k. Remove the connecting rod and big end bearings.
- I. Measure the compressed Plastigauge® width on the crankshaft pin. If the crankshaftpin-to-big-end-bearing clearance is out of specification, select replacement big end bearings.




```
*****
```

- 2. Select:
- Big end bearings $(P_1 P_2)$


TIP.


- The numbers "A" stamped into the crankshaft web and the numbers "B" on the connecting rods are used to determine the replacement big end bearings sizes.
- "P₁"-"P₂" refer to the bearings shown in the crankshaft illustration.





Α





For example, if the connecting rod " P_1 " and the crankshaft web " P_1 " numbers are "5" and "2" respectively, then the bearing size for " P_1 " is:

" P_1 " (connecting rod)– " P_1 " (crankshaft) = 5 – 2 = 3 (brown)

K

Bearing color code 1. Blue 2. Black 3. Brown 4. Green


INSTALLING THE CONNECTING ROD AND PISTON


The following procedure applies to all of the connecting rods and pistons.

- 1. Install:
 - Big end bearings
 - Connecting rod cap
 - (onto the connecting rod)

TIP __

- Be sure to reinstall each big end bearing in its original place.
- Align the projections "a" on the big end bearings with the notches "b" in the connecting rods and connecting rod caps.
- Make sure that the projection "c" on the connecting rod cap faces the same direction as the "Y" mark "d" on the connecting rod.





- 2. Tighten:
- Connecting rod bolts New

NOTICE

Tighten the connecting rod bolts using the plastic-region tightening angle method. Always install new bolts.

TIP

Install by carrying out the following procedures in order to assemble in the most suitable condition.

- ******
- Replace the connecting rod bolts with new ones.
- b. Clean the connecting rod bolts and lubricate the bolt threads and seats with molybdenum disulfide oil.
- c. After installing the big end bearing, assemble the connecting rod and connecting rod cap without installing them onto the crankshaft.


d. Tighten the connecting rod bolt while checking that the sections shown "a" and "b" are flush with each other by touching the surface.



Connecting rod bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

TIP

To install the big end bearing, care should be taken not to install it at an angle and the position should not be out of alignment.




- a. Side machined face
- b. Thrusting faces
- e. Loosen the connecting rod bolt, remove the connecting rod and connecting rod cap and install these parts to the crankshaft with the big end bearing kept in the current condition.

3. Install:

- Oil ring expander "1"
- Lower oil ring rail "2"
- Upper oil ring rail "3"
- 2nd ring "4"
- Top ring "5"


TIP_


Be sure to install the piston rings so that the manufacturer's marks "a" face up.



- 4. Install:
 - Piston "1" (onto the respective connecting rod "2")

- Piston pin "3"
- Piston pin clips "4" New
- TIP .
- Apply engine oil onto the piston pin.
- Make sure that the "Y" mark "a" on the connecting rod faces left when the punch mark "b" on the piston is pointing up as shown.
- When installing a piston pin clip, make sure that the clip ends "c" are positioned away from the cutout "d" in the piston as shown in the illustration.
- Reinstall each piston into its original cylinder.






- 5. Lubricate:
 - Piston
 - Piston rings
 - Cylinder


(with the recommended lubricant)

Recommended lubricant Engine oil

- 6. Offset:
- Piston ring end gaps



- a. 2nd ring
- b. Lower oil ring rail
- c. Upper oil ring rail
- d. Top ring
- e. Oil ring expander
- A. Exhaust side
- 7. Lubricate:
 - Crankshaft pin
 - Connecting rod big end bearing inner surface (with the recommended lubricant)



Recommended lubricant Engine oil

8. Install:


- Connecting rod assemblies "1" (into the cylinder and onto the crankshaft pin)
- Connecting rod caps (onto the connecting rod)


TIP .

- While compressing the piston ring with piston ring compressor "2", install the connecting rod assembly into the cylinder with the other hand.
- Make sure the "Y" marks "a" on the connecting rods face towards the left side of the crank-shaft.
- Make sure that the projection "b" on the connecting rod cap faces the same direction as the "Y" mark "a" on the connecting rod.
- Apply Molybdenum disulfide oil to the threads and seats of the connecting rod bolt.




Piston ring compressor 90890-05158 Piston ring compressor YM-08037





- 9. Tighten:
- Connecting rod bolts "1"




TIP_____

Tighten the connecting rod bolts using the following procedure.

a. Tighten the connecting rod bolts with a torque wrench.


Connecting rod bolt (1st) 20 Nm (2.0 m·kgf, 14 ft·lbf)

b. Put a mark "1" on the corner of the connecting rod bolt "2" and the connecting rod cap "3".



c. Tighten the connecting rod bolts further to reach the specified angle 175–185°.





EWA16610 WARNING

If the bolt is tightened more than the specified angle, do not loosen the bolt and then retighten it. Instead, replace the bolt with a new one and perform the procedure again.


ECA20890

Do not use a torque wrench to tighten the bolt to the specified angle.

d. After the installation, check that the section shown "a" is flush with each other by touching the surface.

WARNING

If the connecting rod and cap are not flush with each other, remove the connecting rod bolts and big end bearing and restart from step (1). In this case, make sure to replace the connecting rod bolts.



Removing the crankshaft and balancer shaft 6 6 4 6 8 3 3 • 0 3 -1 5 0 5 5 8 e 2 2 2 🔳 E B

Order	Job/Parts to remove	Q'ty	Remarks
	Crankcase		Refer to "CRANKCASE" on page 5-64.
	Connecting rod		Refer to "CONNECTING RODS AND PIS- TONS" on page 5-70.
1	Balancer shaft assembly	1	
2	Balancer shaft journal lower bearing	3	
3	Balancer shaft journal upper bearing	3	
4	Crankshaft assembly	1	
5	Crankshaft journal lower bearing	3	
6	Crankshaft journal upper bearing	3	

REMOVING THE BALANCER SHAFT JOURNAL BEARINGS

- 1. Remove:
 - Balancer shaft journal lower bearings (from the crankcase)
 - Balancer shaft journal upper bearings (from the cylinder)

TIP.

Identify the position of each balancer shaft journal bearing so that it can be reinstalled in its original place.

EAS31074

REMOVING THE CRANKSHAFT JOURNAL BEARINGS

- 1. Remove:
 - Crankshaft journal lower bearings (from the crankcase)
 - Crankshaft journal upper bearings (from the cylinder)

TIP

Identify the position of each crankshaft journal bearing so that it can be reinstalled in its original place.


EAS31142

CHECKING THE BALANCER SHAFT ASSEMBLY

- 1. Check:
 - Balancer driven gear Damage/wear → Replace the balancer drive gear and balancer shaft assembly as a set. Excessive noise during operation → Replace the balancer drive gear and balancer shaft assembly as a set.
- 2. Measure:
 - Balancer shaft runout Out of specification → Replace the balancer shaft assembly.




Balancer shaft runout limit 0.030 mm (0.0012 in)



- 3. Check:
- Balancer shaft assembly Cracks/damage/wear → Replace the balancer shaft assembly and journal bearings. Dirt → Clean.
- Bearings
 - Damage/wear \rightarrow Replace.
- 4. Measure:
- Balancer shaft-journal-to-balancer shaft-journal-bearing clearance
 Out of specification → Replace the balancer

shaft journal bearings.




ECA18400

Do not interchange the balancer shaft journal bearings. To obtain the correct balancer shaft-journal-to-balancer shaft-journal-bearing clearance and prevent engine damage, the balancer shaft journal bearings must be installed in their original positions.

- a. Clean the balancer shaft journal bearings, balancer shaft journals, and bearing portions of the crankcase and cylinder.
- b. Install the balancer shaft journal upper bearings "1" and the balancer shaft assembly into the cylinder.

TIP

Align the projections "a" on the balancer shaft journal upper bearings with the notches "b" in the cylinder.




c. Put a piece of Plastigauge® "2" on each balancer shaft journal.

CRANKSHAFT AND BALANCER SHAFT

TIP_


Do not put the Plastigauge® over the oil hole in the balancer shaft journal.




d. Install the balancer shaft journal lower bearings "3" into the crankcase and assemble the crankcase and cylinder.

TIP_

- Align the projections "c" of the balancer shaft journal lower bearings with the notches "d" in the crankcase.
- Do not move the balancer shaft until the clearance measurement has been completed.



- e. Tighten the bolts to specification in the tightening sequence cast on the crankcase. Refer to "CRANKCASE" on page 5-64.
- f. Remove the crankcase and the balancer shaft journal lower bearings.
- g. Measure the compressed Plastigauge® width "e" on each balancer shaft journal. If the balancer shaft-journal-to-balancer shaft-journal-bearing clearance is out of specification, select replacement balancer shaft journal bearings.





5. Select:

• Balancer shaft journal bearings (J₁–J₃)


TIP_

- The numbers "A" stamped into the crankcase and the numbers "B" stamped into the balancer shaft web are used to determine the replacement balancer shaft journal bearing sizes.
- J₁–J₃ refer to the bearings shown in the crankcase and balancer shaft web illustration.
- If J₁–J₃ are the same, use the same size for all of the bearings.





CRANKSHAFT AND BALANCER SHAFT



For example, if the crankcase J_1 and balancer shaft web J_1 numbers are 6 and 5 respectively, then the bearing size for J_1 is:

J_1 (crankcase) – J_1 (balancer shaft web)	
= 6 - 5 =	
1 (blue)	

X

Bearing color code 1. Blue 2. Black 3. Brown 4. Green 5. Yellow


EAS31075

CHECKING THE CRANKSHAFT

- 1. Check:
 - Balancer drive gear Damage/wear → Replace the balancer drive gear and balancer shaft assembly as a set. Excessive noise during operation → Replace the balancer drive gear and balancer shaft assembly as a set.
- 2. Measure:
 - Crankshaft runout Out of specification → Replace the crankshaft.



Runout limit 0.030 mm (0.0012 in)



- 3. Check:
 - Crankshaft journal surfaces
 - Crankshaft pin surfaces
 - Bearing surfaces Scratches/wear \rightarrow Replace the crankshaft.

- 4. Measure:
- Crankshaft-journal-to-crankshaft-journalbearing clearance
 Out of specification → Replace the crankshaft journal bearings.

Journal oil clearance 0.018–0.042 mm (0.0007–0.0017 in)


NOTICE

Do not interchange the crankshaft journal bearings. To obtain the correct crankshaftjournal-to-crankshaft-journal-bearing clearance and prevent engine damage, the crankshaft journal bearings must be installed in their original positions.

- ****
- a. Clean the crankshaft journal bearings, crankshaft journals, and bearing portions of the cylinder and crankcase.
- b. Install the crankshaft journal upper bearings "1" and the crankshaft into the cylinder.

TIP _

Align the projections "a" on the crankshaft journal upper bearings with the notches "b" in the cylinder.




c. Put a piece of Plastigauge® "2" on each crankshaft journal.

TIP _

Do not put the Plastigauge® over the oil hole in the crankshaft journal.


CRANKSHAFT AND BALANCER SHAFT




d. Install the crankshaft journal lower bearings "3" into the crankcase and assemble the crankcase and cylinder.

TIP.

- Align the projections "d" of the crankshaft journal lower bearings with the notches "e" in the crankcase.
- Do not move the crankshaft until the clearance measurement has been completed.



- e. Tighten the bolts to specification in the tightening sequence cast on the crankcase. Refer to "CRANKCASE" on page 5-64.
- f. Remove the crankcase and the crankshaft journal lower bearings.
- g. Measure the compressed Plastigauge® width "g" on each crankshaft journal. If the crankshaft-journal-to-crankshaft-journal-bearing clearance is out of specification, select replacement crankshaft journal bearings.





5. Select:

```
• Crankshaft journal bearings (J_1-J_3)
```


TIP _

- The numbers "A" stamped into the crankcase and the numbers "B" stamped into the crankshaft web are used to determine the replacement crankshaft journal bearing sizes.
- J₁–J₃ refer to the bearings shown in the crankcase and crankshaft web illustration.
- If J₁–J₃ are the same, use the same size for all of the bearings.









For example, if the crankcase J_1 and crankshaft web J_1 numbers are 5 and 3 respectively, then the bearing size for J_1 is:


J ₁ (crankcase) – J ₁ (crankshaft web) –2
= 5 - 3 - 2
= 0 (white-pink)




Bearing color code -1. Violet-Pink 0. White-Pink 1. Blue-Pink 2. Black-Pink 3. Brown-Pink

EAS31077 INSTALLING THE CRANKSHAFT

- 1. Install:
 - Crankshaft journal upper bearings (into the upper crankcase)
 - Crankshaft journal lower bearings (into the lower crankcase)
- TIP_
- Align the projections "a" on the crankshaft journal bearings "1" with the notches "b" in the crankcase.
- Be sure to install each crankshaft journal bearing in its original place.





- A. Cylinder
- B. Crankcase


EAS31078


INSTALLING THE BALANCER SHAFT ASSEMBLY

- 1. Install:
 - Balancer shaft journal upper bearings (into the upper crankcase)
 - Balancer shaft journal lower bearings (into the lower crankcase)

TIP _

- Align the projections "a" on the balancer shaft journal bearings "1" with the notches "b" in the crankcase.
- Be sure to install each balancer shaft journal bearing in its original place.







- A. Upper crankcase
- B. Lower crankcase
- 2. Install:
- Balancer shaft "1"


TIP_


Align the punch mark "a" in the balancer drive gear with the punch mark "b" in the balancer driven gear.







Order	Job/Parts to remove	Q'ty	Remarks
	Crankcase		Refer to "CRANKCASE" on page 5-64.
1	Drive axle assembly	1	
2	Shift drum retainer	1	
3	Shift fork guide bar	2	
4	Shift fork "L"	1	
5	Shift fork "R"	1	
6	Shift drum assembly	1	
7	Shift fork "C"	1	
8	Bearing retainer	1	
9	Main axle assembly	1	











REMOVING THE TRANSMISSION

- 1. Remove:
 - Drive axle assembly "1"
 - Shift drum retainer "2"
 - Shift fork guide bars
 - Shift fork "L" and "R"
 - Shift drum assembly
 - Shift fork "C"



- 2. Remove:
 - Bearing retainer
 - Main axle assembly bearing housing "1"
- Main axle assembly "2"

a. Insert two bolts "3" of the proper size, as shown in the illustration, into the main axle assembly bearing housing.



- b. Tighten the bolts until they contact the crankcase surface.
- c. Continue tightening the bolts until the main axle assembly comes free from the cylinder.


CHECKING THE SHIFT FORKS

The following procedure applies to all of the shift forks.

1. Check:


EAS20/21

- Shift fork cam follower "1"
- Shift fork pawl "2" Bends/damage/scoring/wear → Replace the shift fork.



- 2. Check:
- Shift fork guide bar Roll the shift fork guide bar on a flat surface. Bends → Replace.

Do not attempt to straighten a bent shift fork guide bar.



3. Check:

Shift fork movement

 (along the shift fork guide bar)
 Rough movement → Replace the shift forks
 and shift fork guide bar as a set.




319-011

319-010

CHECKING THE SHIFT DRUM ASSEMBLY

- 1. Check:
 - Shift drum groove
 - Damage/scratches/wear \rightarrow Replace the shift drum assembly.
 - Shift drum segment "1" Damage/wear → Replace the shift drum assembly.
 - Shift drum bearing "2" Damage/pitting → Replace the shift drum assembly.




- EAS30433 CHECKING THE TRANSMISSION
- 1. Measure:

• Main axle runout

(with a centering device and dial gauge "1") Out of specification \rightarrow Replace the main axle.





Main axle runout limit 0.08 mm (0.0032 in)



- 2. Measure:
- Drive axle runout


(with a centering device and dial gauge "1") Out of specification \rightarrow Replace the drive axle.





- 3. Check:
 - Transmission gears Blue discoloration/pitting/wear → Replace the defective gear(s).

- Transmission gear dogs
 - $\label{eq:cracks/damage/rounded edges} \rightarrow \mbox{Replace} the defective gear(s).$



4. Check:

• Transmission gear engagement (each pinion gear to its respective wheel gear)

 $\ensuremath{\mathsf{Incorrect}} \to \ensuremath{\mathsf{Reassemble}}$ the transmission axle assemblies.

5. Check:

 Transmission gear movement Rough movement → Replace the defective part(s).

- 6. Check:
 - Circlips

 $\texttt{Bends/damage/looseness} \rightarrow \texttt{Replace}.$


ASSEMBLING THE MAIN AXLE AND DRIVE AXLE


1. Install:


- Toothed washer "1"
- Circlip "2" New

TIP _

- Be sure the circlip sharp-edged corner "a" is positioned opposite side to the toothed washer and gear.
- Align the opening between the ends "b" of the circlip with a groove "c" in the axle.








- A. Main axle
- B. Drive axle
- 2. Install:

Α

- Toothed lock washer retainer "1"
- Toothed lock washer "2"

TIP _

- With the toothed lock washer retainer in the groove "a" in the axle, align the projection "b" on the retainer with an axle spline "c", and then install the toothed lock washer.
- Be sure to align the projection on the toothed lock washer that is between the alignment marks "e" with the alignment mark "d" on the retainer.
- Be sure the toothed lock washer retainer sharp-edged corner "f" is positioned opposite side to the toothed lock washer.



INSTALLING THE TRANSMISSION

- 1. Install:
 - Main axle assembly "1"


Bearing retainer



Bearing retainer bolt 12 Nm (1.2 m·kgf, 8.7 ft·lbf) LOCTITE®

TIP

Use a suitable pin "a" to position the bearing housing, and then install the housing until it contacts the cylinder.



- 2. Install:
- Shift fork "C"
- Shift drum assembly
- Shift fork guide bar

TIP .


- The embossed marks on the shift forks should face towards the right side of the engine.
- Install shift fork "C" into the groove in the 3rd pinion gear on the main axle.
- 3. Install:
 - Shift fork "L" "1"
 - Shift fork "R" "2"
 - Shift fork guide bar
 - Shift drum retainer
 - Drive axle assembly "3"




Shift drum retainer bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf) LOCTITE®

TIP

- Install shift fork "L" into the groove in the 6th wheel gear and shift fork "R" into the groove in the 5th wheel gear on the drive axle.
- Make sure that the projection "a" on the drive axle assembly is inserted into the slot in the cylinder.
- Make sure that the drive axle bearing circlip "b" and flange "c" of the oil seal are inserted into the grooves in the cylinder.





- 4. Check:
 - Transmission
 - Rough movement \rightarrow Repair.

TIP ____

Oil each gear, shaft, and bearing thoroughly.

COOLING SYSTEM

RADIATOR	
CHECKING THE RADIATOR	6-3
INSTALLING THE RADIATOR SIDE COVER BRACKETS AND	
RADIATOR SIDE COVERS	6-3
INSTALLING THE RADIATOR	6-4
OIL COOLER	
CHECKING THE OIL COOLER	6-6
CHECKING THE WATER JACKET JOINT	
INSTALLING THE OIL COOLER	6-6
THERMOSTAT	
CHECKING THE THERMOSTAT	6-8
INSTALLING THE THERMOSTAT	6-8
WATER PUMP	6-9
DISASSEMBLING THE WATER PUMP	
CHECKING THE WATER PUMP	
ASSEMBLING THE WATER PUMP	6-11
INSTALLING THE CLUTCH COVER	6-13

RADIATOR

1

2

3

4

5

6

7

Radiator cap

Coolant reservoir hose


Coolant reservoir cover

Radiator side cover (left)

Radiator side cover bracket bolt (left)

Coolant reservoir cap

Coolant reservoir



1

1

1


1

1

1

1

RADIATOR




CHECKING THE RADIATOR

- 1. Check:
- Radiator fins Obstruction → Clean. Apply compressed air to the rear of the radiator.
 - Damage \rightarrow Repair or replace.

TIP_

Straighten any flattened fins with a thin, flat-head screwdriver.



- 2. Check:
 - Radiator hoses
 Cracks/damage → Replace.
 - Radiator pipes Cracks/damage \rightarrow Replace the radiator.
- 3. Measure:
 - Radiator cap opening pressure Below the specified pressure → Replace the radiator cap.





Radiator cap valve opening pressure

108.0–137.4 kPa (1.08–1.37

kgf/cm², 15.7–19.9 psi)

a. Install the radiator cap tester "1" and radiator cap tester adapter "2" to the radiator cap "3".





b. Apply the specified pressure for ten seconds and make sure there is no drop in pressure.

- 4. Check:
 - Radiator fan
 - Damage \rightarrow Replace. Malfunction \rightarrow Check and repair. Refer to "COOLING SYSTEM" on page 8-29.

INSTALLING THE RADIATOR SIDE COVER BRACKETS AND RADIATOR SIDE COVERS

The following procedure applies to both of the radiator side cover brackets and radiator side covers.


- 1. Install:
 - Radiator side cover bracket bolt "1"
 - Radiator side cover "2"




Radiator side cover bracket bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Radiator side cover bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

TIP _

- Install the radiator side cover bracket so that the end with round hole "a" is pointing upward and the end with the oval hole "b" is pointing downward.
- Install the radiator side cover so that the end with the round hole "c" is pointing upward and the end with the oval hole "d" is pointing downward.






EAS30440

INSTALLING THE RADIATOR

- 1. Install:
- Coolant reservoir cap "1"

TIP_

Point the tab "a" on the coolant reservoir cap in the direction shown in the illustration.




- 2. Fill:
 - Cooling system

(with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" on page 3-24.

- 3. Check:
 - Cooling system
 - Leaks \rightarrow Repair or replace any faulty part.
- 4. Measure:
 - Radiator cap opening pressure Below the specified pressure → Replace the radiator cap.
 Refer to "CHECKING THE RADIATOR" on page 6-3.

OIL COOLER



CHECKING THE OIL COOLER

- 1. Check:
 - Oil cooler Cracks/damage \rightarrow Replace.
- 2. Check:
 - Oil cooler inlet hose
 - Oil cooler outlet hose
 - Water pump outlet hose Cracks/damage \rightarrow Replace.
- CHECKING THE WATER JACKET JOINT
- 1. Check:
- Water jacket joint Mineral deposits/rust → Eliminate.

EAS30442 INSTALLING THE OIL COOLER


- 1. Clean:
 - Mating surfaces of the oil cooler and the crankcase
- (with a cloth dampened with lacquer thinner) 2. Install:
 - Gasket New
 - Oil cooler "1"
 - Oil filter cartridge union bolt



Oil filter cartridge union bolt 40 Nm (4.0 m·kgf, 29 ft·lbf)

TIP

- Before installing the oil cooler, apply engine oil lightly to the oil filter cartridge union bolt.
- Align the projection "a" on the oil cooler with the slot "b" in the crankcase.




- 3. Fill:
 - Cooling system (with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" on page 3-24.

- Crankcase
 - (with the specified amount of the recommended engine oil) Refer to "CHANGING THE ENGINE OIL" on page 3-21.
- 4. Check:
 - Cooling system Leaks → Repair or replace any faulty part. Refer to "INSTALLING THE RADIATOR" on page 6-4.
- 5. Measure:
- Radiator cap opening pressure Below the specified pressure → Replace the radiator cap.
 Refer to "CHECKING THE RADIATOR" on page 6-3.

6

EAS20065 THERMOSTAT



) N

Δ

5

🔀 12 Nm (1.2 m·kgf, 8.7 ft·lbf)

Order	Job/Parts to remove	Q'ty	Remarks
	Coolant		Drain. Refer to "CHANGING THE COOLANT" on page 3-24.
	Seat		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Fuel tank center cover		Refer to "GENERAL CHASSIS (3)" on page 4-5.
	Fuel tank/Canister		Refer to "FUEL TANK" on page 7-1.
1	Coolant temperature sensor coupler	1	Disconnect.
2	Coolant temperature sensor	1	
3	Radiator inlet hose	1	Disconnect.
4	Thermostat cover	1	
5	Thermostat	1	

2

🔌 16 Nm (1.6 m·kgf, 12 ft·lbf)

10 M


New


CHECKING THE THERMOSTAT

- 1. Check:
 - Thermostat Does not open at 80–84 °C (176–183.2 °F) → Replace.



- a. Suspend the thermostat "1" in a container "2" filled with water.
- b. Slowly heat the water "3".
- c. Place a thermometer "4" in the water.
- d. While stirring the water, observe the thermostat and thermometer's indicated temperature.





- A. Fully closed
- B. Fully open

TIP_

If the accuracy of the thermostat is in doubt, replace it. A faulty thermostat could cause serious overheating or overcooling.

- 2. Check:
 - Thermostat cover Cracks/damage \rightarrow Replace.


EAS30939

INSTALLING THE THERMOSTAT

- 1. Install:
 - Thermostat

TIP.

Install the thermostat with its breather valve "a" facing inward.





- 2. Fill:
 - Cooling system (with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" on page 3-24.
- 3. Check:
 - Cooling system Leaks \rightarrow Repair or replace any faulty part.
- 4. Measure:

 Radiator cap opening pressure Below the specified pressure → Replace the radiator cap.

Refer to "CHECKING THE RADIATOR" on page 6-3.

WATER PUMP






EAS30446 DISASSEMBLING THE WATER PUMP

- 1. Remove:
 - Mechanical seal (impeller side) "1" (from the impeller, with a thin, flat-head screwdriver)

TIP_

Do not scratch the impeller shaft.




2. Remove:

• Mechanical seal (housing side) "1"

TIP.

Remove the mechanical seal (housing side) from the inside of the clutch cover "2".




3. Remove:

- Bearing "1"
- Oil seal "2"

TIP.

Remove the bearing and oil seal from the outside of the clutch cover "3".



EAS30447 CHECKING THE WATER PUMP


- 1. Check:
 - Water pump housing
 - Clutch cover
 - Impeller shaft
 - $Cracks/damage/wear \rightarrow Replace.$
- 2. Check:
- Bearing
 - Rough movement \rightarrow Replace.
- 3. Check:
 - Water pump outlet pipe
 - Water pump inlet pipe Cracks/damage/wear \rightarrow Replace.


EAS30448

- ASSEMBLING THE WATER PUMP
- 1. Install:
 - Oil seal "1" New
 - Bearing
 - (into the clutch cover "2")

TIP_

Install the oil seal with a socket "3" that matches its outside diameter.





- 2. Install:
- Mechanical seal (housing side) "1" New (into the clutch cover "2")


ECA20330

Never lubricate the mechanical seal (housing side) surface with oil or grease.

TIP

Use the special tools and a press to press the mechanical seal (housing side) straight in until it touches the clutch cover.


Mechanical seal installer 90890-04132 Water pump seal installer YM-33221-A Middle driven shaft bearing driver 90890-04058 Middle drive bearing installer 40 & 50 mm YM-04058



- 3. Mechanical seal installer
- 4. Middle driven shaft bearing driver
- A. Push down
- 3. Install:
 - Mechanical seal (impeller side) "1" New

TIP.

Before installing the mechanical seal (impeller side), apply tap water or coolant onto its outer surface.




- 4. Measure:
- Mechanical seal (impeller side) Out of specification → Repeat steps (3) and (4).


NOTICE

Make sure the rubber damper and rubber damper holder are flush with the impeller.

TIP __

If the surface "a" of the mechanical seal (impeller side) that contacts the mechanical seal (housing side) is dirty, clean it.






- 1. Straightedge
- 2. Impeller
- 5. Install:
- Impeller shaft "1"
- Circlip "2"

TIP __

- Be sure the circlip sharp-edged corner "a" is positioned opposite side to the bearing.
- After installation, check that the impeller shaft rotates smoothly.



INSTALLING THE CLUTCH COVER 1. Install:


- Dowel pins "1"
- Clutch cover gasket "2" New
- Clutch cover "3"



Clutch cover bolt 12 Nm (1.2 m·kgf, 8.7 ft·lbf) Clutch cable holder bolt 12 Nm (1.2 m·kgf, 8.7 ft·lbf) LOCTITE®

TIP_

- Align the slit "a" in the impeller shaft with the projection "b" on the oil pump driven sprocket.
- Face the serrations on the clutch pull rod "4" rearward and align the rod with the hole "c" in the clutch cover.
- Apply looking agent (LOCTITE®) to the threads of only the clutch cable holder bolts "5".
- Tighten the bolts in stages and in a crisscross pattern.
- After installing the clutch cover, make sure that the alignment mark "d" on the clutch cover is aligned with the punch mark "e" on the pull lever "6".



- 2. Fill:
 - Cooling system (with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" on page 3-24.

- 3. Check:
 - Cooling system Leaks \rightarrow Repair or replace the faulty part.
- 4. Measure:
- Radiator cap opening pressure Below the specified pressure → Replace the radiator cap.
 Refer to "CHECKING THE RADIATOR" on page 6-3.
- 5. Adjust:
 - Clutch lever free play Refer to "ADJUSTING THE CLUTCH LEVER FREE PLAY" on page 3-12.


FUEL SYSTEM

FUEL TANK	7-1
REMOVING THE FUEL TANK	7-4
REMOVING THE FUEL PUMP	
CHECKING THE FUEL PUMP BODY	7-4
INSTALLING THE CANISTER	
INSTALLING THE FUEL PUMP	7-4
INSTALLING THE DAMPERS	7-5
INSTALLING THE FUEL TANK BRACKET	7-5
INSTALLING THE FUEL TANK	7-5
THROTTLE BODIES	7-7
CHECKING THE INJECTORS (BEFORE REMOVING)	
REMOVING THE INJECTORS	
CHECKING THE INJECTORS	7-10
CHECKING THE THROTTLE BODIES	7-10
CLEANING THE ISC (IDLE SPEED CONTROL) VALVE	7-10
CHECKING THE THROTTLE BODY JOINTS	
ADJUSTING THE THROTTLE POSITION SENSOR	7-13
INSTALLING THE FUEL INJECTORS	7-13
CHECKING THE INJECTOR PRESSURE	7-14
CHECKING THE FUEL PRESSURE	7-14
INSTALLING THE THROTTLE BODY JOINTS	7-15
INSTALLING THE AIR FILTER CASE	7-15

FUEL TANK Removing the fuel tank and fuel pump 🔀 30 Nm (3.0 m·kgf, 22 ft·lbf) 🔀 7 Nm (0.7 m·kgf, 5.1 ft·lbf) C Č) 🔌 3.8 Nm (0.38 m·kgf, 2.8 ft·lbf) C 10 Nm (1.0 m·kgf, 7.2 ft·lbf) New Ê മ 0 | 5 3 (4) 🔀 7 Nm (0.7 m·kgf, 5.1 ft·lbf) 🔌 10 Nm (1.0 m·kgf, 7.2 ft·lbf) 🔌 4.0 Nm (0.40 m·kgf, 2.9 ft·lbf) Order Q'ty Job/Parts to remove Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Seat Refer to "GENERAL CHASSIS (3)" on page Fuel tank center cover/Inner side cover (left) 4-5. 1 Intake air temperature sensor coupler 1 Disconnect. 2 Disconnect. Fuel tank overflow hose 1 3 Fuel tank breather hose 1 Disconnect. 4 Fuel pump coupler 1 Disconnect. 5 Fuel hose 1

EAS20067

FUEL TANK



FUEL TANK

	the canister			
	4		5	
Order	4 Job/Parts to remove	Q'ty	Remarks	
Order	4 Job/Parts to remove Seat	Q'ty	Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1.	
Order		Q'ty	Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Refer to "GENERAL CHASSIS (3)" on page 4-5.	
Order	Seat Fuel tank center cover Fuel tank	Q'ty	Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Refer to "GENERAL CHASSIS (3)" on page	
Order	Seat Fuel tank center cover	Q'ty	Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Refer to "GENERAL CHASSIS (3)" on page 4-5.	
	Seat Fuel tank center cover Fuel tank		Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Refer to "GENERAL CHASSIS (3)" on page 4-5.	
1	Seat Fuel tank center cover Fuel tank Fuel tank overflow hose	1	Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Refer to "GENERAL CHASSIS (3)" on page 4-5.	
1 2	Seat Fuel tank center cover Fuel tank Fuel tank overflow hose Fuel tank breather hose (fuel tank to canister)	1	Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Refer to "GENERAL CHASSIS (3)" on page 4-5.	
1 2 3	Seat Fuel tank center cover Fuel tank Fuel tank overflow hose Fuel tank breather hose (fuel tank to canister) Canister purge hose (hose joint to canister)	1 1 1 1	Remarks Refer to "GENERAL CHASSIS (1)" on page 4-1. Refer to "GENERAL CHASSIS (3)" on page 4-5.	

EAS30450 **REMOVING THE FUEL TANK**

- 1. Extract the fuel in the fuel tank through the fuel tank cap with a pump.
- 2. Remove:
- Fuel hose


Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hose.

ECA20020 NOTICE

Although the fuel has been removed from the fuel tank, be careful when removing the fuel hose, since there may be fuel remaining in it.

TIP

- To remove the fuel hose from the fuel rail and fuel pump, slide the fuel hose connector cover "1" on the end of the hose in the direction of the arrow shown, press the two buttons "2" on the sides of the connector, and then remove the hose.
- Remove the fuel hose manually without using any tools.
- Before removing the hose, place a few rags in the area under where it will be removed.



- 3. Remove:
- Fuel tank
- TIP

Do not set the fuel tank down on the installation surface of the fuel pump. Be sure to lean the fuel tank against a wall or the like.

EAS3045 **REMOVING THE FUEL PUMP**

- 1. Remove:
- Fuel pump

ECA14721 NOTICE

- Do not drop the fuel pump or give it a strong shock.
- · Do not touch the base section of the fuel sender.

EAS20464 CHECKING THE FUEL PUMP BODY

- 1. Check:
 - Fuel pump body Obstruction \rightarrow Clean. Cracks/damage \rightarrow Replace fuel pump assembly.


EAS31330

INSTALLING THE CANISTER

- 1. Install:
 - Canister "1"
- Canister holder "2"

TIP

Fit the projection on the canister into the slot "a" in the canister holder.



EAS30456

INSTALLING THE FUEL PUMP

- 1. Install:
- Fuel pump gasket "1" New
- Fuel pump
- Fuel pump bracket




Fuel pump bolt 4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)

TIP

- Do not damage the installation surfaces of the fuel tank when installing the fuel pump.
- Always use a new fuel pump gasket.
- The gasket lip "a" shall face toward the fuel tank.
- Align the projection "b" on the fuel pump with the punch mark "c" on the fuel tank.
- Align the slot in the fuel pump bracket with the projection "b" on the fuel pump.

• Tighten the fuel pump bolts in the proper tightening sequence as shown.




EAS31801

INSTALLING THE DAMPERS

- 1. Install:
 - Damper 2 "1"
 - Damper 1 "2"

TIP.

- Fit the slot "a" in each damper 2 over the rib "b" on the fuel tank.
- Align the projections "c" on damper 1 with the projection "d" on each damper 2.



INSTALLING THE FUEL TANK BRACKET 1. Install:


- Grommets
- Collars
- Front fuel tank bracket "1"



Fuel tank bolt (front side) 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

TIP.

Make sure that the arrow mark "a" on the front fuel tank bracket points toward the hole "b" in the fuel tank.




- 2. Install:
 - Grommets
- Collars
- Rear fuel tank bracket "1"



Fuel tank bolt (rear side) 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

TIP _

Make sure that the arrow mark "a" on the rear fuel tank bracket points toward the punch mark "b" on the fuel tank.



EAS30457 INSTALLING THE FUEL TANK

- 1. Tighten:
- Front fuel tank bracket bolt (temporarily)

TIP __

Temporarily tighten the front fuel tank bracket bolt.

2. Install:


• Fuel hose

ECA18420

When installing the fuel hose, make sure that it is securely connected, and that the fuel hose connector cover on the fuel hose is in the correct position; otherwise, the fuel hose will not be properly installed.

TIP .

- Install the fuel hose securely onto the fuel rail and fuel pump until a distinct "click" is heard.
- To install the fuel hose, slide the fuel hose connector cover "1" on each end of the hose in the direction of the arrow shown.



- 3. Connect:
 - Fuel pump coupler
 - Fuel tank breather hose
 - Fuel tank overflow hose
 - Intake air temperature sensor
- 4. Tighten:
 - Rear fuel tank bracket bolts




Rear fuel tank bracket bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

- 5. Tighten:
 - Front fuel tank bracket bolt





Front fuel tank bracket bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

THROTTLE BODIES



Order	Job/Parts to remove	Q'ty	Remarks
	Seat		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Fuel tank center cover/Inner side covers		Refer to "GENERAL CHASSIS (3)" on page 4-5.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Air duct bracket		Refer to "GENERAL CHASSIS (4)" on page 4-7.
	Pivot shaft protector (left/right)		Refer to "SWINGARM" on page 4-88.
1	Cylinder head breather hose	1	
2	Throttle position sensor coupler	1	Disconnect.
3	Canister purge hose	3	
4	Hose joint	1	
5	Injector coupler	2	Disconnect.






CHECKING THE INJECTORS (BEFORE REMOVING)

- 1. Check:
- Injectors

Use the diagnostic code numbers "36–37". Refer to "SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE" on page 9-5.

EAS30476

- Check the injectors in a well-ventilated area free of combustible materials. Make sure that there is no smoking or use of electric tools in the vicinity of the injectors.
- Be careful when disconnecting the fuel hose. Any remaining pressure in the fuel hose may cause the fuel to spray out. Place a container or rag under the hose to catch any fuel that spills. Always clean up any spilt fuel immediately.
- Turn the main switch to "OFF" and disconnect the negative battery lead from the battery terminal before removing the injectors.
- 1. Remove:
- Fuel rail "1"
- a. Remove the fuel rail bolts "2" as shown.



CHECKING THE INJECTORS

- 1. Check:
- Injectors

Obstruction \rightarrow Replace and check the fuel pump/fuel supply system. Deposit \rightarrow Replace. Damage \rightarrow Replace.

- 2. Check:
- Injector resistance Refer to "CHECKING THE FUEL INJEC-TORS" on page 8-171.

CHECKING THE THROTTLE BODIES

TIP.

Before checking the throttle bodies, check the following items:

- Valve clearance
- Spark plugs
- Air filter element
- Throttle body joints
- Fuel hose
- Exhaust system
- Cylinder head breather hose
- Vacuum hoses

If the throttle bodies are subjected to strong shocks or dropped during checking, replace them.

- 1. Check:
 - Throttle bodies

 $\mbox{Cracks/damage} \rightarrow \mbox{Replace}$ the throttle bodies.

EAS31143

CLEANING THE ISC (IDLE SPEED CONTROL) VALVE

1. Remove the throttle bodies from the vehicle.

Before removing the throttle bodies, disconnect the throttle cables and couplers.


Cleaning the throttle bodies

- 1. Clean:
- Throttle bodies


NOTICE

- Observe the following precautions; otherwise, the throttle bodies may not operate properly.
- Do not open the throttle valves quickly.
- Do not subject the throttle bodies to excessive force.
- Wash the throttle bodies in a petroleumbased solvent.
- Do not use any caustic carburetor cleaning solution.
- Do not apply cleaning solvent directly to any plastic parts, sensors, or seals.
- Do not directly push the throttle valves to open them.

• Do not turn the bypass air screws "a"; otherwise, the throttle body synchronization will be affected.



- a. Place the throttle bodies on a flat surface with the air filter case side facing up.
- b. Install the caps (895-14169-00) onto the hose fittings "a".




c. Push the lever in the direction shown in the illustration to hold the throttle valves in the open position.

WARNING

When cleaning the throttle bodies, be careful not to injure yourself on the throttle valves or other components of the throttle bodies.

ECA21190

- Do not use tools to open the throttle valves or to keep them in the open position.
- Do not open the throttle valves quickly.




d. Apply a petroleum-based solvent to the throttle valves and the inside of the throttle bodies to remove any carbon deposits.

TIP _

- Do not allow any petroleum-based solvent to enter the opening for the injectors.
- Do not apply any petroleum-based solvent to the portions of the throttle valve shafts between the throttle bodies.
- e. Remove the carbon deposits from the inside of each throttle body in a downward direction, from the air filter case side of the throttle body to the engine side.

NOTICE

- Do not use a tool, such as a wire brush, to remove the carbon deposits; otherwise, the inside of the throttle bodies may be damaged.
- Do not allow carbon deposits or other foreign materials to enter any of the passages in each throttle body or in the space between the throttle valve shaft and the throttle body.
- f. After removing the carbon deposits, clean the inside of the throttle bodies with a petroleumbased solvent, and then dry the throttle bodies using compressed air.
- g. Make sure that there are no carbon deposits or other foreign materials in any of the passages "a" in each throttle body or in the space "b" between the throttle valve shaft and the throttle body.



Cleaning the ISC (idle speed control) valve 1. Remove:

- ISC (Idle Speed Control) valve plate
- ISC (Idle Speed Control) valve
- O-ring
- 2. Clean:
 - ISC (Idle Speed Control) valve "1"

Recommended cleaning agent: Yamaha oil & brake cleaner


NOTICE


ECA21230

- Be sure to use the recommended cleaning agent.
- Do not spray the cleaning agent directly onto the ISC valve or throttle bodies and do not immerse them in the cleaning agent.
- To prevent scratching the components, do not use a brush, metal file, or other abrasive tool.
- Do not clean with compressed air.
- Do not allow the removed deposits or foreign materials to adhere to the sealing surfaces of the O-ring.
- Do not scratch or deform the ISC valve or air passage; otherwise, poor starting performance, an unstable engine idling speed, or uncontrollable engine speed could result.
- Do not clean any areas other than those indicated in the illustrations. If the cleaning agent attaches to the ISC valve or enters the throttle bodies, thoroughly wipe it off.

TIP_

Clean the area "a" of the ISC valve and the ISC valve installation hole "b" in the throttle bodies.





3. Install:


• O-ring New

- ISC (Idle Speed Control) valve
- ISC (Idle Speed Control) valve plate

ISC (Idle Speed Control) valve plate screw 5 Nm (0.5 m·kgf, 3.6 ft·lbf)

TIP.

Align the slot "a" in the ISC valve plate with the projection "b" on the ISC valve.



Resetting the ISC (idle speed control) learning values


- 1. Install:
 - Throttle bodies
- 2. Reset:
 - ISC (idle speed control) learning values Use the diagnostic code number "67". Refer to "SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE" on page 9-5.
- 3. Adjust:
- Throttle bodies synchronizing Out of specification → Replace the throttle bodies.
 Refer to "SYNCHRONIZING THE THROT-

TLE BODIES" on page 3-8.

EAS30792

CHECKING THE THROTTLE BODY JOINTS 1. Check:

Throttle body joints "1"
 Cracks/damage → Replace.



THROTTLE BODIES

ADJUSTING THE THROTTLE POSITION SENSOR


- Handle the throttle position sensor with special care.
- Never subject the throttle position sensor to strong shocks. If the throttle position sensor is dropped, replace it.

1. Check:

- Throttle position sensor Refer to "CHECKING THE THROTTLE PO-SITION SENSOR" on page 8-169.
- 2. Adjust:
- Throttle position sensor angle
- *****
- a. Temporary tighten the throttle position sensor bolts.
- b. Check that the throttle valves are fully closed.
- c. Connect the throttle position sensor to the wire harness.
- d. Remove the protective cap "1", and then connect the Yamaha diagnostic tool to coupler.

TIP _

For information about using the Yamaha diagnostic tool, refer to the operation manual that is included with the tool.




- e. Diagnostic code number "01" is selected.
- f. Adjust the position of the throttle position sensor angle so that 11–21 can appear in the Yamaha diagnostic tool screen.
- g. After adjusting the throttle position sensor angle, tighten the throttle position sensor bolts "2".

Throttle position sensor screw 3.5 Nm (0.35 m·kgf, 2.5 ft·lbf)



INSTALLING THE FUEL INJECTORS

- Always use new O-rings.
- When checking the injectors, do not allow any foreign material to enter or adhere to the injectors, fuel rail, or O-rings.
- Be careful not to twist or pinch the O-rings when installing the injectors.
- If an injector is subject to strong shocks or excessive force, replace it.
- If installing the original fuel rail and screws, remove the white paint marks using a cleaning solvent. Otherwise, paint chips on the screw seats could prevent the screws from being tightened to the specified torque.
- 1. Install new seals onto the end of each injector.
- 2. Install the fuel injectors "1" to the fuel rail "2".





Fuel rail bolt 3.5 Nm (0.35 m·kgf, 2.5 ft·lbf)


- 3. Install the fuel injector assemblies to the throttle bodies.
- Check the injector pressure after the fuel injectors are installed to the throttle bodies. Refer to "CHECKING THE INJECTOR PRESSURE" on page 7-14.


CHECKING THE INJECTOR PRESSURE

TIP _

- After installing the fuel injectors, perform the following steps to check the injector pressure.
- Do not allow any foreign materials to enter the fuel lines.
- 1. Check:
 - Injector pressure

- a. Connect the fuel injector pressure adapter "1" to the fuel rail "2", and then connect an air compressor "3" to the adapter.
- b. Connect the pressure gauge "4" to the fuel injector pressure adapter "1".





- c. Close the valve on the fuel injector pressure adapter.
- d. Apply air pressure with the air compressor.
- e. Open the valve on the fuel injector pressure adapter until the specified pressure is reached.



Specific air pressure

490 kPa (4.9 kgf/cm², 69.7 psi)

NOTICE

ECA18440

Never exceed the specified air pressure or damage could occur.

- f. Close the valve on the fuel injector pressure adapter.
- g. Check that the specified air pressure is held for about one minute.

Pressure drops \rightarrow Check the pressure gauge and adapter.

Check the seals and O-rings, and then reinstall.

Replace the fuel injectors.

CHECKING THE FUEL PRESSURE

1. Remove:

EAS3048


Seat

Refer to "GENERAL CHASSIS (1)" on page 4-1.

- Fuel tank center cover Refer to "GENERAL CHASSIS (3)" on page 4-5.
- 2. Check:
- Fuel pressure
- *****
- a. Remove the rear fuel tank bracket bolts "1" and holdup the fuel tank.

NOTICE

When lifting up the fuel tank, be careful not to pull the fuel tank overflow hose and fuel tank breather hose.




b. Disconnect the fuel hose "2" from the fuel tank.

WARNING


Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hoses.


ECA20010

Be sure to disconnect the fuel hose by hand. Do not forcefully disconnect the hose with tools.



c. Connect the pressure gauge "3" and adapter "4" to the fuel hose "2".





- d. Start the engine.
- e. Measure the fuel pressure.

Fuel line pressure at idling 300–390 kPa (3.0–3.9 kgf/cm², 43.5–56.6 psi) / Regulated pressure 324 kPa (3.2 kgf/cm², 47.0 psi)

Faulty \rightarrow Replace the fuel pump.

- 3. Install:
- Fuel tank

Rear fuel tank bracket bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

Refer to "FUEL TANK" on page 7-1. • Fuel tank center cover Refer to "GENERAL CHASSIS (3)" on page 4-5.

- Seat
 - Refer to "GENERAL CHASSIS (1)" on page 4-1.

EAS30937

INSTALLING THE THROTTLE BODY JOINTS 1. Install:


Throttle body joint clamp screw 3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)

• Throttle body joints "1"



TIP

Be sure to install the throttle body joints "1" as shown in the illustration.



- a. #1 cylinder
- b. #2 cylinder
- A. Left
- B. Right


- **INSTALLING THE AIR FILTER CASE** 1. Install:
 - Air filter case joint clamps "1"



Air filter case joint clamp screw 3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)

TIP

- Align the projection "a" on the air filter case joint with the slot "b" in the air filter case joint clamp.
- Face the screw head "c" of the air filter case joint clamp outward.




ELECTRICAL SYSTEM

IGNITION SYSTEM	8-1
CIRCUIT DIAGRAM	8-1
ENGINE STOPPING DUE TO SIDESTAND OPERATION	8-3
TROUBLESHOOTING	8-4
ELECTRIC STARTING SYSTEM	
CIRCUIT DIAGRAM	
STARTING CIRCUIT CUT-OFF SYSTEM OPERATION	
TROUBLESHOOTING	8-10
CHARGING SYSTEM	8-13
CIRCUIT DIAGRAM	
TROUBLESHOOTING	
LIGHTING SYSTEM	8-17
CIRCUIT DIAGRAM	8-17
TROUBLESHOOTING	8-19
SIGNALING SYSTEM	8-21
CIRCUIT DIAGRAM	
TROUBLESHOOTING	
COOLING SYSTEM	
CIRCUIT DIAGRAM	
TROUBLESHOOTING	8-31
FUEL INJECTION SYSTEM	
CIRCUIT DIAGRAM	
ECU SELF-DIAGNOSTIC FUNCTION	
TROUBLESHOOTING METHOD	
YAMAHA DIAGNOSTIC TOOL	
TROUBLESHOOTING DETAILS (FAULT CODE)	
TROUBLESHOOTING DETAILS (EVENT CODE)	
FUEL PUMP SYSTEM	0 101
TROUBLESHOOTING	8-103
IMMOBILIZER SYSTEM	8-105
CIRCUIT DIAGRAM	
GENERAL INFORMATION	8-107
PARTS REPLACEMENT AND KEY CODE REGISTRATION	
REQUIREMENTS	
TROUBLESHOOTING	
SELF-DIAGNOSIS FAULT CODE INDICATION	8-112

ABS (ANTI-LOCK BRAKE SYSTEM)	8-115
CIRCUIT DIAGRAM	
ABS COUPLER LOCATION CHART	8-117
MAINTENANCE OF THE ABS ECU	8-119
ABS TROUBLESHOOTING OUTLINE	
BASIC INSTRUCTIONS FOR TROUBLESHOOTING	8-120
BASIC PROCESS FOR TROUBLESHOOTING	8-121
[A] CHECKING THE ABS WARNING LIGHT	8-123
[A-1] ONLY THE ABS WARNING LIGHT FAILS TO COME ON	8-123
[A-2] ALL INDICATOR LIGHTS FAIL TO COME ON	8-123
[A-3] THE ABS WARNING LIGHT COMES ON	8-123
[A-4] ONLY THE ABS ECU FAILS TO COMMUNICATE	
(The select unit screen does not appear.)	8-123
[A-5] ABS ECU AND FI ECU FAIL TO COMMUNICATE	
(Cannot connect due to a tool error.)	
[B-1] MALFUNCTION ARE CURRENTLY DETECTED	
[B-2] DIAGNOSIS USING THE FAULT CODES	
[B-3] DELETING THE FAULT CODES	
[C-1] FINAL CHECK	8-147
ELECTRICAL COMPONENTS	8-149
CHECKING THE SWITCHES	
CHECKING THE BULBS AND BULB SOCKETS	
CHECKING THE FUSES	
REPLACING THE ECU (engine control unit)	
CHECKING AND CHARGING THE BATTERY	
CHECKING THE RELAYS	
CHECKING THE TURN SIGNAL/HAZARD RELAY	
CHECKING THE RELAY UNIT (DIODE)	
CHECKING THE IGNITION COILS	
CHECKING THE IGNITION SPARK GAP	8-164
CHECKING THE CRANKSHAFT POSITION SENSOR	8-165
CHECKING THE LEAN ANGLE SENSOR	8-165
CHECKING THE STARTER MOTOR OPERATION	8-166
CHECKING THE STATOR COIL	
CHECKING THE RECTIFIER/REGULATOR	8-166
CHECKING THE FUEL SENDER	
CHECKING THE FUEL METER/FUEL LEVEL WARNING LIGHT	8-167
CHECKING THE RADIATOR FAN MOTOR	
CHECKING THE COOLANT TEMPERATURE SENSOR	8-168
CHECKING THE THROTTLE POSITION SENSOR	
CHECKING THE INTAKE AIR PRESSURE SENSOR	
CHECKING THE INTAKE AIR TEMPERATURE SENSOR	
CHECKING THE GEAR POSITION SWITCH	
CHECKING THE FUEL INJECTORS	8-171

IGNITION SYSTEM

EAS30490 CIRCUIT DIAGRAM




- 1. Main switch
- 7. Ignition fuse
- 10.Fuel injection system fuse
- 15.Battery
- 16.Engine ground
- 18.Main fuse
- 22.Relay unit
- 25.Joint coupler
- 26.Sidestand switch
- 27.Crankshaft position sensor
- 30.Ignition coil #1
- 31.Ignition coil #2
- 32.Spark plug
- 36.ECU (Engine Control Unit)
- 40.Lean angle sensor
- 61.Gear position switch
- 62.Handlebar switch (right)
- 65.Start/engine stop switch
- A. Wire harness
- C. Sub-wire harness (gear position switch, coolant temperature sensor, fuel injector)

EAS30491 ENGINE STOPPING DUE TO SIDESTAND OPERATION

When the engine is running and the transmission is in gear, the engine will stop if the sidestand is moved down. This is because the electric current from the ECU does not flow to the ignition coils or fuel injectors when the gear position switch (neutral circuit) or sidestand switch is open. However, the engine continues to run under the following conditions:

- The transmission is in gear (the neutral circuit of the gear position switch is open) and the sidestand is up (the sidestand switch circuit is closed).
- The transmission is in neutral (the neutral circuit of the gear position switch is closed) and the sidestand is down (the sidestand switch circuit is open).



- 1. Battery
- 2. Main fuse
- 3. Main switch
- 4. Ignition fuse
- 5. Start/engine stop switch
- 6. Ignition coil
- 7. Spark plug
- 8. ECU (Engine Control Unit)
- 9. Relay unit (diode)
- 10. Sidestand switch
- 11. Gear position switch


The ignition system fails to operate (no spa Defere troubleshooting, remove the follow Battery cover E. Fuel tank center cover/Air scoops B. Fuel tank L. Drive sprocket cover Defending tassembly		
 Check the fuses. (Ignition, fuel injection system, and main) Refer to "CHECKING THE FUS- ES" on page 8-157. 	$NG \rightarrow$	Replace the fuse(s).
ОК↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158.	$NG \to$	 Clean the battery terminals. Recharge or replace the battery.
ОК↓		
 Check the spark plugs. Refer to "CHECKING THE SPARK PLUGS" on page 3-4. 	$NG \to$	Re-gap or replace the spark plug(s).
ОК↓		
4. Check the ignition spark gap. Refer to "CHECKING THE IGNI- TION SPARK GAP" on page 8-164.	$OK \to$	Ignition system is OK.
NG↓		
5. Check the ignition coils. Refer to "CHECKING THE IGNI- TION COILS" on page 8-164.	$NG \to$	Replace the ignition coil(s).
ОК↓		
 Check the crankshaft position sen- sor. Refer to "CHECKING THE CRANK- SHAFT POSITION SENSOR" on page 8-165. 	$NG \rightarrow$	Replace the crankshaft position sensor.
OK↓		L
7. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	Replace the main switch/immobilizer unit.

IGNITION SYSTEM

$NG \to$	The start/engine stop switch is faulty.Replace the right handlebar switch.
$NG \rightarrow$	Replace the gear position switch.
$NG \to$	Replace the sidestand switch.
$NG \to$	Replace the relay unit.
$NG \to$	Replace the lean angle sensor.
$NG \to$	Properly connect or replace the wiring har- ness.
	$NG \rightarrow$ $NG \rightarrow$ $NG \rightarrow$

ELECTRIC STARTING SYSTEM

EAS30493 CIRCUIT DIAGRAM



8-7


- 1. Main switch
- 7. Ignition fuse
- 15.Battery
- 16.Engine ground
- 18.Main fuse
- 19.Starter relay
- 20.Starter motor
- 22.Relay unit
- 23.Starting circuit cut-off relay
- 25.Joint coupler
- 26.Sidestand switch
- 61.Gear position switch
- 62.Handlebar switch (right)
- 65.Start/engine stop switch
- 67.Handlebar switch (left)
- 68.Clutch switch
- A. Wire harness
- C. Sub-wire harness (gear position switch, coolant temperature sensor, fuel injector)

EAS30494

STARTING CIRCUIT CUT-OFF SYSTEM OPERATION If the main switch is turned to "ON" and the " (\mathbf{s}) " side of the start/engine stop switch is pushed, the starter motor can only operate if at least one of the following conditions is met:

- The transmission is in neutral (the neutral circuit of the gear position switch is closed).
- The clutch lever is pulled to the handlebar (the clutch switch is closed) and the sidestand is up (the sidestand switch is closed).

The starting circuit cut-off relay prevents the starter motor from operating when neither of these conditions has been met. In this instance, the starting circuit cut-off relay is open so current cannot reach the starter motor. When at least one of the above conditions has been met, the starting circuit cut-off relay is closed and the engine can be cranked up by pressing the "^(a) side of the start/engine stop switch.



- a. WHEN THE TRANSMISSION IS IN NEUTRAL
- b. WHEN THE SIDESTAND IS UP AND THE CLUTCH LEVER IS PULLED TO THE HANDLEBAR
- 1. Battery
- 2. Main fuse
- 3. Main switch
- 4. Ignition fuse
- 5. Starting circuit cut-off relay
- 6. Relay unit (diode)
- 7. Clutch switch

- 8. Sidestand switch
- 9. Gear position switch
- 10. Start/engine stop switch
- 11. Starter relay
- 12. Starter motor


EAS30495 TROUBLESHOOTING The starter motor fails to turn. TIP • Before troubleshooting, remove the following part(s): 1. Battery cover 2. Fuel tank center cover/Air scoops 3. Fuel tank 4. Throttle bodies/Air filter case 5. Drive sprocket cover 6. Headlight assembly 1. Check the fuses. $NG \rightarrow$ (Ignition, fuel injection system, and main) Replace the fuse(s). Refer to "CHECKING THE FUS-ES" on page 8-157. OK↓ 2. Check the battery. $NG \rightarrow$ Refer to "CHECKING AND • Clean the battery terminals. CHARGING THE BATTERY" on • Recharge or replace the battery. page 8-158. OK ↑ 3. Check the starter motor operation. $OK \rightarrow$ Starter motor is OK. Perform the electric Refer to "CHECKING THE STARTstarting system troubleshooting, starting ER MOTOR OPERATION" on page with step 5. 8-166. NG↓ 4. Check the starter motor. $NG \rightarrow$ Refer to "CHECKING THE START-Repair or replace the starter motor. ER MOTOR" on page 5-44. OK↓ 5. Check the relay unit (starting circuit $NG \rightarrow$ cut-off relay). Replace the relay unit. Refer to "CHECKING THE RE-LAYS" on page 8-161. OK↓ 6. Check the relay unit (diode). $NG \rightarrow$ Refer to "CHECKING THE RELAY Replace the relay unit. UNIT (DIODE)" on page 8-163. OK↓ 7. Check the starter relay. $NG \rightarrow$ Refer to "CHECKING THE RE-Replace the starter relay. LAYS" on page 8-161. OK↓

ELECTRIC STARTING SYSTEM

8. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	Replace the main switch/immobilizer unit.
ОК↓		·
9. Check the gear position switch. Refer to "CHECKING THE GEAR POSITION SWITCH" on page 8-170.	NG ightarrow	Replace the gear position switch.
OK↓		
10.Check the sidestand switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	Replace the sidestand switch.
OK↓		
11.Check the clutch switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	Replace the clutch switch.
OK↓		
12.Check the start/engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	The start/engine stop switch is faulty.Replace the right handlebar switch.
OK↓		·
13.Check the entire starting system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-7.	NG ightarrow	Properly connect or replace the wiring har- ness.
OK↓		
The starting system circuit is OK.		

CHARGING SYSTEM

EAS30496 CIRCUIT DIAGRAM




13.AC magneto14.Rectifier/regulator15.Battery16.Engine ground18.Main fuse

 FIP Before troubleshooting, remove the follow 1. Battery cover 2. Air scoop (left) 	ving part(s):	
1. Check the fuse. (Main) Refer to "CHECKING THE FUS- ES" on page 8-157.	$NG \rightarrow$	Replace the fuse.
OK \downarrow		
 Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158. 	$NG \rightarrow$	 Clean the battery terminals. Recharge or replace the battery.
$OK\downarrow$		
3. Check the stator coil. Refer to "CHECKING THE STATOR COIL" on page 8-166.	$NG \rightarrow$	Replace the stator coil assembly.
OK↓		
 Check the rectifier/regulator. Refer to "CHECKING THE RECTI- FIER/REGULATOR" on page 8-166. 	$NG \rightarrow$	Replace the rectifier/regulator.
OK↓		
 Check the entire charging system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-13. 	$NG \rightarrow$	Properly connect or replace the wiring har ness.
ОК↓		
The charging system circuit is OK.		

LIGHTING SYSTEM

EAS30498 CIRCUIT DIAGRAM



- 1. Main switch
- 7. Ignition fuse
- 8. Signaling system fuse
- 9. Headlight fuse
- 10.Fuel injection system fuse
- 15.Battery
- 16.Engine ground
- 18.Main fuse
- 25.Joint coupler
- 36.ECU (Engine Control Unit)
- 48.Meter assembly
- 51.Meter light
- 57.High beam indicator light
- 67.Handlebar switch (left)
- 69.Dimmer switch
- 70.Pass switch
- 76.Headlight assembly
- 77. Auxiliary light
- 78.Headlight
- 80.License plate light
- 81.Tail/brake light
- 84.Headlight relay
- A. Wire harness
- E. Sub-wire harness (headlight, turn signal light, auxiliary light)

EAS30499 TROUBLESHOOTING

Any of the following fail to light: headlight, high beam indicator light, taillight, license plate light or meter light.

TIP		
 Before troubleshooting, remove the follow 1. Battery cover 2. Fuel tank center cover/Air scoops 3. Fuel tank 4. Headlight assembly 	wing part(s):	
 Check the each bulbs and bulb sockets condition. Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 8-156. 	$NG \to$	Replace the bulb(s) and bulb socket(s).
OK↓		
 Check the fuses. (Ignition, signaling system, head- light, fuel injection system, and main) Refer to "CHECKING THE FUS- ES" on page 8-157. 	NG ightarrow	Replace the fuse(s).
OK↓		
 Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158. 	$NG \rightarrow$	 Clean the battery terminals. Recharge or replace the battery.
OK↓		
4. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	Replace the main switch/immobilizer unit.
ОК↓		
5. Check the dimmer switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	The dimmer switch is faulty.Replace the left handlebar switch.
ОК↓		
 Check the pass switch. Refer to "CHECKING THE SWITCHES" on page 8-153. 	$NG \to$	The pass switch is faulty.Replace the left handlebar switch.
OK↓		
 Check the headlight relay. Refer to "CHECKING THE RE- LAYS" on page 8-161. 	$NG \to$	Replace the headlight relay.

 $\mathsf{OK}\, \downarrow$

LIGHTING SYSTEM

 Check the entire lighting system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-17.

 $\mathsf{OK}\, \downarrow$


Replace the ECU, meter assembly, or tail/brake light. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.

 $\text{NG} \rightarrow$

Properly connect or replace the wiring harness.


EAS20076 SIGNALING SYSTEM

EAS30500 CIRCUIT DIAGRAM



1. Main switch

- 4. Parking lighting fuse
- 5. ABS control unit fuse
- 7. Ignition fuse
- 8. Signaling system fuse
- 10.Fuel injection system fuse
- 11.Backup fuse
- 15.Battery
- 16.Engine ground
- 18.Main fuse
- 21.Rear brake light switch
- 22.Relay unit
- 25.Joint coupler
- 36.ECU (Engine Control Unit)
- 38.Coolant temperature sensor
- 42.Rear wheel sensor
- 43.ABS ECU (electronic control unit)
- 45.Fuel sender
- 47.Oil pressure switch
- 48.Meter assembly
- 50.Neutral indicator light
- 52.Tachometer
- 53.Multi-function meter
- 54.Oil pressure warning light
- 56. Coolant temperature warning light
- 58.Turn signal indicator light
- 60.Horn
- 61.Gear position switch
- 62.Handlebar switch (right)
- 63. Front brake light switch
- 64.Hazard switch
- 66.Turn signal/hazard relay
- 67.Handlebar switch (left)
- 71.Turn signal switch
- 72.Horn switch
- 73.Rear turn signal light (right)
- 74.Rear turn signal light (left)
- 75.Front turn signal light (right)
- 79.Front turn signal light (left)
- 81.Tail/brake light
- A. Wire harness
- C. Sub-wire harness (gear position switch, coolant temperature sensor, fuel injector)
- E. Sub-wire harness (headlight, turn signal light, auxiliary light)



SIGNALING SYSTEM

 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	NG ightarrow	Properly connect or replace the wiring har- ness.
OK↓	1	
Replace the horn.		
The tail/brake light fails to come on.	1	
1. Check the front brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \rightarrow$	Replace the front brake light switch.
ОК↓	1	
2. Check the rear brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \rightarrow$	Replace the rear brake light switch.
ОК↓	1	
 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	$NG \rightarrow$	Properly connect or replace the wiring har- ness.
OK↓	1	
Replace the tail/brake light.		
The turn signal light, turn signal indicator l	ight or both fa	il to blink.
 Check the turn signal light bulbs and sockets. Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 8-156. 	$NG \rightarrow$	Replace the turn signal light bulb, socket or both.
OK↓	1	
2. Check the turn signal switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \rightarrow$	The turn signal switch is faulty.Replace the left handlebar switch.
ОК↓	_	
3. Check the hazard switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \rightarrow$	The hazard switch is faulty.Replace the right handlebar switch.
OK↓		
 Check the turn signal/hazard relay. Refer to "CHECKING THE RE- LAYS" on page 8-161. 	$NG \rightarrow$	Replace the turn signal/hazard relay.
OK↓		

SIGNALING SYSTEM

 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	$NG \to$	Properly connect or replace the wiring har- ness.
OK↓		
Replace the meter assembly.		
The neutral indicator light fails to come on	<u>.</u>	
 Check the gear position switch. Refer to "CHECKING THE GEAR POSITION SWITCH" on page 8-170. 	$NG \to$	Replace the gear position switch.
OK↓		
2. Check the relay unit (diode). Refer to "CHECKING THE RELAY UNIT (DIODE)" on page 8-163.	$NG \to$	Replace the relay unit.
OK↓		
 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	$NG \rightarrow$	Properly connect or replace the wiring har- ness.
OK↓		
Replace the meter assembly.		
The oil pressure warning light fails to come on when the main switch is set to "ON".		
 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	$NG \to$	Properly connect or replace the wiring har- ness
OK↓		
2. Disconnect the oil pressure switch lead from the oil pressure switch, and then check whether the oil pressure warning light comes on when the lead is connected to the engine ground.	$NG \rightarrow$	Replace the meter assembly.
OK↓		
Replace the oil pressure switch.		

SIGNALING SYSTEM

The oil pressure warning light remains on a	The oil pressure warning light remains on after the engine is started.					
 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	$NG \to$	Properly connect or replace the wiring har- ness.				
OK↓						
2. Measure the engine oil pressure. Refer to "MEASURING THE EN- GINE OIL PRESSURE" on page 3-23.	$NG \rightarrow$	Check the engine oil leakage, oil viscosity, oil seal, oil filter, or oil pump.				
ОК↓						
Replace the oil pressure switch.						
The fuel meter, fuel level warning light, or l	both fail to co	me on.				
1. Check the fuel sender. Refer to "CHECKING THE FUEL SENDER" on page 8-167.	$NG \to$	Replace the fuel pump assembly.				
OK↓						
 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	$NG \rightarrow$	Properly connect or replace the wiring har- ness.				
Οκ↓						
Replace the meter assembly.						
The coolant temperature warning light fails	s to come on.					
1. Check the coolant temperature sen- sor. Refer to "CHECKING THE COOL- ANT TEMPERATURE SENSOR" on page 8-168.	$NG \rightarrow$	Replace the coolant temperature sensor.				
ОК↓						
 Check the entire signaling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-21. 	$NG \rightarrow$	Properly connect or replace the wiring har- ness.				
ОК↓						
Replace the ECU or meter assembly. Refer to "REPLACING THE ECU (en- gine control unit)" on page 8-158.						

SIGNALING SYSTEM


The speedometer fails to operate.		
1. Check the rear wheel sensor. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.	$NG \to$	Replace the rear wheel sensor.
OK↓		
 Check the entire rear wheel sensor wiring. Refer to TIP. 	$NG \to$	Properly connect or replace the wiring har- ness.
ОК↓		
Replace the ECU, ABS ECU, or meter assembly. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.		
 TIP		
Replace the wire harness if there is an ope		
 Between rear wheel sensor coupler and (white–white) 	ABS ECU coi	upler.

(black-black)

 Between ABS ECU coupler and meter assembly coupler. (blue/black–blue/black) (blue/red–blue/red)

COOLING SYSTEM

EAS30502 CIRCUIT DIAGRAM



- 1. Main switch
- 7. Ignition fuse
- 10.Fuel injection system fuse
- 12.Radiator fan motor fuse
- 15.Battery
- 16.Engine ground
- 18.Main fuse
- 25.Joint coupler
- 36.ECU (Engine Control Unit)
- 38.Coolant temperature sensor
- 82.Radiator fan motor
- 83.Radiator fan motor relay
- A. Wire harness
- C. Sub-wire harness (gear position switch, coolant temperature sensor, fuel injector)

TROUBLESHOOTING The radiator fan motor fails to turn.		
 Before troubleshooting, remove the follow 1. Battery cover 2. Fuel tank center cover/Air scoops 3. Fuel tank 	ving part(s):	
 Check the fuses. (Ignition, fuel injection system, radi- ator fan motor, and main) Refer to "CHECKING THE FUS- ES" on page 8-157. 	NG ightarrow	Replace the fuse(s).
OK↓		
 Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158. 	$NG \rightarrow$	 Clean the battery terminals. Recharge or replace the battery.
OK↓		
 Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-153. 	$NG \to$	Replace the main switch/immobilizer unit.
OK↓		
4. Check the radiator fan motor. Refer to "CHECKING THE RADIA- TOR FAN MOTOR" on page 8-168.	$NG \to$	Replace the radiator fan motor.
OK↓		
5. Check the radiator fan motor relay. Refer to "CHECKING THE RE- LAYS" on page 8-161.	$NG \to$	Replace the radiator fan motor relay.
OK↓		
 Check the coolant temperature sensor. Refer to "CHECKING THE COOL- ANT TEMPERATURE SENSOR" on page 8-168. 	$NG \rightarrow$	Replace the coolant temperature sensor.
ОК↓		

COOLING SYSTEM


 Check the entire cooling system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-29.

OK↓

Replace the ECU. Refer to "REPLAC-ING THE ECU (engine control unit)" on page 8-158. $\text{NG} \rightarrow$

Properly connect or replace the wiring harness.

EAS30504 CIRCUIT DIAGRAM



1. Main switch 5. ABS control unit fuse 7. Ignition fuse 9. Headlight fuse 10. Fuel injection system fuse 11.Backup fuse 15.Battery 16.Engine ground 18.Main fuse 22.Relay unit 23.Starting circuit cut-off relay 24. Fuel pump relay 25.Joint coupler 26.Sidestand switch 27.Crankshaft position sensor 28.O₂ sensor 29.Throttle position sensor 30. Ignition coil #1 31. Ignition coil #2 32.Spark plug 33. Fuel injector #1 34. Fuel injector #2 35.ISC (Idle Speed Control) unit 36.ECU (Engine Control Unit) 37.Intake air temperature sensor 38.Coolant temperature sensor 39.Intake air pressure sensor 40.Lean angle sensor 42.Rear wheel sensor 43.ABS ECU (electronic control unit) 44. Yamaha diagnostic tool coupler 46.Fuel pump 48.Meter assembly 53.Multi-function meter 55.Engine trouble warning light 61.Gear position switch 62.Handlebar switch (right) 65.Start/engine stop switch 67.Handlebar switch (left) 68.Clutch switch 83.Radiator fan motor relay 84.Headlight relay A. Wire harness C. Sub-wire harness (gear position switch, coolant temperature sensor, fuel injector)

D. Sub-wire harness (throttle position sensor, ISC)

ECU SELF-DIAGNOSTIC FUNCTION

The ECU is equipped with a self-diagnostic function in order to ensure that the fuel injection system is operating normally. If this function detects a malfunction in the system, it immediately operates the engine under substitute characteristics and illuminates the engine trouble warning light to alert the rider that a malfunction has occurred in the system. Once a malfunction has been detected, a fault code number is stored in the memory of the ECU.

Checking the engine trouble warning light

The engine trouble warning light comes on for around 2 seconds after the main switch has been set to "ON". If the warning light does not come on, the warning light (LED) may be defective.

ECU detects an abnormal signal from a sensor

If the ECU detects an abnormal signal from a sensor while the vehicle is being driven, the ECU illuminates the engine trouble warning light and provides the engine with alternate operating instructions that are appropriate for the type of malfunction.

When an abnormal signal is received from a sensor, the ECU processes the specified values that are programmed for each sensor in order to provide the engine with alternate operating instructions that enable the engine to continue operating or stop operating, depending on the conditions.

EAS30506 TROUBLESHOOTING METHOD

The engine operation is not normal and the engine trouble warning light comes on.

1. Check:

• Fault code number

- a. Check the fault code numbers that have a condition of "Detected" using the Yamaha diagnostic tool.
- b. Identify the faulty system with the fault code number.
- c. Identify the probable cause of the malfunction.

2. Check and repair the probable cause of the malfunction.

Fault code No.	No fault code No.
Check and repair. Refer to "TROUBLESHOOTING DETAILS (FAULT CODE)" on page 8-38. Monitor the operation of the sensors and actuators in the diagnostic mode. Refer to "TROUBLESHOOT- ING DETAILS (FAULT CODE)" on page 8-38 and "SELF-DIAGNOSTIC FUNCTION AND DIAGNOS- TIC CODE TABLE" on page 9-5.	Check and repair.

 Perform the reinstatement action for the fuel injection system. Refer to "Confirmation of service completion" in the appropriate table in "TROUBLESHOOTING DE-TAILS (FAULT CODE)" on page 8-38.

TIP _

• If another fault code number is displayed, repeat steps (1) to (3) until no fault code number is displayed.

• Turning the main switch to "OFF" will not erase the malfunction history.

The engine operation is not normal, but the engine trouble warning light does not come on.

 Check the operation of the following sensors and actuators in the diagnostic mode. Refer to "DIAG-NOSTIC CODE: SENSOR OPERATION TABLE" on page 9-12 and "DIAGNOSTIC CODE: ACTU-ATOR OPERATION TABLE" on page 9-14.

01: Throttle position sensor signal (throttle angle)

30: Cylinder-#1 ignition coil

31: Cylinder-#2 ignition coil

36: Fuel injector #1

37: Fuel injector #2

If a malfunction is detected in the sensors or actuators, repair or replace all faulty parts. If no malfunction is detected in the sensors and actuators, check and repair the inner parts of the engine.

EAS30951 YAMAHA DIAGNOSTIC TOOL

This model uses the Yamaha diagnostic tool to identify malfunctions.

For information about using the Yamaha diagnostic tool, refer to the operation manual that is included with the tool.



Yamaha diagnostic tool 90890-03250

TIP

A generic scan tool can also be used to identify malfunctions.



OBD/ GST Leadwire kit 90890-03249

Features of the Yamaha diagnostic tool

You can use the Yamaha diagnostic tool to identify malfunctions quicker than with conventional methods.

By connecting the adapter interface, which is connected to the USB port of a computer, to a vehicle's ECU using the communication cable, you can display information that is necessary for identifying malfunctions and for maintenance to display on the computer. The displayed information includes the sensor output data and information recorded in the ECU.

Functions of the Yamaha diagnostic tool


Diagnosis of malfunction:	Fault codes recorded on the ECU are read, and the contents are dis- played. The freeze frame data (FFD) is the operation data when a malfunction was detected. This data can be used to identify when the malfunction occurred and check the engine conditions and running conditions when it occurred.
Diagnosis of function:	Check the operation of the output value of each sensor and actuator.
Dynamic inspection:	Check the electric component condition automatically.
Active test:	Manually adjust injection duration and/or switch some actuators for troubleshooting.
Maintenance record:	Store the inspection history into the Yamaha diagnostic tool application.
Recall search:	Search the recall campaign information.
Monitoring:	Displays a graph of sensor output values for actual operating condi- tions.
Logging:	Records and saves the sensor output value in actual driving conditions.
CO adjustment:	Adjust the concentration of CO admissions during idling.

Reprogram ECU:	If necessary, the ECU is rewritten using ECU rewrite data provided by Yamaha. Ignition timing adjustment, etc. cannot be changed from the vehicle's original state.
Writing VIN/frame number:	Write the VIN/frame number in the ECU.
View logs:	Displays the logging data.

However, the Yamaha diagnostic tool cannot be used to freely change the basic vehicle functions, such as adjusting the ignition timing.

Connecting the Yamaha diagnostic tool


Remove the protective cap "1", and then connect the Yamaha diagnostic tool to the coupler.




Operation of the Yamaha diagnostic tool (Malfunction mode)

The results of the fault diagnosis are displayed as shown in the following screen shot.

The screen display may vary depending on the version of the Yamaha diagnostic tool that you are using.



- 1. The types of the control units are displayed. (e.g., FI, ABS)
- 2. The icons indicating the diagnosis results are displayed.



- A. Detected malfunction
- B. Recovered malfunction
- 3. The fault code numbers are displayed.
- 4. The current conditions are displayed. (Detected/Recovered)
- 5. The item names and symptoms of the detected malfunctions are displayed.

EAS31791

TROUBLESHOOTING DETAILS (FAULT CODE)

This section describes the measures per fault code number displayed on the Yamaha diagnostic tool. Check and service the items or components that are the probable cause of the malfunction following the order given.

After the check and service of the malfunctioning part have been completed, delete the fault codes displayed on the Yamaha diagnostic tool according to the reinstatement method. Fault code No.:

Fault code number displayed on the Yamaha diagnostic tool when the engine failed to work normally. Diagnostic code No.:

Diagnostic code number to be used when the diagnostic mode is operated. Refer to "SELF-DIAGNOS-TIC FUNCTION AND DIAGNOSTIC CODE TABLE" on page 9-5.

Parts connected to the ECU

The following parts are connected to the ECU.

When checking for a power short circuit, the couplers must be disconnected from all of the following parts beforehand.

- Crankshaft position sensor
- Fuel injector #1
- Fuel injector #2
- Ignition coil #1
- Ignition coil #2
- Throttle position sensor
- Intake air pressure sensor
- Coolant temperature sensor
- Intake air temperature sensor

- O₂ sensor
- Lean angle sensor
- ABS ECU (electronic control unit)
- ISC (Idle Speed Control) unit
- Relay unit
- Headlight relay
- Radiator fan motor relay
- Meter assembly
- Immobilizer unit

Fault code No. P0030

TIP_

- If fault code numbers "P0030" and "P0112" are both indicated, take the actions specified for fault code number "P0112" first.
- If fault code numbers "P0030" and "P0113" are both indicated, take the actions specified for fault code number "P0113" first.
- If fault code numbers "P0030" and "P0122" are both indicated, take the actions specified for fault code number "P0122" first.
- If fault code numbers "P0030" and "P0123" are both indicated, take the actions specified for fault code number "P0123" first.


Fault	code No.	P0030		
ltem		O ₂ sensor heater: defective heater controller detected.		
Faile	afe system	Able	to start engine	
raii-5	ale system	Able	to drive vehicle	
Diagn	ostic code No.	—		
Tool o	display	—		
Proce	dure	—		
ltem	Probable cause of malfunc- tion and check		Maintenance job	Confirmation of service com- pletion
1	Connection of O ₂ sensor c pler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d vken	Improperly connected → Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Start the engine, and then check the condition of the fault code. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 2. TIP For this check, also set the en- gine stop switch to "ON".


2	Connection of wire harness ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Start the engine, and then check the condition of the fault code. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 3. TIP For this check, also set the en- gine stop switch to "ON".
3	Wire harness continuity.	Open or short circuit → Properly connect or replace the wire har- ness. Between O ₂ sensor coupler and ECU coupler. pink/black–pink/black Between O ₂ sensor coupler and joint coupler. red/white–red/white Between main switch and igni- tion fuse. brown/blue–brown/blue Between ignition fuse and joint coupler. red/white–red/white	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Start the engine, and then check the condition of the fault code. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 4. TIP For this check, also set the en- gine stop switch to "ON".
4	Defective O ₂ sensor heater.	Replace the O ₂ sensor.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Start the engine, and then check the condition of the fault code. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 5. TIP For this check, also set the en- gine stop switch to "ON".
5	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.

6	Delete the fault code and check that the engine trouble warning light goes off.	a condition of "Recovered" us- ing the Yamaha diagnostic tool,	
		and then delete the fault code.	

Fault	code No.	P010	7, P0108	
ltem		[P0107] Intake air pressure sensor: ground short circuit detected. [P0108] Intake air pressure sensor: open or power short circuit de- tected.		
Eail_e	Able to start engine			
raii-5	afe system	Able	to drive vehicle	
Diagn	nostic code No.	03		
Tool o	display	Displ	ays the intake air pressure.	
Proce	edure		ate the throttle while pushing the " h. (If the display value changes, th	
Item	Probable cause of malf tion and check	unc-	Maintenance job	Confirmation of service com pletion
1	Connection of intake air pr sure sensor coupler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected → Con- nect the coupler securely or re- place the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha d agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.
2	Connection of ECU couple Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha d agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.
3	Wire harness continuity.		Open or short circuit → Replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha d agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service Condition is "Detected" \rightarrow Go to item 4.
3-1	1. Intake air pressure sen	1	2 5 7 7 7 7 7 7 7 7 7 7 7 7 7	5V • • •
	 ECU Sensor input lead Sensor output lead Sensor ground lead 	501		

Fault code No. P0107, P0108






5	Defective intake air pressure sensor.	Execute the diagnostic mode. (Code No. 03) When engine is stopped: Atmospheric pressure at the current altitude and weather conditions is indicated. At sea level: Approx. 101 kPa (757.6 mmHg, 29.8 inHg) 1000 m (3300 ft) above sea lev- el: Approx. 90 kPa (675.1 mmHg, 26.6 inHg) 2000 m (6700 ft) above sea lev- el: Approx. 80 kPa (600.0 mmHg, 23.6 inHg) 3000 m (9800 ft) above sea lev- el: Approx. 70 kPa (525.0 mmHg, 20.7 inHg) When engine is cranking: Make sure that the indication value changes. The value does not change when engine is cranking. \rightarrow Check the intake air pressure sensor. Replace if defective. Refer to "CHECKING THE IN- TAKE AIR PRESSURE SEN- SOR" on page 8-169.	Crank the engine, and then check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	


Fault code No. P0112, P0113

TIP ____

Perform this procedure when the engine is cold.

Fault	code No.	P011	2, P0113	
ltem		[P0112] Intake air temperature sensor: ground short circuit detect- ed. [P0113] Intake air temperature sensor: open or power short circuit detected.		
Fail-s	afe system	Able	to start engine	
1 ali-5	are system	Able	to drive vehicle	
	nostic code No.	05		
Tool o	display		ays the air temperature.	
Proce	edure	Com ue.	pare the actually measured air tem	perature with the tool display val-
ltem	Probable cause of malf tion and check	unc-	Maintenance job	Confirmation of service com- pletion
1	Connection of intake air tel perature sensor coupler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d Iken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.
2	Connection of ECU couple Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.
3	Wire harness continuity.		Open or short circuit → Replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.






7	Delete the fault code and check that the engine trouble warning light goes off.	a condition of "Recovered" us- ing the Yamaha diagnostic tool,	
	light goes on.	and then delete the fault code.	


Fault code No. P0117, P0118

TIP ____

Perform this procedure when the engine is cold.

Fault	code No.	P011	7, P0118		
Item		[P0117] Coolant temperature sensor: ground short circuit detected. [P0118] Coolant temperature sensor: open or power short circuit detected.			
Faile	afe system	Able	to start engine		
i ali-5		Able	to drive vehicle		
Diagn	ostic code No.	06			
Tool c	display	Wher	n engine is cold: Displays tempera n engine is hot: Displays current co	oolant temperature.	
Proce	edure	Comp value	pare the actually measured coolant	t temperature with the tool display	
ltem	Probable cause of malf tion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Connection of coolant tempera- ture sensor coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Wire harness continuity.		Open or short circuit → Replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	







7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	
		and then delete the laut code.	

Fault	code No.	P012	2, P0123		
ltem		tecte	[P0122] Throttle position sensor: open or ground short circuit de- tected. [P0123] Throttle position sensor: power short circuit detected.		
Fail-s	afe system		Unable to start engine		
	-	Able/	Unable to drive vehicle		
Diagn	ostic code No.	01			
01	Tool display	• 11–	tle position sensor signal 21 (fully closed position) 106 (fully open position)		
	Procedure	• Che • Che	eck with throttle valves fully closed eck with throttle valves fully open.		
Item	Probable cause of malf tion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Connection of throttle position sensor coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Wire harness continuity.		Open or short circuit → Replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di agnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	

Fault code No. P0122, P0123





4	Installed condition of throttle po- sition sensor.	Check for looseness or pinch- ing. Improperly installed sensor → Reinstall or adjust the sensor. Refer to "ADJUSTING THE THROTTLE POSITION SEN- SOR" on page 7-13.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 5.
5	Throttle position sensor resis- tance.	Measure the throttle position sensor resistance. black/blue-blue Refer to "CHECKING THE THROTTLE POSITION SEN- SOR" on page 8-169.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Defective throttle position sen- sor.	Check throttle position sensor signal. Execute the diagnostic mode. (Code No. 01) When the throttle valves are ful- ly closed: A value of 11–21 is indicated. When throttle valves are fully open: A value of 96–106 is indicated.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 7.
7	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
8	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault code No.		P0132			
Item		O ₂ sensor: short circuit detected (power short circuit).			
		Able	to start engine		
raii-s	afe system	Able	to drive vehicle		
-	nostic code No.	—			
	display	—			
Proce		—	Ι		
Item	Probable cause of malfe tion and check		Maintenance job	Confirmation of service com- pletion	
1	Installed condition of O ₂ sensor.		Check for looseness or pinch- ing. Improperly installed sensor → Reinstall or replace the sensor.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of O_2 sensor coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Connection of wire harness ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	
4	Wire harness continuity.		Open or short circuit \rightarrow Properly connect or replace the wire har- ness. Between O ₂ sensor coupler and joint coupler. black/blue-black/blue Between O ₂ sensor coupler and ECU coupler. gray/green-gray/green	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 5.	
5	Defective O ₂ sensor.		Check the O_2 sensor. Defective \rightarrow Replace the O_2 sensor. Refer to "ENGINE REMOVAL" on page 5-3.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.	

6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault code No. P0201 Fuel injector #1: malfunction in fuel injector #1. Item Able to start engine (depending on the number of faulty cylinders) Fail-safe system Able to drive vehicle (depending on the number of faulty cylinders) Diagnostic code No. 36 Actuates fuel injector #1 five times at one-second intervals. The "check" indicator on the Yamaha diagnostic tool screen comes on Actuation each time the fuel injector is actuated. F I 7 2 З

Fault code No. P0201

		each	time the fuel injector is actuated.		
Proce	fi		connect the fuel pump coupler. Check that fuel injector #1 is actuated times by listening for the operating sound.		
Item	Item Probable cause of malfunc- tion and check		Maintenance job	Confirmation of service com- pletion	
1	Connection of fuel injector #1 coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 36) Operating sound \rightarrow Go to item 7. No operating sound \rightarrow Go to item 2.	
2	Defective fuel injector #1.		Measure the fuel injector resis- tance. Replace if out of specification. Refer to "CHECKING THE FUEL INJECTORS" on page 8-171.	Execute the diagnostic mode. (Code No. 36) Operating sound \rightarrow Go to item 7. No operating sound \rightarrow Go to item 3.	
3	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 36) Operating sound \rightarrow Go to item 7. No operating sound \rightarrow Go to item 4.	
4	Connection of sub-wire har ness coupler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or brol terminals and locking condi of the pins).	n of I ken	Improperly connected \rightarrow Connect the coupler securely or replace the sub-wire harness.	Execute the diagnostic mode. (Code No. 36) Operating sound \rightarrow Go to item 7. No operating sound \rightarrow Go to item 5.	
5	Wire harness continuity.		Open or short circuit → Replace the wire harness. Between fuel injector coupler and sub-wire harness coupler. red/black–red/black red/blue–red/blue Between sub-wire harness cou- pler and ECU coupler. red/black–red/black red/blue–red/blue Between sub-wire harness cou- pler and relay unit coupler. red/blue–red/blue	Execute the diagnostic mode. (Code No. 36) Operating sound \rightarrow Go to item 7. No operating sound \rightarrow Go to item 6.	

6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	
7	Delete the fault code and check that the engine trouble warning light goes off.	Start the engine and let it idle for approximately 5 seconds. Confirm that the fault code has a condition of "Recovered" us- ing the malfunction mode of the Yamaha diagnostic tool, and then delete the fault code.	

Fault code No. P0202 Fault code No. P0202 Fuel injector #2: malfunction in fuel injector #2. Item Able to start engine (depending on the number of faulty cylinders) Fail-safe system Able to drive vehicle (depending on the number of faulty cylinders) Diagnostic code No. 37 Actuates fuel injector #2 five times at one-second intervals. Actuation The "check" indicator on the Yamaha diagnostic tool screen comes on each time the fuel injector is actuated. Disconnect the fuel pump coupler. Check that fuel injector #2 is actuated Procedure five times by listening for the operating sound. Probable cause of malfunc-Confirmation of service com-Item Maintenance job tion and check pletion 1 Execute the diagnostic mode. Connection of fuel injector #2 Improperly connected \rightarrow Connect the coupler securely or recoupler. (Code No. 37) Check the locking condition of place the wire harness. Operating sound \rightarrow Go to item the coupler. 7. Disconnect the coupler and No operating sound \rightarrow Go to check the pins (bent or broken item 2. terminals and locking condition of the pins). 2 Defective fuel injector #2. Measure the fuel injector resis-Execute the diagnostic mode. (Code No. 37) tance. Replace if out of specification. Operating sound \rightarrow Go to item **Refer to "CHECKING THE** 7. FUEL INJECTORS" on page No operating sound \rightarrow Go to 8-171. item 3. 3 Connection of ECU coupler. Improperly connected \rightarrow Con-Execute the diagnostic mode. Check the locking condition of nect the coupler securely or re-(Code No. 37) the coupler. Operating sound \rightarrow Go to item place the wire harness. Disconnect the coupler and 7. check the pins (bent or broken No operating sound \rightarrow Go to terminals and locking condition item 4. of the pins). 4 Connection of sub-wire har-Execute the diagnostic mode. Improperly connected \rightarrow Conness coupler. nect the coupler securely or re-(Code No. 37) Check the locking condition of place the sub-wire harness. Operating sound \rightarrow Go to item the coupler. 7. Disconnect the coupler and No operating sound \rightarrow Go to check the pins (bent or broken item 5. terminals and locking condition of the pins). 5 Wire harness continuity. Open or short circuit \rightarrow Replace Execute the diagnostic mode. the wire harness. (Code No. 37) Between fuel injector coupler Operating sound \rightarrow Go to item and sub-wire harness coupler. 7. green/black-green/black No operating sound \rightarrow Go to red/blue-red/blue item 6. Between sub-wire harness coupler and ECU coupler. green/black-green/black red/blue-red/blue Between sub-wire harness coupler and relay unit coupler. red/blue-red/blue

FUEL INJECTION SYSTEM

6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	
7	Delete the fault code and check that the engine trouble warning light goes off.	Start the engine and let it idle for approximately 5 seconds. Confirm that the fault code has a condition of "Recovered" us- ing the malfunction mode of the Yamaha diagnostic tool, and then delete the fault code.	

Fault	Fault code No.		P0335		
Item			Crankshaft position sensor: no normal signals are received from the crankshaft position sensor.		
Eoil o	Fail-safe system		Unable to start engine		
raii-s			le to drive vehicle		
Diagn	ostic code No.	—			
Tool o	display	—			
Proce	edure	—			
Item	Probable cause of malfe tion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Connection of crankshaft posi- tion sensor coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected → Con- nect the coupler securely or re- place the wire harness.	Crank the engine, and then check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected → Con- nect the coupler securely or re- place the wire harness.	Crank the engine, and then check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Wire harness continuity.		Open or short circuit → Replace the wire harness. Between crankshaft position sensor coupler and ECU cou- pler. gray–gray Between crankshaft position sensor coupler and joint cou- pler. black/blue–black/blue Between joint coupler and ECU coupler. black/blue–black/blue	Crank the engine, and then check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	
4	Installed condition of crankshaft position sensor. Check for looseness or pinch- ing. Check the gap between the crankshaft position sensor and the generator rotor.		Improperly installed sensor → Reinstall or replace the sensor. Refer to "GENERATOR AND STARTER CLUTCH" on page 5-36.	Crank the engine, and then check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 5.	

5	Defective crankshaft position sensor.	Check the crankshaft position sensor. Refer to "CHECKING THE CRANKSHAFT POSITION SENSOR" on page 8-165. Replace if defective.	Crank the engine, and then check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault code No. P0351 Cylinder-#1 ignition coil: open or short circuit detected in the prima-Item ry lead of the cylinder-#1 ignition coil. Able to start engine (depending on the number of faulty cylinders) Fail-safe system Able to drive vehicle (depending on the number of faulty cylinders) Diagnostic code No. 30 Actuates the cylinder-#1 ignition coil five times at one-second intervals. Actuation The "check" indicator on the Yamaha diagnostic tool screen comes on each time the ignition coil is actuated.

Proce		eck that a spark is generated five times. onnect an ignition checker.		
Item	Probable cause of malfun tion and check	>- Maintenance	job Confirmation of service completion	
1	Connection of cylinder-#1 ign tion coil coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broke terminals and locking condition of the pins).	nect the coupler sec place the wire harne	urely or re- approximately 5 seconds.	
2	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broke terminals and locking condition of the pins).	place the wire harne	urely or re- approximately 5 seconds.	
3	Wire harness continuity.	Open or short circuit the wire harness. Between cylinder-#1 coupler and ECU co orange–orange Between cylinder-#1 coupler and right ha switch coupler. red/black–red/black	ignition coil ignition coil ignition coil ignition coil ignition coil ignition coil	
4	Installed condition of cylinder- ignition coil.	 #1 Check for looseness ing. Improperly installed → Reinstall or replace tion coil. 	approximately 5 seconds. gnition coil Check the condition of the fault	

5	Defective cylinder-#1 ignition coil.	Measure the primary coil resis- tance of the cylinder-#1 ignition coil. Replace if out of specification. Refer to "CHECKING THE IG- NITION COILS" on page 8-164.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Malfunction in ECU.	Execute the diagnostic mode. (Code No. 30) No spark \rightarrow Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault code No.		P035	2		
ltem	Item		Cylinder-#2 ignition coil: open or short circuit detected in the prima- ry lead of the cylinder-#2 ignition coil.		
Fail-safe system		Able	Able to start engine (depending on the number of faulty cylinders)		
r an-5	uie system	Able	to drive vehicle (depending on the	number of faulty cylinders)	
Diagn	ostic code No.	31			
Actua	ation	The "	ates the cylinder-#2 ignition coil five check" indicator on the Yamaha di time the ignition coil is actuated.	e times at one-second intervals. agnostic tool screen comes on	
Proce	edure		k that a spark is generated five tim nect an ignition checker.		
Item	Probable cause of malf tion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Connection of cylinder-#2 tion coil coupler. Check the locking conditio the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected → Connect the coupler securely or replace the wire harness.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Wire harness continuity.		Open or short circuit → Replace the wire harness. Between cylinder-#2 ignition coil coupler and ECU coupler. gray/red–gray/red Between cylinder-#2 ignition coil coupler and right handlebar switch coupler. red/black–red/black	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	
4	Installed condition of cylind ignition coil.	er-#2	Check for looseness or pinch- ing. Improperly installed ignition coil → Reinstall or replace the igni- tion coil.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 5.	

5	Defective cylinder-#2 ignition coil.	Measure the primary coil resis- tance of the cylinder-#2 ignition coil. Replace if out of specification. Refer to "CHECKING THE IG- NITION COILS" on page 8-164.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Malfunction in ECU.	Execute the diagnostic mode. (Code No. 31) No spark \rightarrow Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

	code No. P0500				
Fault	code No.	P050	0		
		Α	Rear wheel sensor: no normal rear wheel sensor.	signals are received from the	
Item		В	Gear position switch: open or short circuit is detected.		
		С	Clutch switch: open or short c	rcuit is detected.	
Faile	afe system	Able	to start engine		
raii-5	ale system	Able	to drive vehicle		
Diagn	ostic code No.	07			
Tool o	lisplay	Rear 0–99	wheel speed pulse 9		
Proce	dure		k that the number increases when per is cumulative and does not rese		
Item	Probable cause of malfution and check	unc-	Maintenance job	Confirmation of service com- pletion	
A-1	A-1 Locate the malfunction.		Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases.	Value does not increase \rightarrow Go to item A-2.	
			Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF"	Incorrect indication \rightarrow Go to item B-2 for the gear position switch.	
			When the transmission is in gear with the clutch lever squeezed and the sidestand re-tracted: "ON"	Incorrect indication \rightarrow Go to item C-2 for the clutch switch.	
A-2	Connection of rear wheel s sor coupler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d vken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases. Value increases \rightarrow Go to item A-8. Value does not increase \rightarrow Go to item A-3.	
A-3	Connection of ABS ECU connection of ABS ECU connection pler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or broot terminals and locking cond of the pins).	n of d oken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases. Value increases \rightarrow Go to item A-8. Value does not increase \rightarrow Go to item A-4.	

A-4	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases. Value increases \rightarrow Go to item A-8. Value does not increase \rightarrow Go to item A-5.
A-5	Rear wheel sensor lead continu- ity, or defective rear wheel sen- sor.	Open or short circuit, or defec- tive sensor → Replace the rear wheel sensor. Between rear wheel sensor cou- pler and ABS ECU coupler. black–black white–white Between ABS ECU coupler and ECU coupler. white/yellow–white/yellow	Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases. Value increases \rightarrow Go to item A-8. Value does not increase \rightarrow Go to item A-6.
A-6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases. Value increases \rightarrow Go to item A-8. Value does not increase \rightarrow Go to item A-7.
A-7	Malfunction in ABS ECU.	Replace the ABS ECU.	Go to item A-8.
A-8	Delete the fault code and check that the engine trouble warning light goes off.	Turn the main switch to "ON", and then rotate the rear wheel by hand. Start the engine, and input the vehicle speed signals by operat- ing the vehicle at 20 to 30 km/h(12 to 19 mph). Confirm that the fault code has a condition of "Recovered" us- ing the malfunction mode of the Yamaha diagnostic tool, and then delete the fault code. Delete this fault code even if it has a condition of "Detected".	

Fault code No. P050		0		
	Item -		Rear wheel sensor: no normal rear wheel sensor.	signals are received from the
Item			Gear position switch: open or	short circuit is detected.
			Clutch switch: open or short c	ircuit is detected.
Fail-s	afe system	Able	to start engine	
i un o		Able	to drive vehicle	
Diagn	ostic code No.	21		
	lisplay	• "ON	position switch " (when the transmission is in neu F" (when the transmission is in ge	
Proce	dure	Opera	ate the transmission and clutch lev	
Item	Probable cause of malfition and check	unc-	Maintenance job	Confirmation of service com- pletion
B-1	Locate the malfunction.		Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases.	Value does not increase \rightarrow Go to item A-2 for the rear wheel sensor.
			Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF"	Incorrect indication \rightarrow Go to item B-2.
			When the transmission is in gear with the clutch lever squeezed and the sidestand is retracted: "ON"	Incorrect indication \rightarrow Go to item C-2 for the clutch switch.
B-2	Connection of gear position switch coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected → Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF" Correct indication \rightarrow Go to item B-9. Incorrect indication \rightarrow Go to item B-3.
B-3	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF" Correct indication \rightarrow Go to item B-9. Incorrect indication \rightarrow Go to item B-4.

B-4	Wire harness continuity.	Open or short circuit → Replace the wire harness. Between ECU coupler and joint coupler. black/yellow–black/yellow Between joint coupler and relay unit coupler. black/yellow–black/yellow Between relay unit coupler and sub-wire harness coupler. sky blue–sky blue Between sub-wire harness cou- pler and gear position switch coupler. sky blue–sky blue	Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF" Correct indication \rightarrow Go to item B-9. Incorrect indication \rightarrow Go to item B-5.
B-5	Defective relay unit.	Check the relay unit. Replace if defective. Refer to "CHECKING THE RE- LAY UNIT (DIODE)" on page 8-163.	Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF" Correct indication \rightarrow Go to item B-9. Incorrect indication \rightarrow Go to item B-6.
B-6	Defective gear position switch.	Check the gear position switch. Replace if defective. Refer to "CHECKING THE GEAR POSITION SWITCH" on page 8-170.	Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF" Correct indication \rightarrow Go to item B-9. Incorrect indication \rightarrow Go to item B-7.
B-7	Faulty shift drum (neutral detec- tion area).	Malfunction → Replace the shift drum. Refer to "TRANSMISSION" on page 5-88.	Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF" Correct indication \rightarrow Go to item B-9. Incorrect indication \rightarrow Go to item B-8.
B-8	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.

B-9	Delete the fault and and aback	Turn the main quitch to "ON"	
D-9	Delete the fault code and check	Turn the main switch to "ON",	
	that the engine trouble warning	and then rotate the rear wheel	
	light goes off.	by hand.	
	0 0	Start the engine, and input the	
		vehicle speed signals by operat-	
		ing the vehicle at 20 to 30	
		km/h(12 to 19 mph).	
		Confirm that the fault code has	
		a condition of "Recovered" us-	
		ing the malfunction mode of the	
		Yamaha diagnostic tool, and	
		then delete the fault code.	
		Delete this fault code even if it	
		has a condition of "Detected".	

Fault	code No.	P050	0	
		A	Rear wheel sensor: no normal rear wheel sensor.	signals are received from the
Item	Item		Gear position switch: open or s	short circuit is detected.
		С	Clutch switch: open or short ci	rcuit is detected.
Fail-s	afe system	Able	o start engine	
i uli S		Able	to drive vehicle	
Diagn	ostic code No.	21		
	Tool display		h switch " (when the clutch lever is squeeze when the sidestand is retracted) F" (when the clutch lever is squeeze when the sidestand is extended)	zed with the transmission in gear
Proce		•	ate the transmission, clutch lever, a	
ltem	Probable cause of malfution and check	unc-	Maintenance job	Confirmation of service com- pletion
C-1	Locate the malfunction.		Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases.	Value does not increase \rightarrow Go to item A-2 for the rear wheel sensor.
			Execute the diagnostic mode. (Code No. 21) When the transmission is in neutral: "ON" When the transmission is in gear with the clutch lever re- leased: "OFF"	item B-2 for the gear position switch.
			When the transmission is in gear with the clutch lever squeezed and the sidestand re-tracted: "ON"	Incorrect indication \rightarrow Go to item C-2.
C-2	Clutch lever adjustment.		Refer to "ADJUSTING THE CLUTCH LEVER FREE PLAY" on page 3-12.	Execute the diagnostic mode. (Code No. 21) When the clutch lever is re- leased with the transmission in gear and when the sidestand is retracted: "OFF" When the clutch lever is squeezed with the transmission in gear and when the sidestand is retracted: "ON" Correct indication \rightarrow Go to item C-8. Incorrect indication \rightarrow Go to item C-3.

C-3	Connection of clutch switch cou- pler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 21) When the clutch lever is re- leased with the transmission in gear and when the sidestand is retracted: "OFF" When the clutch lever is squeezed with the transmission in gear and when the sidestand is retracted: "ON" Correct indication \rightarrow Go to item C-8. Incorrect indication \rightarrow Go to item C-4.
C-4	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 21) When the clutch lever is re- leased with the transmission in gear and when the sidestand is retracted: "OFF" When the clutch lever is squeezed with the transmission in gear and when the sidestand is retracted: "ON" Correct indication \rightarrow Go to item C-8. Incorrect indication \rightarrow Go to item C-5.
C-5	Wire harness continuity.	Open or short circuit → Replace the wire harness. Between clutch switch coupler and left handlebar switch cou- pler. black/red-black/red black/yellow-black/yellow Between left handlebar switch coupler and joint coupler. black/red-black/red black/yellow-black/yellow Between joint coupler and ECU coupler. black/red-black/red black/yellow-black/yellow	Execute the diagnostic mode. (Code No. 21) When the clutch lever is re- leased with the transmission in gear and when the sidestand is retracted: "OFF" When the clutch lever is squeezed with the transmission in gear and when the sidestand is retracted: "ON" Correct indication \rightarrow Go to item C-8. Incorrect indication \rightarrow Go to item C-6.
C-6	Defective clutch switch.	Check the clutch switch. Replace if defective. Refer to "CHECKING THE SWITCHES" on page 8-153.	Execute the diagnostic mode. (Code No. 21) When the clutch lever is re- leased with the transmission in gear and when the sidestand is retracted: "OFF" When the clutch lever is squeezed with the transmission in gear and when the sidestand is retracted: "ON" Correct indication \rightarrow Go to item C-8. Incorrect indication \rightarrow Go to item C-7.

C-7	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
C-8	Delete the fault code and check that the engine trouble warning light goes off.	Turn the main switch to "ON", and then rotate the rear wheel by hand. Start the engine, and input the vehicle speed signals by operat- ing the vehicle at 20 to 30 km/h(12 to 19 mph). Confirm that the fault code has a condition of "Recovered" us- ing the malfunction mode of the Yamaha diagnostic tool, and then delete the fault code. Delete this fault code even if it has a condition of "Detected".	

TIP_

- If fault code numbers "P0507" and "P0560" are both indicated, take the actions specified for fault code number "P0560" first.
- If fault code numbers "P0507" and "P0500" are both indicated, take the actions specified for fault code number "P0500" first.

Fault	code No.	P050	7	
ltem		Α	Component other than ISC (idle tive (ISC operating sound is he	
nem			Defective ISC (idle speed contron not heard).	ol) unit (ISC operating sound is
Fail-s	afe system	Able	to start engine	
	-		to drive vehicle	
Diagn	ostic code No.	54		
Actua	ition	perfo "cheo	closes the ISC valve, and then oper rmed 3 times and takes approxima k" indicator on the Yamaha diagno peration.	ately 6 seconds each time. The
Proce	dure		k that the ISC unit is actuated three ound.	e times by listening for the operat-
Item	Probable cause of malfe tion and check	unc-	Maintenance job	Confirmation of service com- pletion
A-1	Locate the malfunction.		Execute the diagnostic mode. (Code No. 54) Fully closes the ISC (idle speed control) valve, and then fully opens the valve. This operation takes approximately 6 seconds.	ISC operating sound is heard \rightarrow Go to item A-2. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item A-6 and finish the ser- vice. Condition is "Detected" \rightarrow Go to item A-2.
A-2	Incorrect rear wheel sensor signal.		Check the rear wheel sensor. Execute the diagnostic mode. (Code No. 07) Rotate the rear wheel by hand and check that the indicated val- ue increases. Value does not increase \rightarrow Go to the section for the defective rear wheel sensor for fault code No. P0500.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item A-6 and finish the ser- vice. Condition is "Detected" \rightarrow Go to item A-3.
A-3	Throttle valve does not fully close.		Check the throttle body assem- bly. Refer to "THROTTLE BODIES" on page 7-7. Check the throttle grip free play. Refer to "CHECKING THE THROTTLE GRIP OPERA- TION" on page 3-27.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item A-6 and finish the ser- vice. Condition is "Detected" \rightarrow Go to item A-4.

A-4	ISC valve is not moving correct- ly.	Replace the ISC valve.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item A-6 and finish the ser- vice. Condition is "Detected" \rightarrow Go to item A-5.
A-5	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
A-6	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault	code No.	P050	7	
Itom	Item		Component other than ISC (idl tive (ISC operating sound is he	
item			Defective ISC (idle speed control) unit (ISC operating sound is not heard).	
Fail-s	afe system	Able	to start engine	
i un o		Able	to drive vehicle	
Diagn	ostic code No.	54		
Actua	ition	perfo "chec	closes the ISC valve, and then oper rmed 3 times and takes approxima k" indicator and " ලා" on the Yama rring the operation.	ately 6 seconds each time. The
Proce	dure	The I	SC unit vibrates when the ISC value	/e operates.
Item	Probable cause of malfe tion and check	unc-	Maintenance job	Confirmation of service com- pletion
B-1	Locate the malfunction.		Execute the diagnostic mode. (Code No. 54) Fully closes the ISC (idle speed control) valve, and then fully opens the valve. This operation takes approximately 6 seconds.	ISC operating sound is heard \rightarrow Go to item A-2 for the compo- nent other than ISC (idle speed control) unit is defective. ISC operating sound is not heard \rightarrow Go to item B-2.
B-2	Connection of ISC (idle speed control) unit coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected → Con- nect the coupler securely or re- place the wire harness.	Execute the diagnostic mode. (Code No. 54) ISC operating sound is heard \rightarrow Go to item B-8. ISC operating sound is not heard \rightarrow Go to item B-3.
B-3	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Execute the diagnostic mode. (Code No. 54) ISC operating sound is heard \rightarrow Go to item B-8. ISC operating sound is not heard \rightarrow Go to item B-4.
B-4	Wire harness continuity.		Open or short circuit → Replace the wire harness. Between ISC (idle speed con- trol) unit coupler and sub-wire harness coupler. red/green-red/green pink/blue-pink/blue white/green-white/green brown/blue-brown/blue Between sub-harness and ECU coupler. red/green-red/green pink/blue-pink/blue white/green-white/green brown/blue-brown/blue	Execute the diagnostic mode. (Code No. 54) ISC operating sound is heard \rightarrow Go to item B-8. ISC operating sound is not heard \rightarrow Go to item B-5.

·			
B-5	Installed condition of ISC (idle speed control) unit.	Check for looseness or pinch- ing. Improperly installed ISC (idle speed control) unit \rightarrow Reinstall the ISC (idle speed control) unit. Check the intake air passages for air leaks.	Execute the diagnostic mode. (Code No. 54) ISC operating sound is heard \rightarrow Go to item B-8. ISC operating sound is not heard \rightarrow Go to item B-6.
B-6	ISC valve is not moving correct- ly.	Replace the ISC valve.	Execute the diagnostic mode. (Code No. 54) ISC operating sound is heard \rightarrow Go to item B-8. ISC operating sound is not heard \rightarrow Go to item B-7.
B-7	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
B-8	Delete the fault code and check that the engine trouble warning light goes off.	Start the engine and let it idle for approximately 10 seconds. Confirm that the fault code has a condition of "Recovered" us- ing the malfunction mode of the Yamaha diagnostic tool, and then delete the fault code.	

Fault code No. P0511 Fault code No. P0511 ISC unit: malfunction in ISC unit. Item Able to start engine Fail-safe system Able to drive vehicle Diagnostic code No. Tool display Procedure Probable cause of malfunc-Confirmation of service com-Item Maintenance job tion and check pletion Connection of ISC unit coupler. Turn the main switch to "ON". 1 Improperly connected \rightarrow Con-Check the locking condition of nect the coupler securely or reand then check the condition of the fault code using the malthe coupler. place the wire harness. function mode of the Yamaha di-Disconnect the coupler and check the pins (bent or broken agnostic tool. terminals and locking condition Condition is "Recovered" \rightarrow Go to item 6 and finish the service. of the pins). Condition is "Detected" \rightarrow Go to item 2 2 Connection of wire harness Improperly connected \rightarrow Con-Turn the main switch to "ON". nect the coupler securely or reand then check the condition of ECU coupler. Check the locking condition of place the wire harness. the fault code using the malthe coupler. function mode of the Yamaha di-Disconnect the coupler and agnostic tool. check the pins (bent or broken Condition is "Recovered" \rightarrow Go terminals and locking condition to item 6 and finish the service. Condition is "Detected" \rightarrow Go to of the pins). item 3. 3 Wire harness continuity. Open or short circuit \rightarrow Properly Turn the main switch to "ON", connect or replace the wire harand then check the condition of ness. the fault code using the malfunction mode of the Yamaha di-Between ISC (idle speed control) unit coupler and sub-wire agnostic tool. Condition is "Recovered" \rightarrow Go harness coupler. to item 6 and finish the service. red/green-red/green pink/blue-pink/blue Condition is "Detected" \rightarrow Go to white/green-white/green item 4. brown/blue-brown/blue Between sub-harness and ECU coupler. red/green-red/green pink/blue-pink/blue white/areen-white/areen brown/blue-brown/blue 4 Faulty ISC valve operation. Execute the diagnostic mode. Turn the main switch to "ON". and then check the condition of (Code No. 54) the fault code using the mal-ISC operating sound is not heard \rightarrow Replace the throttle function mode of the Yamaha dibody assembly. agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 5. 5 Malfunction in ECU. Replace the ECU. Service is finished. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.

Fault code No. P05		P056	0	
Item Ch		Char	ging voltage is abnormal.	
		Able	to start engine	
Fall-S	afe system	Able	to drive vehicle	
Diagn	ostic code No.	—		
Tool o	display	—		
Proce	edure	—		
Item	Probable cause of malfunc- tion and check		Maintenance job	Confirmation of service com- pletion
1	Malfunction in charging sy	stem.	Check the charging system. Refer to "CHARGING SYSTEM" on page 8-13. Defective rectifier/regulator or AC magneto \rightarrow Replace. Defective connection in the charging system circuit \rightarrow Prop- erly connect or replace the wire harness.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 2 and finish the service. Condition is "Detected" \rightarrow Re- peat item 1.
2	Delete the fault code and check that the engine trouble warning light goes off.		Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault	code No.	P0601			
		Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the tool display.)			
Fail a	afe system	Able/	Unable to start engine		
raii-5	ale system	Able/Unable to drive vehicle			
Diagn	ostic code No.	—	-		
Tool display —		—			
Proce	edure	—			
Item	Probable cause of malf tion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Malfunction in ECU.		Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Turn the main switch to "ON". Check that the engine trouble warning light does not come on.	

Fault	code No.	P062	F		
ltem			ROM fault code number: an error is detected while reading or ng on EEPROM.		
Fail-safe system		Able/	Unable to start engine		
1 all-5	ale system	Able/	Unable to drive vehicle		
Diagn	ostic code No.	60			
Tool display		 00 No malfunctions detected (If the self-diagnosis fault code P062F is inclusted, the ECU is defective.) 01–02 (CO adjustment value) (If more than one cylinder is defective, the display alternates every two seconds to show all the detected cylinder numbers. When all cylinder numbers are shown, the display repeats the same process.) 11 (Data error for ISC (idle speed control) learning values) 12 (O₂ feedback learning value) 13 (OBD memory value) 			
Proce	edure	_			
Item	Probable cause of malfe tion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Locate the malfunction		Execute the diagnostic mode. (Code No. 60) 00: Go to item 5. 01: Go to item 2. 02: Go to item 3. 11–13: Go to item 4.		
2	"01" is indicated in diagnostic mode (code No. 60). EEPROM data error for adjustment of CO concentration of cylinder #1.		Change the CO concentration of cylinder #1, and rewrite in EE- PROM. Refer to "ADJUSTING THE EX- HAUST GAS VOLUME" on page 5-2. After this adjustment is made, turn the main switch to "OFF".	Set the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Re- peat item 1. If the same number is indicated, go to item 5.	
3	"02" is indicated in diagnos mode (code No. 60). EEPF data error for adjustment o concentration of cylinder #	ROM f CO	Change the CO concentration of cylinder #2, and rewrite in EE- PROM. Refer to "ADJUSTING THE EX- HAUST GAS VOLUME" on page 5-2. After this adjustment is made, turn the main switch to "OFF".	Set the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Re- peat item 1. If the same number is indicated, go to item 5.	

4	 "11" is indicated in diagnostic mode (code No. 60). EEPROM data error for ISC (idle speed control) learning values. "12" is indicated in the diagnos- tic mode. (Code No. 60) EE- PROM data error for O₂ feedback learning values. "13" is indicated in the diagnos- tic mode. (Code No. 60) EE- PROM data error for OBD memory values. 	Turn the main switch to "OFF".	Set the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Re- peat item 1. If the same number is indicated, go to item 5.
5	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
6	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault	code No.	P065	7		
Item			Fuel system voltage: incorrect voltage supplied to the fuel injector and fuel pump.		
Fail-safe system		Able	to start engine		
raii-s	ale system	Able	to drive vehicle		
Diagr	nostic code No.	09, 5	0		
	Tool display	Appr	system voltage (battery voltage) oximately 12.0		
09	Procedure	meas	The start/engine stop switch to " \bigcirc ", sured battery voltage with the tool of battery voltage is low, recharge the surface structure of the structure struc	display value. (If the actually mea-	
50	Actuation	The "	Actuates the relay unit five times at one-second intervals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the relay is actuated.		
			Check that the relay unit is actuated five times by listening for the operating sound.		
ltem	Probable cause of malfunc- tion and check		Maintenance job	Confirmation of service com- pletion	
1	Connection of relay unit co Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro- terminals and locking cond- of the pins).	on of Id oken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	

3	Wire harness continuity.	Open or short circuit → Replace the wire harness. Between relay unit coupler and ECU coupler. red/blue–red/blue blue/yellow–blue/yellow Between relay unit coupler and joint coupler. red/white–red/white Between joint coupler and igni- tion fuse. red/white–red/white Between ignition fuse and main switch coupler. brown/blue–brown/blue Between main switch coupler and starter relay coupler. red–red Between starter relay coupler and battery terminal. red–red	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.
4	Defective relay unit.	Execute the diagnostic mode. (Code No. 50) No operating sound → Replace the relay unit.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 5.
5	Defective relay unit.	Execute the diagnostic mode. (Code No. 09) Fuel system voltage is below 3 $V \rightarrow$ Replace the relay unit.	Start the engine and let it idle for approximately 5 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault	Fault code No.		1		
Item			Sidestand switch: open or short circuit of the black/red lead of the ECU is detected.		
Fail-safe system		Unable to start engine			
		Unab	le to drive vehicle		
Diagn	ostic code No.	20			
Tool o	display	• "ON	stand switch I" (sidestand retracted) F" (sidestand extended)		
Proce	edure	Exter	nd and retract the sidestand (with t	he transmission in gear).	
Item	Probable cause of malfution and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Connection of sidestand su coupler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then extend and retract the sidestand. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of ECU couple Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected → Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then extend and retract the sidestand. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Connection of relay unit co Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then extend and retract the sidestand. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	
4	Wire harness continuity.		Open or short circuit → Replace the wire harness. Between sidestand switch cou- pler and relay unit coupler. blue/green—blue/green Between relay unit coupler and joint coupler. black/red—black/red Between joint coupler and ECU coupler. black/red—black/red	Turn the main switch to "ON", and then extend and retract the sidestand. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 5.	

5	Defective sidestand switch.	Execute the diagnostic mode. (Code No. 20) Shift the transmission into gear. Sidestand retracted: "ON" Sidestand extended: "OFF" Replace if defective.	Turn the main switch to "ON", and then extend and retract the sidestand. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	


Fault	Fault code No.		P1602		
ltem	Item		Malfunction in ECU internal circuit (malfunction of ECU power cut- off function).		
Fail-safe system		Able/Unable to start engine			
		Able/	Unable to drive vehicle		
Diagr	nostic code No.	—			
Tool o	display	—			
Proce	edure	—			
ltem	Probable cause of malfettion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Installed condition of batte leads. Check the installed dition of the battery and ba leads (loose bolts).	con-	Improperly installed battery or battery leads → Reinstall or re- place the battery leads.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of starter relay pler. Check the locking con of the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking conc of the pins).	dition d ken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Check the backup fuse.		Blown fuse → Replace the fuse or wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	
4	Wire harness continuity be tween battery and ECU co		Open or short circuit → Replace the wire harness. Between battery terminal and starter relay. red-red Between starter relay and fuel injection system fuse. red-red Between fuel injection system fuse and ECU coupler. red/black-red/black	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 5.	


5	Wire harness continuity be- tween main switch and ECU coupler.	Open or short circuit → Replace the wire harness. Between main switch and igni- tion fuse. brown/blue-brown/blue Between ignition fuse and joint coupler. red/white-red/white Between joint coupler and ECU coupler. red/white-red/white	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 7 and finish the service. Condition is "Detected" \rightarrow Go to item 6.
6	Malfunction in ECU.	Replace the ECU.	Service is finished.
7	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

Fault	code No.	P160	4, P1605	
Item		[P1604] Lean angle sensor: ground short circuit detected. [P1605] Lean angle sensor: open or power short circuit.		
Fail-safe system		Unab	le to start engine	
1 all-5	ale system	Unab	le to drive vehicle	
Diagn	ostic code No.	08		
Tool d	display	• 0.4-	angle sensor output voltage -1.4 (upright) -4.4 (overturned)	
Proce	edure	Remo	ove the lean angle sensor and incl	ine it more than 65 degrees.
ltem	Probable cause of malfettion and check	unc-	Maintenance job	Confirmation of service com pletion
1	Connection of lean angle sensor coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected → Con- nect the coupler securely or re- place the wire harness.	Turn the main switch to "ON", then to "OFF", and then back to "ON". Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 2.
2	Connection of ECU couple Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected → Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", then to "OFF", and then back to "ON". Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 3.
3	Wire harness continuity.		Open or short circuit → Replace the wire harness.	Turn the main switch to "ON", then to "OFF", and then back to "ON". Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 4.

Fault code No. P1604, P1605

FUEL INJECTION SYSTEM





<u> </u>			
4	Defective lean angle sensor.	Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-165.	Turn the main switch to "ON", then to "OFF", and then back to "ON". Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 5.
5	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
6	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

TIP_

If fault code numbers "P2195" and "P0030" are both indicated, take the actions specified for fault code number "P0030" first.

Fault	Fault code No.		P2195		
Item	Item		O ₂ sensor: Open circuit detected.		
	Fail-safe system		to start engine		
Fail-s			to drive vehicle		
Diagn	ostic code No.	—			
Tool o	display	—			
Proce	edure	—			
Item	Probable cause of malf tion and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Installed condition of O ₂ se	ensor.	Check for looseness or pinch- ing. Improperly installed sensor → Reinstall or replace the sensor.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 2. Also, delete this fault code, which has a condition of "De- tected".	
2	Connection of O ₂ sensor coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected → Con- nect the coupler securely or re- place the wire harness.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 3. Also, delete this fault code, which has a condition of "De- tected".	
3	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 4. Also, delete this fault code, which has a condition of "De- tected".	

4	Wire harness continuity.	Open or short circuit → Replace the wire harness. Between O ₂ sensor coupler and ECU coupler. gray/green-gray/green pink/black-pink/black Between O ₂ sensor coupler and joint coupler. black/blue-black/blue red/white-red/white Between joint coupler and joint coupler. black/blue-black/blue Between joint coupler and ECU coupler. black/blue-black/blue red/white-red/white Between joint coupler and igni- tion fuse. red/white-red/white	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 5. Also, delete this fault code, which has a condition of "De- tected".
5	Check fuel pressure.	Refer to "CHECKING THE FUEL PRESSURE" on page 7-14.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 6. Also, delete this fault code, which has a condition of "De- tected".
6	Defective O ₂ sensor.	Check the O ₂ sensor. Replace if defective. Refer to "ENGINE REMOVAL" on page 5-3.	Start the engine and let it idle for approximately 10 seconds. Check the condition of the fault code using the malfunction mode of the Yamaha diagnostic tool. Condition is "Recovered" \rightarrow Go to item 8 and finish the service. Condition is "Detected" \rightarrow Go to item 7. Also, delete this fault code, which has a condition of "De- tected".
7	Malfunction in ECU.	Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.
8	Delete the fault code and check that the engine trouble warning light goes off.	Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.	

TROUBLESHOOTING DETAILS (EVENT CODE)

Event code No. U0155 or "Err"

TIP_


- "Err" is displayed on the clock display of the multi-function meter, but the engine trouble warning light does not come on.
- When the Yamaha diagnostic tool is used, event code No. U0155 is displayed as a fault code.

Event	code No.	U015	55 or "Err"		
ltem			-function meter: signals cannot be he multi-function meter.	transmitted between the ECU	
Item	Probable cause of malfution and check	unc-	Maintenance job	Confirmation of service com- pletion	
1	Connection of meter asser coupler. Check the locking condition the coupler. Disconnect the coupler and check the pins (bent or bro terminals and locking cond of the pins).	n of d ken	Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 2.	
2	Connection of ECU coupler. Check the locking condition of the coupler. Disconnect the coupler and check the pins (bent or broken terminals and locking condition of the pins).		Improperly connected \rightarrow Connect the coupler securely or replace the wire harness.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 3.	
3	Wire harness continuity.		Open or short circuit → Replace the wire harness. Between meter assembly cou- pler and ECU coupler. blue/black–blue/black blue/red–blue/red	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 4.	
4	Defective meter assembly.		Replace the meter assembly.	Turn the main switch to "ON", and then check the condition of the fault code using the mal- function mode of the Yamaha di- agnostic tool. Condition is "Recovered" \rightarrow Go to item 6 and finish the service. Condition is "Detected" \rightarrow Go to item 5.	
5	Malfunction in ECU.		Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.	
6	Delete the fault code and c that the engine trouble war light goes off.		Confirm that the fault code has a condition of "Recovered" us- ing the Yamaha diagnostic tool, and then delete the fault code.		

Event	Event code No. 30						
			_atch up detected.				
			Unable to start engine				
Fail-s	afe system		le to drive vehicle				
Diagn	ostic code No.	08					
Diagi		••	angle sensor output voltage				
Tool c	display	• 0.4-	-1.4 (upright) -4.4 (overturned)				
Proce	dure	Remo	ove the lean angle sensor and incl	ine it more than 65 degrees.			
ltem	Probable cause of malfettion and check	unc-	Maintenance job	Confirmation of service com- pletion			
1	The vehicle has overturned.		Raise the vehicle upright.	Turn the main switch to "ON", then to "OFF", and then back to "ON". Engine trouble warning light does not come on \rightarrow Service is finished. Engine trouble warning light comes on \rightarrow Go to item 2.			
2	Installed condition of lean angle sensor.		Check the installed direction and condition of the sensor.	Turn the main switch to "ON", then to "OFF", and then back to "ON". Engine trouble warning light does not come on \rightarrow Service is finished. Engine trouble warning light comes on \rightarrow Go to item 3.			
3	Defective lean angle sensor.		Execute the diagnostic mode. (Code No. 08) Replace if defective. Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-165.	Turn the main switch to "ON", then to "OFF", and then back to "ON". Engine trouble warning light does not come on \rightarrow Service is finished. Engine trouble warning light comes on \rightarrow Go to item 4.			
4	Malfunction in ECU.		Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-158.	Service is finished.			

FUEL PUMP SYSTEM

EAS30513 CIRCUIT DIAGRAM



1. Main switch

7. Ignition fuse

10. Fuel injection system fuse

15.Battery

16.Engine ground

18.Main fuse

22.Relay unit

24.Fuel pump relay

25.Joint coupler

36.ECU (Engine Control Unit)

46.Fuel pump

62.Handlebar switch (right)

65.Start/engine stop switch

TROUBLESHOOTING If the fuel pump fails to operate.		
 Before troubleshooting, remove the follow 1. Battery cover 2. Fuel tank center cover/Air scoops 3. Fuel tank 4. Headlight assembly 	ving part(s):	
 Check the fuses. (Ignition, fuel injection system, and main) Refer to "CHECKING THE FUS- ES" on page 8-157. 	$NG \to$	Replace the fuse(s).
OK↓		
 Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158. 	$NG \to$	 Clean the battery terminals. Recharge or replace the battery.
OK↓		
3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	Replace the main switch/immobilizer unit.
OK↓		
4. Check the start/engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-153.	$NG \to$	The start/engine stop switch is faulty.Replace the right handlebar switch.
OK↓		
5. Check the relay unit (fuel pump re- lay). Refer to "CHECKING THE RE- LAYS" on page 8-161.	$NG \rightarrow$	Replace the relay unit.
OK↓		
6. Check the fuel pump. Refer to "CHECKING THE FUEL PUMP BODY" on page 7-4.	$NG \to$	Replace the fuel pump assembly.
<u></u> ОК↓		

OK↓

 Check the entire fuel pump system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-101.


 $\mathsf{OK}\, \downarrow$

Replace the ECU. Refer to "REPLAC-ING THE ECU (engine control unit)" on page 8-158. $\text{NG} \rightarrow$

Properly connect or replace the wiring harness.

EAS20084

EAS30519 CIRCUIT DIAGRAM



1. Main switch

- 7. Ignition fuse
- 10.Fuel injection system fuse
- 11.Backup fuse
- 15.Battery
- 16.Engine ground
- 17.Immobilizer unit
- 18.Main fuse
- 25.Joint coupler
- 36.ECU (Engine Control Unit)
- 48.Meter assembly
- 49.Immobilizer system indicator light
- 53.Multi-function meter

GENERAL INFORMATION

This vehicle is equipped with an immobilizer system to help prevent theft by re-registering codes in the standard keys. This system consists of the following:

- a code re-registering key (with a red bow)
- two standard keys (with a black bow) that can be re-registered with new codes
- a transponder (which is installed in the code re-registering key)
- an immobilizer unit
- the ECU
- an immobilizer system indicator light

The key with the red bow is used to register codes in each standard key. Do not use the key with the red bow for driving. It should only be used for re-registering new codes in the standard keys. The immobilizer system cannot be operated with a new key until the key is registered with a code. If you lose the code re-registering key, the ECU and main switch (equipped with the immobilizer unit) need to be replaced.

Therefore, always use a standard key for driving. (See NOTICE.)

TIP

Each standard key is registered during production, therefore re-registering at purchase is not necessary.

ECA14971

NOTICE

- DO NOT LOSE THE CODE RE-REGISTERING KEY! If the code re-registering key is lost, registering new codes in the standard keys is impossible. The standard keys can still be used to start the vehicle. However, if code re-registering is required (e.g., if a new standard key is made or all keys are lost) the entire immobilizer system must be replaced. Therefore, it is highly recommended to use either standard key for driving, and to keep the code re-registering key in a safe place.
- Do not submerse the keys in water.
- Do not expose the keys to excessively high temperatures.
- Do not place the keys close to magnets (this includes, but is not limited to, products such as speakers, etc.).
- Do not place heavy items on the keys.
- Do not grind the keys or alter their shape.
- Do not disassemble the key bows.
- Do not put two keys of any immobilizer system on the same key ring.
- Keep the standard keys as well as other immobilizer system keys away from the code re-registering key.
- Keep other immobilizer system keys away from the main switch as they may cause signal interference.

EAS30521

PARTS REPLACEMENT AND KEY CODE REGISTRATION REQUIREMENTS

In the course of use, you may encounter the following cases where replacement of parts and registration of code re-registering/standard keys are required.

TIP

Each standard key is registered during production, therefore re-registering at purchase is not necessary.

		Part				
	Main switch/immobi- lizer unit		Standard	FOU	Accessory lock* and	Key registration re- quirement
	Main switch	Immobilizer unit	key	ECU	key	•
Standard key is lost						New standard key
All keys have been lost (including code re-reg- istering key)			\checkmark	\checkmark	\checkmark	Code re-registering key and standard keys
ECU is defective				\checkmark		Code re-registering key and standard keys
Immobilizer unit is de- fective		\checkmark				Code re-registering key and standard keys
Main switch is defective				\checkmark	\checkmark	Code re-registering key and standard keys
Accessory lock* is de- fective					\checkmark	Not required

* Accessory locks mean the seat lock and fuel tank cap.

Code re-registering key registration:

When the immobilizer unit or ECU is replaced, the code re-registering key must be registered to the unit.

To register a code re-registering key:

1. Turn the main switch to "ON" with the code re-registering key.

TIP_

Check that the immobilizer system indicator light comes on for a few seconds, then goes off. When the immobilizer system indicator light goes off, the code re-registering key has been registered.


2. Check that the engine can be started.

3. Register the standard key, following the instructions in the section below.

Standby mode:

To enable the immobilizer system, turn the ignition key to "OFF". 30 seconds later, the indicator light will start flashing continuously in the standby flashing mode pattern for up to 24 hours. After that time, the indicator light will stop flashing, but the immobilizer system is still enabled.

Standby mode



- c. LED on
- d. LED off
- e. Standby mode on

Standard key registration:

Standard key registration is required when a standard key is lost and needs to be replaced, or when the code re-registering key is re-registered after the immobilizer unit or ECU are replaced. **TIP**

Do not start the engine with a standard key that has not been registered. If the main switch is turned "ON" with a standard key that has not been registered, the immobilizer system indicator light flashes to indicate fault code "52". (Refer to "SELF-DIAGNOSIS FAULT CODE INDICATION" on page 8-112).

- 1. Check that the immobilizer system indicator light signals the standby mode.
- 2. Using the code re-registering key, turn the main switch to "ON", then "OFF", and then remove the key within 5 seconds.
- 3. Insert the first standard key to be registered into the main switch, then turn the key to "ON" within 5 seconds to activate the key registration mode.

TIP.

The existing standard key code is erased from the memory when the key registration mode is activated. When the key registration mode is activated, the immobilizer system indicator light flashes rapidly.

4. While the indicator light is flashing, turn the main switch to "OFF", remove the key, and within 5 seconds, insert the second standard key to be registered into the main switch.

TIP.

If the immobilizer system indicator light stops flashing 5 seconds after the first standard key is registered, the registration mode is deactivated. If this occurs, the second standard key cannot be registered, and steps 2 to 4 need to be repeated to register both standard keys.


5. Turn the main switch to "ON".

TIP ___

When the indicator light goes off, the registration is complete.

6. Check that the engine can be started with the two registered standard keys.

Standard key registration




- a. Main switch "ON"
- b. Main switch "OFF"
- c. LED on
- d. LED off
- e. Less than 5.0 s
- f. Code re-registering key
- g. First standard key
- h. Second standard key
- i. Registration mode
- A. Registration of the second standard key is complete.
- B. Immobilizer system indicator light stops flashing when the registration of the second standard key is complete.

Voiding the standard key code:

If a standard key has been lost, it is possible to disable its use by re-registering the remaining standard key. Standard key registration erases the stored standard key code from the memory, thus disabling the lost standard key. To re-register, refer to "Standard key registration".

Standard key code voiding method



- a. Main switch "ON"
- b. Main switch "OFF"
- c. LED on
- d. LED off
- e. Less than 5.0 s
- f. Code re-registering key
- g. Remaining standard key
- h. Registration mode
- A. If the immobilizer system indicator light stops flashing 5 seconds after the first standard key is registered, the second standard key cannot be registered.

EAS30522 TROUBLESHOOTING

When the main switch is turned to "ON", the immobilizer system indicator light does not come on nor flashes.

 Check the fuses. (Ignition, fuel injection system, backup, and main) Refer to "CHECKING THE FUS- ES" on page 8-157. 	$NG \rightarrow$	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158.	NG ightarrow	 Clean the battery terminals. Recharge or replace the battery.
OK↓		
 Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-153. 	$NG \to$	Replace the main switch/immobilizer unit.
OK↓		
 Check the entire immobilizer system wiring. Refer to "CIRCUIT DIAGRAM" on page 8-105. 	NG ightarrow	Properly connect or replace the wiring har- ness.
OK↓		
 Check the condition each of the immobilizer system circuits. Refer to "SELF-DIAGNOSIS FAULT CODE INDICATION" on page 8-112. 		

EAS30523 SELF-DIAGNOSIS FAULT CODE INDICATION

When a system malfunction occurs, the immobilizer system indicator light flashes. The pattern of flashing also shows the fault code.


Fault code	Part	Symptom	Cause	Action
51	IMMOBILIZER UNIT	Code cannot be trans- mitted between the key and the immobiliz- er unit.	 Radio wave interference caused by objects around the keys and antennas. Immobilizer unit malfunction. Key malfunction. 	 Keep magnets, metal objects, and other immobilizer system keys away from the keys and antennas. Replace the main switch/immobiliz- er unit. Replace the key.
52	IMMOBILIZER UNIT	Codes between the key and immobilizer unit do not match.	 Signal received from other transponder (failed to recognize code after ten consecu- tive attempts). Signal received from unregistered standard key. 	 Place the immobilizer unit at least 50 mm away from the transponder of other vehicles. Register the stan- dard key.
53	IMMOBILIZER UNIT	Codes cannot be transmitted between the ECU and the im- mobilizer unit.	 Noise interference or disconnected lead/cable. 1. Interference due to radio wave noise. 2. Disconnected communication harness. 3. Immobilizer unit malfunction. 4. ECU malfunction. 	 Check the wire harness and con- nector. Replace the main switch/immobiliz- er unit. Replace the ECU. Refer to "REPLAC- ING THE ECU (en- gine control unit)" on page 8-158.
54	IMMOBILIZER UNIT	Codes transmitted be- tween the ECU and the immobilizer unit do not match.	 Noise interference or disconnected lead/cable. 1. Interference due to radio wave noise. 2. Disconnected communication harness. 3. Immobilizer unit malfunction. 4. ECU failure. (The ECU or immobilizer unit was replaced with a used unit from another vehicle.) 	 Register the code re-registering key. Check the wire harness and con- nector. Replace the main switch/immobiliz- er unit. Replace the ECU. Refer to "REPLAC- ING THE ECU (en- gine control unit)" on page 8-158.
55	IMMOBILIZER UNIT	Key code registration malfunction.	Same standard key was at- tempted to be registered two consecutive times.	Register another standard key.

IMMOBILIZER SYSTEM

Fault code	Part	Symptom	Cause	Action
56	ECU	Unidentified code is received.	Noise interference or dis- connected lead/cable.	 Check the wire harness and con- nector. Replace the main switch/immobiliz- er unit. Replace the ECU. Refer to "REPLAC- ING THE ECU (en- gine control unit)" on page 8-158.

Immobilizer system indicator light fault code indication


Units of 10: Cycles of on for 1 second and off for 1.5 seconds. Units of 1: Cycles of on for 0.5 second and off for 0.5 second. Example: fault code 52



a. Light on


b. Light off

CIRCUIT DIAGRAM



- 1. Main switch
- 2. ABS solenoid fuse
- 3. ABS motor fuse
- 5. ABS control unit fuse
- 7. Ignition fuse
- 8. Signaling system fuse
- 10. Fuel injection system fuse
- 11.Backup fuse
- 15.Battery
- 16.Engine ground
- 18.Main fuse
- 21.Rear brake light switch
- 25.Joint coupler
- 36.ECU (Engine Control Unit)
- 41.Front wheel sensor
- 42.Rear wheel sensor
- 43.ABS ECU (electronic control unit)
- 44. Yamaha diagnostic tool coupler
- 48.Meter assembly
- 53.Multi-function meter
- 59.ABS warning light
- 62.Handlebar switch (right)
- 63. Front brake light switch
- 81.Tail/brake light
- A. Wire harness
- B. Positive battery sub-wire harness

ABS COUPLER LOCATION CHART




- 1. ABS ECU coupler
- 2. Rear wheel sensor coupler
- 3. Yamaha diagnostic tool coupler
- 4. Meter assembly coupler
- 5. Front wheel sensor coupler

EAS300991 MAINTENANCE OF THE ABS ECU

Checking the ABS ECU

- 1. Check:
 - Terminals "1" of the ABS ECU Cracks/damages → Replace the hydraulic unit assembly, brake hoses, and brake pipes that are connected to the assembly as a set.
 - Terminals "2" of the ABS ECU coupler Connection defective, contaminated, come-off \rightarrow Correct or clean.
- TIP

If the ABS ECU coupler is clogged with mud or dirt, clean with compressed air.



EAS30992

ABS TROUBLESHOOTING OUTLINE

This section describes the troubleshooting for the ABS in detail. Read this service manual carefully and make sure you fully understand the information provided before repairing any malfunctions or performing service.

The ABS ECU (electronic control unit) has a self-diagnosis function. When failures occur in the system, the ABS warning light on the meter assembly indicates a malfunction.

The following troubleshooting describes the problem identification and service method using the Yamaha diagnostic tool. For information about using the Yamaha diagnostic tool, refer to "[B-2] DIAG-NOSIS USING THE FAULT CODES" on page 8-124. For troubleshooting items other than the following items, follow the normal service method.

When maintenance or checks have been performed on components related to the ABS, be sure to perform a final check before delivering the vehicle to the customer.

TIP .

To final check, refer to "[C-1] FINAL CHECK" on page 8-147.

ABS operation when the ABS warning light comes on

- 1. The ABS warning light remains on \rightarrow ABS operates as a normal brake system.
- A malfunction was detected using the ABS self-diagnosis function.
- The ABS self-diagnosis has not been completed. The ABS self-diagnosis starts when the main switch is turned to "ON" and finishes when the vehicle has traveled at a speed of approximately 10 km/h (6 mi/h).
- 2. The ABS warning light comes on after the engine starts, and then goes off when the vehicle starts moving (traveling at a speed of approximately 10 km/h (6 mi/h)). → ABS operation is normal.
- 3. The ABS warning light flashes \rightarrow ABS operation is normal.
- Refer to "BASIC INSTRUCTIONS FOR TROUBLESHOOTING" on page 8-120.

Self-diagnosis and servicing

The ABS ECU has a self-diagnosis function. By utilizing this function, quick problem identification and service are possible. Previous malfunctions can be checked since the ABS ECU also stores the malfunction history.

The fault codes recorded in the ABS ECU can be checked using the Yamaha diagnostic tool. When the service is finished, check the normal operation of the vehicle, and then delete the fault code(s). For information about deleting the fault codes, refer to "[B-3] DELETING THE FAULT CODES" on page 8-147. By deleting the fault codes stored in the ABS ECU memory, it is possible to pursue the cause correctly if another malfunction occurs.

TIP_

The ABS performs a self-diagnosis test for a few seconds each time the vehicle first starts off after the main switch was turned to "ON". During this test, a "clicking" noise can be heard from inside of the right air scoop, and if the brake lever or brake pedal are even slightly applied, a vibration can be felt at the lever and pedal, but these do not indicate a malfunction.

Self-diagnosis using the ABS ECU

The ABS ECU performs a static check of the entire system when the main switch is turned to "ON". It also checks for malfunctions while the vehicle is ridden. Since all malfunctions are recorded after they are detected, it is possible to check the recorded malfunction data by utilizing the Yamaha diagnostic tool when the ABS ECU has entered the self-diagnosis mode.

Special precautions for handling and servicing a vehicle equipped with ABS

NOTICE

Care should be taken not to damage components by subjecting them to shocks or pulling on them with too much force since the ABS components are precisely adjusted.

• The ABS ECU and hydraulic unit are united assemblies and cannot be disassembled.

• The malfunction history is stored in the memory of the ABS ECU. Delete the fault codes when the service is finished. (This is because the past fault codes will be displayed again if another malfunction occurs.)

EAS30993 BASIC INSTRUCTIONS FOR TROUBLESHOOTING EWA17420

 Perform the troubleshooting [A]→[B]→[C] in order. Be sure to follow the order since a wrong diagnosis could result if the steps are followed in a different order or omitted.

Use sufficiently charged regular batteries only.


[A] Malfunction check using the ABS warning light

[B] Use the Yamaha diagnostic tool and determine the location of the malfunction and the cause from the recorded fault code.

Determine the cause of the malfunction from the condition and place where the malfunction occurred. [C] Servicing the ABS

Execute the final check after disassembly and assembly.

EAS30994 BASIC PROCESS FOR TROUBLESHOOTING



EWA16710

When maintenance or checks have been performed on components related to the ABS, be sure to perform a final check before delivering the vehicle to the customer.

TIP.

To final check, refer to "[C-1] FINAL CHECK" on page 8-147.

[A] CHECKING THE ABS WARNING LIGHT

Turn the main switch to "ON". (Do not start the engine.)

- 1. The ABS warning light does not come on.
- Only the ABS warning light fails to come on. [A-1]
- The ABS warning light and all other indicator lights fail to come on. [A-2]
- 2. The ABS warning light comes on. [A-3]

EAS30996

[A-1] ONLY THE ABS WARNING LIGHT FAILS TO COME ON

- 1. Check for a short circuit to the ground between the green/red terminal of the ABS ECU coupler and green/red terminal of the meter assembly.
- If there is short circuit to the ground, the wire harness is defective. Replace the wire harness.
- 2. Disconnect the ABS ECU coupler and check that the ABS warning light comes on when the main switch is turned to "ON".
- If the ABS warning light does not come on, the meter assembly circuit (including the ABS warning light [LED]) is defective. Replace the meter assembly.
- If the ABS warning light comes on, the ABS ECU is defective. Replace the hydraulic unit assembly.

[A-2] ALL INDICATOR LIGHTS FAIL TO COME ON

- 1. Main switch
- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES" on page 8-153.
- If there is no continuity, replace the main switch/immobilizer unit.
- 2. Battery
- Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158.
- If the battery is defective, clean the battery terminals and recharge it, or replace the battery.
- 3. Main fuse
- Check the fuse for continuity.
 - Refer to "CHECKING THE FUSES" on page 8-157.
- If the main fuse is blown, replace the fuse.
- 4. Circuit
- Check the meter assembly circuit. Refer to "CIRCUIT DIAGRAM" on page 8-115.
- If the meter assembly circuit is open, replace the wire harness.

EAS31134

[A-3] THE ABS WARNING LIGHT COMES ON

Connect the Yamaha diagnostic tool to the Yamaha diagnostic tool coupler and execute functional diagnosis. (For information about how to execute functional diagnosis, refer to the operation manual that is included with the tool.)

Check that communication with the ABS ECU is possible.

- Only the ABS ECU fails to communicate. [A-4]
- ABS ECU and FI ECU fail to communicate. [A-5]

• Communication is possible with the ABS ECU. [B-1] (The ABS is displayed on the select unit screen.)

[A-3] ONLY THE ABS ECU FAILS TO COMMUNICATE (The select unit screen does not appear.)

- 1. ABS control unit fuse
- Check the ABS control unit fuse for continuity. Refer to "CHECKING THE FUSES" on page 8-157.
- If the ABS control unit fuse is blown, replace the fuse.

2. ABS ECU coupler

- Check that the ABS ECU coupler is connected properly. For information about connecting the ABS ECU coupler properly, refer to "INSTALLING THE HY-DRAULIC UNIT ASSEMBLY" on page 4-58.
- 3. Wire harness
- Open circuit between the main switch and the ABS ECU, or between the ABS ECU and the ground. Check for continuity between brown/blue terminal of the main switch coupler and brown/white terminal of the ABS ECU coupler.

Check for continuity between black/green terminal of the ABS ECU coupler and the ground, and between the black terminal of the ABS ECU coupler and ground.

If there is no continuity, the wire harness is defective. Replace the wire harness.

• Open circuit in the wire harness between the ABS ECU coupler and the Yamaha diagnostic tool coupler.

Check for continuity between blue/red terminal of the ABS ECU coupler and blue/red terminal of the Yamaha diagnostic tool coupler. (CANH)

Check for continuity between blue/black terminal of the ABS ECU coupler and blue/black terminal of the Yamaha diagnostic tool coupler. (CANL)

4. ABS ECU malfunction

Replace the hydraulic unit assembly.

EAS31136

[A-5] ABS ECU AND FI ECU FAIL TO COMMUNICATE (Cannot connect due to a tool error.)

1. Yamaha diagnostic tool

Check that the Yamaha diagnostic tool is properly connected.

- 2. Wire harness
- Open circuit in the wire harness between the ABS ECU coupler and the Yamaha diagnostic tool coupler.

Check for continuity between blue/red terminal of the ABS ECU coupler and blue/red terminal of the Yamaha diagnostic tool coupler. (CANH)

Check for continuity between blue/black terminal of the ABS ECU coupler and blue/black terminal of the Yamaha diagnostic tool coupler. (CANL)

EAS31137

[B-1] MALFUNCTION ARE CURRENTLY DETECTED

When the Yamaha diagnostic tool is connected to the Yamaha diagnostic tool coupler, the fault codes will be displayed on the computer screen.

- A fault code is displayed. [B-2]
- A fault code is not displayed. [C-1]

EAS31138

[B-2] DIAGNOSIS USING THE FAULT CODES

This model uses the Yamaha diagnostic tool to identify malfunctions.

For information about using the Yamaha diagnostic tool, refer to the operation manual that is included with the tool.




Yamaha diagnostic tool 90890-03250

Connecting the Yamaha diagnostic tool

Removing the seat. Refer to "GENERAL CHASSIS (1)" on page 4-1.

Removing the protective cap "1", and then connect the Yamaha diagnostic tool to the coupler.



Details about the displayed fault codes are shown in the following chart. Refer to this chart and check the vehicle.


Once all the work is complete, delete the fault codes. [B-3] **TIP**

Check the inspection points after terminating the connection with the Yamaha diagnostic tool and turning the main switch off.

Operation of the Yamaha diagnostic tool (Fault diagnosis mode)

The results of the fault diagnosis are displayed as shown in the following screen shot. **TIP**_____

The screen display may vary depending on the version of the Yamaha diagnostic tool that you are using.



- 1. The types of the control units are displayed. (e.g., FI, ABS)
- 2. The icons indicating the diagnosis results are displayed.



- A. Detected malfunction
- B. Recovered malfunction
- 3. The fault code numbers are displayed.
- 4. The current conditions are displayed. (Detected/Recovered)
- 5. The item names and symptoms of the detected malfunctions are displayed.

Fault code table

TIP.

Record all of the fault codes displayed and inspect the check points.

Fault code No.	Item	Symptom	Check point
11* 25*	Front wheel sensor (intermit- tent pulses or no pulses)	Front wheel sensor signal is not received properly. (Puls- es are not received or are re- ceived intermittently while the vehicle is traveling.)	 Foreign material adhered around the front wheel sen- sor Incorrect installation of the front wheel Defective sensor rotor or incorrect installation of the rotor Defective front wheel sen- sor or incorrect installation of the sensor
12	Rear wheel sensor (intermit- tent pulses or no pulses)	Rear wheel sensor signal is not received properly. (Puls- es are not received or are re- ceived intermittently while the vehicle is traveling.)	 Foreign material adhered around the rear wheel sen- sor Incorrect installation of the rear wheel Defective sensor rotor or incorrect installation of the rotor Defective rear wheel sen- sor or incorrect installation of the sensor
13* 26*	Front wheel sensor (abnor- mal pulse period)	Front wheel sensor signal is not received properly. (The pulse period is abnormal while the vehicle is traveling.)	 Foreign material adhered around the front wheel sen- sor Incorrect installation of the front wheel Defective sensor rotor or incorrect installation of the rotor Defective front wheel sen- sor or incorrect installation of the sensor

Fault code No.	Item	Symptom	Check point
14* 27*	Rear wheel sensor (abnor- mal pulse period)	Rear wheel sensor signal is not received properly. (The pulse period is abnormal while the vehicle is traveling.)	 Foreign material adhered around the rear wheel sen- sor Incorrect installation of the rear wheel Defective sensor rotor or incorrect installation of the rotor Defective rear wheel sen- sor or incorrect installation of the sensor
15	Front wheel sensor (open or short circuit)	Open or short circuit is de- tected in the front wheel sen- sor.	 Defective coupler between the front wheel sensor and the hydraulic unit assembly Open or short circuit in the wire harness between the front wheel sensor and the hydraulic unit assembly Defective front wheel sen- sor or hydraulic unit as- sembly
16	Rear wheel sensor (open or short circuit)	Open or short circuit is de- tected in the rear wheel sen- sor.	 Defective coupler between the rear wheel sensor and the hydraulic unit assembly Open or short circuit in the wire harness between the rear wheel sensor and the hydraulic unit assembly Defective rear wheel sen- sor or hydraulic unit as- sembly
17* 45*	Front wheel sensor (missing pulses)	Front wheel sensor signal is not received properly. (Miss- ing pulses are detected in the signal while the vehicle is traveling.)	 Foreign material adhered around the front wheel sen- sor Incorrect installation of the front wheel Defective sensor rotor or incorrect installation of the rotor Defective front wheel sen- sor or incorrect installation of the sensor
18* 46*	Rear wheel sensor (missing pulses)	Rear wheel sensor signal is not received properly. (Miss- ing pulses are detected in the signal while the vehicle is traveling.)	 Foreign material adhered around the rear wheel sen- sor Incorrect installation of the rear wheel Defective sensor rotor or incorrect installation of the rotor Defective rear wheel sen- sor or incorrect installation of the sensor
21	Hydraulic unit assembly (de- fective solenoid drive circuit)	Solenoid drive circuit in the hydraulic unit assembly is open or short-circuited.	 Defective hydraulic unit as- sembly

Fault code No.	Item	Symptom	Check point
24	Brake light switch or tail/brake light	Brake light signal is not re- ceived properly while the ve- hicle is traveling. (Brake light circuit, or front or rear brake light switch circuit)	 Defective signaling system (tail/brake light or brake light switch) Defective coupler between the signaling system (tail/brake light or brake light switch) and the hy- draulic unit assembly Open or short circuit in the wire harness between the signaling system (tail/brake light or brake light switch) and the hydraulic unit as- sembly Defective hydraulic unit as- sembly
31	Hydraulic unit assembly (ab- normal ABS solenoid power supply)	Power is not supplied to the solenoid circuit in the hy- draulic unit assembly.	 Blown ABS solenoid fuse Defective coupler between the battery and the hydrau- lic unit assembly Open or short circuit in the wire harness between the battery and the hydraulic unit assembly Defective hydraulic unit as- sembly
32	Hydraulic unit assembly (short circuit in ABS solenoid power supply circuit)	Short circuit is detected in the solenoid power supply circuit in the hydraulic unit assembly.	 Defective hydraulic unit as- sembly
33	Hydraulic unit assembly (ab- normal ABS motor power supply)	Power is not supplied to the motor circuit in the hydraulic unit assembly.	 Blown ABS motor fuse Defective coupler between the battery and the hydrau- lic unit assembly Open or short circuit in the wire harness between the battery and the hydraulic unit assembly Defective hydraulic unit as- sembly
34	Hydraulic unit assembly (short circuit in ABS motor power supply circuit)	Short circuit is detected in the motor power supply cir- cuit in the hydraulic unit as- sembly.	 Defective hydraulic unit as- sembly
41	Front wheel ABS (intermit- tent wheel speed pulses or incorrect depressurization)	 Pulses from the front wheel sensor are received inter- mittently while the vehicle is traveling. Front wheel will not recover from the locking tendency even though the signal is transmitted from the ABS ECU to reduce the hydrau- lic pressure. 	 Incorrect installation of the front wheel sensor Incorrect rotation of the front wheel Front brake dragging Defective hydraulic unit assembly

Fault code No.	Item	Symptom	Check point
42 47	Rear wheel ABS (intermit- tent wheel speed pulses or incorrect depressurization)	 Pulses from the rear wheel sensor are received inter- mittently while the vehicle is traveling. (for fault code No. 42) Rear wheel will not recover from the locking tendency even though the signal is transmitted from the ABS ECU to reduce the hydrau- lic pressure. 	 Incorrect installation of the rear wheel sensor (for fault code No. 42) Incorrect rotation of the rear wheel Rear brake dragging Defective hydraulic unit assembly
43	Front wheel sensor (missing pulses)	Front wheel sensor signal is not received properly. (Miss- ing pulses are detected in the signal while the vehicle is traveling.)	 Foreign material adhered around the front wheel sen- sor Incorrect installation of the front wheel Defective sensor rotor or incorrect installation of the rotor Defective front wheel sen- sor or incorrect installation of the sensor
44	Rear wheel sensor (missing pulses)	Rear wheel sensor signal is not received properly. (Miss- ing pulses are detected in the signal while the vehicle is traveling.)	 Foreign material adhered around the rear wheel sen- sor Incorrect installation of the rear wheel Defective sensor rotor or incorrect installation of the rotor Defective rear wheel sen- sor or incorrect installation of the sensor
51 52	 Vehicle system power supply (voltage of ABS ECU power supply is high) (for fault code No. 51) Vehicle system power supply (voltage of wheel sensor power supply is high) (for fault code No. 52) 	 Power voltage supplied to the ABS ECU in the hy- draulic unit assembly is too high. (for fault code No. 51) Power voltage supplied to the wheel sensor is too high. (for fault code No. 52) 	 Defective battery Disconnected battery terminal Defective charging system
53	Vehicle system power supply (voltage of ABS ECU power supply is low)	Power voltage supplied to the ABS ECU in the hydrau- lic unit assembly is too low.	 Defective battery Defective coupler between the battery and the hydrau- lic unit assembly Open or short circuit in the wire harness between the battery and the hydraulic unit assembly Defective charging system

Fault code No.	Item	Symptom	Check point
54	Hydraulic unit assembly (de- fective ABS solenoid and ABS motor power supply cir- cuits)	Abnormality is detected in the solenoid or motor power supply circuit in the hydraulic unit assembly.	 Defective battery Defective coupler between the battery and the hydrau- lic unit assembly Open or short circuit in the wire harness between the battery and the hydraulic unit assembly Defective charging system Defective hydraulic unit as- sembly
55	Hydraulic unit assembly (de- fective ABS ECU)	Abnormal data is detected in the hydraulic unit assembly.	 Defective hydraulic unit as- sembly
56	Hydraulic unit assembly (ab- normal internal power sup- ply)	Abnormality is detected in the power supply circuit in the hydraulic unit assembly.	 Defective hydraulic unit as- sembly
63	Front wheel sensor power supply (voltage of power supply is low)	Power voltage supplied from the ABS ECU to the front wheel sensor is too low.	 Short circuit in the wire harness between the front wheel sensor and the hydraulic unit assembly Defective front wheel sensor Defective hydraulic unit assembly
64	Rear wheel sensor power supply (voltage of power supply is low)	Power voltage supplied from the ABS ECU to the rear wheel sensor is too low.	 Short circuit in the wire harness between the rear wheel sensor and the hydraulic unit assembly Defective rear wheel sensor Defective hydraulic unit assembly

* The fault code number varies according to the vehicle conditions.

Fault code No. 11, 25

TIP_

With the front wheel stopped, the rear wheel was rotated for longer than about 20 seconds (fault code No. 11) or for longer than about 2 seconds (fault code No. 25).

Fault code No.		11 25		
ltem		Front wheel sensor (intermittent pulses or no pulses)		
		Front wheel sensor signal is not received properly. (Pulses are not re- ceived or are received intermittently while the vehicle is traveling.)		
Order	Order Item/components and probable cause		Check or maintenance job	
1	Foreign material adhered around the front wheel sensor		Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.	
2	Incorrect installation of the front wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-14.	
3	Defective sensor rotor or incorrect instal- lation of the rotor		Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.	
4	Defective front wheel sensor or incorrect installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.	

Fault code No. 12

Fault code No. Item		12	
		Rear wheel sensor (intermittent pulses or no pulses)	
Symptom		Rear wheel sensor signal is not received properly. (Pulses are not re- ceived or are received intermittently while the vehicle is traveling.)	
Order	Item/components and probable cause		Check or maintenance job
1	Foreign material adhered around the rear wheel sensor		Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the rear wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-24.
3	Defective sensor rotor or incorrect instal- lation of the rotor		Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.
4	Defective rear wheel sensor or incorrect installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.

Fault code No. 13, 26

- If the front brake ABS operates continuously for 20 seconds or more, fault code No. 26 will be recorded. If the front brake ABS operates continuously for 36 seconds or more, fault code No. 13 will be recorded.
- Vehicle possibly ridden on uneven roads.

Fault code No.13 26ItemFront wheel sensor			
		Front wheel sen	sor (abnormal pulse period)
Sympt	ptom Front wheel sensor signal is not received properly. (The pulse is abnormal while the vehicle is traveling.)		
Order	r Item/components and probable cause		Check or maintenance job
1	Foreign material adhered around the front wheel sensor		Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the front wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-14.
3	Defective sensor rotor or incorrect instal- lation of the rotor		Check the surface of the sensor rotor for damage. Re- place the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.
4	Defective front wheel sensor or incorrect installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.

TIP_

Fault code No. 14, 27

- If the rear brake ABS operates continuously for 20 seconds or more, fault code No. 27 will be recorded. If the rear brake ABS operates continuously for 36 seconds or more, fault code No. 14 will be recorded.
- Vehicle possibly ridden on uneven roads.

Fault code No.14 27ItemRear wheel s			
		Rear wheel sense	nsor (abnormal pulse period)
Symptom Rear wheel sensor signal is not received is abnormal while the vehicle is traveling		sor signal is not received properly. (The pulse period le the vehicle is traveling.)	
Order	r Item/components and probable cause		Check or maintenance job
1	Foreign material adhered around the rear wheel sensor		Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the rear wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-24.
3	Defective sensor rotor or incorrect instal- lation of the rotor		Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.
4	Defective rear wheel sensor or incorrect installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.

TIP_

TIP ____

Turn the main switch to "OFF" before disconnecting or connecting a coupler.

Fault c	ode No.	15	
Item		Front wheel sensor (open or short circuit)	
Sympt	om	Open or short c	rcuit is detected in the front wheel sensor.
Order	Item/components and p	robable cause	Check or maintenance job
1	Defective coupler between the front wheel sensor and the hydraulic unit assembly		 Check the coupler for any pins that may be pulled out. Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely. See TIP.
2	Open or short circuit in the wire harness between the front wheel sensor and the hydraulic unit assembly		 Check for continuity between the white terminal "1" and the white terminal "4" and between the black terminal "2" and the black terminal "5". If there is no continuity, the wire harness is defective. Replace the wire harness. Check that there is no short circuit between the white terminal "1" and the black terminal "2" and between the white terminal "4" and the black terminal "5". If there is short circuit, the wire harness is defective. Replace the wire harness. Check that there is no short circuit between the black terminal "3" and the black terminal "4" and between the black terminal "3" and the white terminal "4" and between the black terminal "3" and the black terminal "4" and between the black terminal "3" and the black terminal "5". If there is short circuit, the wire harness is defective. Replace the wire harness. Check that there is no short circuit between the black terminal "3" and the black terminal "4" and between the black terminal "3" and the black terminal "5". If there is short circuit, the wire harness is defective. Replace the wire harness. If there is short circuit, the wire harness is defective. Replace the wire harness. If there is short circuit, the wire harness is defective. Replace the wire harness. If there is a constructive the terminal "4" and between the black terminal "5". If there is short circuit, the wire harness is defective. Replace the wire harness. If there is a constructive terminal terminal
3	Defective front wheel ser unit assembly	nsor or hydraulic	If the above items were performed and no malfunctions were found, the wheel sensor or hydraulic unit assembly is defective. Replace the wheel sensor or hydraulic unit assembly. Refer to "FRONT WHEEL" on page 4-12 and "ABS (AN- TI-LOCK BRAKE SYSTEM)" on page 4-56.

TIP ____

Turn the main switch to "OFF" before disconnecting or connecting a coupler.

Fault code No. 1		16	
ltem		Rear wheel sensor (open or short circuit)	
Sympt	om	Open or short c	ircuit is detected in the rear wheel sensor.
Order	Item/components and p	robable cause	Check or maintenance job
1	Defective coupler betwee sensor and the hydraulic		 Check the coupler for any pins that may be pulled out. Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely. See TIP.
2	Open or short circuit in the wire harness between the rear wheel sensor and the hydraulic unit assembly		 Check for continuity between the white terminal "1" and the white terminal "4" and between the black terminal "2" and the black terminal "5". If there is no continuity, the wire harness is defective. Replace the wire harness. Check that there is no short circuit between the white terminal "1" and the black terminal "2" and between the white terminal "4" and the black terminal "5". If there is short circuit, the wire harness is defective. Replace the wire harness. Check that there is no short circuit between the black terminal "3" and the white terminal "4" and between the black terminal "3" and the white terminal "4" and between the black terminal "3" and the white terminal "4" and between the black terminal "3" and the black terminal "5". If there is short circuit, the wire harness is defective. Replace the wire harness. Check that there is no short circuit between the black terminal "3" and the black terminal "4" and between the black terminal "3" and the black terminal "5". If there is short circuit, the wire harness is defective. Replace the wire harness. If there is short circuit, the wire harness is defective. Replace the wire harness. If there is a continuity the wire harness is defective. Replace the wire harness. If there is a continuity the wire harness is defective. Replace the wire harness. If there is a continuity the wire harness is defective. Replace the wire harness. If there is a continuity the wire harness is defective. Replace the wire harness. If there is a continuity the wire harness is defective. Replace the wire harness. If there is a continuity the wire harness is defective. Replace the wire harness. If there is a continuity the wire harness the black terminal the black terminal
3	Defective rear wheel sen unit assembly	sor or hydraulic	If the above items were performed and no malfunctions were found, the wheel sensor or hydraulic unit assembly is defective. Replace the wheel sensor or hydraulic unit assembly. Refer to "REAR WHEEL" on page 4-20 and "ABS (ANTI- LOCK BRAKE SYSTEM)" on page 4-56.

Fault code No. 17, 45

TIP_

If pulse gaps are detected when the vehicle is traveling at a speed of 30 km/h (19 mi/h) or more, fault code No. 17 will be recorded. If the vehicle is traveling at a speed of 29 km/h (18 mi/h) or less, fault code No. 45 will be recorded first and fault code No. 17 will be recorded if the condition continues.

Fault o	code No.	17 45	
ltem		Front wheel sen	sor (missing pulses)
Sympt	om	Front wheel sensor signal is not received properly. (Missing pulses are detected in the signal while the vehicle is traveling.)	
Order	Item/components and p	probable cause	Check or maintenance job
1	Foreign material adhered around the front wheel sensor		Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the front wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-14.
3	Defective sensor rotor or incorrect instal- lation of the rotor		Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.
4	Defective front wheel sensor or incorrect installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.

Fault code No. 18, 46

TIP_

If pulse gaps are detected when the vehicle is traveling at a speed of 30 km/h (19 mi/h) or more, fault code No. 18 will be recorded. If the vehicle is traveling at a speed of 29 km/h (18 mi/h) or less, fault code No. 46 will be recorded first and fault code No. 18 will be recorded if the condition continues.

Fault code No		18 46	
ltem		Rear wheel sense	sor (missing pulses)
Sympt	om	Rear wheel sensor signal is not received properly. (Missing pulses are detected in the signal while the vehicle is traveling.)	
Order	Item/components and p	probable cause	Check or maintenance job
1	Foreign material adhered around the rear wheel sensor		Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the rear wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-24.
3	Defective sensor rotor or incorrect instal- lation of the rotor		Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.
4	Defective rear wheel sensor or incorrect installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.

Fault code No. 21

Fault code No.		21	
Item		Hydraulic unit assembly (defective solenoid drive circuit)	
Sympt	om	Solenoid drive circuit in the hydraulic unit assembly is open or short- circuited.	
Order	Item/components and probable cause		Check or maintenance job
1	Defective hydraulic unit assembly		Replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.

Fault o	Fault code No. 24			
Fault code No.		24		
ltem		Brake light switch or tail/brake light		
Sympt	om	Brake light signal is not received properly while the vehicle is travel- ing (Brake light circuit, or front or rear brake light switch circuit).		
Order	Item/components and p	probable cause	Check or maintenance job	
1	Defective signaling system (tail/brake light or brake light switch)		Check the brake light switches. Refer to "CHECKING THE SWITCHES" on page 8-153.	
2	Defective coupler between the signaling system (tail/brake light or brake light switch) and the hydraulic unit assembly		 Check the coupler for any pins that may be pulled out. Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely. 	
3	Open or short circuit in the wire harness between the signaling system (tail/brake light or brake light switch) and the hydrau- lic unit assembly		 Between ABS ECU coupler and joint coupler. (yellow–yellow) Between joint coupler and front brake light switch coupler. (yellow–yellow) Between ABS ECU coupler and joint coupler. (yellow–yellow) Between joint coupler and rear brake light switch coupler. (yellow–yellow) 	
4	Defective hydraulic unit assembly		If the above items were performed and no malfunctions were found, replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

TIP ____

Turn the main switch to "OFF" before disconnecting or connecting a coupler.

Fault o	code No.	31		
ltem		Hydraulic unit assembly (abnormal ABS solenoid power supply)		
Sympt	om	Power is not su sembly.	Power is not supplied to the solenoid circuit in the hydraulic unit as- sembly.	
Order	Item/components and p	probable cause	Check or maintenance job	
1	Blown ABS solenoid fuse		Check the ABS solenoid fuse. If the ABS solenoid fuse is blown, replace the fuse and check the wire harness. Refer to "CHECKING THE FUSES" on page 8-157.	
2	Defective coupler between the battery and the hydraulic unit assembly		 Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely. See TIP. 	
3	Open or short circuit in the wire harness between the battery and the hydraulic unit assembly		 Replace if there is an open or short circuit. Between ABS ECU coupler and ABS solenoid fuse. (red/white–red/white) 	
4	Defective hydraulic unit assembly		If the above items were performed and no malfunctions were found, replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

Fault code No. 32				
Fault code No. 3		32		
Item		Hydraulic unit assembly (short circuit in ABS solenoid power supply circuit)		
Sympt	om	Short circuit is detected in the solenoid power supply circuit in the hy- draulic unit assembly.		
Order	Item/components and probable cause		Check or maintenance job	
1	Defective hydraulic unit assembly		Replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

TIP ____

Turn the main switch to "OFF" before disconnecting or connecting a coupler.

Fault o	code No.	33		
ltem		Hydraulic unit a	ssembly (abnormal ABS motor power supply)	
Sympt	om	Power is not sup bly.	Power is not supplied to the motor circuit in the hydraulic unit assembly.	
Order	Item/components and p	orobable cause	Check or maintenance job	
1	Blown ABS motor fuse		Check the ABS motor fuse. If the ABS motor fuse is blown, replace the fuse and check the wire harness. Refer to "CHECKING THE FUSES" on page 8-157.	
2	Defective coupler between the battery and the hydraulic unit assembly		 Check the coupler for any pins that may be pulled out. Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely. See TIP. 	
3	Open or short circuit in the wire harness between the battery and the hydraulic unit assembly		 Replace if there is an open or short circuit. Between ABS ECU coupler and ABS motor fuse. (red/blue–red/blue) Between ABS ECU coupler and ground. (black–black) 	
4	Defective hydraulic unit assembly		If the above items were performed and no malfunctions were found, replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

Fault code No. 34

Fault code No.		34	
Item		Hydraulic unit assembly (short circuit in ABS motor power supply cir- cuit)	
Symptom		Short circuit is detected in the motor power supply circuit in the hy- draulic unit assembly.	
Order	Item/components and probable cause		Check or maintenance job
1	Defective hydraulic unit assembly		Replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.

Fault code No. 41					
Fault o	code No.	41			
ltem		Front wheel AB pressurization)	Front wheel ABS (intermittent wheel speed pulses or incorrect depressurization)		
Symptom		 Pulses from the front wheel sensor are received intermittently while the vehicle is traveling. Front wheel will not recover from the locking tendency even though the signal is transmitted from the ABS ECU to reduce the hydraulic pressure. 			
Order	Item/components and probable cause		Check or maintenance job		
1	Incorrect installation of the front wheel sensor		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-14.		
2	Incorrect rotation of the front wheel		Check that there is no brake disc drag on the front wheel and make sure that it rotates smoothly. Refer to "CHECKING THE FRONT WHEEL" on page 4-14 and "CHECKING THE FRONT BRAKE DISCS" on page 4-35.		
3	Front brake dragging		Check that the brake fluid pressure is correctly transmit- ted to the brake caliper when the brake lever is operated and that the pressure decreases when the lever is re- leased. Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-35.		
4	Defective hydraulic unit assembly		If the above items were performed and no malfunctions were found, replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.		

Fault code No. 42, 47

Fault o	code No.	42 47		
ltem		Rear wheel ABS (intermittent wheel speed pulses or incorrect depres- surization)		
Symptom		 Pulses from the rear wheel sensor are received intermittently while the vehicle is traveling. (for fault code No. 42) Rear wheel will not recover from the locking tendency even though the signal is transmitted from the ABS ECU to reduce the hydraulic pressure. 		
Order	Item/components and probable cause		Check or maintenance job	
1	Incorrect installation of the rear wheel sensor (for fault code No. 42)		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-24.	
2	Incorrect rotation of the rear wheel		Check that there is no brake disc drag on the wheel and make sure that it rotates smoothly. Refer to "CHECKING THE REAR WHEEL" on page 4-24.	
3	Rear brake dragging		Check that the brake fluid pressure is correctly transmit- ted to the brake caliper when the brake pedal is operat- ed and that the pressure decreases when the pedal is released. Refer to "CHECKING THE REAR BRAKE DISC" on page 4-49.	
4	Defective hydraulic unit assembly		If the above items were performed and no malfunctions were found, replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

Fault code No. 43

Fault o	code No.	43		
ltem		Front wheel sensor (missing pulses)		
		Front wheel sensor signal is not received properly. (Missing pulses are detected in the signal while the vehicle is traveling.)		
Order	r Item/components and probable cause		Check or maintenance job	
1	Foreign material adhered wheel sensor	d around the front	Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.	
2	Incorrect installation of the front wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-14.	
3	Defective sensor rotor of lation of the rotor	r incorrect instal-	Check the surface of the sensor rotor for damage. Re- place the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.	
4	Defective front wheel ser installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-15.	

Fault code No. 44								
Item F		44 Rear wheel sensor (missing pulses) Rear wheel sensor signal is not received properly. (Missing pulses are detected in the signal while the vehicle is traveling.)						
					Order	ltem/components and probable cause		Check or maintenance job
					1	Foreign material adhered around the rear wheel sensor		Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the rear wheel		Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-24.					
3	Defective sensor rotor or incorrect instal- lation of the rotor		Check the surface of the sensor rotor for damage. Re- place the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.					
4	Defective rear wheel ser installation of the sensor		Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-25.					

Fault code No. 51, 52

Fault code No.		51 52		
ltem		 Vehicle system power supply (voltage of ABS ECU power supply is high) (for fault code No. 51) Vehicle system power supply (voltage of wheel sensor power supply is high) (for fault code No. 52) 		
Symptom bly is • Powe		bly is too high	supplied to the ABS ECU in the hydraulic unit assem- . (for fault code No. 51) supplied to the wheel sensor is too high. (for fault	
Order	Item/components and probable cause		Check or maintenance job	
1	Defective battery		Recharge or replace the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158.	
2	Disconnected battery terminal		Check the connection. Replace or reconnect the termi- nal if necessary.	
3	Defective charging syste	m	Check the charging system. Refer to "CHARGING SYSTEM" on page 8-13.	

TIP ____

Turn the main switch to "OFF" before disconnecting or connecting a coupler.

Item		53 Vehicle system power supply (voltage of ABS ECU power supply is low)		
Order	ltem/components and probable cause		Check or maintenance job	
1	Defective battery		Recharge or replace the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158.	
2	Defective coupler between the battery and the hydraulic unit assembly		 Check the coupler for any pins that may be pulled out. Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely. See TIP. 	
3	Open or short circuit in the wire harness between the battery and the hydraulic unit assembly		 Replace if there is an open or short circuit. Between ABS ECU coupler and ABS control unit fuse. (brown/white–brown/white) 	
4	Defective charging system		Check the charging system. Refer to "CHARGING SYSTEM" on page 8-13.	

TIP ____

Turn the main switch to "OFF" before disconnecting or connecting a coupler.

Fault code No.		54	
		Hydraulic unit assembly (defective ABS solenoid and ABS motor power supply circuits)	
		Abnormality is detected in the solenoid or motor power supply circuit in the hydraulic unit assembly.	
Order	Item/components and p	robable cause	Check or maintenance job
1	Defective battery		Recharge or replace the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-158.
2	Defective coupler between the battery and the hydraulic unit assembly		 Check the coupler for any pins that may be pulled out. Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely. See TIP.
3	Open or short circuit in the wire harness between the battery and the hydraulic unit assembly		 Replace if there is an open or short circuit. Between ABS ECU coupler and ABS motor fuse. (red/blue–red/blue) Between ABS ECU coupler and ABS solenoid fuse. (red/white–red/white)
4	Defective charging system		Check the charging system. Refer to "CHARGING SYSTEM" on page 8-13.
5	Defective hydraulic unit assembly		If the above items were performed and no malfunctions were found, replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.

Fault code No. 55

Fault code No.		55		
Item		Hydraulic unit assembly (defective ABS ECU)		
Sympt	om	Abnormal data is detected in the hydraulic unit assembly.		
Order	Item/components and probable cause		Check or maintenance job	
1	Defective hydraulic unit assembly		Replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

Fault code No. 56

Fault code No.		56		
Item		Hydraulic unit assembly (abnormal internal power supply)		
Symptom		Abnormality is detected in the power supply circuit in the hydraulic unit assembly.		
Order	Item/components and probable cause		Check or maintenance job	
1	Defective hydraulic unit assembly		Replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

Fault code No. 63				
Fault code No.		63		
Symptom		Front wheel sensor power supply (voltage of power supply is low) Power voltage supplied from the ABS ECU to the front wheel sensor is too low.		
1	Short circuit in the wire harness between the front wheel sensor and the hydraulic unit assembly		 Check that there is no short circuit between the white terminal "1" and the black terminal "2". Check that there is no short circuit between the black terminal "3" and the white terminal "1". If there is a short circuit, the wire harness is defective. Replace the wire harness. 	
			(B) (B) 4 5	
			4. ABS ECU5. Front wheel sensor	
2	Defective front wheel set	nsor	 Check that there is no short circuit between the gray terminal "1" and the white terminal "2". If there is a short circuit, the wheel sensor is defective. Repair or replace the wheel sensor. 	
			(B) (B) (B) (B) (B) (B) (B) (B) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C	
			3. ABS ECU4. Front wheel sensor	
3	Defective hydraulic unit a	assembly	Replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	

Fault code No. 64				
Fault c	ode No.	64		
Item		Rear wheel sensor power supply (voltage of power supply is low)		
Symptom		Power voltage supplied from the ABS ECU to the rear wheel sensor is too low.		
Order	Item/components and p	orobable cause	Check or maintenance job	
1	the rear wheel sensor and the hydraulic unit assembly		 Check that there is no short circuit between the white terminal "1" and the black terminal "2". Check that there is no short circuit between the black terminal "3" and the white terminal "1". If there is a short circuit, the wire harness is defective. Replace the wire harness. 	
			(B) 4. ABS ECU 5. Rear wheel sensor	
2	Defective rear wheel ser	ISOr	 Check that there is no short circuit between the gray terminal "1" and the white terminal "2". If there is a short circuit, the wheel sensor is defective. Repair or replace the wheel sensor. 	
			(B) (B) (B) (B) (B) (B) (B) (B) (C) (C) (C) (C) (C) (C) (C) (C) (C) (C	
			3. ABS ECU4. Rear wheel sensor	
3	Defective hydraulic unit a	assembly	Replace the hydraulic unit assembly. Refer to "ABS (ANTI-LOCK BRAKE SYSTEM)" on page 4-56.	


[B-3] DELETING THE FAULT CODES

To delete the fault codes, use the Yamaha diagnostic tool. For information about deleting the fault codes, refer to the operation manual of the Yamaha diagnostic tool. Check that all the displayed fault codes are deleted.

Yamaha diagnostic tool 90890-03250

Connecting the Yamaha diagnostic tool

Remove the protective cap "1", and then connect the Yamaha diagnostic tool to the coupler.




EAS31140 [C-1] FINAL CHECK

Check all the following items to complete the inspection.


If the process is not completed properly, start again from the beginning.

Checking procedures

- 1. Check the brake fluid level in the brake master cylinder reservoir and brake fluid reservoir. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-15.
- 2. Check the wheel sensors for proper installation. Refer to "INSTALLING THE FRONT WHEEL (DISC BRAKE)" on page 4-17 and "INSTALLING THE REAR WHEEL (REAR BRAKE DISC)" on page 4-26.
- 3. Perform brake line routing confirmation. Refer to "HYDRAULIC UNIT OPERATION TESTS" on page 4-60. If it does not have reaction-force properly, the brake hose is not properly routed or connected.
- Delete the fault codes. Refer to "[B-3] DELETING THE FAULT CODES" on page 8-147.
- Checking the ABS warning light. Refer to "CHECKING THE ABS WARNING LIGHT" on page 4-64. If the ABS warning light does not turn off, the possible causes are following:
 - The problem is not solved.
 - Open circuit between the ABS ECU and the meter assembly. Check for continuity between green/red terminal of the ABS ECU coupler and green/red terminal of the meter assembly coupler.
 - Malfunction in the meter assembly circuit.
 - Malfunction in the ABS warning light circuit in the hydraulic unit assembly.




- 1. Main switch
- 2. Front brake light switch
- 3. Clutch switch
- 4. Rectifier/regulator
- 5. Ignition coil
- 6. Battery
- 7. Fuse box 1
- 8. Fuse box 2
- 9. Main fuse
- 10. Starter relay
- 11. Rear brake light switch
- 12. Sidestand switch
- 13.0₂ sensor
- 14. Gear position switch
- 15. Oil pressure switch
- 16. Horn
- 17. Radiator fan motor
- 18. ECU (Engine Control Unit)



- 1. Intake air temperature sensor
- 2. Hydraulic unit assembly
- 3. Intake air pressure sensor
- 4. Fuel pump
- 5. Lean angle sensor
- 6. Rear wheel sensor
- 7. Coolant temperature sensor
- 8. Crankshaft position sensor
- 9. Fuel injector
- 10. Throttle position sensor
- 11. Front wheel sensor
- 12. Radiator fan motor relay
- 13. Headlight relay
- 14. Relay unit
- 15. Turn signal/hazard relay

CHECKING THE SWITCHES



- 1. Start/engine stop switch
- 2. Hazard switch
- 3. Front brake light switch
- 4. Rear brake light switch
- 5. Sidestand switch
- 6. Main switch
- 7. Clutch switch
- 8. Horn switch
- 9. Turn signal switch
- 10. Pass switch
- 11. Dimmer switch

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

NOTICE


Never insert the tester probes into the coupler terminal slots "a". Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

TIP

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.




The switches and their terminal connections are illustrated as in the following example of the main switch.

The switch positions "a" are shown in the far left column and the switch lead colors "b" are shown in the top row.

The continuity (i. e., a closed circuit) between switch terminals at a given switch position is indicated by "O____O".

There is continuity between red/white, brown/blue and brown/red when the switch is set to "ON". There is continuity between red/white and brown/red when the switch is set to " $_{P \in}$ ".



CHECKING THE BULBS AND BULB SOCKETS

Check each bulb and bulb socket for damage or wear, proper connections, and also for continuity between the terminals.


 $\label{eq:def-Damage} \begin{array}{l} \mbox{Damage/wear} \rightarrow \mbox{Repair} \mbox{ or replace the bulb,} \\ \mbox{bulb socket or both.} \end{array}$

Improperly connected \rightarrow Properly connect. No continuity \rightarrow Repair or replace the bulb, bulb socket or both.

Types of bulbs

The bulbs used on this vehicle are shown in the illustration on the left.

- Bulbs "a" are used for the headlights and usually use a bulb holder that must be detached before removing the bulb. The majority of these types of bulbs can be removed from their respective socket by turning them counterclockwise.
- Bulbs "b" are used for turn signal lights and can be removed from the socket by pushing and turning the bulb counterclockwise.
- Bulbs "c" are used for license plate and auxiliary lights and can be removed from their respective sockets by carefully pulling them out.



Checking the condition of the bulbs

The following procedure applies to all of the bulbs.

- 1. Remove:
- Bulb

WARNING

Since the headlight bulb gets extremely hot, keep flammable products and your hands away from the bulb until it has cooled down.

NOTICE


- Be sure to hold the socket firmly when removing the bulb. Never pull the lead, otherwise it may be pulled out of the terminal in the coupler.
- Avoid touching the glass part of a headlight bulb to keep it free from oil, otherwise the transparency of the glass, the life of the bulb, and the luminous flux will be adversely affected. If the headlight bulb gets soiled, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.
- 2. Check:
 - Bulb (for continuity) (with the pocket tester) No continuity → Replace.

Pocket tester 90890-03112 Analog pocket tester YU-03112-C

TIP

Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.

- a. Connect the positive tester probe to terminal "1" and the negative tester probe to terminal "2", and check the continuity.
- b. Connect the positive tester probe to terminal "1" and the negative tester probe to terminal "3", and check the continuity.
- c. If either of the readings indicate no continuity, replace the bulb.



Checking the condition of the bulb sockets

The following procedure applies to all of the bulb sockets.

- 1. Check:
 - Bulb socket (for continuity) (with the pocket tester) No continuity → Replace.

Pocket tester 90890-03112 Analog pocket tester YU-03112-C

TIP __

Check each bulb socket for continuity in the same manner as described in the bulb section; however, note the following.

- a. Install a good bulb into the bulb socket.
- b. Connect the pocket tester probes to the respective leads of the bulb socket.
- c. Check the bulb socket for continuity. If any of the readings indicate no continuity, replace the bulb socket.

EAS30551

CHECKING THE FUSES

The following procedure applies to all of the fuses.

NOTICE

To avoid a short circuit, always set the main switch to "OFF" when checking or replacing a fuse.

- 1. Remove:
 - Seat
 - Seat bracket
 - Battery cover Refer to "GENERAL CHASSIS (1)" on page 4-1.
- 2. Check:
- Fuse
- a. Connect the pocket tester to the fuse and check the continuity.

TIP_

Set the pocket tester selector to " $\Omega \times 1$ ".

Pocket tester 90890-03112 Analog pocket tester YU-03112-C b. If the pocket tester indicates "∞", replace the fuse.

- 3. Replace:
- Blown fuse
- ****
- a. Set the main switch to "OFF".
- b. Install a new fuse of the correct amperage rating.
- c. Set on the switches to verify if the electrical circuit is operational.
- d. If the fuse immediately blows again, check the electrical circuit.

Fuses	Amperage rating	Q'ty
Main	30 A	1
ABS motor	30 A	1
ABS solenoid	20 A	1
Headlight	15 A	1
Signaling system	10 A	1
Ignition	10 A	1
Fuel injection system	10 A	1
Radiator fan motor	10 A	1
Parking lighting	7.5 A	1
ABS control unit	7.5 A	1
Backup	7.5 A	1
Auxiliary	2.0 A	1
Spare	30 A	1
Spare	20 A	1
Spare	15 A	1
Spare	10 A	1
Spare	7.5 A	1
Spare	2.0 A	1

Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the lighting and ignition systems to malfunction and could possibly cause a fire.

- 4. Install:
 - Battery cover
 - Seat bracket

Seat

Refer to "GENERAL CHASSIS (1)" on page 4-1.

REPLACING THE ECU (engine control unit)

- 1. Turn the main switch to "OFF".
- Replace the ECU (engine control unit). Refer to "REMOVING THE ECU (engine control unit)" on page 4-11.
- 3. Clean the ISC (idle speed control). Refer to "CLEANING THE ISC (IDLE SPEED CONTROL) VALVE" on page 7-10.
- 4. Check:
 Engine idling speed Start the engine, warm it up, and then measure the engine idling speed.

Engine idling speed 1250–1450 r/min

EAS30552 CHECKING AND CHARGING THE BATTERY EWA13290

A WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- DO NOT SMOKE when charging or handling batteries.
- KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- Skin Wash with water.
- Eyes Flush with water for 15 minutes and get immediate medical attention. INTERNAL
- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.

ECA13661

- This is a VRLA (Valve Regulated Lead Acid) battery. Never remove the sealing caps because the balance between cells will not be maintained and battery performance will deteriorate.
- Charging time, charging amperage and charging voltage for a VRLA (Valve Regulated Lead Acid) battery are different from those of conventional batteries. The VRLA (Valve Regulated Lead Acid) battery should be charged according to the appropriate charging method. If the battery is overcharged, the electrolyte level will drop considerably. Therefore, take special care when charging the battery.


TIP .

Since VRLA (Valve Regulated Lead Acid) batteries are sealed, it is not possible to check the charge state of the battery by measuring the specific gravity of the electrolyte. Therefore, the charge of the battery has to be checked by measuring the voltage at the battery terminals.

- 1. Remove:
 - Seat
 - Seat bracket
 - Battery cover Refer to "GENERAL CHASSIS (1)" on page 4-1.
- 2. Disconnect:
 - Battery leads
 (from the battery termina
 - (from the battery terminals)

NOTICE

First, disconnect the negative battery lead "1", and then positive battery lead "2".



- 3. Remove:
 - Battery


Refer to "GENERAL CHASSIS (1)" on page 4-1.


4. Check:

- Battery charge
- a. Connect a pocket tester to the battery terminals.
- Positive tester probe \rightarrow
- positive battery terminal
- Negative tester probe \rightarrow
- negative battery terminal


TIP

- The charge state of a VRLA (Valve Regulated Lead Acid) battery can be checked by measuring its open-circuit voltage (i.e., the voltage when the positive battery terminal is disconnected).
- No charging is necessary when the open-circuit voltage equals or exceeds 12.8 V.
- b. Check the charge of the battery, as shown in the charts and the following example.





- A. Open-circuit voltage (V)
- B. Charging time (hours)
- C. Relationship between the open-circuit voltage and the charging time at 20 °C (68 °F)
- D. These values vary with the temperature, the condition of the battery plates, and the electrolyte level.



- A. Open-circuit voltage (V)
- B. Charging condition of the battery (%)
- C. Ambient temperature 20 °C (68 °F)

- 5. Charge:
 - Battery (refer to the appropriate charging method)


WARNING

Do not quick charge a battery.

ECA13671 NOTICE

- Do not use a high-rate battery charger since it forces a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
- If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
- When charging a battery, be sure to remove it from the vehicle. (If charging has to be done with the battery mounted on the vehicle, disconnect the negative battery lead from the battery terminal.)
- To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.
- Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
- Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
- If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!

• As shown in the following illustration, the open-circuit voltage of a VRLA (Valve Regulated Lead Acid) battery stabilizes about 30 minutes after charging has been completed. Therefore, wait 30 minutes after charging is completed before measuring the open-circuit voltage.



- A. Open-circuit voltage (V)
- B. Time (minutes)
- C. Charging
- D. Ambient temperature 20 °C (68 °F)
- E. Check the open-circuit voltage.

Charging method using a variable-current (voltage) charger

a. Measure the open-circuit voltage prior to charging.

TIP

Voltage should be measured 30 minutes after the engine is stopped.

b. Connect a charger and ammeter to the battery and start charging.

TIP_

Set the charging voltage to 16–17 V. If the setting is lower, charging will be insufficient. If too high, the battery will be over-charged.

c. Make sure that the current is higher than the standard charging current written on the battery.

TIP_

If the current is lower than the standard charging current written on the battery, set the charging voltage adjust dial at 20–24 V and monitor the amperage for 3–5 minutes to check the battery.

- Standard charging current is reached
- Battery is good.
- Standard charging current is not reached Replace the battery.

- d. Adjust the voltage so that the current is at the standard charging level.
- e. Set the time according to the charging time suitable for the open-circuit voltage.
- f. If charging requires more than 5 hours, it is advisable to check the charging current after a lapse of 5 hours. If there is any change in the amperage, readjust the voltage to obtain the standard charging current.
- g. Measure the battery open-circuit voltage after leaving the battery unused for more than 30 minutes.

12.8 V or more --- Charging is complete. 12.7 V or less --- Recharging is required. Under 12.0 V --- Replace the battery.

Charging method using a constant voltage charger

a. Measure the open-circuit voltage prior to charging.

TIP .

Voltage should be measured 30 minutes after the engine is stopped.

- b. Connect a charger and ammeter to the battery and start charging.
- c. Make sure that the current is higher than the standard charging current written on the battery.

TIP .

If the current is lower than the standard charging current written on the battery, this type of battery charger cannot charge the VRLA (Valve Regulated Lead Acid) battery. A variable voltage charger is recommended.

d. Charge the battery until the battery's charging voltage is 15 V.

TIP

Set the charging time at 20 hours (maximum).

e. Measure the battery open-circuit voltage after leaving the battery unused for more than 30 minutes.

12.8 V or more --- Charging is complete. 12.7 V or less --- Recharging is required. Under 12.0 V --- Replace the battery.


6. Install:

- Battery Refer to "GENERAL CHASSIS (1)" on page 4-1.
- 7. Connect:
 - Battery leads

(to the battery terminals) ECA13630

NOTICE

First, connect the positive battery lead "1", and then the negative battery lead "2".



- 8. Check:
 - Battery terminals

Dirt \rightarrow Clean with a wire brush.

Loose connection \rightarrow Connect properly.

- 9. Lubricate:
- Battery terminals

Recommended lubricant Dielectric grease

10.Install:

- Battery cover
- Seat bracket
- Seat Refer to "GENERAL CHASSIS (1)" on page 4-1.

CHECKING THE RELAYS

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, replace the relay.




Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- 1. Disconnect the relay from the wire harness.
- Connect the pocket tester (Ω × 1) and battery (12 V) to the relay terminal as shown. Check the relay operation.
 Out of apacification → Deplece

Out of specification \rightarrow Replace.

Starter relay




- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe



Relay operation Continuity (between "3" and "4")

Relay unit (starting circuit cut-off relay)




- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe



Result Continuity (between "3" and "4")

Relay unit (fuel pump relay)




1. Positive battery terminal

- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe


0

Result Continuity (between "3" and "4")


Headlight relay




- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe



Radiator fan motor relay



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe



CHECKING THE TURN SIGNAL/HAZARD RELAY

- 1. Check:
 - Turn signal/hazard relay input voltage Out of specification → The wiring circuit from the main switch to the turn signal/hazard relay coupler is faulty and replace the wire harness.




a. Connect the pocket tester (DC 20 V) to the turn signal/hazard relay terminal as shown.




Pocket tester 90890-03112 Analog pocket tester YU-03112-C

Positive tester probe

- Blue/red "1"
- Negative tester probe Ground



- b. Turn the main switch to "ON".
- c. Measure the turn signal/hazard relay input voltage.
- 2. Check:
 - Turn signal/hazard relay output voltage Out of specification \rightarrow Replace.




a. Connect the pocket tester (DC 20 V) to the turn signal/hazard relay terminal as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe
- Brown/white "1" • Negative tester probe Ground



- b. Turn the main switch to "ON".
- c. Measure the turn signal/hazard relay output voltage.

EAS30795 CHECKING THE RELAY UNIT (DIODE)

- 1. Check:
 - Relay unit (diode) Out of specification \rightarrow Replace.


Pocket tester
 90890-03112
 Analog pocket tester
 YU-03112-C

TIP_

The pocket tester or the analog pocket tester readings are shown in the following table.



Continuity Positive tester probe Sky blue "1" Negative tester probe Black/yellow "2" No continuity Positive tester probe Black/yellow "2" Negative tester probe Sky blue "1" Continuity Positive tester probe Sky blue "1" Negative tester probe Blue/red "3" No continuity Positive tester probe Blue/red "3" Negative tester probe Sky blue "1" Continuity Positive tester probe Sky blue "1" Negative tester probe Sky blue/white "4" No continuity Positive tester probe Sky blue/white "4" Negative tester probe Sky blue "1" Continuity Positive tester probe Blue/green "5" Negative tester probe Black/red "3" No continuity Positive tester probe Black/red "3" Negative tester probe Blue/green "5"



- a. Disconnect the relay unit coupler from the wire harness.
- b. Connect the pocket tester ($\Omega \times 1$) to the relay unit terminal as shown.

- c. Check the relay unit (diode) for continuity.
- d. Check the relay unit (diode) for no continuity.

CHECKING THE IGNITION COILS

The following procedure applies to all of the ignition coils.

1. Check:

EAS30558

 Primary coil resistance Out of specification → Replace.




Primary coil resistance 1.19–1.61 Ω

- a. Disconnect the ignition coil coupler from the ignition coil.
- b. Connect the pocket tester ($\Omega \times 1$) to the ignition coil as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe
- Ignition coil terminal "1"
- Negative tester probe
- Ignition coil terminal "2"



c. Measure the primary coil resistance.

- 2. Check:
- Secondary coil resistance Out of specification → Replace.




Secondary coil resistance 8.50–11.50 k Ω

a. Connect the pocket tester ($\Omega \times 1$ k) to the ignition coil as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Negative tester probe Ignition coil terminal "1"
- Positive tester probe
- Spark plug terminal "2"



b. Measure the secondary coil resistance.

CHECKING THE IGNITION SPARK GAP

- 1. Check:
- Ignition spark gap

Out of specification \rightarrow Perform the ignition system troubleshooting, starting with step 5. Refer to "TROUBLESHOOTING" on page 8-4.



Minimum ignition spark gap 6.0 mm (0.24 in)


TIP .

If the ignition spark gap is within specification, the ignition system circuit is operating normally.

a. Remove the ignition coil from the spark plug.b. Connect the ignition checker "1" as shown.



Ignition checker 90890-06754 Oppama pet–4000 spark checker YM-34487



- 2. Ignition coil
- c. Turn the main switch to "ON".
- d. Measure the ignition spark gap "a".
- e. Crank the engine by pushing the "(s)" side of the start/engine stop switch and gradually increase the spark gap until a misfire occurs.

CHECKING THE CRANKSHAFT POSITION SENSOR

- 1. Disconnect:
- Crankshaft position sensor coupler (from the wire harness)
- 2. Check:
 - Crankshaft position sensor resistance Out of specification → Replace the crankshaft position sensor.




Crankshaft position sensor resistance 228–342 Ω

- a. Connect the pocket tester ($\Omega \times 100$) to the
- crankshaft position sensor coupler as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe
- Gray "1"
- Negative tester probe
- Black "2"



b. Measure the crankshaft position sensor resistance.


CHECKING THE LEAN ANGLE SENSOR 1. Remove:

- Lean angle sensor (from the battery box.)
- 2. Check:
- Lean angle sensor output voltage Out of specification \rightarrow Replace.




Lean angle sensor output voltage Less than 65°: 0.4–1.4 V More than 65°: 3.7–4.4 V

- a. Connect the test harness– lean angle sensor (6P) "1" to the lean angle sensor and wire harness as shown.
- b. Connect the pocket tester (DC 20 V) to the test harness– lean angle sensor (6P).



- Positive tester probe
- Yellow/green (wire harness color)
- Negative tester probe
- Black/blue (wire harness color)



- c. Set the main switch to "ON".
- d. Turn the lean angle sensor to 65°.
- e. Measure the lean angle sensor output voltage.

CHECKING THE STARTER MOTOR


- 1. Check:
 - Starter motor operation Does not operate → Perform the electric starting system troubleshooting, starting with step 4.

Refer to "TROUBLESHOOTING" on page 8-10.

- *****
- a. Connect the positive battery terminal "1" and starter motor lead "2" with a jumper lead "3".

WARNING

- A wire that is used as a jumper lead must have at least the same capacity of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore, make sure no flammable gas or fluid is in the vicinity.



b. Check the starter motor operation.

EAS30566 CHECKING THE STATOR COIL

- 1. Disconnect:
 - Stator coil coupler (from the wire harness)
- 2. Check:
 - Stator coil resistance Out of specification \rightarrow Replace the stator coil.




Stator coil resistance 0.128–0.192 Ω (W-W)

- ***
- a. Connect the digital circuit tester to the stator coil coupler as shown.



Digital circuit tester 90890-03174 Model 88 Multimeter with tachometer YU-A1927


- Positive tester probe
- White "1"
- Negative tester probe White "2"
- Positive tester probe
 - White "1"
- Negative tester probe White "3"
- Positive tester probe
- White "2"
- Negative tester probe
- White "3"




b. Measure the stator coil resistance.

CHECKING THE RECTIFIER/REGULATOR

- 1. Check:
 - Charging voltage Out of specification → Replace the rectifier/regulator.




a. Connect the pocket tester ($\Omega \times 10/ \times 100$) to the fuel sender terminals as shown.



- CHECKING THE RADIATOR FAN MOTOR
- 1. Check:
- Radiator fan motor Faulty/rough movement \rightarrow Replace.

- a. Disconnect the radiator fan motor coupler from the wire harness.
- b. Connect the battery (DC 12 V) as shown.
- Positive tester probe
- Blue "1"
- Negative tester probe Black "2"



c. Measure the radiator fan motor movement.

EAS30578

CHECKING THE COOLANT TEMPERATURE SENSOR

- 1. Remove:
- Coolant temperature sensor Refer to "CYLINDER HEAD" on page 5-23.


- Handle the coolant temperature sensor with special care.
- Never subject the coolant temperature sensor to strong shocks. If the coolant temperature sensor is dropped, replace it.
- 2. Check:
 - Coolant temperature sensor resistance Out of specification → Replace.



Coolant temperature sensor resistance

2510–2780 Ω at 20 °C (2510–2780 Ω at 68 °F)

a. Connect the pocket tester ($\Omega \times 1$ k) to the coolant temperature sensor as shown.




b. Immerse the coolant temperature sensor "1" in a container filled with coolant "2".

TIP .

Make sure the coolant temperature sensor terminals do not get wet.

c. Place a thermometer "3" in the coolant.



- d. Heat the coolant or let it cool down to the specified temperatures.
- e. Measure the coolant temperature sensor resistance.

- 3. Install:
 - Coolant temperature sensor



EAS3058 **CHECKING THE THROTTLE POSITION** SENSOR

- 1. Remove:
- Throttle position sensor (from the throttle body)

WARNING

- Handle the throttle position sensor with special care.
- Never subject the throttle position sensor to strong shocks. If the throttle position sensor is dropped, replace it.
- 2. Check:
 - Throttle position sensor maximum resistance Out of specification \rightarrow Replace the throttle position sensor.




Resistance **2.64–6.16 k**Ω

a. Connect the pocket tester ($\Omega \times 1k$) to the throttle position sensor as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe
- Sensor terminal "1"
- Negative tester probe
- Sensor terminal "2"



b. Check the throttle position sensor maximum resistance.

- 3. Install:
 - Throttle position sensor

TIP_

When installing the throttle position sensor, adjust its angle properly. Refer to "ADJUSTING THE THROTTLE POSITION SENSOR" on page 7-13.

EAS30593

CHECKING THE INTAKE AIR PRESSURE SENSOR

- 1. Check:
 - Intake air pressure sensor output voltage Out of specification \rightarrow Replace.

Intake air pressure sensor output 0 voltage 4.200 V at 119.990 kPa


a. Connect the test harness S-pressure sensor (3P) "1" to the intake air pressure sensor and wire harness as shown.

NOTICE

EC420920

Pay attention to the installing direction of the test harness S- pressure sensor (3P) coupler.

- b. Connect the digital circuit tester (DCV) to the test harness S- pressure sensor (3P) "a".
 - **Digital circuit tester** 90890-03174 Model 88 Multimeter with tachometer YU-A1927 Test harness S– pressure sensor (3P) 90890-03207 Test harness S– pressure sensor (3P) YÚ-03207
- Positive tester probe
- Pink/white (wire harness color)
- Negative tester probe
- Black/blue (wire harness color)



- c. Set the main switch to "ON".
- d. Measure the intake air pressure sensor output voltage.

CHECKING THE INTAKE AIR TEMPERATURE SENSOR

- 1. Remove:
- Intake air temperature sensor

WARNING

- Handle the intake air temperature sensor with special care.
- Never subject the intake air temperature sensor to strong shocks. If the intake air temperature sensor is dropped, replace it.
- 2. Check:
 - Intake air temperature sensor resistance Out of specification → Replace.



Intake air temperature sensor resistance 290–390 Ω at 80 °C (290–390 Ω

at 176 °F)

a. Connect the pocket tester (× 100) to the intake air temperature sensor terminal as shown.




Pocket tester 90890-03112 Analog pocket tester YU-03112-C

b. Immerse the intake air temperature sensor "1" in a container filled with water "2".

TIP_

Make sure that the intake air temperature sensor terminals do not get wet.

c. Place a thermometer "3" in the water.



d. Slowly heat the water, then let it cool down to the specified temperature.

e. Measure the intake air temperature sensor resistance.

- 3. Install:
 - Intake air temperature sensor




Intake air temperature sensor bolt 3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)


EAS31008 CHECKING THE GEAR POSITION SWITCH

- 1. Remove:
 - Drive sprocket cover Refer to "CHAIN DRIVE" on page 4-93.
 - Gear position switch Refer to "CRANKCASE" on page 5-64.
- 2. Check:
 - Gear position switch Out of specification → Replace the gear position switch.

A

Pocket tester 90890-03112 Analog pocket tester YU-03112-C





TROUBLESHOOTING

TROUBLESHOOTING	
GENERAL INFORMATION	9-1
STARTING FAILURE	9-1
INCORRECT ENGINE IDLING SPEED	9-1
POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE	9-2
FAULTY GEAR SHIFTING	9-2
SHIFT PEDAL DOES NOT MOVE	9-2
JUMPS OUT OF GEAR	9-2
FAULTY CLUTCH	9-2
OVERHEATING	
OVERCOOLING	9-3
POOR BRAKING PERFORMANCE	9-3
FAULTY FRONT FORK LEGS	9-3
UNSTABLE HANDLING	
FAULTY LIGHTING OR SIGNALING SYSTEM	9-4
TROUBLESHOOTING AT THE ABS WARNING LIGHT	9-4
SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE	9-5
SELF-DIAGNOSTIC FUNCTION TABLE	
(FOR FUEL INJECTION SYSTEM)	
SELF-DIAGNOSTIC FUNCTION TABLE	
(FOR IMMOBILIZER SYSTEM)	9-11
DIAGNOSTIC CODE: SENSOR OPERATION TABLE	
DIAGNOSTIC CODE: ACTUATOR OPERATION TABLE	9-14
	0.40
EVENT CODE TABLE	

TROUBLESHOOTING

EAS30599

GENERAL INFORMATION

TIP .

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

EAS30600 STARTING FAILURE

Engine

- 1. Cylinder(s) and cylinder head
- Loose spark plug
- Loose cylinder head or cylinder
- Damaged cylinder head gasket
- Damaged cylinder gasket
- Worn or damaged cylinder
- Incorrect valve clearance
- Improperly sealed valve
- Incorrect valve-to-valve-seat contact
- Incorrect valve timing
- · Faulty valve spring
- Seized valve
- 2. Piston(s) and piston ring(s)
 - Improperly installed piston ring
 - Damaged, worn or fatigued piston ring
 - Seized piston ring
 - Seized or damaged piston
- 3. Air filter
 - Improperly installed air filter
- Clogged air filter element
- 4. Crankcase and crankshaft
 - Improperly assembled crankcase
 - Seized crankshaft

Fuel system

- 1. Fuel tank
- Empty fuel tank
- Clogged fuel tank cap breather hose
- Deteriorated or contaminated fuel
- Clogged or damaged fuel hose
- 2. Fuel pump
 - Faulty fuel pump
 - Faulty relay unit (fuel pump relay)
- 3. Throttle body (-ies)
 - Deteriorated or contaminated fuel
 - Sucked-in air

Electrical system

- 1. Battery
- Discharged battery
- Faulty battery
- 2. Fuse(s)
 - Blown, damaged or incorrect fuse
 - Improperly installed fuse
- 3. Spark plug(s)
 - Incorrect spark plug gap
 - Incorrect spark plug heat range
 - Fouled spark plug
 - Worn or damaged electrode
 - Worn or damaged insulator
- 4. Ignition coil(s)
 - Cracked or broken ignition coil body
 - Broken or shorted primary or secondary coils
- 5. Ignition system
- Faulty ECU
- Faulty crankshaft position sensor
- Broken generator rotor straight key
- 6. Switches and wiring
- Faulty main switch
- Faulty start/engine stop switch
- Broken or shorted wiring
- Faulty gear position switch (neutral circuit)
- Faulty sidestand switch
- Faulty clutch switch
- Improperly grounded circuit
- Loose connections
- 7. Starting system
 - Faulty starter motor
- Faulty starter relay
- Faulty relay unit (starting circuit cut-off relay)
- Faulty starter clutch
- INCORRECT ENGINE IDLING SPEED

Engine

- 1. Cylinder(s) and cylinder head
 - Incorrect valve clearance
- Damaged valve train components
- 2. Air filter
 - Clogged air filter element

Fuel system

- 1. Throttle body (-ies)
 - Damaged or loose throttle body joint
 - Improperly synchronized throttle bodies
 - Improper throttle grip free play
 - Flooded throttle body
 - Vacuum hose

Electrical system

- 1. Battery
- Discharged battery
- Faulty battery
- 2. Spark plug(s)
- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- 3. Ignition coil(s)
 - Broken or shorted primary or secondary coils
 - Cracked or broken ignition coil
- 4. Ignition system
 - Faulty ECU
 - Faulty crankshaft position sensor
 - Broken generator rotor straight key

POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE

Refer to "STARTING FAILURE" on page 9-1.

Engine

- 1. Air filter
 - Clogged air filter element

Fuel system

- 1. Throttle body (-ies)
- Faulty throttle body
- 2. Fuel pump
- Faulty fuel pump

FAULTY GEAR SHIFTING

Shifting is difficult

Refer to "Clutch drags".

EAS30604

SHIFT PEDAL DOES NOT MOVE

Shift shaft

- Improperly adjusted shift rod
- Bent shift shaft

Shift drum and shift forks

- Foreign object in a shift drum groove
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Foreign object between transmission gears
- Improperly assembled transmission

LAS30605 JUMPS OUT OF GEAR

Shift shaft

- Incorrect shift pedal position
- Improperly returned stopper lever

Shift forks

Worn shift fork

Shift drum

- Incorrect axial play
- Worn shift drum groove

Transmission

• Worn gear dog

FAULTY CLUTCH

Clutch slips

- 1. Clutch
 - Improperly assembled clutch
 - Improperly adjusted clutch cable
 - Loose or fatigued clutch spring
 - Worn friction plate
 - Worn clutch plate
- 2. Engine oil
 - Incorrect oil level
 - Incorrect oil viscosity (low)
 - Deteriorated oil

Clutch drags

- 1. Clutch
 - Unevenly tensioned clutch springs
 - Warped pressure plate
 - Bent clutch plate
 - Swollen friction plate
 - Bent clutch pull rod
- Broken clutch boss
- Burnt primary driven gear bushing
- Match marks not aligned
- 2. Engine oil
- Incorrect oil level
- Incorrect oil viscosity (high)
- Deteriorated oil

EAS30607 OVERHEATING

Enaine

- 1. Clogged coolant passages
- Cylinder head and piston(s)
- Heavy carbon buildup

TROUBLESHOOTING

- 2. Engine oil
 - Incorrect oil level
 - Incorrect oil viscosity
 - Inferior oil quality

Cooling system

- 1. Coolant
- Low coolant level
- 2. Radiator
 - Damaged or leaking radiator
 - Faulty radiator cap
 - Bent or damaged radiator fin
- 3. Water pump
- Damaged or faulty water pump
- 4. Thermostat
 - Thermostat stays closed
- 5. Oil cooler
- Clogged or damaged oil cooler
- 6. Hose(s) and pipe(s)
 - Damaged hose
 - Improperly connected hose
 - Damaged pipe
 - Improperly connected pipe

Fuel system

- 1. Throttle body (-ies)
- Damaged or loose throttle body joint
- 2. Air filter
- Clogged air filter element

Chassis

- 1. Brake(s)
- Dragging brake

Electrical system

- 1. Spark plug(s)
- Incorrect spark plug gap
- Incorrect spark plug heat range
- 2. Ignition system
- Faulty ECU

OVERCOOLING

Cooling system

- 1. Thermostat
- Thermostat stays open

EAS30609

POOR BRAKING PERFORMANCE

- Worn brake pad
- Worn brake disc
- Air in hydraulic brake system
- Leaking brake fluid
- Faulty brake caliper kit

- Faulty brake caliper seal
- Loose union bolt
- Damaged brake hose
- Oil or grease on the brake disc
- Oil or grease on the brake pad
- Incorrect brake fluid level

FAULTY FRONT FORK LEGS

Leaking oil

- Bent, damaged or rusty inner tube
- Cracked or damaged outer tube
- · Improperly installed oil seal
- Damaged oil seal lip
- Incorrect oil level (high)
- · Loose damper rod assembly bolt
- Damaged damper rod assembly bolt copper washer
- Cracked or damaged cap bolt O-ring

Malfunction

- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Worn or damaged outer tube bushing
- Bent or damaged damper rod
- Incorrect oil viscosity
- Incorrect oil level

EAS30611

UNSTABLE HANDLING

Handlebar

• Bent or improperly installed handlebar

Steering head components

- Improperly installed upper bracket
- Improperly installed lower bracket (improperly tightened cap nut)
- Bent steering stem
- Damaged ball bearing or bearing race

Front fork leg(s)

- Uneven oil levels (both front fork legs)
- Unevenly tensioned fork spring (both front fork legs)
- Broken fork spring
- Bent or damaged inner tube
- Bent or damaged outer tube

Swingarm

- Worn bearing or bushing
- Bent or damaged swingarm

TROUBLESHOOTING

Rear shock absorber assembly

- Faulty rear shock absorber spring
- Leaking oil or gas

Tire(s)

- Uneven tire pressures (front and rear)
- Incorrect tire pressure
- Uneven tire wear

Wheel(s)

- Incorrect wheel balance
- Deformed cast wheel
- Damaged wheel bearing
- Bent or loose wheel axle
- Excessive wheel runout

Frame

- Bent frame
- Damaged steering head pipe
- Improperly installed bearing race

FAULTY LIGHTING OR SIGNALING SYSTEM

Headlight does not come on

- Wrong headlight bulb
- Too many electrical accessories
- Hard charging
- Incorrect connection
- Improperly grounded circuit
- Poor contacts (main switch)
- Burnt-out headlight bulb

Headlight bulb burnt out

- Wrong headlight bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded circuit
- · Faulty main switch
- Headlight bulb life expired

Tail/brake light does not come on

- Faulty brake light switch
- Too many electrical accessories
- Incorrect connection
- Faulty tail/brake light assembly

Turn signal does not come on

- Faulty turn signal switch
- Faulty turn signal/hazard relay
- Burnt-out turn signal bulb
- Incorrect connection
- Damaged or faulty wire harness
- Improperly grounded circuit

- Faulty battery
- Blown, damaged or incorrect fuse

Turn signal blinks slowly

- Faulty turn signal/hazard relay
- · Faulty main switch
- Faulty turn signal switch
- Incorrect turn signal bulb

Turn signal remains lit

- Faulty turn signal/hazard relay
- Burnt-out turn signal bulb

Turn signal blinks quickly

- Incorrect turn signal bulb
- Faulty turn signal/hazard relay
- Burnt-out turn signal bulb

Horn does not sound

- Damaged or faulty horn
- · Faulty main switch
- Faulty horn switch
- Faulty battery
- Blown, damaged or incorrect fuse
- Faulty wire harness

EAS30848

TROUBLESHOOTING AT THE ABS WARNING LIGHT

Refer to "BASIC PROCESS FOR TROUBLE-SHOOTING" on page 8-121.

SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE

SELF-DIAGNOSTIC FUNCTION TABLE (FOR FUEL INJECTION SYSTEM)

TIP_

For details of the fault code, refer to "TROUBLESHOOTING METHOD" on page 8-35.

Fault code No.	Item	Probable cause of malfunction	Vehicle symptom	Fail-safe system op- eration
P0030	O ₂ sensor heater (de- fective heater control- ler detected)	 Open or short circuit in wire harness. Disconnected coupler. Defective O₂ sensor heater controller. Broken or disconnected lead in O₂ sensor heater. 	(When the O ₂ sensor does not operate be- cause the exhaust temperature is low) Increased exhaust emissions. Fuel learning cannot be carried out.	Display only (If the O_2 sensor does not oper- ate, O_2 feedback is not carried out.)
P0107 P0108	[P0107] Intake air pressure sensor (ground short circuit detected) [P0108] Intake air pressure sensor (open or power short circuit detected)	 [P0107] Low voltage of the intake air pres- sure sensor circuit (0.2 V or less) [P0108] High voltage of the intake air pres- sure sensor circuit (4.8 V or more) Defective coupler between intake air pressure sensor and ECU. Open or short cir- cuit in wire harness between intake air pressure sensor and ECU. Defective intake air pressure sensor and ECU. Defective intake air pressure sensor. Malfunction in ECU. 	Engine idling speed is high. Engine idling speed is unstable. Engine response is poor. Loss of engine power. Increased exhaust emissions.	Intake air pressure difference is fixed to 0 [kPa]. α –N is fixed. Fuel is not cut off due to the intake air pres- sure difference. Intake air pressure is fixed to 101.3 [kPa]. O ₂ feedback is not carried out. ISC feedback is not carried out. ISC learning is not carried out.

Fault code No.	Item	Probable cause of malfunction	Vehicle symptom	Fail-safe system op- eration
P0112 P0113	[P0112] Intake air temperature sensor (ground short circuit detected) [P0113] Intake air temperature sensor (open or power short circuit detected)	 [P0112] Low voltage of the intake air tem- perature sensor circuit (0.2 V or less) [P0113] High voltage of the intake air tem- perature sensor circuit (4.8 V or more) Defective coupler between intake air temperature sensor and ECU. Open or short cir- cuit in wire harness between intake air temperature sensor and ECU. Improperly installed intake air tempera- ture sensor. Defective intake air temperature sensor. Malfunction in ECU. 	Engine is difficult to start. Increased exhaust emissions. Engine idling speed is unstable.	The intake air tem- perature is fixed to 20 [°C]. O ₂ feedback is not carried out. ISC feedback is not carried out. ISC learning is not carried out.
P0117 P0118	[P0117] Coolant tem- perature sensor (ground short circuit detected) [P0118] Coolant tem- perature sensor (open or power short circuit detected)	 [P0117] Low voltage of the coolant tem- perature sensor circuit (0.2 V or less) [P0118] High voltage of the coolant tem- perature sensor circuit (4.8 V or more) Defective coupler between coolant temperature sensor and ECU. Open or short cir- cuit in wire harness between coolant temperature sensor and ECU. Improperly installed coolant temperature sensor. Defective coolant temperature sensor. Malfunction in ECU. 	Engine is difficult to start. Increased exhaust emissions. Engine idling speed is unstable.	The radiator fan motor relay is on only when the vehicle is traveling at low speeds. O ₂ feedback is not carried out. ISC feedback is not carried out. ISC learning is not carried out. The coolant tempera- ture is fixed to 60 [°C].

Fault code No.	ltem	Probable cause of malfunction	Vehicle symptom	Fail-safe system op- eration
P0122 P0123	[P0122] Throttle posi- tion sensor (open or ground short circuit detected) [P0123] Throttle posi- tion sensor (power short circuit detected)	 [P0122] Low voltage of the throttle position sensor circuit (0.2 V or less) [P0123] High voltage of the throttle position sensor circuit (4.8 V or more) Defective coupler between throttle po- sition sensor and ECU. Open or short cir- cuit in wire harness between throttle po- sition sensor and ECU. Improperly installed throttle position sen- sor. Defective throttle po- sition sensor. Malfunction in ECU. 	Engine idling speed is high. Engine idling speed is unstable. Engine response is poor. Loss of engine power. Deceleration is poor. Increased exhaust emissions. Vehicle cannot be driven.	Change in the throttle opening is 0 (transient control is not carried out). D-j is fixed. Throttle opening is fixed to 125 [°]. Estimated atmospher- ic pressure is fixed to 101.3 [kPa]. O ₂ feedback is not carried out. Fuel is not cut off due to the throttle open- ing. Output is restricted. ISC feedback is not carried out. ISC learning is not carried out.
P0132	O ₂ sensor (short cir- cuit detected (power short circuit))	 [P0132] High voltage of the O₂ sensor cir- cuit (4.8 V or more) Improperly installed O₂ sensor. Defective coupler between O₂ sensor and ECU. Open or short cir- cuit in wire harness between O₂ sensor and ECU. Incorrect fuel pres- sure. Defective O₂ sensor. Malfunction in ECU. 	Increased exhaust emissions.	O ₂ feedback is not carried out. O ₂ feedback learning is not carried out.
P0201 P0202	[P0201] Fuel injector #1 (malfunction in fuel injector #1) [P0202] Fuel injector #2 (malfunction in fuel injector #2)	 Defective coupler between injector and ECU. Open or short cir- cuit in wire harness between injector and ECU. Defective injector. Malfunction in ECU. Improperly installed injector. 	Loss of engine power. Engine is difficult to start. Engine cannot be started. Engine stops. Engine idling speed is unstable. Increased exhaust emissions.	O ₂ feedback is not carried out. ISC feedback is not carried out. ISC learning is not carried out. Injection to the appli- cable cylinder group is cut off.

Fault code No.	ltem	Probable cause of malfunction	Vehicle symptom	Fail-safe system op- eration
P0335	Crankshaft position sensor (no normal signals are received from the crankshaft position sensor)	 Defective coupler between crankshaft position sensor and ECU. Open or short cir- cuit in wire harness between crankshaft position sensor and ECU. Improperly installed crankshaft position sensor. Malfunction in gen- erator rotor. Defective crank- shaft position sen- sor. Malfunction in ECU. 	Engine cannot be started.	Does not operate. ISC feedback is not carried out. ISC learning is not carried out.
P0351 P0352	[P0351] Cylinder-#1 ignition coil (open or short circuit detected in the primary lead of the cylinder-#1 igni- tion coil.) [P0352] Cylinder-#2 ignition coil (open or short circuit detected in the primary lead of the cylinder-#2 igni- tion coil.)	 Defective coupler between ignition coil and ECU. Open or short cir- cuit in wire harness between ignition coil and ECU. Improperly installed ignition coil. Defective ignition coil. Malfunction in ECU. 	Engine stops. Loss of engine power. Engine is difficult to start. Engine cannot be started. Engine idling speed is unstable. Increased exhaust emissions.	Injection to the appli- cable cylinder group is cut off. O_2 feedback is not carried out. ISC feedback is not carried out. ISC learning is not carried out.
P0500	 Rear wheel sensor (no normal signals are received from the rear wheel sen- sor) Gear position switch (open or short circuit is detected) Clutch switch (open or short circuit is de- tected) 	 Open or short circuit in wire harness between rear wheel sensor and ECU. Open or short circuit in wire harness between ABS unit and ECU. Open or short circuit in wire harness between gear position switch and ECU. Open or short circuit in wire harness between gear position switch and ECU. Open or short circuit in wire harness between clutch switch and ECU. Open or short circuit in wire harness between clutch switch and ECU. Defective rear wheel sensor. Defective gear position switch. Defective clutch switch. Improper adjustment of clutch lever. Malfunction in ECU. 	Vehicle speed is not displayed on the me- ter. Engine stalls when the vehicle is deceler- ating to a stop. Engine idling speed is high. Indication of the neu- tral indicator light is in- correct. Engine cannot be re- started when the transmission is in gear even with the clutch lever squeezed. Engine idling speed is unstable. Increased exhaust emissions.	Vehicle speed dis- played on the meter = 0 [km/h] The gear ratio is fixed to the gear ratio of the top gear. O ₂ feedback is not carried out. Fuel cut-off control when the rear wheel sensor or gear posi- tion switch malfunc- tions is carried out. ISC feedback is not carried out. ISC learning is not carried out.

Fault code No.	ltem	Probable cause of malfunction	Vehicle symptom	Fail-safe system op- eration
P0507	 Component other than ISC (idle speed control) unit is de- fective (ISC operat- ing sound is heard). Defective ISC (idle speed control) unit (ISC operating sound is not heard). 	 Defective speed sensor. Defective coupler between ISC unit and ECU. Open or short cir- cuit in wire harness between ISC unit and ECU. Improperly installed ISC unit. Disconnected ISC unit hose or air leak from intake air pas- sage. Defective throttle valve or throttle ca- ble. Defective ISC unit (ISC valve stuck ful- ly open). Malfunction in ECU. 	Engine idling speed is high.	ISC learning is not carried out.
P0511	ISC unit (malfunction in ISC unit)	 Defective coupler between ISC unit and ECU. Open or short cir- cuit in wire harness between ISC unit and ECU. Defective ISC step- ping motor. Malfunction in ECU. 	Engine is difficult to start. Engine idling speed is unstable. Engine idling speed is high.	Power is not supplied to the ISC unit. ISC learning is not carried out.
P0560	Charging voltage is abnormal.	 Battery overcharg- ing (defective rectifi- er/regulator). Battery overcharg- ing (broken or dis- connected lead in rectifier/regulator wire harness). Battery over-dis- charging (broken or disconnected lead in charging system). Battery over-dis- charging (defective rectifier/regulator). 	Engine is difficult to start. Increased exhaust emissions. Battery performance has deteriorated or battery is defective.	O ₂ feedback is not carried out.

Fault code No.	ltem	Probable cause of malfunction	Vehicle symptom	Fail-safe system op- eration
P0601	Faulty ECU memory. (When this malfunc- tion is detected in the ECU, the fault code number might not ap- pear on the tool dis- play.)	Malfunction in ECU.	Engine cannot be started. Engine response is poor. Loss of engine power.	Engine cannot be started. Ignition and injection are not carried out. Judgment for other fault codes is not car- ried out. Writing to EEPROM is not carried out. Load control is not carried out. (The relay unit, headlight relay, and other relays are all turned off.) The CO adjustment mode and diagnostic mode cannot be acti- vated. Output is restricted.
P062F	EEPROM fault code number (an error is detected while read- ing or writing on EE- PROM)	 CO adjustment value is not properly written. ISC learning value is not properly written. OBD memory value is not properly written. Malfunction in ECU. 	Increased exhaust emissions. Engine cannot be started or is difficult to start. Engine idling speed is unstable. OBD memory value is not correct.	CO adjustment value for the faulty cylinder = 0 (default value) ISC learning values = Default values OBD memory value is initialized.
P0657	Fuel system voltage (incorrect voltage sup- plied to the fuel injec- tor and fuel pump)	 Open or short circuit in wire harness between relay unit and ECU. Open circuit in wire harness between battery and ECU. Defective relay unit. Malfunction in ECU. 	Engine is difficult to start. Increased exhaust emissions.	Monitor voltage = 12 [V] O_2 feedback is not carried out.
P1601	Sidestand switch (open or short circuit of the black/red lead of the ECU is detect- ed)	 Defective coupler between relay unit and ECU. Open or short cir- cuit in wire harness between relay unit and ECU. Defective coupler between sidestand switch and ECU. Open or short cir- cuit in wire harness between sidestand switch and ECU. Defective sidestand switch. Malfunction in ECU. 	Engine cannot be started.	Engine is forcefully stopped (the injector output is stopped).

Fault code No.	ltem	Probable cause of malfunction	Vehicle symptom	Fail-safe system op- eration
P1602	Malfunction in ECU internal circuit (mal- function of ECU pow- er cut-off function)	 Open or short circuit in wire harness between ECU and battery. Open or short circuit in wire harness between ECU and main switch. Blown backup fuse. Malfunction in ECU. 	Engine idling speed is unstable. Engine idling speed is high. Increased exhaust emissions. Engine is difficult to start.	O_2 feedback learning is not carried out. O_2 feedback learning value is not written.
P1604 P1605	[P1604] Lean angle sensor (ground short circuit detected) [P1605] Lean angle sensor (open or pow- er short circuit detect- ed)	 [P1604] Low voltage of the lean angle sen- sor circuit (0.2 V or less) [P1605] High voltage of the lean angle sen- sor circuit (4.8 V or more) Open or short cir- cuit in wire harness between lean angle sensor and ECU. Defective lean an- gle sensor. Malfunction in ECU. 	Engine cannot be started.	Engine cannot be started.
P2195	O ₂ sensor (open cir- cuit detected)	 Signal voltage is 0.25–0.53 V. Improperly installed O₂ sensor. Defective coupler between O₂ sensor and ECU. Open or short cir- cuit in wire harness between O₂ sensor and ECU. Defective O₂ sensor. Malfunction in ECU. 	Increased exhaust emissions.	O_2 feedback is not carried out. O_2 feedback learning is not carried out.

EAS31795 SELF-DIAGNOSTIC FUNCTION TABLE (FOR IMMOBILIZER SYSTEM)

TIP __

For details of the fault code, refer to "SELF-DIAGNOSIS FAULT CODE INDICATION" on page 8-112.

Fault code No.	Item		
51	Immobilizer unit: Code cannot be transmitted between the key and the immobilizer unit.		
52	Immobilizer unit: Codes between the key and immobilizer unit do not match.		
53	Immobilizer unit: Codes cannot be transmitted between the ECU and the immobilizer unit.		
54	Immobilizer unit: Codes transmitted between the ECU and the immobilizer unit do not match.		
55	Immobilizer unit: Key code registration malfunction.		
56	ECU: Unidentified code is received.		

EAS31120 DIAGNOSTIC CODE: SENSOR OPERATION TABLE

Diagnostic code No.	Item	Tool display	Procedure
01	Throttle position sensor sig- nal		
	Fully closed position	11–21	Check with throttle valves fully closed.
	Fully open position	96–106	Check with throttle valves fully open.
03	Intake air pressure	Displays the intake air pres- sure.	Operate the throttle while pushing the "()" side of the start/engine stop switch. (If the display value changes, the performance is OK.)
05	Intake air temperature	Displays the air temperature.	Compare the actually mea- sured air temperature with the tool display value.
06	Coolant temperature	When engine is cold: Dis- plays temperature closer to air temperature. When engine is hot: Displays current coolant temperature.	Compare the actually mea- sured coolant temperature with the tool display value.
07	Rear wheel vehicle speed pulses	Rear wheel speed pulse 0–999	Check that the number in- creases when the rear wheel is rotated. The number is cu- mulative and does not reset each time the wheel is stopped.
08	Lean angle sensor	Lean angle sensor output voltage	Remove the lean angle sen- sor and incline it more than 65 degrees.
	Upright	0.4–1.4	
	Overturned	3.7–4.4	
09	Fuel system voltage (battery voltage)	Approximately 12.0	Set the start/engine stop switch to "∩", and then com- pare the actually measured battery voltage with the tool display value. (If the actually measured battery voltage is low, recharge the battery.)
20	Sidestand switch		Extend and retract the side- stand (with the transmission in gear).
	 Stand retracted 	ON	
	 Stand extended 	OFF	

Diagnostic code No.	Item	Tool display	Procedure
21	Gear position switch and clutch switch		Operate the transmission, clutch lever, and sidestand.
	• Transmission is in gear or the clutch lever released	OFF	
	• Clutch lever is squeezed with the transmission in gear and when the side- stand is retracted	ON	
	• Clutch lever is squeezed with the transmission in gear and when the side- stand is extended	OFF	
60	EEPROM fault code display		
	• No history	 00 No malfunctions detected (If the self-diagnosis fault code P062F is indicated, the ECU is defective.) 	
	 History exists Display the EEPROM writ- ing error for fault code No. P062F. If more than one item is de- fective, the displays alter- nates every two seconds to show all the detected num- bers. 	 01–02 (CO adjustment value) (If more than one cylinder is defective, the display alternates every two seconds to show all the detected cylinder numbers. When all cylinder numbers are shown, the display repeats the same process.) 	
		 11 (Data error for ISC (idle speed control) learning values) 12 (O₂ feedback learning value) 13 (OBD memory value) 	
67	ISC (idle speed control) learning condition display ISC (idle speed control) learning data erasure	00 ISC (idle speed control) learning data has been erased. 01 It is not necessary to erase the ISC (idle speed control) learning data. 02 It is necessary to erase the ISC (idle speed control) learning data.	To erase the ISC (idle speed control) learning data, set the start/engine stop switch from "⊗" to "∩" 3 times in 5 seconds.
70	Control number	0–254 [-]	—
87	O ₂ feedback learning data erasure	00 O_2 feedback learning data has been erased. 01 O_2 feedback learning data has not been erased.	To erase the O_2 feedback learning data, set the engine stop switch from " \boxtimes " to " \bigcirc " 3 times in 5 seconds.

Diagnostic code No.	Item	Actuation	Procedure
30	Cylinder-#1 ignition coil	Actuates cylinder-#1 ignition coil five times at one-second intervals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the ignition coil is actuated.	Check that a spark is generated five times.Connect an ignition checker.
31	Cylinder-#2 ignition coil	Actuates cylinder-#2 ignition coil five times at one-second intervals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the ignition coil is actuated.	Check that a spark is generated five times.Connect an ignition checker.
36	Fuel injector #1	Actuates fuel injector #1 five times at one-second inter- vals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the fuel injector is actuated.	Disconnect the fuel pump coupler. Check that fuel injector #1 is actuated five times by listen- ing for the operating sound.
37	Fuel injector #2	Actuates fuel injector #2 five times at one-second inter- vals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the fuel injector is actuated.	Disconnect the fuel pump coupler. Check that fuel injector #2 is actuated five times by listen- ing for the operating sound.
50	Relay unit	Actuates the relay unit five times at one-second inter- vals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the relay is actuated.	Check that the relay unit is actuated five times by listen- ing for the operating sound.
51	Radiator fan motor relay	Actuates the radiator fan mo- tor relay five times at five- second intervals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the relay is actuated.	Check that the radiator fan motor relay is actuated five times by listening for the op- erating sound.
52	Headlight relay	Actuates the headlight relay five times at five-second in- tervals. The "check" indicator on the Yamaha diagnostic tool screen come on each time the relay is actuated.	Check that the headlight re- lay is actuated five times by listening for the operating sound.

EAS31121 DIAGNOSTIC CODE: ACTUATOR OPERATION TABLE

Diagnostic code No.	Item	Actuation	Procedure
54	ISC valve	Fully closes the ISC valve, and then opens the valve. This operation is performed 3 times and takes approxi- mately 6 seconds each time. The "check" indicator on the Yamaha diagnostic tool screen come on during the operation.	Check that the ISC unit is ac- tuated three times by listen- ing for the operating sound.

EVENT CODE TABLE

No.	Item	Symptom	Possible cause	Remarks
U0155	CAN communication error (with the meter)	Communication be- tween the ECU and the meter is not possi- ble	 Defective meter coupler and ECU coupler Open or short circuit in the wire harness between the sensor and the ECU Defective meter Defective ECU 	Perform the checks and maintenance jobs for event code number U0155 (meter display: Err).
30	Latch up detected	Latch up detected	 Vehicle has over- turned Improperly installed sensor Sensor malfunction Defective ECU 	Perform the checks and maintenance jobs for event code number 30.
70	Engine idling stop	Engine has been left idling (This is not a malfunction.)	This is not a malfunc- tion.	Activation of the en- gine idling stop control is not a system mal- function.
192	Intake air pressure sensor	Brief abnormality de- tected in intake air pressure sensor	Same as for fault code number P0107 and P0108	Perform the checks and maintenance jobs for fault code number P0107 and P0108.
193	Throttle position sen- sor	Brief abnormality de- tected in throttle posi- tion sensor	Same as for fault code number P0122 and P0123	Perform the checks and maintenance jobs for fault code number P0122 and P0123.
195	Sidestand switch	Brief abnormality de- tected in black/red in- put lead of ECU	Same as for fault code number P1601	Perform the checks and maintenance jobs for fault code number P1601.
196	Coolant temperature sensor	Brief abnormality de- tected in coolant tem- perature sensor	Same as for fault code number P0117 and P0118	Perform the checks and maintenance jobs for fault code number P0117 and P0118.
197	Intake air temperature sensor	Brief abnormality de- tected in intake air temperature sensor	Same as for fault code number P0112 and P0113	Perform the checks and maintenance jobs for fault code number P0112 and P0113.
203	Lean angle sensor	Brief abnormality de- tected in lean angle sensor	Same as for fault code number P1604 and P1605	Perform the checks and maintenance jobs for fault code number P1604 and P1605.
204	Fuel system voltage (monitor voltage)	Brief abnormality de- tected in voltage sup- plied to fuel injector and fuel pump	Same as for fault code number P0657	Perform the checks and maintenance jobs for fault code number P0657.
205	Vehicle system power supply	Brief abnormality de- tected in charging volt- age	Same as for fault code number P0560	Perform the checks and maintenance jobs for fault code number P0560.

EVENT CODE TABLE

No.	Item	Symptom	Possible cause	Remarks
240	O ₂ sensor (Correction value re- mains at upper limit)	Correction value re- mains at upper limit during O ₂ feedback	 Open or short circuit in the wire harness between the sensor and the ECU gray/green- gray/green pink/black-pink/black black/blue-black/blue Low fuel pressure Clogged fuel injector Sensor malfunction Defective ECU Defective fuel injec- tion system 	 If a fault code is indicated, perform the checks and maintenance jobs for the fault code first. * Event code number 240 may be indicated even if the system is normal.
241	O ₂ sensor (Correction value re- mains at lower limit)	Correction value re- mains at lower limit during O ₂ feedback	 Open or short circuit in the wire harness between the sensor and the ECU gray/green– gray/green pink/black–pink/black black/blue–black/blue Low fuel pressure Clogged fuel injector Sensor malfunction Defective ECU Defective fuel injec- tion system 	 If a fault code is indicated, perform the checks and maintenance jobs for the fault code first. * Event code number 241 may be indicated even if the system is normal.
242	ISC (idle speed con- trol) (Correction value re- mains at upper limit)	Correction value re- mains at upper limit while the engine is idling	Low engine idling speed • Clogged throttle body • Improperly adjusted throttle cable • Improperly adjusted clutch cable • Defective fuel injec- tion system • Dirty or worn spark plug • Defective battery • Defective ECU	 Execute the diagnostic code number 67) and check the ISC maintenance requirements. If a fault code is indicated, perform the checks and maintenance jobs for the fault code first. * Event code number 242 may be indicated even if the system is normal.
243	ISC (idle speed con- trol) (Correction value re- mains at lower limit)	Correction value re- mains at lower limit while the engine is idling	 High engine idling speed Improperly adjusted throttle cable Improperly adjusted clutch cable Defective fuel injec- tion system Dirty or worn spark plug Defective battery Defective ECU 	 If a fault code is indicated, perform the checks and maintenance jobs for the fault code first. * Event code number 243 may be indicated even if the system is normal.

EVENT CODE TABLE

No.	Item	Symptom	Possible cause	Remarks
244	Difficult/unable to start engine	Engine starting diffi- cult/unable condition detected	 Empty fuel tank Defective fuel injection system Dirty or worn spark plug Defective battery Defective ECU 	 If a fault code is indicated, perform the checks and maintenance jobs for the fault code first. * Event code number 244 may be indicated even if the system is normal.
245	Engine stall	Engine stall detected	 Empty fuel tank Improperly adjusted throttle cable Improperly adjusted clutch cable Defective fuel injec- tion system Dirty or worn spark plug Defective battery Defective ECU 	 If a fault code is indicated, perform the checks and maintenance jobs for the fault code first. * Event code number 245 may be indicated even if the system is normal.

EAS2009 WIRING DIAGRAM

MTM690/MTM690-U 2016

- 1. Main switch
- 2. ABS solenoid fuse 3. ABS motor fuse
- 4. Parking lighting fuse
- 5. ABS control unit fuse
- 6. Auxiliary fuse
- 7. Ignition fuse
- 8. Signaling system fuse
- 9. Headlight fuse
- 10. Fuel injection system fuse
- 11. Backup fuse
- 12. Radiator fan motor fuse
- 13. AC magneto
- 14. Rectifier/regulator
- 15. Battery
- 16. Engine ground
- 17. Immobilizer unit
- 18. Main fuse
- 19. Starter relay
- 20. Starter motor
- 21. Rear brake light switch
- 22. Relay unit
- 23. Starting circuit cut-off relay
- 24. Fuel pump relay
- 25. Joint coupler
- 26. Sidestand switch
- 27. Crankshaft position sensor
- 28. O₂ sensor
- 29. Throttle position sensor
- 30. Ignition coil #1
- 31. Ignition coil #2
- 32. Spark plug
- 33. Fuel injector #1
- 34. Fuel injector #2
- 35. ISC (Idle Speed Control) unit
- 36. ECU (Engine Control Unit)
- 37. Intake air temperature sensor
- 38. Coolant temperature sensor
- 39. Intake air pressure sensor
- 40. Lean angle sensor
- 41. Front wheel sensor
- 42. Rear wheel sensor
- 43. ABS ECU (electronic control unit)
- 44. Yamaha diagnostic tool coupler
- 45. Fuel sender
- 46. Fuel pump
- 47. Oil pressure switch
- 48. Meter assembly
- 49. Immobilizer system indicator light
- 50. Neutral indicator light
- 51. Meter light
- 52. Tachometer
- 53. Multi-function meter
- 54. Oil pressure warning light
- 55. Engine trouble warning light

56. Coolant temperature warning light 57. High beam indicator light 58. Turn signal indicator light 59. ABS warning light 60. Horn 61. Gear position switch 62. Handlebar switch (right) 63. Front brake light switch 64. Hazard switch 65. Start/engine stop switch 66. Turn signal/hazard relay 67. Handlebar switch (left) 68. Clutch switch 69. Dimmer switch 70. Pass switch 71. Turn signal switch 72. Horn switch 73. Rear turn signal light (right) 74. Rear turn signal light (left) 75. Front turn signal light (right) 76. Headlight assembly 77. Auxiliary light 78. Headlight 79. Front turn signal light (left) 80. License plate light 81. Tail/brake light 82. Radiator fan motor 83. Radiator fan motor relay 84. Headlight relay 85. Auxiliary DC outlet A. Wire harness B. Positive battery sub-wire harness C. Sub-wire harness (gear position switch, coolant temperature sensor, fuel injector)

- D. Sub-wire harness (throttle position sensor, ISC)
- E. Sub-wire harness (headlight, turn signal light, auxiliary light)


COLOR CODE		
В	Black	
Br	Brown	
Ch	Chocolate	
Dg	Dark green	
G	Green	
Gy	Gray	
L	Blue	
Lg	Light green	
O P	Orange Pink	
R	Red	
Sb	Sky blue	
Ŵ	White	
Y	Yellow	
B/G	Black/Green	
B/L	Black/Blue	
B/R	Black/Red	
B/W	Black/White	
B/Y	Black/Yellow	
Br/L Br/R	Brown/Blue Brown/Red	
Br/W	Brown/White	
G/B	Green/Black	
G/L	Green/Blue	
G/R	Green/Red	
G/W	Green/White	
G/Y	Green/Yellow	
Gy/G	Gray/Green	
Gy/R	Gray/Red	
L/B L/G	Blue/Black Blue/Green	
L/R	Blue/Red	
L/W	Blue/White	
L/Y	Blue/Yellow	
P/B	Pink/Black	
P/L	Pink/Blue	
P/W	Pink/White	
R/B	Red/Black	
R/G	Red/Green	
R/L R/W	Red/Blue Red/White	
R/Y	Red/Yellow	
Sb/W	Sky blue/White	
W/G	White/Green	
W/L	White/Blue	
W/R	White/Red	
W/Y	White/Yellow	
Y/B	Yellow/Black	
Y/G	Yellow/Green	
Y/L Y/W	Yellow/Blue Yellow/White	
1/ 1/		


EAS30613


MBK Industrie
 Z.I. de Rouvroy 02100 Saint Quentin
 Société Anonyme au capital de 45 000 000 €
 R.C St-Quentin B 329 035 422











WIRING DIAGRAM

MTM690-U 2016

MTM690-U 2016

