WOODCRAFT Technologies, Inc.

Installation Instructions
2011+ Kawasaki ZX10R RH Ignition Cover



1) Remove the OEM cover from the motor and unbolt the ignition pickup assembly.

2) Attach the skid plate to the Woodcraft cover by bolting it from the inside. Each bolt should have an o-ring (supplied) on it before assembly. It is a good idea to use a very small amount of grease on the o-ring.

IMPORTANT - USE **THREADLOCKING COMPOUND** ON THE THREE SKID PLATE MOUNTING BOLTS

3) Attach the pickup and wire retainer using the OEM hardware to the Woodcraft cover.

IMPORTANT - USE **THREADLOCKING COMPOUND** ON ALL OF THE PICKUP / RETAINER MOUNTING BOLTS AND USE A **QUALITY SILICONE SEALANT** ON BOTH SIDES OF THE RUBBER WIRE PLUG (MANDATORY)

4) Completely clean the engine gasket surface

5) Install the Woodcraft cover with a new gasket using the OEM mounting hardware

6) Start the motorcycle and inspect for any leaks before riding.

WARNING

Installation of Woodcraft Billet Covers involve removal and reinstallation of certain factory components such as fasteners, alternator stators and oil-retention gaskets. FAILURE TO INSTALL THESE COMPONENTS IN COMPLIANCE WITH ALL SPECIFIC INSTRUCTIONS SUPPLIED WITH BILLET COVER KIT, MAY CAUSE OIL LOSS OR DAMAGE TO ENGINE RESULTING IN LOSS OF CONTROL OF MOTORCYCLE AND SERIOUS INJURY OR DEATH.