WOODCRAFT Technologies, Inc.

Installation Instructions
60-0656RB Clutch Cover

1) Remove the OEM cover from the motor. If the motorcycle is leaned to the left to cause the oil to flow to the opposite side of the engine, this can be done without draining the oil.

2) Attach the skid plate to the Woodcraft cover by bolting it from the inside.

IMPORTANT - USE **BLUE THREADLOCKING COMPOUND** ON THE THREE SKID PLATE MOUNTING BOLTS. Coat the threads completely and allow the threadlocking compound to fully set before use.



3) Transfer the OEM O-Ring from the stock cover to the Woodcraft cover.

4) Completely clean the engine gasket surface

5) Install the Woodcraft cover using the OEM mounting hardware. Torque according to service manual specifications (standard torque for 6mm hardware is 8-10 ft lbs).

6) Run the motorcycle and check thoroughly for leaks before operation.

WARNING

Installation of Woodcraft Billet Covers involves removal and reinstallation of certain factory components such as fasteners, alternator stators and oil-retention gaskets. FAILURE TO INSTALL THESE COMPONENTS IN COMPLIANCE WITH ALL SPECIFIC INSTRUCTIONS SUPPLIED WITH BILLET COVER KIT MAY CAUSE OIL LOSS OR DAMAGE TO ENGINE RESULTING IN LOSS OF CONTROL OF MOTORCYCLE AND SERIOUS INJURY OR DEATH.