

PARTS CATALOGUE


MODEL YEAR 2004

YZF-R1


YZF-R1S (5VY4) 49

YZF-R1SC (5VY5) CA


1. Engine Serial No.



2. Vehicle Identification No.



3. Model Label Affixing Location



STARTING VEHICLE ID. NO. (5VY4): JYARN13E34A000009 and following
 STARTING VEHICLE ID. NO. (5VY5): JYARN13Y34A000005 and following

Color Name	Abbreviation
SHIFT RED (DEEP RED METALLIC K)	DRMK
TEAM YAMAHA BLUE/WHITE (DEEP PURPLISH BLUE METALLIC C)	DPBMC
CERULEAN SILVER/LIQUID SILVER	BS4/S3

OWNERS LIT-11626-17-55
 ASSEMBLY LIT-11666-17-55
 SERVICE LIT-11616-17-55

CONTENTS


AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CYLINDER HEAD

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-11101-00-00	CYLINDER HEAD ASSY	1	
2	5VY-11133-10-00	..GUIDE, VALVE 1	12	
3	5VY-11134-10-00	..GUIDE, VALVE 2	8	
4	93440-07149-00	..CIRCLIP	12	
5	93440-10153-00	..CIRCLIP	8	
6	90340-18150-00	..PLUG, STRAIGHT SCREW ..	3	
7	91808-16023-00	..PIN, DOWEL	6	
8	90105-06026-00	..BOLT, FLANGE	28	
9	95024-06012-00	. BOLT, FLANGE	1	
10	90430-06014-00	. GASKET	1	
11	95617-08625-00	BOLT, STUD	8	
12	90201-10013-00	WASHER, PLATE	8	
13	90179-10006-00	NUT	8	
14	90201-10013-00	WASHER, PLATE	2	
15	90176-10075-00	NUT, CROWN	2	
16	90201-06016-00	WASHER, PLATE	2	
17	91314-06105-00	BOLT	2	
18	94701-00403-00	PLUG, SPARK (NGK CR9EK) .	4	
19	5VY-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
20	5VY-11191-00-00	COVER, CYLINDER HEAD 1 ..	1	
21	5BE-12241-00-00	..GUIDE, STOPPER 2	1	
22	5VY-11193-00-00	GASKET, HEAD COVER 1	1	
23	5VY-1482K-00-00	PLATE	4	
24	5SL-14890-00-00	REED VALVE ASSY	2	
25	5VY-14899-00-00	CAP, CASE	2	
26	90110-06118-00	BOLT, HEXAGON SOCKET HEAD	4	
27	90109-066F0-00	BOLT	6	
28	4KG-1111G-00-00	RUBBER, MOUNT 1	6	
29	99530-10114-00	PIN, DOWEL	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C010

CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-11311-00-00	CYLINDER 1	1	
2	5VY-11351-00-00	GASKET, CYLINDER	1	
3	99530-10114-00	PIN, DOWEL	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C020

CRANKSHAFT PISTON

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-11411-01-00	CRANKSHAFT	1	
2	5VY-11650-01-00	CONNECTING ROD ASSY	4	
3	5VY-11654-01-00	. .BOLT, CONNECTING ROD ..	2	
4	5VY-11656-00-00	PLANE BEARING, CONNECTING ROD	8	UR BLUE
	5VY-11656-30-00	PLANE BEARING, CONNECTING ROD	8	UR GREEN
	5VY-11656-20-00	PLANE BEARING, CONNECTING ROD	8	UR BROWN
	5VY-11656-10-00	PLANE BEARING, CONNECTING ROD	8	UR BLACK
5	5VY-11549-00-00	SPROCKET, CAM CHAIN	1	
6	5VY-11416-A0-00	PLANE BEARING, CRANKSHAFT 1	10	UR WHITE
	5VY-11416-10-00	PLANE BEARING, CRANKSHAFT 1	10	UR BLACK
	5VY-11416-20-00	PLANE BEARING, CRANKSHAFT 1	10	UR BROWN
	5VY-11416-30-00	PLANE BEARING, CRANKSHAFT 1	10	UR GREEN
	5VY-11416-00-00	PLANE BEARING, CRANKSHAFT 1	10	UR BLUE
7	5VY-11631-01-00	PISTON (STD)	4	
8	5VY-11603-00-00	PISTON RING SET (STD)	4	
9	90468-12069-00	CLIP	8	
10	5VY-11633-00-00	PIN, PISTON	4	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




 5VY1300-C030

VALVE

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-12111-00-00	VALVE, INTAKE	4	
2	5VY-12112-00-00	VALVE, INTAKE 2	8	
3	5VY-12121-00-00	VALVE, EXHAUST	8	
4	5NL-12116-00-00	SEAT, VALVE SPRING	12	
5	3GM-12126-00-00	SEAT, VALVE SPRING 2	8	
6	5VY-12113-00-00	SPRING, VALVE INNER	12	
7	5VY-12114-00-00	SPRING, VALVE OUTER	8	
8	5VY-12117-00-00	RETAINER, VALVE SPRING ..	12	
9	5VY-12127-00-00	RETAINER, VALVE SPRING ..	8	
10	1HX-12118-00-00	COTTER, VALVE	24	
11	1WG-12118-00-00	COTTER, VALVE	16	
12	4TV-12119-00-00	SEAL, VALVE STEM	12	
13	4SV-12119-00-00	SEAL, VALVE STEM	8	
14	1HX-12168-00-00	PAD, ADJUSTING 2 (1.20)	20	UR
	1HX-12168-20-00	PAD, ADJUSTING 2 (1.25)	20	UR
	1HX-12168-40-00	PAD, ADJUSTING 2 (1.30)	20	UR
	1HX-12168-60-00	PAD, ADJUSTING 2 (1.35)	20	UR
	1HX-12168-80-00	PAD, ADJUSTING 2 (1.40)	20	UR
	1HX-12168-A0-00	PAD, ADJUSTING 2 (1.45)	20	UR
	1HX-12168-F0-00	PAD, ADJUSTING 2 (1.50)	20	UR
	1HX-12168-H1-00	PAD, ADJUSTING 2 (1.55)	20	UR
	1HX-12168-K1-00	PAD, ADJUSTING 2 (1.60)	20	UR
	1HX-12168-M1-00	PAD, ADJUSTING 2 (1.65)	20	UR
	1HX-12168-R1-00	PAD, ADJUSTING 2 (1.70)	20	UR
	1HX-12168-U1-00	PAD, ADJUSTING 2 (1.75)	20	UR
	1HX-12168-W1-00	PAD, ADJUSTING 2 (1.80)	20	UR
	1HX-12168-Y1-00	PAD, ADJUSTING 2 (1.85)	20	UR
	1HX-12169-11-00	PAD, ADJUSTING 2 (1.90)	20	UR
	1HX-12169-31-00	PAD, ADJUSTING 2 (1.95)	20	UR
	1HX-12169-50-00	PAD, ADJUSTING 2 (2.00)	20	UR

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C040

CONTINUED ON NEXT FRAME ►

VALVE

Ref. No.	Part Number	Description	Qty	Remarks
14	1HX-12169-70-00	PAD, ADJUSTING 2 (2.05)	20	UR
	1HX-12169-90-00	PAD, ADJUSTING 2 (2.10)	20	UR
	1HX-12169-E0-00	PAD, ADJUSTING 2 (2.15)	20	UR
	1HX-12169-G0-00	PAD, ADJUSTING 2 (2.20)	20	UR
	1HX-12169-J0-00	PAD, ADJUSTING 2 (2.25)	20	UR
	1HX-12169-L0-00	PAD, ADJUSTING 2 (2.30)	20	UR
	1HX-12169-N0-00	PAD, ADJUSTING 2 (2.35)	20	UR
	1HX-12169-T0-00	PAD, ADJUSTING 2 (2.40)	20	UR
15	3LN-12153-20-00	LIFTER, VALVE	12	UR BLUE
	3LN-12153-30-00	LIFTER, VALVE	12	UR RED
	3LN-12153-09-00	LIFTER, VALVE (O/S)	12	UR GREEN
16	3FV-12153-09-00	LIFTER, VALVE (O/S)	8	UR GREEN
	3FV-12153-20-00	LIFTER, VALVE	8	UR BLUE
	3FV-12153-30-00	LIFTER, VALVE	8	UR RED



CONTENTS


AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C040

CAMSHAFT CHAIN

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-12170-00-00	CAMSHAFT ASSY 1	1	
2	5VY-12180-00-00	CAMSHAFT ASSY 2	1	
3	5VY-12176-00-00	SPROCKET, CAM CHAIN	2	
4	90105-07003-00	BOLT, FLANGE	4	
5	94591-60122-00	CHAIN	1	
6	5VY-12210-00-00	TENSIONER ASSY, CAM CHAIN	1	
7	93210-26741-00	. O-RING	1	
8	91314-06020-00	BOLT	2	
9	5VY-12251-00-00	DAMPER, CHAIN 1	1	
10	5VY-12252-00-00	DAMPER, CHAIN 2	1	
11	93607-44190-00	PIN, DOWEL	2	




CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C050

WATER PUMP



5VY1300-C060


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-12469-00-00	JOINT 1	1	
2	5VY-12576-00-00	HOSE 1	1	
3	90450-38040-00	HOSE CLAMP ASSY	1	
4	93210-47675-00	O-RING	1	
5	95024-06025-00	BOLT, FLANGE	3	
6	5VY-12637-00-00	STAY 1	1	
7	5VY-12421-00-00	HOUSING, WATER PUMP	1	
8	93306-00106-00	BEARING	2	
9	93102-12372-00	OIL SEAL	1	
10	11H-12438-10-00	SEAL, MECHANICAL	1	
11	5VY-12450-00-00	IMPELLER SHAFT ASSY	1	
12	4XV-12439-00-00	O-RING	1	
13	93603-12007-00	PIN, DOWEL	2	
14	5VY-12422-00-00	COVER, HOUSING	1	
15	90105-066A5-00	BOLT, FLANGE	5	
16	93603-17070-00	PIN, DOWEL	1	
17	5VY-13310-00-00	ROTOR ASSY 1	1	
18	93603-12007-00	PIN, DOWEL	2	
19	5VY-13336-00-00	HOUSING, ROTOR	1	
20	91317-06040-00	BOLT	3	
21	5VY-13355-00-00	SPROCKET, DRIVEN	1	
22	90105-06154-00	BOLT, FLANGE	1	
23	5VY-12456-00-00	WASHER	1	
24	91808-30031-00	PIN, DOWEL	1	
25	90110-06026-00	BOLT, HEXAGON SOCKET HEAD	2	
26	93210-357A2-00	O-RING	1	
27	4XV-12485-00-00	PIPE 5	1	
28	93210-06667-00	O-RING	2	
29	5VY-12481-00-00	PIPE 1	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

WATER PUMP




Ref. No.	Part Number	Description	Qty	Remarks
30	93210-235A1-00	O-RING	1	
31	93210-27370-00	O-RING	1	
32	5VY-12588-00-00	HOSE 5	1	
33	90467-200A0-00	CLIP	1	
34	90450-32001-00	HOSE CLAMP ASSY	1	
35	90110-06041-00	BOLT, HEXAGON SOCKET HEAD	1	
36	5VY-12484-00-00	PIPE 4	1	
37	90430-06014-00	GASKET	1	
38	90153-06029-00	SCREW, HEXAGON	1	
39	93210-235A1-00	O-RING	1	
40	90480-12010-00	GROMMET	1	
41	90387-06087-00	COLLAR	1	
42	90110-06041-00	BOLT, HEXAGON SOCKET HEAD	1	
43	90110-06019-00	BOLT, HEXAGON SOCKET HEAD	1	
44	90201-06055-00	WASHER, PLATE	1	
45	90450-32001-00	HOSE CLAMP ASSY	1	
46	90467-200A0-00	CLIP	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

RADIATOR HOSE



5VY1300-C070


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-12410-00-00	THERMOSTAT ASSY	1	
2	5LP-12411-00-00	.THERMOSTAT	1	
3	93210-49046-00	.O-RING	1	
4	90176-06065-00	.NUT, CROWN	2	
5	5VY-12485-00-00	PIPE 5	1	
6	5VY-12579-00-00	HOSE 4	1	
7	90450-35001-00	HOSE CLAMP ASSY	1	
8	90450-38040-00	HOSE CLAMP ASSY	1	
9	5VY-12577-00-00	HOSE 2	1	
10	90450-38040-00	HOSE CLAMP ASSY	1	
11	5GV-1246A-00-00	COVER 1	1	
12	5VY-12552-00-00	HOSE 8	1	
13	90467-11044-00	CLIP	1	
14	5VY-1243F-00-00	HOSE, 3	1	
15	90467-11090-00	CLIP	2	
16	90110-06004-00	BOLT, HEXAGON SOCKET HEAD	1	
17	93210-235A1-00	O-RING	1	
18	5VY-1243A-00-00	HOSE 1	1	
19	5VY-1244G-00-00	HOSE, 4	1	
20	90467-11090-00	CLIP	3	
21	90413-07023-00	WAY 3	1	
22	5VY-1243E-00-00	HOSE 2	1	
23	90467-11090-00	CLIP	2	
24	90467-200A0-00	CLIP	1	
25	5VY-12483-00-00	PIPE 3	1	
26	90445-11418-00	HOSE (L18)	1	
27	5VY-12578-00-00	HOSE 3	1	
28	90450-35001-00	HOSE CLAMP ASSY	1	
29	5VY-12461-00-00	RADIATOR ASSY	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

RADIATOR HOSE



5VY1300-C070

Ref. No.	Part Number	Description	Qty	Remarks
30	5VY-12405-00-00	BLOWER ASSY	1	
31	5VY-12405-10-00	BLOWER ASSY	1	
32	5GJ-12675-00-00	BOLT, BLOWER HOLDING ...	6	
33	90480-15363-00	GROMMET	3	
34	90387-0614M-00	COLLAR	2	
35	5VY-12551-00-00	HOSE 7	1	
36	90450-35001-00	HOSE CLAMP ASSY	1	
37	90464-13249-00	CLAMP	1	
38	5SL-12462-00-00	CAP, RADIATOR	1	
39	90387-0614M-00	COLLAR	1	
40	91317-06030-00	BOLT	1	
41	90201-06071-00	WASHER, PLATE	1	
42	90201-06074-00	WASHER, PLATE	1	
43	95827-06030-00	BOLT, FLANGE	2	
44	95607-06200-00	NUT, SELF U-FLANGE	1	
45	90467-12191-00	CLIP	1	
46	90467-11090-00	CLIP	1	
47	90450-35001-00	HOSE CLAMP ASSY	2	
48	5GV-1246E-00-00	COVER 2	1	
49	5VY-12589-01-00	HOSE 6	1	
50	90450-22017-00	HOSE CLAMP ASSY	1	

CONTENTS


AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	94580-25078-00	CHAIN (DID25 78LE)	1	
2	5VY-13410-00-00	STRAINER HOUSING ASSY ...	1	
3	93210-22298-00	O-RING	1	
4	90480-13010-00	GROMMET	1	
5	5VY-13117-00-00	COLLAR, DISTANCE	1	
6	90110-06060-00	BOLT, HEXAGON SOCKET HEAD	3	
7	5VY-13416-00-00	PIPE, OIL 1	1	
8	93210-14003-00	O-RING	2	
9	90110-06041-00	BOLT, HEXAGON SOCKET HEAD	2	
10	5VY-1316E-00-00	PIPE, DELIVERY 5	1	
11	93210-09165-00	O-RING	2	
12	93210-06667-00	O-RING	1	
13	5VY-13898-00-00	HOLDER	1	
14	90110-06018-00	BOLT, HEXAGON SOCKET HEAD	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




 5VY1300-C080

OIL CLEANER

Ref. No.	Part Number	Description	Qty	Remarks
1	90401-20145-00	BOLT, UNION	1	
2	5GH-13440-00-00	ELEMENT ASSY, OIL CLEANER	1	
3	5VY-13490-00-00	RELIEF VALVE ASSY	1	
4	93210-15566-00	O-RING	1	
5	5VY-13417-00-00	COVER, STRAINER	1	
6	90340-14132-00	. PLUG, STRAIGHT SCREW ...	1	
7	214-11198-01-00	. GASKET	1	
8	99530-08012-00	PIN, DOWEL	2	
9	5VY-13414-01-00	GASKET, STRAINER COVER ..	1	
10	91317-06025-00	BOLT	14	
11	90110-06020-00	BOLT, HEXAGON SOCKET HEAD	1	
12	5VY-13161-00-00	PIPE, DELIVERY 1	1	
13	90110-06018-00	BOLT, HEXAGON SOCKET HEAD	1	
14	5VY-13470-00-00	OIL COOLER ASSY	1	
15	5EB-12822-00-00	..BOLT, UNION	1	
16	5EB-13475-00-00	..GASKET	1	
17	5JW-13473-00-00	..O-RING	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C090

INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-13595-00-00	JOINT	1	
2	90450-62001-00	HOSE CLAMP ASSY	2	
3	5VY-13596-00-00	JOINT, CARBURETOR 2	1	
4	90450-62001-00	HOSE CLAMP ASSY	2	
5	5VY-13597-00-00	JOINT, CARBURETOR 3	1	
6	90450-62001-00	HOSE CLAMP ASSY	2	
7	5VY-13598-00-00	JOINT, CARBURETOR 4	1	
8	90450-62001-00	HOSE CLAMP ASSY	2	
9	5VY-14411-00-00	CASE, AIR CLEANER 1	1	
10	5VY-14421-00-00	CASE, AIR CLEANER 2	1	
11	5VY-14451-00-00	ELEMENT, AIR CLEANER	1	
12	5VY-14419-00-00	PIPE	1	
13	31A-14435-00-00	GROMMET	1	
14	5CA-85886-00-00	SENSOR, AIR TEMPRATURE	1	
15	5VY-14435-00-00	GROMMET	1	
16	5VY-14452-00-00	SEAL	1	
17	5VY-14462-00-00	SEAL	1	
18	5VY-14457-00-00	SEAL	2	
19	5VY-15393-00-00	PIPE, BREATHER 2	2	
20	90467-160A1-00	CLIP	1	
21	90480-08264-00	GROMMET	2	
22	5VY-14498-00-00	STAY 1	1	
23	5VY-14467-00-00	SEAL	1	
24	5VY-1440B-00-00	JOINT ASSY	2	
25	90109-05005-00	..BOLT	3	
26	90154-05004-00	SCREW, BINDING	10	
27	5VY-14862-00-00	PLUG	1	
28	5VY-14425-00-00	DAMPER 1	1	
29	90467-14015-00	CLIP	1	
30	5VY-12682-00-00	PROTECTOR, HEAT	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY4100-C100


CONTINUED ON NEXT FRAME ►

INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
31	5VY-2179V-00-00	PLATE, EPA 1 (NON CALIFORNIA)	1	UR 49
	5VY-2179R-00-00	PLATE, EPA 2 (CALIFORNIA)	1	UR CA


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY4100-C100

INTAKE 2



5VY4100-C110


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-13750-00-00	THROTTLE BODY ASSY	1	UR 49
	5VY-13750-10-00	THROTTLE BODY ASSY	1	UR CA
2	5FL-85885-01-00	.THROTTLE SENSOR ASSY	2	
3	5VY-85850-00-00	.GEARED MOTOR COMP.	1	
4	22U-14952-00-00	.WASHER	2	
5	91492-12010-00	.PIN, COTTER	2	
6	98507-06012-00	.SCREW, PAN HEAD	2	
7	98507-05008-00	.SCREW, PAN HEAD	2	
8	5VY-13906-00-00	.REGULATOR, PRESSURE	1	
9	4KM-14137-00-00	.CLIP	5	
10	5VY-82386-00-00	.EXTENSION, WIRE HARNESS	1	
11	68V-24376-00-00	.PIPE, JOINT 1	2	
12	5JW-14396-00-00	.PIPE	1	
13	5PW-1410F-00-00	.CONNECTOR	1	
14	98507-05014-00	.SCREW, PAN HEAD	4	
15	5VY-14171-00-00	.PLUNGER, STARTER	2	
16	5VY-14204-00-00	.CASE, STARTER	1	
17	5VX-82380-00-00	.SENSOR, PRESSURE	1	
18	98507-05016-00	.SCREW, PAN HEAD	2	
19	92907-05100-00	.WASHER, SPRING	2	
20	92907-05600-00	.WASHER, PLATE	2	
21	5FL-14349-10-00	.PIPE	2	
22	98507-03016-00	.SCREW, PAN HEAD	4	
23	92990-03100-00	.WASHER, SPRING	4	
24	5PW-14349-00-00	.PIPE	2	
25	5PS-14987-00-00	.HOSE	3	
26	5PW-14251-00-00	.NIPPLE	2	
27	5DM-14936-00-00	.SEAT, SPRING	1	
28	5JW-14589-00-00	.SPRING	1	
29	5SL-14349-00-00	.PIPE	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

INTAKE 2



5VY4100-C110

Ref. No.	Part Number	Description	Qty	Remarks
30	5VY-14348-00-00	..PIPE 1	1	
31	8CC-14216-10-00	..SCREW	4	
32	5PW-14103-00-00	..THROTTLE SCREW SET	1	
33	5VY-13761-00-00	..INJECTOR ASSY	4	
34	5PS-14147-00-00	...O-RING	1	
35	90430-09002-00	..GASKET	4	
36	5JW-14104-00-00	..AIR SCREW SET	2	
37	5VY-14905-00-00	..LEVER, STARTER	1	
38	98507-06020-00	..SCREW, PAN HEAD	2	
39	5VY-13972-00-00	..PIPE, FUEL 2	1	
40	90467-120A1-00	..CLIP	1	
41	5VY-13543-00-00	..HOSE, AIR	2	
42	90464-30040-00	..CLAMP	1	
43	5VY-14465-00-00	.. PIPE	1	UR CA
44	5VY-14466-00-00	.. PIPE	1	UR CA
45	90413-08012-00	.. WAY 3	1	UR CA
46	90467-09006-00	. CLIP	4	UR CA
47	5VY-13971-00-00	PIPE, FUEL 1	1	
48	90464-16005-00	CLAMP	1	
49	90467-12003-00	CLIP	1	
50	5VY-14413-00-00	STAY	1	

CONTENTS


AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

AIR INDUCTION SYSTEM

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-14840-00-00	AIR CUT VALVE ASS'Y	1	
2	5VY-14881-00-00	HOSE, BEND 1	1	
3	5VY-14882-00-00	HOSE, BEND 2	1	
4	90467-18172-00	CLIP	2	
5	5VY-14883-00-00	HOSE, BEND 3	1	
6	90467-18172-00	CLIP	1	
7	90467-17128-00	CLIP	1	
8	90467-180A0-00	CLIP	2	
9	90464-30003-00	CLAMP	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C120

EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-14610-00-00	EXHAUST PIPE ASSY 1	1	
2	5VY-14602-00-00	.EXHAUST PIPE COMP.	1	
3	5VY-14623-00-00	.GASKET, EXHAUST PIPE	1	
4	5VY-14821-00-00	.ARM, SHAFT (VALVE)	1	
5	5VY-14638-00-00	.COLLAR	1	
6	5VY-14811-00-00	.HOUSING	1	
7	5VY-14865-00-00	.PULLEY	1	
8	5VY-14856-00-00	.SPRING	1	
9	5VY-14867-00-00	.BRACKET	1	
10	5VY-14643-00-00	.GASKET 3	1	
11	90110-06110-00	.BOLT, HEXAGON SOCKET HEAD	7	
12	90179-06M28-00	.NUT	1	
13	5VY-14648-00-00	.COLLAR 2	1	
14	5VY-14674-00-00	.VALVE, PLATE	1	
15	92990-06200-00	.WASHER, PLAIN	1	
16	5VY-14826-00-00	PROTECTOR, EXHAUST	1	
17	90110-06110-00	BOLT, HEXAGON SOCKET HEAD	2	
18	4FM-14613-00-00	GASKET, EXHAUST PIPE	4	
19	90179-08410-00	NUT	8	
20	5VY-14740-00-00	CATALYST ASSY.	1	
21	5VY-14755-00-00	.GASKET, SILENCER	1	
22	95814-08030-00	.BOLT, FLANGE	1	
23	5JJ-14715-00-00	.BAND, MUFFLER	1	
24	5VY-14710-10-00	MUFFLER ASSY 1	1	
25	5VY-14714-00-00	.GASKET, MUFFLER	1	
26	90105-08063-00	.BOLT, FLANGE	1	
27	5VY-14715-00-00	.BAND, MUFFLER	1	
28	90183-060A2-00	.NUT, SPRING	2	
29	90338-06007-00	.PLUG	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




CONTINUED ON NEXT FRAME ►

EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
30	5VY-14720-10-00	MUFFLER ASSY 2	1	
31	5VY-14714-00-00	.GASKET, MUFFLER	1	
32	90105-08063-00	.BOLT, FLANGE	1	
33	5VY-14715-00-00	.BAND, MUFFLER	1	
34	90183-060A2-00	.NUT, SPRING	2	
35	90338-06007-00	.PLUG	1	
36	5VY-21890-00-00	STAY ASSY. , 2	1	
37	5VY-14747-00-00	.DAMPER, MUFFLER	1	
38	90387-08021-00	.COLLAR	1	
39	95817-08040-00	BOLT, FLANGE	1	
40	90201-087G2-00	WASHER, PLATE	2	
41	95604-08200-00	NUT, U FLANGE	1	
42	90201-10054-00	WASHER, PLATE	1	
43	5VY-21880-00-00	STAY ASSY. , 1	1	
44	4XV-27424-00-00	.DAMPER, FOOTREST 2	1	
45	90387-08005-00	.COLLAR	1	
46	90201-08034-00	WASHER, PLATE	1	
47	92014-08040-00	BOLT, BUTTON HEAD	1	
48	90111-08016-00	BOLT	1	
49	5VY-27424-00-00	DAMPER, FOOTREST 2	4	
50	90387-08020-00	COLLAR	2	
51	95814-08045-00	BOLT, FLANGE	2	
52	90201-08034-00	WASHER, PLATE	2	
53	95604-08200-00	NUT, U FLANGE	2	
54	5VY-1133E-00-00	CABLE, PULLEY 1	1	
55	5VY-1133F-00-00	CABLE, PULLEY 2	1	
56	5VY-14718-01-P0	PROTECTOR, MUFFLER 1	1	MT2
57	90387-062L2-00	COLLAR	2	
58	90111-06038-00	BOLT	2	
59	5VY-14757-00-00	.DAMPER, MUFFLER 2	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C130


CONTINUED ON NEXT FRAME ►

EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
60	5VY-1475P-00-00	SEAT, 1	1	
61	5VY-1477P-00-00	SEAT, 3	1	
62	5VY-14728-01-P0	PROTECTOR, MUFFLER 2	1	MT2
63	90387-062L2-00	COLLAR	2	
64	90111-06038-00	BOLT	2	
65	5VY-14757-00-00	.DAMPER, MUFFLER 2	1	
66	5VY-1476P-00-00	SEAT, 2	1	
67	5VY-1478P-00-00	SEAT, 4	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C130

CRANKCASE


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-15100-00-00	CRANKCASE ASSY	1	
2	5EB-15155-00-00	..NOZZLE 3	4	
3	93210-04092-00	..O-RING	4	
4	99530-10014-00	. PIN, DOWEL	3	
5	5VY-13418-00-00	PIPE, OIL 2	1	
6	93210-14003-00	O-RING	2	
7	90110-06041-00	BOLT, HEXAGON SOCKET HEAD	2	
8	90116-10020-00	BOLT, STUD	7	
9	90116-10023-00	BOLT, STUD	3	
10	90119-09003-00	BOLT, WITH WASHER	10	
11	95817-08050-00	BOLT, FLANGE	3	
12	95817-08060-00	BOLT, FLANGE	2	
13	90105-08015-00	BOLT, FLANGE	1	
14	90109-06063-00	BOLT	2	
15	95817-06060-00	BOLT, FLANGE	3	
16	95817-06070-00	BOLT, FLANGE	3	
17	95817-06050-00	BOLT, FLANGE	2	
18	90430-06166-00	GASKET	1	
19	5PW-15361-00-00	GAUGE, LEVEL	1	
20	5VY-15316-00-00	DAMPER, ENGINE MOUNT 1 ..	1	

CONTENTS	
AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C140

CRANKCASE COVER 1



5VY1300-C150


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-15411-00-00	COVER, CRANKCASE 1	1	
2	93306-20124-00	BEARING	1	
3	93605-10108-00	PIN, DOWEL	2	
4	5VY-15164-00-00	HOUSING, BEARING 2	1	
5	5VY-15542-00-00	COLLAR 2	1	
6	90149-06020-00	SCREW	3	
7	90201-06431-00	WASHER, PLATE	3	
8	5VY-15451-00-00	GASKET, CRANKCASE COVER 1	1	
9	99480-10018-00	PIN	2	
10	90109-06031-00	BOLT	4	
11	90110-08068-00	BOLT, HEXAGON SOCKET HEAD	3	
12	5PX-15189-00-00	PLUG	1	
13	93210-22382-00	O-RING	1	
14	5VY-15418-00-00	COVER, CHAIN CASE	1	
15	90462-08225-00	CLAMP	1	
16	90110-06020-00	BOLT, HEXAGON SOCKET HEAD	2	
17	90110-06047-00	BOLT, HEXAGON SOCKET HEAD	1	
18	5VY-15421-00-00	COVER, CRANKCASE 2	1	
19	5VY-15499-00-00	PROTECTOR, COVER	1	
20	92014-06014-00	BOLT, BUTTON HEAD	2	
21	5VY-15362-00-00	PLUG, OIL LEVEL	1	
22	93210-27370-00	O-RING	1	
23	5VY-15461-00-00	GASKET, CRANKCASE COVER 2	1	
24	93610-20189-00	PIN, DOWEL	2	
25	90109-06016-00	BOLT	7	
26	90110-06112-00	BOLT, HEXAGON SOCKET HEAD	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

CRANKCASE COVER 1




5VY1300-C150

Ref. No.	Part Number	Description	Qty	Remarks
27	5VY-15416-00-00	COVER, OIL PUMP	1	
28	90340-32004-00	PLUG, STRAIGHT SCREW	1	
29	93210-32172-00	O-RING	1	
30	90430-08143-00	GASKET	1	
31	92014-08016-00	BOLT, BUTTON HEAD	1	
32	5VY-15456-00-00	GASKET, OIL PUMP COVER 1	1	
33	90109-06014-00	BOLT	6	
34	5VY-11165-00-00	PLATE, BREATHER	1	
35	90110-06018-00	BOLT, HEXAGON SOCKET HEAD	3	
36	5VY-15441-00-00	HOLDER, CLUTCH CABLE	1	
37	91314-06014-00	BOLT	1	
38	5VY-15113-00-00	PLATE	1	
39	90110-06004-00	BOLT, HEXAGON SOCKET HEAD	2	
40	5VY-15413-00-00	COVER	1	
41	5VY-15462-00-00	GASKET, CRANKCASE COVER 3	1	
42	90109-06015-00	BOLT	4	
43	5VY-15431-00-00	COVER, CRANKCASE 3	1	
44	93210-57001-00	O-RING	1	
45	90151-06014-00	SCREW, COUNTERSUNK	3	
46	36Y-15189-00-00	PLUG	3	
47	93210-16325-00	O-RING	3	
48	4H7-15189-00-00	PLUG	1	
49	93210-22382-00	O-RING	1	
50	90340-12112-00	PLUG, STRAIGHT SCREW	2	
51	5VY-12443-00-00	STAY	1	
52	90480-13398-00	GROMMET	1	
53	91380-06014-00	BOLT	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

STARTER



Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-11537-00-00	GEAR, DRIVEN	1	
2	5VY-16155-00-00	ABSORBER 1	3	
3	90201-20016-00	WASHER, PLATE	1	
4	5VY-11478-00-00	COLLAR	1	
5	5VY-15570-00-00	STARTER CLUTCH ASSY	1	
6	5VY-15586-00-00	PLATE, STARTER CLUTCH ASSY	1	
7	5VY-15515-00-00	GEAR 3	1	
8	5VY-11445-00-00	SPACER	1	
9	90201-20017-00	WASHER, PLATE	1	
10	93210-18397-00	O-RING	1	
11	93306-20230-00	BEARING	1	
12	5VY-15517-00-00	GEAR, IDLER 2	1	
13	5VY-15521-00-00	SHAFT 1	1	
14	90201-06589-00	WASHER, PLATE	1	
15	90110-06063-00	BOLT, HEXAGON SOCKET HEAD	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C160

CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-16382-00-00	AXLE, PUSH LEVER	1	
2	92907-08600-00	WASHER, PLATE	1	
3	99001-07600-00	CIRCLIP	1	
4	93317-11020-00	BEARING	1	
5	93102-15212-00	OIL SEAL	1	
6	93315-31502-00	BEARING	1	
7	5VY-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
8	5VY-16154-00-00	PLATE, THRUST 1	1	
9	5VY-16370-00-00	CLUTCH BOSS ASSY	1	
10	5VY-16384-00-00	..PLATE, SEAT	1	
11	5VY-16383-00-00	..SPRING, CLUTCH BOSS ...	1	
12	5VY-16331-00-00	..PLATE, FRICTION 2	1	
13	5VY-16325-00-00	. PLATE, CLUTCH 2	1	
14	4X7-16385-00-00	..RING, CLUTCH BOSS	1	
15	5VY-16321-00-00	PLATE, FRICTION	7	
16	5VY-16325-00-00	PLATE, CLUTCH 2	7	
17	5VY-16330-00-00	PLATE, FRICTION 2	1	
18	5VY-16351-00-00	PLATE, PRESSURE 1	1	
19	93306-00304-00	BEARING (B6003C4)	1	
20	90501-230A0-00	SPRING, COMPRESSION	6	
21	90159-06009-00	SCREW, WITH WASHER	6	
22	90208-20001-00	WASHER, CONICAL SPRING ..	1	
23	90179-20007-00	NUT	1	
24	93310-232R9-00	BEARING	1	
25	4XV-16356-01-00	ROD, PUSH 1	1	
26	5VY-16340-00-00	PUSH LEVER ASSY	1	
27	90508-164B2-00	SPRING, TORSION	1	
28	90201-10029-00	WASHER, PLATE	1	
29	99009-10400-00	CIRCLIP	1	

CONTENTS	
AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C170


CONTINUED ON NEXT FRAME ►

CLUTCH


Ref. No.	Part Number	Description	Qty	Remarks
30	5VY-16164-00-00	PLATE, THRUST 2	1	
31	5VY-16181-00-00	SPACER 1	1	
32	5VY-13354-00-00	SPROCKET, DRIVE	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



TRANSMISSION



5VY1300-C180


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-17411-00-00	AXLE, MAIN (15T)	1	
2	90387-28003-00	COLLAR	1	
3	5VY-17151-00-00	GEAR, 5TH PINION (22T)	1	
4	90209-25011-00	WASHER	2	
5	93440-28184-00	CIRCLIP	2	
6	5VY-17131-00-00	GEAR, 3RD PINION (21/23T)	1	
7	90387-25007-00	COLLAR	1	
8	5VY-17161-00-00	GEAR, 6TH PINION (26T)	1	
9	5VY-17121-00-00	GEAR, 2ND PINION (16T)	1	
10	5VY-15163-00-00	HOUSING, BEARING 1	1	
11	93306-20652-00	BEARING	1	
12	90214-25004-00	WASHER, CLAW	1	
13	90214-25003-00	WASHER, CLAW	1	
14	93306-27208-00	BEARING	1	
15	5VY-17446-00-00	PLATE	1	
16	90110-06027-00	BOLT, HEXAGON SOCKET HEAD	3	
17	5VY-17402-00-00	DRIVE AXLE ASSY	1	
18	93305-20605-00	..BEARING	1	
19	5VY-17442-00-00	..COLLAR, DISTANCE	1	
20	90387-31003-00	COLLAR	1	
21	5VY-17221-10-00	GEAR, 2ND WHEEL (33T)	1	
22	90209-28008-00	WASHER	3	
23	93440-31187-00	CIRCLIP	3	
24	5VY-17261-10-00	GEAR, 6TH WHEEL (33T)	1	
25	90387-28004-00	COLLAR	2	
26	5VY-17241-00-00	GEAR, 4TH WHEEL (35T)	1	
27	90214-29002-00	WASHER, CLAW	1	
28	90214-28002-00	WASHER, CLAW	1	
29	5VY-17231-00-00	GEAR, 3RD WHEEL (37T)	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

TRANSMISSION



5VY1300-C180

Ref. No.	Part Number	Description	Qty	Remarks
30	5VY-17251-00-00	GEAR, 5TH WHEEL (30T)	1	
31	90387-25008-00	COLLAR	1	
32	5VY-17211-00-00	GEAR,1ST WHEEL (38T)	1	
33	93102-40330-00	OIL SEAL	1	
34	93440-62032-00	CIRCLIP	1	
35	3CV-17460-00-00	SPROCKET, DRIVE (17T)	1	
36	90215-30233-00	WASHER, LOCK	1	
37	90179-22003-00	NUT	1	
38	90201-257H0-00	WASHER, PLATE	1	
39	93306-205A2-00	BEARING	1	
40	93440-52009-00	CIRCLIP	1	

CONTENTS


AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

SHIFT CAM FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-18540-00-00	SHIFT CAM ASSY	1	
2	136-18542-00-00	. .POINT, NEUTRAL	1	
3	93306-00106-00	BEARING	1	
4	5VY-18511-01-00	FORK, SHIFT 1	1	
5	5VY-18512-01-00	FORK, SHIFT 2	1	
6	5VY-18513-01-00	FORK, SHIFT 3	1	
7	5VY-18531-00-00	BAR, SHIFT FORK GUIDE 1 ...	1	
8	5VY-18535-00-00	BAR, SHIFT FORK GUIDE 2 ...	1	
9	90501-064L1-00	SPRING, COMPRESSION	2	
10	5VY-18536-00-00	STOPPER, SHIFT BAR	1	
11	5VY-18562-00-00	PLATE, STOPPER 2	1	
12	90110-06018-00	BOLT, HEXAGON SOCKET HEAD	2	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C190

SHIFT SHAFT




Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-18144-00-00	HANGER, SPRING	1	
2	132-16346-00-00	HOOK, SPRING	1	
3	5VY-18140-00-00	STOPPER LEVER ASSY	1	
4	90387-0804S-00	COLLAR	1	
5	5VY-18127-00-00	STOPPER, SCREW	1	
6	93317-11287-00	BEARING	2	
7	93101-12004-00	OIL SEAL	1	
8	99001-10600-00	CIRCLIP	1	
9	90201-12575-00	WASHER, PLATE	2	
10	5VY-18101-00-00	SHIFT SHAFT ASSY	1	
11	90508-32020-00	..SPRING, TORSION	1	
12	90387-1211D-00	..COLLAR	1	
13	5VY-18112-00-00	ARM, SHIFT	1	
14	95027-06020-00	BOLT, FLANGE	1	
15	5VY-18110-00-00	SHIFT PEDAL ASSY	1	
16	5EB-18113-00-00	..COVER, SHIFT PEDAL	1	
17	4XV-18154-00-00	..COVER, DUST	1	
18	5VY-18115-00-00	ROD, SHIFT	1	
19	90170-06228-00	NUT (COUNTER CLOCKWISE)	1	
20	95304-06700-00	NUT	1	
21	5LV-18116-00-00	JOINT, ROD 1	1	
22	4XV-18154-00-00	COVER, DUST	1	
23	90111-06019-00	BOLT	1	

CONTENTS	
AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C200

FRAME



5VY1300-C210


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-2116J-00-00	BRACKET 7	1	
2	90480-14005-00	GROMMET	2	
3	90387-063E6-00	COLLAR	2	
4	95027-06020-00	BOLT, FLANGE	2	
5	90201-06M31-00	WASHER, PLATE	2	
6	95024-06012-00	BOLT, FLANGE	1	
7	5VY-21110-00-00	FRAME COMP.	1	UR 49
	5VY-21110-10-00	FRAME COMP.	1	UR CA
8	5VY-21190-00-00	REAR FRAME COMP.	1	
9	5VY-21268-00-00	SEAL	2	
10	5VY-21269-00-00	SEAL	1	
11	90149-10015-00	SCREW	2	
12	90149-10017-00	SCREW	2	
13	95024-10040-00	BOLT, FLANGE	1	
14	95024-10045-00	BOLT, FLANGE	1	
15	5VY-21414-00-00	BOSS, ENGINE MOUNT	1	
16	5VY-21424-00-00	BOSS, ENGINE MOUNT	1	
17	90110-10005-00	BOLT, HEXAGON SOCKET HEAD	1	
18	90179-10696-00	NUT	1	
19	5EB-21495-00-00	BOLT, ENGINE ADJUSTING ..	1	
20	90110-10005-00	BOLT, HEXAGON SOCKET HEAD	1	
21	90179-10696-00	NUT	1	
22	5EB-21495-00-00	BOLT, ENGINE ADJUSTING ..	1	
23	90338-15004-00	PLUG	2	
24	90338-23004-00	PLUG	2	
25	5VY-21435-00-00	BRACKET, MUFFLER 1	1	
26	90109-06056-00	BOLT	1	
27	5VY-21131-00-00	BRACKET	1	
28	95827-06016-00	BOLT, FLANGE	4	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

FRAME




5VY1300-C210

Ref. No.	Part Number	Description	Qty	Remarks
29	5VY-2110M-00-00	COVER ASSY	1	
30	5VY-2174X-00-00	..DAMPER	1	
31	5VY-21746-00-00	..DAMPER	1	
32	5VY-2131P-00-00	COVER PLATE COMP.	1	
33	90338-06018-00	..PLUG	1	
34	90167-05080-00	SCREW, TAPPING	3	
35	5VY-2110M-10-00	COVER ASSY	1	
36	5VY-2174Y-00-00	..DAMPER	1	
37	90480-01333-00	..GROMMET	1	
38	90464-16006-00	..CLAMP	1	
39	5VY-2117R-00-00	COVER 4	1	
40	5SL-84753-00-00	DAMPER	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

FENDER



5VY1300-C220


Ref. No.	Part Number	Description	Qty	Remarks
1	5PW-21511-00-P1	FENDER, FRONT	1	UR DPBMC
	5PW-21511-00-P3	FENDER, FRONT	1	UR DRMK
	5PW-21511-00-P5	FENDER, FRONT	1	UR BS4
2	90480-12072-00	GROMMET	6	
3	90387-065J6-00	COLLAR	6	
4	90111-06043-00	BOLT	4	
5	90111-06030-00	BOLT	2	
6	95707-06500-00	NUT, FLANGE	2	
7	5VY-8212B-00-00	BOX, BATTERY 1	1	
8	133-82131-00-00	BAND, BATTERY	1	
9	5VY-21617-00-00	BRACKET, FENDER	1	
10	90267-32161-00	RIVET, BLIND	4	
11	5VY-82122-00-00	SEAT, BATTERY	1	
12	5VY-82123-00-00	SEAT, BATTERY	1	
13	90109-06043-00	BOLT	2	
14	90269-07076-00	RIVET	1	
15	5VY-2164G-00-00	STAY 2	1	
16	95827-06016-00	BOLT, FLANGE	2	
17	5VY-8212C-00-00	BOX, BATTERY 2	1	
18	90269-07076-00	RIVET	1	
19	90269-07077-00	RIVET	3	
20	90464-12036-00	CLAMP	3	
21	4XV-21376-00-00	BAND, TOOL	1	
22	5VY-21611-00-P0	FENDER, REAR	1	UR DRMK
	5VY-21611-00-P1	FENDER, REAR	1	UR DPBMC
	5VY-21611-00-P3	FENDER, REAR	1	UR BS4
23	5VY-21669-00-00	SEAL	1	
24	90465-04020-00	CLAMP	2	
25	5VY-21639-00-00	DAMPER 2	2	
26	5PW-21732-00-00	.SEAL 1	4	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

FENDER



5VY1300-C220

Ref. No.	Part Number	Description	Qty	Remarks
27	1UF-15379-00-00	SEAL, CRANKCASE	4	
28	5VY-21732-00-00	SEAL 1	4	
29	90464-13073-00	CLAMP	2	
30	90465-04020-00	CLAMP	1	
31	90269-06081-00	RIVET	2	
32	90269-06081-00	RIVET	2	
33	90269-07077-00	RIVET	1	
34	5VY-2163A-00-00	COVER, REAR FENDER 1	1	
35	5VY-2163E-00-00	COVER, REAR FENDER 2	1	
36	97707-50014-00	SCREW, TAPPING	6	
37	5VY-21652-00-00	PROTECTOR	1	
38	5VY-2161G-00-00	BRACKET 6	1	
39	90111-06030-00	BOLT	4	
40	90387-06071-00	COLLAR	4	
41	5VY-2164K-00-00	PATCH 5	1	
42	5VY-2164L-00-00	PATCH 6	1	
43	5VY-2164F-00-00	STAY 1	1	
44	90119-05011-00	BOLT, WITH WASHER	1	
45	90387-05017-00	COLLAR	1	
46	90119-05193-00	BOLT, WITH WASHER	1	
47	5VY-27490-00-00	PROTECTOR ASSY	1	
48	90387-0603J-00	..COLLAR	4	
49	5VY-14757-00-00	..DAMPER, MUFFLER 2	1	
50	5VY-2838G-00-00	..SEAT 1	1	
51	90149-06298-00	SCREW	4	
52	5VY-28100-00-00	TOOL KIT	1	

CONTENTS


AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	F8
TAILLIGHT	E5
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-21710-00-P0	SIDE COVER ASSY 1	1	UR DRMK
	5VY-21710-00-P1	SIDE COVER ASSY 1	1	UR DPBMC
	5VY-21710-00-P3	SIDE COVER ASSY 1	1	UR BS4
2	5PW-2174X-00-00	..DAMPER	2	
3	5VY-2172E-00-00	..STAY, SIDE COVER 1	2	
4	90338-06018-00	..PLUG	2	
5	5VY-21747-00-00	..DAMPER	1	
6	1JK-21735-00-00	..SEAL 2	1	
7	5PW-21732-00-00	..SEAL 1	1	
8	5VY-2172P-00-00	..SEAT, 1	1	
9	5VY-2173P-00-00	..SEAT, 2	1	
10	1UJ-21717-00-00	..DAMPER	2	
11	5VY-21735-00-00	..SEAL 2	1	
12	90269-07076-00	RIVET	2	
13	90269-06011-00	RIVET	2	
14	90111-05007-00	BOLT	1	
15	90183-05076-00	NUT, SPRING	1	
16	99246-00080-00	EMBLEM, YAMAHA	1	UR FOR BS4
	99244-00080-00	EMBLEM, YAMAHA	1	UR FOR DRMK
	99241-00080-00	EMBLEM, YAMAHA	1	UR FOR DPBMC
17	5VY-21871-00-00	TANK, RECOVERY	1	
18	5VY-21875-00-00	CAP	1	
19	26H-21828-00-00	ELBOW	1	
20	90445-08022-00	HOSE	1	
21	5VY-21843-00-00	STAY, 4	1	
22	98504-06010-00	SCREW, PAN HEAD	1	
23	92903-06600-00	WASHER, PLATE	1	
24	90467-08075-00	CLIP	2	
25	90445-087K6-00	HOSE (L700)	1	
26	90387-062M9-00	COLLAR	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C230


CONTINUED ON NEXT FRAME ►

SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
27	92017-06012-00	BOLT, BUTTON HEAD	1	
28	90480-20001-00	GROMMET	1	
29	90467-08075-00	CLIP	1	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C230

REAR ARM



5VY1300-C240


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-22110-00-00	REAR ARM COMP.	1	
2	5VY-22184-00-00	BUSH	1	
3	93317-52865-00	BEARING	1	
4	93317-428U8-00	BEARING	1	
5	5VY-22128-00-00	COVER, THRUST 1	1	
6	5VY-22128-10-00	COVER, THRUST 1	1	
7	93315-31758-00	.BEARING	1	
8	93109-17071-00	.OIL SEAL	2	
9	90387-1012A-00	COLLAR	1	
10	5VY-22151-00-00	SEAL, GUARD	1	
11	92017-06016-00	BOLT, BUTTON HEAD	2	
12	90387-062X0-00	COLLAR	1	
13	90387-06066-00	COLLAR	1	
14	90464-16011-00	CLAMP	1	
15	5VY-22311-00-00	CASE, CHAIN	1	
16	90183-05076-00	NUT, SPRING	1	
17	90149-06298-00	SCREW	1	
18	90387-07717-00	COLLAR	1	
19	5VY-22873-00-00	SEAL 1	1	
20	5VY-2217A-00-00	ARM, RELAY	2	
21	5VY-2217M-00-00	ARM 1	1	
22	93315-31758-00	.BEARING	2	
23	93109-17071-00	.OIL SEAL	4	
24	90105-10017-00	BOLT, FLANGE	1	
25	95607-10200-00	NUT, U FLANGE	1	
26	90387-1012A-00	COLLAR	2	
27	90105-10017-00	BOLT, FLANGE	2	
28	95607-10200-00	NUT, U FLANGE	2	
29	90387-1013U-00	COLLAR	1	
30	90110-10011-00	BOLT, HEXAGON SOCKET HEAD	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

REAR ARM



Ref. No.	Part Number	Description	Qty	Remarks
31	95607-10200-00	NUT, U FLANGE	1	
32	5VY-22141-00-00	SHAFT, PIVOT	1	
33	90185-18167-00	NUT, SELF-LOCKING	1	
34	90201-18013-00	WASHER, PLATE	1	
35	5VY-21650-00-00	REAR FENDER COMP.	1	
36	90480-12005-00	GROMMET	2	
37	90387-06057-00	COLLAR	2	
38	90464-16012-00	CLAMP	1	
39	90149-06302-00	SCREW	2	
40	90269-08002-00	RIVET	1	
41	5PW-28372-00-00	DAMPER	1	
42	90111-05003-00	BOLT	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9


5VY1300-C240

REAR SUSPENSION

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-22210-10-00	SHOCK ABSORBER ASSY, REAR	1	
2	93315-31758-00	..BEARING	1	
3	93109-17071-00	..OIL SEAL	2	
4	90387-1012A-00	COLLAR	1	
5	90105-10017-00	BOLT, FLANGE	1	
6	95607-10200-00	NUT, U FLANGE	1	
7	5SL-22219-00-00	BRACKET, UPPER	1	
8	95607-14200-00	NUT, SELF-LOCKING	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C250

STEERING

Ref. No.	Part Number	Description	Qty	Remarks
1	93399-99932-00	BEARING	2	
2	3FV-23462-00-00	SEAL, STEERING	1	
3	4XV-23415-01-00	COVER, BALL RACE 1	1	
4	90179-30691-00	NUT	2	
5	4XV-23418-00-00	WASHER, SPECIAL	1	
6	90202-30235-00	WASHER, PLATE	1	
7	90170-28419-00	NUT	1	
8	90201-281U8-00	WASHER, PLATE	1	
9	5VY-23435-10-00	CROWN, HANDLE	1	
10	91314-08030-00	BOLT	2	
11	4XV-2341B-00-00	EMBLEM	1	
12	90111-06041-00	BOLT	1	
13	5VY-26292-00-00	STAY	1	
14	90387-06057-00	COLLAR	1	
15	90183-050A0-00	NUT, SPRING	1	
16	90480-14003-00	GROMMET	1	
17	5VY-23808-00-00	STEERING, COVER ASSY	1	
18	90387-0611K-00	..COLLAR	2	
19	90109-065G4-00	BOLT	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C260

YZF-R1S

D5

FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-23102-10-00	FRONT FORK ASSY (L.H)	1	
2	5VY-23136-10-00	. .TUBE, OUTER	1	
3	5PW-23146-00-00	. . .WASHER, OIL SEAL	1	
4	4PU-23145-01-00	. . .OIL SEAL	1	
5	4V4-23153-L0-00	. . .RING, SNAP	1	
6	4PU-23144-00-00	. . .SEAL, DUST	1	
7	5VY-23110-00-00	. . INNER TUBE COMP. 1	1	
8	5VY-23170-00-00	. .CYLINDER COMP., FRONT FORK	1	
9	509-23158-L0-00	. .GASKET	1	
10	5UX-23181-00-00	. .BOLT, HEXAGON SOCKET HEAD	1	
11	5VY-23141-00-00	. .SPRING, FRONT FORK	1	
12	5VY-12277-00-00	. .WASHER	1	
13	5VY-23118-00-00	. .SPACER	1	
14	3LC-23357-00-00	. .NUT	1	
15	5VY-23111-00-00	. .BOLT, CAP	1	
16	3XJ-23147-L0-00	. . .O-RING	1	
17	91314-08040-00	. .BOLT	2	
18	5VY-23103-10-00	FRONT FORK ASSY (R.H)	1	
19	5VY-23136-10-00	. .TUBE, OUTER	1	
20	5PW-23146-00-00	. . .WASHER, OIL SEAL	1	
21	4PU-23145-01-00	. . .OIL SEAL	1	
22	4V4-23153-L0-00	. . .RING, SNAP	1	
23	4PU-23144-00-00	. . .SEAL, DUST	1	
24	5VY-23120-00-00	. . INNER TUBE COMP. 2	1	
25	5VY-23170-00-00	. .CYLINDER COMP., FRONT FORK	1	
26	509-23158-L0-00	. .GASKET	1	
27	5UX-23181-00-00	. .BOLT, HEXAGON SOCKET HEAD	1	

CONTENTS


AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►



5VY1300-C270

FRONT FORK




5VY1300-C270

Ref. No.	Part Number	Description	Qty	Remarks
28	5VY-23141-00-00	..SPRING, FRONT FORK	1	
29	5VY-12277-00-00	..WASHER	1	
30	5VY-23118-00-00	..SPACER	1	
31	3LC-23357-00-00	..NUT	1	
32	5VY-23111-00-00	..BOLT, CAP	1	
33	3XJ-23147-L0-00	...O-RING	1	
34	91314-08040-00	..BOLT	2	
35	5VY-23340-00-00	UNDER BRACKET COMP.	1	
36	91314-08030-00	BOLT	4	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

FUEL TANK




Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-YK241-30-P0	FUEL TANK COMP.	1	UR DRMK
	5VY-Y2410-30-01	FUEL TANK COMP.	1	UR DPBMC
	5VY-YK241-M0-P1	FUEL TANK COMP.	1	UR S3 FOR BS4
2	5VY-24240-00-00	. .GRAPHIC SET	1	FOR DPBMC
3	91317-06016-00	BOLT	2	
4	5VY-24183-00-00	DAMPER, LOCATING 3	2	
5	5VY-24191-00-00	BRACKET, FUEL TANK 1	1	
6	5VY-24181-00-00	DAMPER, LOCATING 1	1	
7	90480-10542-00	GROMMET	1	
8	90387-066Y6-00	COLLAR	1	
9	90387-061U9-00	COLLAR	2	
10	5VY-24192-00-00	BRACKET, FUEL TANK 2	1	
11	5VY-24181-00-00	DAMPER, LOCATING 1	1	
12	90480-10542-00	GROMMET	1	
13	90387-066Y6-00	COLLAR	1	
14	95027-06030-00	BOLT, FLANGE	2	
15	90201-06063-00	WASHER, PLATE	2	
16	91317-06090-00	BOLT	1	
17	5VY-2413Y-00-00	BRACKET, TANK FITTING	1	
18	5SL-24183-00-00	DAMPER, LOCATING 3	2	
19	90387-06055-00	COLLAR	1	
20	95027-06020-00	BOLT, FLANGE	4	
21	5JJ-24602-00-00	CAP ASSY	1	
22	90110-05112-00	BOLT, HEXAGON SOCKET HEAD	3	
23	91317-05010-00	BOLT	1	
24	5PW-13907-01-00	FUEL PUMP COMP.	1	
25	5VY-24491-00-00	BRACKET, FUEL PUMP	1	
26	5PW-24192-00-00	BRACKET, FUEL TANK 2	1	
27	98907-05008-00	SCREW, BIND	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	F8
TAILLIGHT	E5
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ➤

FUEL TANK




Ref. No.	Part Number	Description	Qty	Remarks
28	90461-10010-00	CLAMP	1	
29	90154-05012-00	SCREW, BINDING	1	
30	5JW-24486-00-00	O-RING	1	
31	90110-05014-00	BOLT, HEXAGON SOCKET HEAD	6	
32	5VY-24315-00-00	PIPE 5	1	
33	5VY-24316-00-00	PIPE 6	1	
34	5VY-24317-00-00	PIPE 7	1	
35	90413-07007-00	WAY 3	1	
36	90467-09006-00	CLIP	5	
37	5VY-2171A-00-P0	COVER, TOP	1	UR DRMK
	5VY-2171A-00-P1	COVER, TOP	1	UR DPBMC
	5VY-2171A-00-P3	COVER, TOP	1	UR BS4
38	5VY-2414J-00-00	DAMPER, PLATE 2	2	
39	4XV-2834E-00-00	DAMPER 1	2	
40	5VY-24145-00-00	DAMPER, SIDE COVER	1	
41	91314-06025-00	BOLT	1	
42	90480-12314-00	GROMMET	1	
43	90387-065J6-00	COLLAR	1	
44	90201-06M30-00	WASHER, PLATE	1	
45	90183-05074-00	NUT, SPRING	4	
46	5VY-24117-00-00	STAY, FUEL TANK 3	1	
47	5VY-24118-00-00	STAY, FUEL TANK 4	1	
48	95707-05500-00	NUT, FLANGE	2	
49	90105-05002-00	BOLT, FLANGE	4	
50	90179-05523-00	NUT	2	
51	98907-05014-00	SCREW, BIND	2	
52	5VY-2414N-00-00	DAMPER, PLATE 4	1	
53	5VY-2414P-00-00	DAMPER, PLATE 5	1	
54	5VY-24129-00-00	COVER, SIDE 1	1	

CONTENTS	
AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

FUEL TANK



Ref. No.	Part Number	Description	Qty	Remarks
55	5PW-2414J-00-00	DAMPER, PLATE 2	1	
56	5PW-2414H-00-00	DAMPER, PLATE 1	1	
57	5PW-2411J-01-00	DAMPER, SIDE COVER	1	
58	5VY-24139-00-00	COVER, SIDE 2	1	
59	5PW-2414J-00-00	DAMPER, PLATE 2	1	
60	5PW-2414H-00-00	DAMPER, PLATE 1	1	
61	5PW-2411J-01-00	DAMPER, SIDE COVER	1	
62	90159-05015-00	SCREW, WITH WASHER	2	
63	5PW-2413B-00-00	EMBLEM	2	
64	5VY-2414K-00-00	DAMPER, PLATE 3	2	
65	5VY-2414R-00-00	DAMPER, PLATE 6	1	
66	5VY-2414H-00-00	DAMPER, PLATE 1	1	
67	5VY-24313-00-00	PIPE 3	1	UR CA
68	5RB-24180-00-00	ROLL OVER VALVE ASSY	1	UR CA
69	5VY-24314-00-00	PIPE 4	1	UR CA
70	5VY-24170-00-00	CANISTER ASSY	1	UR CA
71	90445-11418-00	HOSE (L18)	1	UR CA
72	90467-09006-00	CLIP	4	UR CA
73	5VY-1443J-00-00	PIPE	1	UR CA
74	90467-09006-00	CLIP	2	UR CA
75	5VY-2419F-00-00	BRACKET, CANISTOR	1	UR CA
76	92017-06016-00	BOLT, BUTTON HEAD	2	UR CA
77	5VY-24216-00-00	STAY	1	UR CA
78	92017-06010-00	BOLT, BUTTON HEAD	2	UR CA
79	90461-15139-00	CLAMP	1	UR CA
80	90269-05001-00	RIVET	1	UR CA
81	92017-06016-00	BOLT, BUTTON HEAD	2	UR CA
82	90480-13018-00	GROMMET	2	UR CA
83	90387-062L2-00	COLLAR	2	UR CA
84	5VY-24312-00-00	PIPE 2	1	UR CA

CONTENTS



AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

SEAT

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-24710-00-00	SINGLE SEAT ASSY	1	
2	5VY-2470F-00-00	..SEAT COVER COMP.	1	
3	90110-06258-00	BOLT, HEXAGON SOCKET HEAD	2	
4	5VY-24750-00-00	TANDEM SEAT ASSY	1	
5	5VY-24751-00-00	..COVER, TANDEM SEAT	1	
6	5SL-24723-00-00	..DAMPER, SEAT	2	
7	5VY-24780-00-00	SEAT LOCK ASSY	1	
8	5VY-24792-00-00	PLATE	1	
9	92017-06025-00	BOLT, BUTTON HEAD	2	
10	5VY-24729-00-00	SPACER 2	1	
11	5VY-2478E-00-00	CABLE, SEAT LOCK	1	
12	5VY-W2470-00-00	SEAT LOCK ASSY	1	
13	5VY-2117K-01-00	STAY, LOCK	1	
14	5VY-2176V-00-00	SPRING, LOCK 2	1	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C290

FRONT WHEEL



Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-25168-00-98	CAST WHEEL, FRONT	1	LGB
2	4XV-25117-00-00	SPACER, BEARING	1	
3	93306-00420-00	BEARING (B6004)	2	
4	93106-28043-00	OIL SEAL	2	
5	94112-17071-00	TIRE (120/70 ZR17M/C 58W D218F)	1	DUNLOP
6	93900-00030-00	VALVE, RIM (TR412)	1	TAIHEIYO
7	5MT-25398-00-00	BALANCER, WHEEL (10G)	1	UN
	5MT-25398-10-00	BALANCER, WHEEL (20G)	1	UN
	5MT-25398-20-00	BALANCER, WHEEL (30G)	1	UN
8	5PW-25181-00-00	AXLE, WHEEL	1	
9	5PW-25188-00-00	CAP	1	
10	90105-14002-00	BOLT, FLANGE	1	
11	4XV-25186-00-00	COLLAR, WHEEL	2	
12	4XV-25118-00-00	COVER, HUB DUST	2	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1332-C300

FRONT BRAKE CALIPER



Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-2581T-20-00	DISK BRAKE ASSY	2	
2	90149-06043-00	SCREW	10	
3	5VY-2580T-00-00	CALIPER ASSY (LEFT)	1	
4	5PW-W0057-00-00	.PISTON ASSY, CALIPER	1	
5	5PW-W0047-00-00	...CALIPER SEAL KIT	1	
6	5PW-W0057-10-00	.PISTON ASSY, CALIPER	1	
7	5PW-W0047-10-00	...CALIPER SEAL KIT	1	
8	5VY-W0045-00-00	.BRAKE PAD KIT	1	
9	4SV-25919-00-00	.SUPPORT, PAD	1	
10	4SV-25924-00-00	.PIN, PAD	1	
11	3GM-25925-00-00	.CLIP	2	
12	1J3-W0048-00-00	.BLEED SCREW KIT	1	
13	5VY-2583B-00-00	.PIN, KNOCK	2	
14	5VY-2580U-00-00	CALIPER ASSY (RIGHT)	1	
15	5PW-W0057-00-00	.PISTON ASSY, CALIPER	1	
16	5PW-W0047-00-00	...CALIPER SEAL KIT	1	
17	5PW-W0057-10-00	.PISTON ASSY, CALIPER	1	
18	5PW-W0047-10-00	...CALIPER SEAL KIT	1	
19	5VY-W0045-00-00	.BRAKE PAD KIT	1	
20	4SV-25919-00-00	.SUPPORT, PAD	1	
21	4SV-25924-00-00	.PIN, PAD	1	
22	3GM-25925-00-00	.CLIP	2	
23	1J3-W0048-00-00	.BLEED SCREW KIT	1	
24	5VY-2583B-00-00	.PIN, KNOCK	2	
25	90401-10012-00	BOLT, UNION	4	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY1300-C310

REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-25338-00-98	CAST WHEEL, REAR	1	LGB
2	93306-20531-00	BEARING	1	
3	93106-40013-00	OIL SEAL	1	
4	93317-43580-00	BEARING	1	
5	93420-61M07-00	CIRCLIP	1	
6	5PW-25317-00-00	SPACER, BEARING	1	
7	4XV-25383-00-00	COLLAR, WHEEL	1	
8	5VX-25364-00-00	DAMPER	6	
9	94119-17025-00	TIRE (190/50 ZR17M/C 73W D218)	1	DUNLOP
10	93900-00030-00	VALVE, RIM (TR412)	1	TAIHEIYO
11	5MT-25398-00-00	BALANCER, WHEEL (10G)	1	UN
	5MT-25398-10-00	BALANCER, WHEEL (20G)	1	UN
	5MT-25398-20-00	BALANCER, WHEEL (30G)	1	UN
12	5SL-25366-00-00	CLUTCH, HUB	1	
13	93306-20531-00	BEARING	1	
14	93106-40013-00	OIL SEAL	1	
15	5VY-25445-20-00	SPROCKET, DRIVEN (45T)	1	
16	90116-10485-00	BOLT, STUD	6	
17	90185-10009-00	NUT, SELF-LOCKING	6	
18	90201-10021-00	WASHER, PLATE	6	
19	5PW-25377-00-00	COLLAR, WHEEL	1	
20	5PW-25367-00-00	COVER, HUB DUST	1	
21	5SL-25376-00-00	COLLAR, WHEEL	1	
22	5SL-25367-00-00	COVER, HUB DUST	1	
23	5VY-25388-00-00	PULLER, CHAIN 1	1	
24	5VY-25389-00-00	PULLER, CHAIN 2	1	
25	5SL-25381-00-00	AXLE, WHEEL	1	
26	90185-24165-00	NUT, SELF-LOCKING	1	
27	90201-257R5-00	WASHER, PLATE	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1332-C320


CONTINUED ON NEXT FRAME ►

REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
28	90101-08766-00	BOLT	2	
29	95307-08600-00	NUT	2	
30	94582-10116-00	CHAIN (DID50VA8-116L)	1	
31	94682-05031-00	. JOINT, CHAIN (DID 50VA8-ZJ)	1	
32	90201-086P8-00	WASHER, PLATE	2	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1332-C320

REAR BRAKE CALIPER




5VY1300-C330

Ref. No.	Part Number	Description	Qty	Remarks
1	5SL-2582W-00-00	DISK, REAR BRAKE 2	1	
2	90149-08009-00	SCREW	5	
3	5VY-2580W-00-00	CALIPER ASSY, REAR 2	1	
4	5VY-W0057-00-00	.PISTON ASSY, CALIPER	1	
5	5SL-W0047-00-00	...CALIPER SEAL KIT	1	
6	5SL-25917-00-00	.BOOT, CALIPER	1	
7	5SL-25838-00-00	.SLEEVE, CALIPER	1	
8	5SL-25919-00-00	.SUPPORT, PAD	1	
9	5SL-25914-00-00	.PIN, SLIDE	1	
10	5VY-25921-50-00	.BRACKET, SUPPORT	1	
11	3JD-25917-00-00	.BOOT, CALIPER	1	
12	5VX-W0046-00-00	.BRAKE PAD KIT 2	1	
13	8CR-25924-00-00	.PIN, PAD	1	
14	5DH-25916-00-00	.PLUG	1	
15	5SL-25926-00-00	.BOLT	1	
16	1UY-W0048-00-00	.BLEED SCREW KIT	1	
17	5SL-25827-00-00	.SHIM, CALIPER	1	
18	5SL-25827-10-00	.SHIM, CALIPER	1	
19	5SL-25828-00-00	.SHIM, CALIPER	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

STEERING HANDLE CABLE



Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-26121-00-00	HANDLEBAR (LEFT)	1	
2	5VY-26122-00-00	HANDLEBAR (RIGHT)	1	
3	4XV-23434-00-00	HOLDER, DAMPER	2	
4	5PW-26246-00-00	END, GRIP	2	
5	91317-06025-00	BOLT	2	
6	91317-06025-00	BOLT	2	
7	91314-08030-00	BOLT	2	
8	2H9-23469-00-00	CAP, BOLT	2	
9	4YR-26241-01-00	GRIP (LEFT)	1	
10	4YR-26240-01-00	GRIP ASSY	1	
11	5VY-26281-00-00	CAP, GRIP UPPER	1	
12	3XW-26282-01-00	CAP, GRIP LOWER	1	
13	90110-05018-00	BOLT, HEXAGON SOCKET HEAD	2	
14	5VY-26302-00-00	THROTTLE CABLE ASSY	1	
15	5VY-26335-00-00	CABLE, CLUTCH	1	
16	5VY-23495-00-00	STAY, DAMPER	1	
17	5VY-23490-00-00	HANDLEBAR SHIMMY DAMPER ASSY	1	
18	95607-08200-00	NUT, SELF-LOCKING	1	
19	90201-08M09-00	WASHER, PLATE	1	
20	90110-06181-00	BOLT, HEXAGON SOCKET HEAD	3	
21	5VY-23389-00-00	GUIDE, CABLE	1	
22	95807-08030-00	BOLT, FLANGE	1	
23	90201-08676-00	WASHER, PLATE	1	
24	5VY-26398-00-00	WASHER	1	
25	5VY-2631E-00-00	WIRE GUIDE ASSY., 1	1	
26	90110-05014-00	BOLT, HEXAGON SOCKET HEAD	1	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C340

FRONT MASTER CYLINDER




5VY1300-C350

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-W2587-00-00	MASTER CYLINDER SUB ASSY	1	
2	5VY-W0041-00-00	..CYLINDER KIT, MASTER ...	1	
3	5VY-W0048-00-00	..BLEED SCREW KIT	1	
4	5VY-25975-00-00SEAL 1	1	
5	5VY-2589F-00-00	BOLT, LEVER	1	
6	5VS-2586F-00-00	NUT, COVER	1	
7	5VY-83922-00-00	LEVER 2	1	
8	4HM-83980-00-00	FRONT STOP SWITCH ASSY .	1	
9	5VS-2585H-00-00	SCREW, SET	1	
10	5VY-25894-00-00	TANK, RESERVOIR	1	
11	5VY-25854-00-00	DIAPHRAGM, RESERVOIR ...	1	
12	5VY-25855-00-00	BUSH, DIAPHRAGM	1	
13	5VY-25852-00-00	CAP, RESERVOIR	1	
14	5SL-25895-00-00	HOSE, RESERVOIR	1	
15	90467-090A1-00	CLIP	2	
16	5VY-2589G-00-00	HOLDER	1	
17	5VY-2589H-00-00	SCREW	1	
18	5VY-25872-00-00	HOSE, BRAKE 1	1	
19	90401-10172-00	BOLT, UNION	3	
20	90201-10118-00	WASHER, PLATE	6	
21	5VS-25867-00-00	BRACKET, MASTER CYLINDER	1	
22	5VS-26332-00-00	BOLT	2	
23	5VY-23377-00-00	BRACKET, HORN	1	
24	90105-06041-00	BOLT, FLANGE	1	
25	90149-05299-00	SCREW	1	
26	3MA-82591-00-00	BAND	2	
27	5VY-25875-00-00	HOLDER, BRAKE HOSE 1	1	
28	5VY-25876-00-00	HOLDER, BRAKE HOSE 2	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

STAND FOOTREST



FWD
5VY1300-C360


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-27311-00-00	STAND, SIDE	1	
2	5JJ-27321-00-00	BRACKET, SIDE STAND	1	
3	4NX-27351-00-00	GUIDE, SIDE STAND	1	
4	5PW-27352-00-00	HOOK, SIDE STAND	1	
5	90506-18008-00	SPRING, TENSION	1	
6	90445-19002-00	HOSE (L60)	1	
7	90201-081R9-00	WASHER, PLATE	1	
8	90101-08662-00	BOLT	1	
9	95607-10200-00	NUT, U FLANGE	1	
10	90201-101J1-00	WASHER, PLATE	1	
11	90201-146F9-00	WASHER, PLATE	1	
12	5JJ-27315-00-00	LINK, SIDE STAND	1	
13	91317-06012-00	BOLT	1	
14	90109-10002-00	BOLT	2	
15	5VY-27442-01-00	BRACKET 2	1	
16	5VY-27410-00-00	FRONT FOOTREST ASSY (LEFT)	1	
17	90109-083E0-00	..BOLT	1	
18	90109-103A9-00	BOLT	1	
19	90214-10002-00	WASHER, CLAW	1	
20	5VY-27445-00-00	PLATE 1	1	
21	90111-06003-00	BOLT	2	
22	90109-085G6-00	BOLT	2	
23	5VY-27443-01-00	BRACKET 3	1	
24	5VY-27420-00-00	FRONT FOOTREST ASSY (RIGHT)	1	
25	90109-083E0-00	..BOLT	1	
26	90109-103A9-00	BOLT	1	
27	90214-10002-00	WASHER, CLAW	1	
28	5VY-27446-00-00	PLATE 2	1	
29	90149-06304-00	SCREW	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

STAND FOOTREST




5VY1300-C360

Ref. No.	Part Number	Description	Qty	Remarks
30	5VY-2144G-00-00	STAY, STOP SWITCH	1	
31	90480-12607-00	GROMMET	1	
32	90387-06023-00	COLLAR	1	
33	90159-06150-00	SCREW, WITH WASHER	1	
34	90109-085G6-00	BOLT	2	
35	5JJ-27431-00-00	FOOTREST, REAR 1	1	
36	5VY-2741L-00-00	BRACKET 4	1	
37	90501-12743-00	SPRING, COMPRESSION	1	
38	93501-04011-00	BALL	1	
39	5JJ-27437-00-00	WASHER, SPECIAL	1	
40	91314-06035-00	BOLT	1	
41	95604-06200-00	NUT, U FLANGE	1	
42	90387-06697-00	COLLAR	1	
43	5JJ-27441-00-00	FOOTREST, REAR 2	1	
44	5VY-2742L-00-00	BRACKET 5	1	
45	90501-12743-00	SPRING, COMPRESSION	1	
46	93501-04011-00	BALL	1	
47	5JJ-27437-00-00	WASHER, SPECIAL	1	
48	91314-06035-00	BOLT	1	
49	95604-06200-00	NUT, U FLANGE	1	
50	90387-06697-00	COLLAR	1	
51	92017-08020-00	BOLT, BUTTON HEAD	4	
52	5VY-27425-00-00	BRACKET, FOOTREST 2	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

REAR MASTER CYLINDER



Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-27211-00-00	PEDAL, BRAKE	1	
2	90506-20193-00	SPRING, TENSION	1	
3	90446-15386-00	HOSE	1	
4	5SL-2583V-00-00	REAR MASTER CYLINDER ASSY.	1	
5	5SL-W0042-50-00	..CYLINDER KIT, MASTER ...	1	
6	5SL-2582A-00-00	..JOINT	1	
7	4BP-2585F-00-00	..BUSH	1	
8	5SL-25894-00-00	TANK, RESERVOIR	1	
9	5SL-25854-00-00	DIAPHRAGM, RESERVOIR ...	1	
10	5SL-25855-00-00	BUSH, DIAPHRAGM	1	
11	5SL-25852-00-00	CAP, RESERVOIR	1	
12	90467-010A0-00	CLIP	2	
13	5VY-25895-00-00	HOSE, RESERVOIR	1	
14	95307-08700-00	NUT	1	
15	5SL-27222-00-00	JOINT	1	
16	90109-06013-00	BOLT	2	
17	91701-06018-00	PIN, CLEVIS	1	
18	92907-06200-00	WASHER	1	
19	91401-16012-00	PIN, COTTER	1	
20	90401-10172-00	BOLT, UNION	2	
21	90201-10118-00	WASHER, PLATE	4	
22	5VY-25874-00-00	HOSE, BRAKE	1	
23	5VY-25886-00-00	HOLDER, BRAKE HOSE	1	
24	90159-06056-00	SCREW, WITH WASHER	1	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C370

COWLING 1



5VY1300-C380


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-Y2881-10-00	WINDSHIELD	1	
2	5VY-2832P-00-00	..GRAPHIC 18	1	
3	90150-05024-00	SCREW, ROUND HEAD	6	
4	90202-05123-00	WASHER, PLATE	6	
5	90179-05523-00	NUT	6	
6	5VY-2835G-00-P0	BODY, FRONT UPPER 1	1	UR DRMK
	5VY-2835G-00-P1	BODY, FRONT UPPER 1	1	UR DPBMC
	5VY-2835G-00-P3	BODY, FRONT UPPER 1	1	UR BS4
7	5PW-2177L-00-00	PLATE, SPRING	2	
8	5JJ-2834W-00-00	PROTECTOR 2	6	
9	90183-05074-00	NUT, SPRING	2	
10	5VY-2834V-00-00	PROTECTOR 1	2	
11	90269-07007-00	RIVET	2	
12	90160-05007-00	SCREW, ROUND TAPPING ...	5	
13	5VY-28356-00-00	STAY 1	1	
14	4XV-83513-00-00	DAMPER	9	
15	91317-05012-00	BOLT	1	
16	4XV-28336-00-00	PLATE	1	
17	95607-08200-00	NUT, SELF-LOCKING	2	
18	5VY-2837L-00-00	PANEL, CONSOLE 1	1	
19	5VY-2837M-00-00	PANEL, CONSOLE 2	1	
20	90154-05013-00	SCREW, BINDING	2	
21	90269-06001-00	RIVET	2	
22	5VY-2838N-00-P0	DUCT 1	1	FOR DRMK, DPBMC
	5VY-2838N-00-P2	DUCT 1	1	FOR BS4
23	5VY-2837N-00-00	GRILL, AIR INTAKE 1	1	
24	5PW-2177L-00-00	PLATE, SPRING	1	
25	5VY-28346-00-00	MOLE 2	1	
26	5VY-2834E-00-00	DAMPER 1	1	
27	1FK-2171H-00-00	GUIDE	3	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

COWLING 1



5VY1300-C380

Ref. No.	Part Number	Description	Qty	Remarks
28	5VY-28371-00-00	DAMPER	1	
29	5VY-2838R-00-P0	DUCT 2	1	FOR DRMK, DPBMC
	5VY-2838R-00-P2	DUCT 2	1	FOR BS4
30	5VY-2837R-00-00	GRILL, AIR INTAKE 2	1	
31	5PW-2177L-00-00	PLATE, SPRING	1	
32	5VY-28346-00-00	MOLE 2	1	
33	5VY-2834F-00-00	DAMPER	1	
34	1FK-2171H-00-00	GUIDE	3	
35	5VY-28372-00-00	DAMPER	1	
36	90269-07007-00	RIVET	2	
37	5VY-2837V-00-00	GRILL, AIR OUTLET 1	1	
38	5PW-2177L-00-00	PLATE, SPRING	2	
39	5VY-2837W-00-00	GRILL, AIR OUTLET 2	1	
40	5PW-2177L-00-00	PLATE, SPRING	2	
41	90269-06081-00	RIVET	4	
42	5VY-26280-00-00	REAR VIEW MIRROR ASSY (LEFT)	1	
43	5VY-26290-00-00	REAR VIEW MIRROR ASSY (RIGHT)	1	
44	5VY-26298-00-00	PLATE, MIRROR FITTING 1 ...	2	
45	90387-06372-00	COLLAR	4	
46	90176-06055-00	NUT, CROWN	4	
47	5SL-84753-00-00	DAMPER	2	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

COWLING 2

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-Y283U-00-P0	PANEL ASSEMBLY 1	1	UR DRMK
	5VY-Y283U-10-P1	PANEL ASSEMBLY 1	1	UR DPBMC
	5VY-Y283U-20-P2	PANEL ASSEMBLY 1	1	UR S3 FOR BS4
2	5PW-2177L-00-00	. PLATE, SPRING	1	
3	5VY-2848H-00-00	.SEAT	1	
4	5VY-28322-00-00	.STAY 2	1	
5	5VY-2834C-00-00	.EMBLEM 1	1	UR FOR DRMK
	5VY-2834C-10-00	.EMBLEM 1	1	UR FOR BS4
	5VY-28391-00-00	.GRAPHIC 1	1	UR FOR DPBMC
6	5VY-2836C-00-00	.EMBLEM	1	FOR DPBMC
7	5VY-Y283V-00-P0	PANEL ASSEMBLY 2	1	UR DRMK
	5VY-Y283V-20-P2	PANEL ASSEMBLY 2	1	UR S3 FOR BS4
	5VY-Y283V-10-P1	PANEL ASSEMBLY 2	1	UR DPBMC
8	5PW-2177L-00-00	. PLATE, SPRING	1	
9	5VY-2848K-00-00	.SEAT 2	1	
10	5VY-28332-00-00	.STAY, LEG SHIELD	1	
11	5VY-2835C-00-00	.EMBLEM 2	1	UR FOR DRMK
	5VY-28392-00-00	.GRAPHIC 2	1	UR FOR DPBMC
	5VY-2835C-10-00	.EMBLEM 2	1	UR FOR BS4
12	5VY-2837C-00-00	.EMBLEM	1	FOR DPBMC
13	2TK-21757-00-00	WASHER, SPECIAL 1	20	
14	5PW-28386-00-00	HEAD	14	
15	5VY-2836K-00-00	PANEL, INNER 1	1	
16	5VY-2836L-00-00	PANEL, INNER 2	1	
17	5VY-28494-00-00	HOOK 3	2	
18	90269-07077-00	RIVET	1	
19	90269-06081-00	RIVET	4	
20	90269-07077-00	RIVET	2	
21	5VY-Y2808-00-P0	COVER ASSY, UNDER	1	UR MBL2 FOR DRMK
	5VY-Y2808-20-P1	COVER ASSY, UNDER	1	UR DPBMC

CONTENTS	
AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9





CONTINUED ON NEXT FRAME ►

COWLING 2

Ref. No.	Part Number	Description	Qty	Remarks
21	5VY-Y2808-10-P2	COVER ASSY, UNDER	1	UR BS4
22	5PW-2177L-00-00	. PLATE, SPRING	3	
23	90480-12596-00	. GROMMET	1	
24	90387-065J6-00	. COLLAR	1	
25	5VY-2848L-00-00	.SEAT 3	1	
26	5VY-2848N-00-00	.SEAT 5	1	
27	5VY-2837J-00-00	.DAMPER 5	1	
28	5VY-2837K-00-00	.DAMPER 6	1	
29	5VY-28307-00-00	.SEAL	1	
30	5JJ-2153E-00-00	.EMBLEM, YAMAHA	1	UR FOR DPBMC
	5JJ-2153E-10-00	.EMBLEM, YAMAHA	1	UR FOR DRMK
	5JJ-2153E-20-00	.EMBLEM, YAMAHA	1	UR FOR BS4
31	5VY-Y2809-00-P0	COVER ASSY 2, UNDER	1	UR MBL2 FOR DRMK
	5VY-Y2809-20-P1	COVER ASSY 2, UNDER	1	UR DPBMC
	5VY-Y2809-10-P2	COVER ASSY 2, UNDER	1	UR BS4
32	5PW-2177L-00-00	. PLATE, SPRING	3	
33	90480-12596-00	. GROMMET	1	
34	90387-065J6-00	. COLLAR	1	
35	5VY-2848M-00-00	.SEAT 4	1	
36	5VY-2848P-00-00	.SEAT 6	1	
37	5VY-28307-00-00	.SEAL	1	
38	5JJ-2153E-00-00	.EMBLEM, YAMAHA	1	UR FOR DPBMC
	5JJ-2153E-10-00	.EMBLEM, YAMAHA	1	UR FOR DRMK
	5JJ-2153E-20-00	.EMBLEM, YAMAHA	1	UR FOR BS4
39	5VY-2836A-00-00	BRACKET 1	1	
40	5VY-2836E-00-00	BRACKET 2	1	
41	5PW-2177L-00-00	PLATE, SPRING	2	
42	90109-06056-00	BOLT	2	
43	90149-06302-00	SCREW	2	
44	2TK-21757-00-00	WASHER, SPECIAL 1	8	

CONTENTS	
AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




CONTINUED ON NEXT FRAME ►

COWLING 2

Ref. No.	Part Number	Description	Qty	Remarks
45	5PW-28386-00-00	HEAD	4	
46	5VY-2836M-00-00	PANEL, INNER 3	1	
47	2TK-21757-00-00	WASHER, SPECIAL 1	4	
48	5PW-28386-00-00	HEAD	4	
49	5VY-2117V-00-00	COVER 7	1	
50	90480-12596-00	GROMMET	3	
51	90387-065J6-00	COLLAR	3	
52	5PW-2177L-00-00	PLATE, SPRING	2	
53	5VY-2117W-00-00	COVER 8	1	
54	90480-12596-00	GROMMET	3	
55	90387-065J6-00	COLLAR	3	
56	5PW-2177L-00-00	PLATE, SPRING	2	
57	90111-06030-00	BOLT	6	
58	5VY-2848R-00-00	SEAT 7	1	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	F5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



GENERATOR

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-81450-00-00	ROTOR ASSY	1	
2	5VY-81410-00-00	STATOR ASSY	1	
3	90149-06035-00	SCREW	3	
4	5VY-15191-00-00	PLATE	1	
5	90105-06050-00	BOLT, FLANGE	1	




CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C400

STARTING MOTOR



Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-81890-00-00	MOTOR ASSY	1	
2	5PW-81801-00-00	..BRUSH SET	1	
3	93210-55669-00	..O-RING	2	
4	93210-25711-00	..O-RING	1	
5	5PW-81846-00-00	..SCREW	2	
6	5PW-8181L-00-00	..WASHER, PLAIN	2	
7	5VY-8183G-00-00	CORD COMP.	1	
8	5PW-81828-00-00	BOLT 2	1	
9	95380-05700-00	NUT	1	
10	95027-06040-00	BOLT, FLANGE	2	


CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C410

FLASHER LIGHT



5SL3100-B410


Ref. No.	Part Number	Description	Qty	Remarks
1	5PW-83310-10-00	FRONT FLASHER LIGHT ASSY 1	1	
2	5GJ-83331-00-00	. . BULB, FLASHER (12V-21/5W T20)	1	
3	5PW-8333A-10-00	. .LENS COMP	1	
4	97706-04012-00	. .SCREW, TAPPING	1	
5	5PW-83320-10-00	FRONT FLASHER LIGHT ASSY 2	1	
6	5GJ-83331-00-00	. . BULB, FLASHER (12V-21/5W T20)	1	
7	5PW-8334A-10-00	. .LENS COMP	1	
8	97706-04012-00	. .SCREW, TAPPING	1	
9	5PW-83318-00-00	STAY, FLASHER 1	2	
10	5PW-83330-10-00	REAR FLASHER LIGHT ASSY 1	1	
11	5PW-83331-00-00	. .BULB (12V-21/5W T20)	1	
12	5PW-8334A-10-00	. .LENS COMP	1	
13	97706-04012-00	. .SCREW, TAPPING	1	
14	5PW-83340-10-00	FLASHER LIGHT ASSY 2	1	
15	5PW-83331-00-00	. .BULB (12V-21/5W T20)	1	
16	5PW-8333A-10-00	. .LENS COMP	1	
17	97706-04012-00	. .SCREW, TAPPING	1	
18	5PW-83318-00-00	STAY, FLASHER 1	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

METER

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-83500-20-00	SPEEDOMETER ASSY (MPH)	1	
2	5VY-8353E-00-00	..CASE, METER UPPER	1	
3	5VY-83572-00-00	..CASE, SPEEDOMETER LOWER	1	
4	5PW-8352S-00-00	..SCREW, PANEL FTTING	11	
5	90160-05006-00	SCREW, ROUND TAPPING	3	




CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



5VY1300-C430

HEADLIGHT



5VY1300-C440

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-84303-40-00	HEADLIGHT UNIT ASSY	1	
2	4SV-84314-00-00	BULB (12V-55W)	2	(H7) HALOGEN
3	4SV-84347-00-00	BULB (12V-5W)	1	
4	5SL-84397-00-00	COVER, SOCKET	1	
5	5GJ-84397-00-00	COVER, SOCKET	1	
6	4SV-84350-00-00	SOCKET CORD ASSY 2	1	
7	90269-06008-00	RIVET	1	
8	5VY-84196-00-00	COVER (L.H)	1	
9	5VY-84312-00-00	CORD ASSY	1	
10	5VY-84303-50-00	HEADLIGHT UNIT ASSY	1	
11	4SV-84314-00-00	BULB (12V-55W)	2	(H7) HALOGEN
12	4SV-84347-00-00	BULB (12V-5W)	1	
13	5SL-84397-00-00	COVER, SOCKET	1	
14	5GJ-84397-00-00	COVER, SOCKET	1	
15	4SV-84350-00-00	SOCKET CORD ASSY 2	1	
16	90269-06008-00	RIVET	1	
17	5VY-84396-00-00	COVER (R.H)	1	
18	5VY-84312-00-00	CORD ASSY	1	
19	90464-47001-00	CLAMP	1	
20	97707-50016-00	SCREW, TAPPING	1	
21	90160-05006-00	SCREW, ROUND TAPPING	6	
22	5VY-84359-10-00	CORD, HEADLIGHT	1	
23	90464-15195-00	CLAMP	1	

CONTENTS



AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

TAILLIGHT

Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-84710-10-00	TAILLIGHT UNIT ASSY	1	
2	90269-06081-00	RIVET	2	
3	5PW-84717-00-00	CORD, TAILLIGHT	1	
4	5VY-21629-10-00	GUARD, MUD	1	
5	5VY-84745-00-00	LICENSE LIGHT UNIT ASSY	1	
6	4HC-84744-00-00	.BULB (12V-5W)	1	
7	97706-04012-00	.SCREW, TAPPING	2	
8	5VY-84726-00-00	SCREW	2	
9	4KB-84117-00-00	NUT	2	
10	3Y6-85130-02-00	REAR REFLECTOR ASSY	1	
11	95607-05100-00	.NUT, U	1	
12	90201-05725-00	WASHER, PLATE	1	
13	5MT-84751-00-00	BRACKET, LICENSE	1	
14	90201-06057-00	WASHER, PLATE	2	
15	95607-06100-00	NUT, U	2	
16	5VY-21688-00-00	BRACKET, REAR STAY	1	
17	5VY-21689-00-00	BRACKET, REAR STAY 2	1	
18	90150-04041-00	SCREW, ROUND HEAD	4	
19	95607-04100-00	NUT, U	4	
20	3Y6-85130-02-00	REAR REFLECTOR ASSY	2	
21	95707-05500-00	NUT, FLANGE	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY4100-C450

HANDLE SWITCH LEVER

Ref. No.	Part Number	Description	Qty	Remarks
1	4XV-82910-13-00	LEVER HOLDER ASSY (LEFT)	1	
2	4XV-83912-11-00	..LEVER 1	1	
3	4XV-83945-00-00	..BOLT, LEVER	1	
4	95607-06100-00	..NUT, U	1	
5	95027-06020-00	..BOLT, FLANGE	1	
6	5LV-83951-00-00	..BOLT, CABLE ADJUSTING ..	1	
7	4XV-82917-01-00	..SWITCH	1	
8	98707-03016-00	..SCREW, FLAT HEAD	1	
9	98507-04010-00	..SCREW, PAN HEAD	1	
10	5JJ-83913-00-00	..COLLAR, LEVER 1	1	
11	5VY-83973-00-00	SWITCH, HANDLE 3	1	
12	98507-05025-00	..SCREW, PAN HEAD	2	
13	5PW-83975-00-00	SWITCH, HANDLE 2	1	
14	98507-05022-00	..SCREW, PAN HEAD	2	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9




5VY4100-C460

ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	90201-12790-00	WASHER, PLATE	1	
2	8CC-85790-01-00	THERMOSENSOR ASSY	1	
3	5VY-81673-00-00	ROTOR	1	
4	90282-03001-00	KEY, STRAIGHT	1	
5	90201-103U4-00	WASHER, PLATE	1	
6	90105-10290-00	BOLT, FLANGE	1	
7	5VY-85820-00-00	SERVO MOTOR ASSY	1	
8	5VY-85829-00-00	COVER, SERVO MOTOR	1	
9	97707-50514-00	SCREW, TAPPING	2	
10	5VX-82380-00-00	SENSOR, PRESSURE	1	
11	97707-50020-00	SCREW, TAPPING	2	
12	5VY-82310-00-00	IGNITION COIL ASSY	4	
13	5VY-82309-00-00	WIRE, SUB LEAD	1	
14	3GB-82540-01-00	NEUTRAL SWITCH ASSY	1	
15	90430-10148-00	GASKET	1	
16	5VY-85720-00-00	OIL LEVEL GAUGE ASSY	1	
17	95027-06016-00	BOLT, FLANGE	2	
18	90465-08013-00	CLAMP	1	
19	4XV-83755-01-00	SENSOR, SPEED	1	
20	90464-51001-00	CLAMP	1	
21	90110-06041-00	BOLT, HEXAGON SOCKET HEAD	1	
22	90465-08028-00	CLAMP	1	
23	5VY-81670-00-00	PICK-UP ASSY	1	
24	5VY-15589-00-00	PLATE, CLUTCH COVER	1	
25	90110-06041-00	BOLT, HEXAGON SOCKET HEAD	1	
26	90465-08191-00	CLAMP	1	
27	5VY-85896-00-00	SENSOR, CAM POSITION	1	
28	90110-06117-00	BOLT, HEXAGON SOCKET HEAD	1	

CONTENTS	
AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



FWD
5VY4100-C470


CONTINUED ON NEXT FRAME ►

ELECTRICAL 1


Ref. No.	Part Number	Description	Qty	Remarks
29	20G-85110-00-00	REFLECTOR ASSY	2	
30	95707-05500-00	NUT, FLANGE	2	
31	5VY-85112-00-00	BRACKET, REFLECTOR 1	1	
32	5VY-85122-00-00	BRACKET, REFLECTOR 2	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9



ELECTRICAL 2



5VY4100-C480


Ref. No.	Part Number	Description	Qty	Remarks
1	5VY-81960-00-00	RECTIFIER & REGULATOR ASSY	1	
2	90110-06066-00	BOLT, HEXAGON SOCKET HEAD	2	
3	90183-06053-00	NUT, SPRING	1	
4	90202-05187-00	WASHER, PLATE	2	
5	5VK-81950-40-00	RELAY ASSY	1	
6	4MY-83350-01-00	FLASHER RELAY ASSY	1	
7	5JW-81940-00-00	STARTER RELAY ASSY	1	
8	36Y-82151-00-00	. . FUSE (15A-BL)	2	
9	5PS-82576-01-00	EMERGENCY STOP SWITCH ASSY	1	
10	91317-04025-00	BOLT	2	
11	90201-047A2-00	WASHER, PLATE	2	
12	90183-04039-00	NUT, SPRING	2	
13	5VY-82501-10-00	MAIN SWITCH STEERING LOCK	1	
14	4BH-82511-09-00	BLANK KEY	1	AP
15	90109-080G5-00	BOLT	2	
16	4TH-83371-00-00	HORN	1	
17	95807-06012-00	BOLT, FLANGE	1	
18	5PX-82566-50-00	SWITCH, SIDE STAND	1	
19	5JJ-82388-00-00	PLATE	1	
20	92017-05030-00	BOLT, BUTTON HEAD	2	
21	95607-05200-00	NUT, U FLANGE	2	
22	90461-10002-00	CLAMP	1	
23	90201-057H5-00	WASHER, PLATE	1	
24	5PW-82530-00-00	STOP SWITCH ASSY	1	
25	5Y9-12491-00-00	CLAMP 1	1	
26	5JJ-81950-20-00	RELAY ASSY	2	
27	5JJ-81952-00-00	. . HOLDER, RELAY	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9

CONTINUED ON NEXT FRAME ►

ELECTRICAL 2



5VY4100-C480

Ref. No.	Part Number	Description	Qty	Remarks
28	5VY-8591A-20-00	ENGINE CONTROL UNIT ASSY	1	
	5VY-8591A-30-00	ENGINE CONTROL UNIT ASSY	1	
29	95027-06008-00	BOLT, FLANGE	2	
30	5VY-82100-00-00	BATTERY ASSY (YUASA YTZ10S)	1	
31	5VY-82590-10-00	WIRE HARNESS ASSY	1	
32	5JJ-82151-10-00	..FUSE (15A-BL)	4	
33	5JJ-82151-30-00	..FUSE (10A-BL)	3	
34	5JJ-82151-70-00	..FUSE (25A-BL)	2	
35	5JW-82151-10-00	..FUSE (50A)	1	
36	5EA-81950-20-00	RELAY ASSY	1	
37	5EA-81952-00-00	..HOLDER, RELAY	1	
38	90464-15195-00	CLAMP	1	
39	90464-15195-00	CLAMP	1	
40	90464-15195-00	CLAMP	1	
41	90464-13073-00	CLAMP	1	
42	1UA-82591-00-00	BAND	1	
43	1UA-82591-00-00	BAND	1	
44	5VY-82171-00-00	STAY, FUSE BOX	1	
45	90387-06040-00	COLLAR	2	
46	90119-06114-00	BOLT, WITH WASHER	2	
47	90464-13077-00	CLAMP	1	
48	90464-15157-00	CLAMP	1	
49	90464-13073-00	CLAMP	2	
50	5VY-82116-00-00	WIRE, MINUS LEAD	1	

CONTENTS

AIR INDUCTION SYSTEM	B6
CAMSHAFT CHAIN	A7
CLUTCH	C2-3
COWLING 1	E10-11
COWLING 2	E12 ,F1-2
CRANKCASE	B10
CRANKCASE COVER 1	B11-12
CRANKSHAFT PISTON	A4
CYLINDER	A3
CYLINDER HEAD	A2
ELECTRICAL 1	F10-11
ELECTRICAL 2	F12 ,G1
EXHAUST	B7-9
FENDER	C10-11
FLASHER LIGHT	F5
FRAME	C8-9
FRONT BRAKE CALIPER	E1
FRONT FORK	D6-7
FRONT MASTER CYLINDER	E6
FRONT WHEEL	D12
FUEL TANK	D8-10
GENERATOR	F3
HANDLE SWITCH LEVER	F9
HEADLIGHT	F7
INTAKE	B2-3
INTAKE 2	B4-5
METER	F6
OIL CLEANER	B1
OIL PUMP	A12
RADIATOR HOSE	A10-11
REAR ARM	D2-3
REAR BRAKE CALIPER	E4
REAR MASTER CYLINDER	E9
REAR SUSPENSION	D4
REAR WHEEL	E2-3
SEAT	D11
SHIFT CAM FORK	C6
SHIFT SHAFT	C7
SIDE COVER	C12 ,D1
STAND FOOTREST	E7-8
STARTER	C1
STARTING MOTOR	F4
STEERING	D5
STEERING HANDLE CABLE	E5
TAILLIGHT	F8
TRANSMISSION	C4-5
VALVE	A5-6
WATER PUMP	A8-9